



Count on it.

Form No. 3378-408 Rev A

Parts Catalog

EU Compliance Kit Multi Pro WM Turf Sprayer

Model No. 41204



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquefied Petroleum Gas

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Contents

EU Compliance Kit 4


Spray Gun and Pressure Filter Assembly 6

Spray Gun Assembly No. 120-8610 8

Pressure Filter Assembly No. 127-9721 10

Pressure Filter Assembly No. 127-9726 11


EU Compliance Kit



EU Compliance Kit (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	99-8664	2	Screw-HH	22	105-4320	1	Switch
2	100-6708	1	Fork	23	120-8635	2	Vain-Rinse
3	100-6713	1	Nut-Bulkhead	24	121-6519	1	Tank-Rinse, 20 Gallon
4	104-8300	2	Nut-Flange, NI	25	125-0635-03	2	Strap-Tank, Rinse
5	104-8301	4	Nut-Flange, NI	26	125-4071-03	2	Angle-Mount, Rinse Tank Band
6	106-4896	1	Fitting-Bulkhead	27	125-4145	1	Hose-Filter, Rinse
6:1	100-6710	1	Gasket-Bulkhead	28	125-4146	1	Hose-Supply, Rinse
7	106-4940	1	Hosebarb-90 DEG	29	125-8085	1	Cover-Rinse Pump
7:1	100-6712	1	O-Ring	30	127-9761-03	1	Valve-Mount
8	107-8641	1	Cap-Water, Fresh	31	127-9762-03	1	Bracket-Mount, Rinse Pump
9	108-3439	1	Tee	32	240-12	1	Grommet
10	117-7872	1	Pump-Rinse	33	321-10	4	Screw-HH
11	119-0479	2	Nozzle-Rinse	34	2412-129	8	Clamp-Hose
12	119-0489	2	Bulkhead	35	3231-21	2	Screw-CARR
13	119-0490	2	Elbow-Hosebarb	36	3234-17	2	Screw-HHF
14	119-0493	2	Hose-Supply, Rinse	37	3256-22	4	Washer-Flat
15	119-0496	1	Hosebarb	38	3256-4	4	Washer-Flat
16	119-0528	2	Bushing	39	32128-33	4	Nut-HF
17	119-4881	2	Bolt-Shoulder	40	33023-00	4	Nut-Lock
18	119-4980	1	Valve, 4-Way	41	33093-00	4	Washer-Flat
19	120-0657-03	1	Bracket-Face Plate	42	33113-016	4	Screw-HH
20	120-0673	1	Decal-Selection	43	9335044	2	Pin-Hair
21	120-0688	1	Hosebarb-90 DEG				

Spray Gun and Pressure Filter Assembly




Spray Gun and Pressure Filter Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	100-6704	1	Tee	19	127-9713-03	1	Hand Gun Bracket ASM
2	100-6708	1	Fork	20	127-9721	1	Pressure Filter ASM
3	100-8635	3	Fork	21	127-9726	1	Pressure Filter ASM
4	104-8301	4	Nut-Flange, NI	22	127-9730	1	Nipple
5	106-4938	1	Reducer ASM	23	127-9764-03	1	Bracket-Hose
5:1	100-8637	1	O-Ring	24	127-9765-03	1	Bracket-Shutoff Valve
6	106-4947	1	Connector	25	127-9768	1	Supply-Hose ASM
6:1	100-8637	2	O-Ring	25:1		1	Hosebarb-90 DEG ●
7	107-8751	1	Hose-Spray Gun	25:1:1	100-6712	1	O-Ring
8	108-0069	1	Valve-Ball	26	127-9770	1	Hose-Shutoff
9	119-0493	1	Hose-Supply, Rinse	27	2412-129	5	Clamp-Hose
10	119-0496	1	Hosebarb	28	2412-36	2	Clamp-Hose
11	120-0652	2	Hosebarb	29	3230-23	2	Screw-CARR
12	120-0668	1	Hosebarb	30	3231-21	2	Screw-CARR
13	120-0669	1	Reducer	31	3234-7	2	Screw-HHF
14	120-0670	1	Hosebarb	32	127-9779	1	Hosebarb-Str
15	120-0687	1	Decal-Rinse Flow	33	125-4117	1	O-Ring
16	120-0688	1	Hosebarb-90 DEG	34	125-4000	1	Fork
17	120-8610	1	Spray Gun ASM	99	112-7929	1	Beaker-Plastic
18	121-4982	1	Hosebarb-Spray Gun	99	99-6124	1	Fuse-Blade, 40 Amp

● Not serviced separately


Spray Gun Assembly No. 120-8610



Spray Gun Assembly No. 120-8610 (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	121-4950	1	Nozzle-2.3Mm	22:1	121-4972	2	O-Ring
1:1	121-4951	1	O-Ring	23	121-4974	1	Slide-Lever
2	121-4952	1	Head-Nozzle Holder	24	121-4975	1	Lever-Spraygun
4	121-4954	1	Ring-Spacer	25	121-4977	1	Spring
5	121-4955	1	Spreader-Micro Jet	26	121-4978	1	Pin-Lever
6	121-4956	1	Tube-Spray Gun	27	121-4979	1	Cover-Drum
7	121-4957	1	Conveyor-Inner	28	121-4980	1	Drum-Regulation
8	121-4958	1	Tube-Spray Gun, Inner	99	121-4981	1	Spray Gun Seal Kit ●
9	121-4959	1	Drum-Regulation	99:1	121-4951	1	O-Ring
10	121-4960	1	Spring-Spray Gun	99:2	121-4953	2	Gasket
14	121-4964	1	Pin-Hinge	99:3	121-4967	2	O-Ring
16	121-4966	2	Washer-Teflon	99:4	121-4972	2	O-Ring
18	121-4968	1	Lever-Drum, Spray Gun	99:5	121-4962	1	Plunger-Cone
19	121-4969	1	Screw	99:6	121-4961	1	O-Ring
20	121-4970	1	Grip-Spray Gun	99:7	121-4963	1	Box And Seat
21	121-4971	1	Fork	99:8	121-4965	1	Seal
22	121-4973	1	Hose-Tail				

● Not illustrated



Pressure Filter Assembly No. 127-9721

Ref.	Part Number	Qty.	Description
1	125-0693	1	Filter-Pressure
1:1	120-8695	1	O-Ring
1:2	120-8697	1	Element-Filter, 50 Mesh
1:3	120-8696	1	O-Ring
1:4	120-8693	1	Housing-Filter
1:5	120-8694	1	Flynut-Filter
1:99	120-8698	1	Element-Filter, 32 Mesh
1:99	120-8699	1	Element-Filter, 80 Mesh
2	117-7967	1	Flange-Female
3	119-4870	3	O-Ring
4	119-0463	1	Adapter-Male-Male
5	125-0692	1	Connector-Flange
6	119-4871	16	Washer
7	48-7730	8	Screw-Cap, HH
8	33024-00	8	Nut-Lock, NI



Pressure Filter Assembly No. 127-9726

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-9722	1	Seal-Filter
2	127-9723	1	Screen-Filter
3	127-9724	1	Head-Filter
4	127-9725	1	Body-Filter



Count on it.