



**Count on it.**


# Parts Catalog

## Out-Front Brush Kit

**Greensmaster® 800/1000 Flex™ 18/21 Flex™  
1800/2100 eFlex® 1800/2100 Mower**

**Model No. 04266**





## Out-Front Brush Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 105-9602    | 1    | Brush                   |
| 2    | 120-9630    | 2    | Tab-Brush               |
| 3    | 120-9631    | 2    | Rod ASM                 |
| 4    | 120-9634    | 2    | Spring-Brush            |
| 5    | 121-4625-01 | 1    | Bracket-Brush, LH       |
| 6    | 121-4626-01 | 1    | Bracket-Brush, RH       |
| 7    | 121-4651-01 | 1    | Bracket-Brush, LH       |
| 8    | 121-4652-01 | 1    | Bracket-Brush, RH       |
| 9    | 120-9635    | 2    | Screw-HH                |
| 10   | 120-9636    | 4    | Spacer                  |
| 11   | 120-9637    | 2    | Screw-Adjustment, Level |

| Ref. | Part Number | Qty. | Description    |
|------|-------------|------|----------------|
| 12   | 120-9638    | 2    | Nut-Jam        |
| 13   | 119-4038    | 6    | Nut-Hex, NI    |
| 14   | 120-9640    | 4    | Screw-HHF      |
| 15   | 120-9645    | 8    | Nut-HHF        |
| 16   | 120-9641    | 4    | Screw-HHF      |
| 17   | 120-9642    | 4    | Screw-HH       |
| 18   | 115-7370    | 4    | Washer-Plain   |
| 19   | 120-9643    | 4    | Nut-Lock       |
| 20   | 120-9644    | 4    | Screw-HH       |
| 21   | 105-9625-03 | 1    | Weight-Brush ● |
| 22   | 110-5052    | 2    | Screw-HHF      |

● Optional Equipment