



Count on it.

Parts Catalog

Trencher Drive

Pro Sneak 360 Vibratory Plow

Model No. 25410—Serial No. 313000001 and Up

Model No. 25410E—Serial No. 313000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquefied Petroleum Gas

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Contents

Frame, Belt and Mounting Arm Assembly 4

Hydraulic Motor Assembly No. AU188974A1 6

Boom Mount and Hydraulic Cylinder Assembly..... 8

Neutral Switch and Hydraulic Mounting Assembly 10


Neutral Switch Assembly No. AU106402A2 12

Neutral Switch Mounting Assembly No. AUH673263..... 14

Hydraulic Control Valve Assembly..... 16

Hydraulic Hose Assembly..... 18


Frame, Belt and Mounting Arm Assembly



Frame, Belt and Mounting Arm Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	105-0369	1	Nut-Crownlock	15	32120-84	1	Ring-Snap, External
2	110-4614	1	Screw-HH	17	AU188974A1	1	HYD Motor ASM
3	125-8501	2	Pin-Mounting	18	AU541857R92	1	Idler Bearing And Sprocket ASM
5	127-1035	1	Frame ASM	19	AUH114140	1	Spacer-Sprocket, Idler
5:2	125-6670	1	Decal-Danger, Entanglement	20	AUH230243	2	Pin-Clevis
5:3	125-6671	1	Decal-Danger, Underground Hazard	21	AUH32292	2	Pin-Hair
5:4	125-8175	1	Decal-Grease	22	AUH413302	3	Spacer
6	127-1038	1	Cover ASM	23	AUH415554	1	Sprocket-Headshaft
6:2	125-6686	1	Decal-Warning, Chain	24	AUH415562	1	Spacer
7	AU230-4218	2	Nut-Lock, Hex	25	AUH415604	1	Key
8	323-6	1	Screw-HH	26	AUH426809	2	Washer-Flat
9	AU426-556	3	Bolt	27	AUH660175-03	1	Arm-Mounting, RH
10	AU426-824	2	Screw-HH	28	AUH660183-03	1	Arm-Mounting, LH
11	AU495-21069	2	Washer-Flat	29	AUH660217	1	Sprocket-Drive
12	3253-21	1	Washer-Lock	30	AUH758862	1	Chain-68P
13	3256-23	3	Washer-Flat	31	32152-1	1	Nut-Lock, Cone
14	3256-24	1	Washer-Flat	32	3272-11	2	Pin-Cotter
				33	302-2	2	Fitting-Grease


Hydraulic Motor Assembly No. AU188974A1



Hydraulic Motor Assembly No. AU188974A1 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-8421	1	Seal Kit


Boom Mount and Hydraulic Cylinder Assembly



Boom Mount and Hydraulic Cylinder Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-1017	1	Hose ASM	15	AUH257048	1	Pin
2	01-201-0530	1	Fitting-Elbow, 90	16	AUH261834	3	Shim
3	323-45	2	Screw-HH	17	AUH314237-03	1	Strip-Back
4	AU425-158	1	Nut	18	AUH413492-03	1	Crank-Boom Cylinder
5	AU426-516	5	Screw-HH	19	AUH413625	3	Key
6	AU432-1628	2	Pin-Cotter	20	AUH426718	1	Flap-Dirt
7	32120-22	1	Ring-Snap, Internal	21	AUH504076	1	HYD Cylinder ASM
8	32152-1	5	Nut-Lock, Cone	22	AUH65011	1	Pin-Clevis
9	AU106541-03	1	Mount-Boom	23	AUH69773	1	Sprocket
10	AU106634	1	Shaft-Drive, Trencher	24	AUH758854	1	Seal-Oil
11	AU38742	1	Bearing	25	3253-21	2	Washer-Lock
12	AUF7356	2	Bearing-Needle	26	3256-23	10	Washer-Flat
13	AUH33746	1	Screw-Set, Dog Point	27	302-2	1	Fitting-Grease
14	AUH69930	1	Hub				

Neutral Switch and Hydraulic Mounting Assembly




Neutral Switch and Hydraulic Mounting Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	97-1204	2	Nut-Hex
2	AU106402A2	1	Neutral Start Switch ASM
3	127-1036	1	Cover ASM
3:2	125-6676	1	Decal-Attachment Selector
4	127-1037	1	Bracket ASM
4:2	125-6678	1	Decal-Chain Direction
5	AU241-1315	1	Link-#50, Connect (Single Pitch)
6	322-32	1	Screw-HH
7	323-6	2	Screw-HH
8	AU426-516	5	Screw-HH
9	AU426-540	1	Bolt

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
10	3256-23	8	Washer-Flat
11	3256-24	4	Washer-Flat
12	3272-1	1	Pin-Cotter
13	32149-8	1	Nut-Keps
14	32152-1	2	Nut-Lock, Cone
15	AU179581A1	1	Lever-Valve
16	AU179590A1	1	Rod-Switch, Neutral
17	AUH346650	5	Nut-U Type
18	AUH35279	1	Pin-Clevis
19	AUH544718	1	HYD Valve ASM
20	AUL12437	1	Joint-Ball


Neutral Switch Assembly No. AU106402A2



Neutral Switch Assembly No. AU106402A2 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	120-7252	1	Nut-Lock	7	AU86992539	1	Switch-Neutral Start
2	32149-6	2	Nut-Keps	8	AUH435881	1	Hub-Actuator
3	AU101637	1	Spacer-Switch	9	AUH436231	1	Spring-Centering
4	AU102475	1	Bolt-U, Switch Mtg (H435814)	10	AUH438465	1	Plate-Actuator
5	AU106403A1	1	Plate-Mounting	11	AUH673263	1	Neutral Switch Mounting ASM
6	AU495-11081	1	Washer-Flat	12	AU426-1232	1	Bolt


Neutral Switch Mounting Assembly No. AUH673263



Neutral Switch Mounting Assembly No. AUH673263 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	AU131050A1	1	Hub	4	125-6645-03	1	Plate-Mounting, Switch
2	AUH257915	3	Shim	5	AU103-11125	1	Ring-Retaining
3	125-6644-03	1	Plate-Mounting, Switch				

Hydraulic Control Valve Assembly




Hydraulic Control Valve Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	92-3505	2	Fitting-Adaptor, 90
1:1	237-42	1	O-Ring
2	97-1204	2	Nut-Hex
3	127-1013	1	Hose ASM
4	127-1014	1	Hose ASM
5	127-1015	1	Hose ASM
6	127-1016	1	Hose ASM

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
7	127-1018	1	Hose ASM
8	353-374	5	Fitting-Elbow, 90 DEG
8:1	237-42	1	O-Ring
9	AU426-652	2	Bolt
10	3256-24	4	Washer-Flat
11	127-6557	1	Valve-Selector Control

Hydraulic Hose Assembly



Hydraulic Hose Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	127-1010	1	Hose ASM
2	127-1011	1	Hose ASM
3	127-1012	2	Hose ASM
4	353-370	2	Fitting-Elbow, 90 DEG
4:1	237-80	1	O-Ring
5	353-385	2	Fitting-Straight

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5:1	237-80	1	O-Ring
6	353-389	2	Fitting-Elbow, 45
7	AU515-23444	1	Clamp
8	AU218-736	1	Fitting-Union
99	AUL18331	4	Strap-Tie, Nylon 15 Inch



Count on it.