



**Count on it.**

**Parts Catalog**

**CM-958H-SED Concrete Mixer**

Model No. 68007C—Serial No. 313000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** Liquefied Petroleum Gas

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard


**TAP:** self tapping

**TTH:** torx truss head

# Contents

|                                 |    |
|---------------------------------|----|
| Frame and Yoke Assembly .....   | 4  |
| Trailer Light Assembly .....    | 6  |
| Axle Assembly .....             | 8  |
| Hub Assembly No. 125-8171 ..... | 9  |
| Engine and Belt Assembly .....  | 10 |
| Drum Assembly .....             | 11 |
| Cowl Assembly .....             | 12 |



# Frame and Yoke Assembly



## Frame and Yoke Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 125-8685-03        | 1           | Frame              | 17          | ST27144-03         | 1           | Guard-Pinion               |
| 2           | ST32032            | 2           | Bushing-Nylon      | 18          | 104-8300           | 1           | Nut-Flange, NI             |
| 3           | ST22029            | 1           | Shaft-Tilt         | 19          | ST46042            | 2           | Fitting-Grease             |
| 4           | ST22096-03         | 1           | Handwheel          | 20          | ST47001            | 2           | Cap-Plug                   |
| 5           | 32121-27           | 1           | Pin-Roll           | 23          | 127-2816           | 1           | Tow Pole ASM               |
| 6           | ST27559-03         | 2           | Bracket-Handle     | 23:2        | 125-8216           | 1           | Decal-Safety Chain, Towing |
| 7           | ST27619-03         | 1           | Dog-Brake          | 24          | ST21875-03         | 1           | Post-Foot                  |
| 8           | ST27733-03         | 1           | Handle-Brake       | 25          | ST21874-03         | 2           | Leg-Stabilizer             |
| 9           | 3234-24            | 1           | Screw-HHF          | 26          | ST80039            | 3           | Pin-Clevis, Lanyard        |
| 10          | 104-8301           | 1           | Nut-Flange, NI     | 27          | 3290-500           | 3           | Screw-PPH                  |
| 11          | 701243             | 4           | Screw-HWHTF        | 28          | 3296-2             | 3           | Nut-Lock, NI               |
| 12          | ST24349-03         | 2           | Trunnion           | 29          | 325-19             | 1           | Screw-HH                   |
| 13          | 125-6308           | 1           | Yoke ASM           | 30          | 99-5107            | 9           | Nut-Lock                   |
| 14          | ST27617-03         | 1           | Guard-Brake, Upper | 33          | ST80031            | 4           | Screw-HWH                  |
| 15          | 3234-38            | 6           | Screw-HHF          | 35          | 99-4693            | 1           | Decal                      |
| 16          | ST27618-03         | 1           | Guard-Brake, Lower | 36          | 125-8175           | 2           | Decal-Grease               |

# Trailer Light Assembly




## Trailer Light Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 112-7069           | 1           | Grommet                      | 9           | 125-8659-03        | 1           | Plate-License Holder |
| 2           | 115-5103           | 12          | Screw-HHF                    | 10          | 120-3735           | 1           | Light-Tail, LH       |
| 3           | 104-6962           | 2           | Reflector-Amber              | 11          | 120-3734           | 1           | Light-Tail, RH       |
| 4           | 32149-2            | 18          | Nut-Keps                     | 12          | 94-5781            | 2           | Screw-HHF            |
| 5           | 2412-87            | 9           | Clamp-Cable                  | 13          | 125-8698           | 1           | Light-Id             |
| 6           | 125-8705           | 1           | Harness-Wire, Trailer Lights | 14          | 120-4831           | 2           | Grommet              |
| 7           | 125-8689-03        | 1           | Bracket-L                    | 99          | 3290-379           | 1           | Tie-Cable            |
| 8           | 125-8690-03        | 1           | Bracket-U                    |             |                    |             |                      |




## Axle Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | ST26971            | 2           | Spring-Leaf        |
| 2           | ST26195            | 2           | Bolt-U             |
| 3           | ST21873-03         | 1           | Axle-Spring        |
| 4           | 100-6116           | 4           | Screw-HHF          |
| 5           | 99-5107            | 10          | Nut-Lock           |
| 6           | 325-33             | 2           | Screw-HH           |
| 7           | ST34972            | 2           | Spring-Coil        |
| 8           | 125-8171           | 2           | Hub ASM            |
| 9           | ST32307            | 2           | Tire And Rim ASM   |
| 10          | 3256-28            | 2           | Washer-Flat        |
| 11          | ST80054            | 2           | Nut                |
| 12          | 3272-13            | 2           | Pin-Cotter         |



## Hub Assembly No. 125-8171


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | ST39190            | 4           | Stud-Wheel         |
| 3           | ST32233            | 2           | Bearing-Roller     |
| 4           | ST80045            | 4           | Nut-Lug            |
| 5           | ST34573            | 1           | Cap-Dust           |



## Engine and Belt Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | ST21487            | 1           | Shaft-Drive           |
| 2           | ST28045-03         | 1           | Base-Motor            |
| 3           | 125-4812           | 1           | Engine-Honda, Gx240 ● |
| 4           | 108-3742           | 4           | Screw-HHF             |
| 5           | 104-8301           | 4           | Nut-Flange, NI        |
| 6           | 5-7280             | 2           | Key                   |
| 7           | ST34986-03         | 1           | Sheave                |
| 8           | ST34984            | 1           | Sheave                |
| 9           | 127-0075           | 2           | Belt-V                |
| 10          | 100-6116           | 4           | Screw-HHF             |
| 11          | ST26326            | 4           | Washer-Flat           |
| 12          | 99-5107            | 4           | Nut-Lock              |
| 13          | 909546             | 2           | Screw-Set, SQH        |

● Obtain parts from [www.honda-engines.com](http://www.honda-engines.com)



## Drum Assembly

| <b>Ref.</b> | <b>Part Number</b> | <b>Qty.</b> | <b>Description</b> |
|-------------|--------------------|-------------|--------------------|
| 1           | 125-6306-01        | 1           | Drum               |
| 2           | 325-6              | 1           | Screw-HH           |
| 3           | 325-7              | 6           | Screw-HH           |
| 4           | 327-4              | 1           | Screw-HH           |
| 5           | 99-5107            | 6           | Nut-Lock           |
| 6           | ST26317-01         | 1           | Gear-Ring          |
| 7           | ST26326            | 6           | Washer-Flat        |
| 8           | ST27267            | 1           | Spindle            |
| 9           | ST27413            | 1           | Washer-Flat        |
| 10          | ST32086            | 1           | Bearing            |
| 11          | ST32161            | 1           | Bearing-Roller     |
| 12          | ST46022            | 1           | Plug               |
| 13          | ST46057            | 1           | Fitting            |
| 14          | ST47001            | 1           | Cap-Plug           |
| 15          | 3256-6             | 12          | Washer-Flat        |



## Cowl Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 1           | 127-2811           | 1           | Stationary Cowl ASM   |
| 1:2         | 125-4940           | 1           | Decal-Engine Stop     |
| 1:3         | 117-2718           | 1           | Decal-Arrester, Spark |
| 2           | 701243             | 2           | Screw-HWHTF           |
| 3           | 3234-38            | 4           | Screw-HHF             |
| 4           | 99-5107            | 4           | Nut-Lock              |
| 5           | 127-1685           | 1           | Movable Cowl ASM      |
| 5:2         | 125-4939           | 1           | Decal-Warning         |
| 6           | ST44368            | 1           | Pin                   |
| 7           | 95-8999            | 1           | Switch                |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 8           | 125-4877           | 1           | Harness-Wire, Mixer |
| 9           | ST47182            | 3           | Latch-Rubber        |
| 10          | 67-7320            | 2           | Decal               |
| 14          | 125-4937           | 2           | Decal               |
| 15          | 125-8218-03        | 1           | Plate-Engine        |
| 16          | 110-9380           | 2           | Screw-HWH           |
| 17          | 125-4942           | 1           | Decal               |
| 19          | 3256-4             | 2           | Washer-Flat         |
| 20          | 3256-6             | 2           | Washer-Flat         |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**