CONFIDENTIAL PROPERTY OF TORO® BLOOMINGTON, MINNESOTA

SPECIFICATIONS

				PART NUMBER:	380-0073	REV.:	A
				ECM NUMBER:	5089738	SHEET:	1 of 1
				ENGINEER:	XXXXXX	DATE:	02-20-14
PRODUCT:	Infinity Series Sprinklers			SAP DESCRIPTION:	Instruct, Breakout, INF34, INF35, INF35-6 Series Golf Sprinkler		
WEIGHT:	0.04 lbs	FINISH:	N/A	ORIGINATING LOCATION:	RIVERSIDE	SIMILAR TO:	N/A
TOLERANCE: All dims in inches	±.010	SCALE:	N/A	CONTROLLED SOURCE:	(If YES, see information at bottom of sheet)		

SPECIFICATIONS:
8.5" x 11" x 0.03", 12-page Parts Breakout booklet. Electronic/Online Release only. Document will not be printed for distribution.

CONTROLLED SOURCE INFORMATION ☐	ALTERNATE or SUGGESTED SOURCE INFORMATION ☑
VENDOR: ADDRESS: CITY/STATE/ZIP: PHONE NUMBER: MFG PART No.: CONTACT:	VENDOR: ADDRESS: CITY/STATE/ZIP: PHONE NUMBER: MFG PART No.: CONTACT:

SEE REVISION SHEET FOR DESCRIPTION OF CHANGE

CONFIDENTIAL PROPERTY OF
TORO®
BLOOMINGTON, MINNESOTA

SPECIFICATIONS

PART NUMBER:	380-0073

REVISION SHEET

Rev.	ECM No.	Description of Change	Drafter	Date	Approved By
A	5089738	Release revision A for production.	NM	02-20-14	

Form No. 380-0073 Rev A

TORO®

Count on it.

Parts Catalog

INFINITY INF34, INF35 and INF35-6 Series Golf Sprinklers

Model No. INF34 INF35 INF35-6

Register at www.Toro.com.
Original Instructions (EN)

380-0073 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquefied Petroleum Gas

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head


Contents

INF34 Series Golf Sprinkler w/ Dual Trajectory 4
INF35 Series Golf Sprinkler w/ Dual Trajectory 6
INF35-6 Series Golf Sprinkler w/ 24-Pos TruJectory 8

© 2014—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved

INF34 Series Golf Sprinkler w/ Dual Trajectory




INF34 Series Golf Sprinkler w/ Dual Trajectory (continued)

Ref.	Part Number	Qty.	Description
1	102-0362	1	Screw, Cap
2	363-4839	1	Radius Reduction Screw
3	118-3089	1	Cap, Black
3	118-3093	1	Cap, Effluent
4	102-5837	1	Nozzle Base Assembly
5	102-2925	1	Intermediate Nozzle, Blue (Used With #31 Main Nozzle)
5	102-2926	1	Intermediate Nozzle, Orange (Used With #32 Main Nozzle)
5	102-2928	1	Intermediate Nozzle, Red (Used With #33 Main Nozzle)
5	102-2929	1	Intermediate Nozzle, Beige (Used With #34 And #35 Main Nozzles)
5	102-6944	1	Intermediate Nozzle Assy., Red W/ Stream Straightener (Used With #36 Main Nozzle)
5	102-6945	1	Intermediate Nozzle Assy., Gray W/ Stream Straightener (Used With #37 Main Nozzle)
6	102-6937	1	Nozzle Assy. Inner, Yellow Nozzle W/ Yellow Helical Restrictor
7	102-4335	2	Plug, Nozzle
8	102-5978	1	O-Ring, Nozzle Housing
9	102-5597	1	Nozzle Housing Assy.
10	363-4978	1	O-Ring, Main Nozzle
11	102-0725	1	Nozzle, Main, #31, Yellow
11	102-7001	1	Nozzle, Main, #32, Blue
11	102-0727	1	Nozzle, Main, #33, Brown
11	102-7002	1	Nozzle, Main, #34, Orange
11	102-6908	1	Nozzle, Main, #35, Green
11	102-0730	1	Nozzle, Main, #36, Gray
11	102-4261	1	Nozzle, Main, #37, Black
12	89-1385	1	Snap Ring, Riser
13	363-4102	1	O-Ring, Paraffin As-568 232
14	102-0134	1	Retainer, Seal
15	102-0151	1	Spring, Return
16	363-4167	1	O-Ring, Nozzle Base
17	102-0202	1	Riser
18	102-4503	1	Drive Assembly, 12-Pack
19	102-6929	1	Stator, Low Flow, High Velocity, Blue (Used With #31-34 Main Nozzles)
19	102-1940	1	Stator Assembly, Medium Flow, White (Used With #35-37 Main Nozzles)
20	102-1715	1	Screen, Riser
21		1	Body Assembly (See Golf Sprinkler Body Assembly Section) ▲
	995-08	1	Valve Removal Tool ■●
	118-1844	1	Valve Insertion Tool ■●
	995-15	1	Selector Tool (Flag Key) ■●
	995-99	1	Nut Driver, 5/8" (For Main Nozzle) ■●
	995-105	1	Nut Driver, 5/16" (For Inner & Intermediate Nozzles And Plugs) ■●
	995-83	1	Multi-Purpose Tool ■●
	995-85	1	Riser Removal Tool ■●
	995-100	1	Valve Snap Ring Pliers With Screen Remover ■●
	995-102	1	Riser Hold-Up Tool, Universal ■●
	118-0954	1	Riser Hold-Up Tool, Red ■●

● SERVICE ITEMS
▲ Not serviced separately
■ Not illustrated

INF35 Series Golf Sprinkler w/ Dual Trajectory




INF35 Series Golf Sprinkler w/ Dual Trajectory (continued)

Ref.	Part Number	Qty.	Description
1	102-6138	1	Screw, Cap, Black
2	363-4839	1	Radius Reduction Screw
3	118-3089	1	Cap, Black
3	118-3093	1	Cap, Effluent
4	89-1385	1	Snap Ring, Riser
5	363-4102	1	O-Ring, Paraffin As-568 232
6	102-0134	1	Retainer, Seal
7	102-0151	1	Spring, Return
8	102-2619	1	Ratchet Ring, 1"
9	118-1079	1	Riser Assembly
10	102-4335	2	Plug, Nozzle
11	102-5670	1	Nozzle Assy. Inner, Yellow W/ White Helical Restrictor (Used With #30-35 Main Nozzles)
11	102-6531	1	Nozzle Assy., Inner, Green W/ White Helical Restrictor (Used With #36-37 Main Nozzles)
12	102-6942	1	Intermediate Nozzle Assy., Beige W/ Stream Straightener (Used With #30 Main Nozzle)
12	102-5671	1	Intermediate Nozzle Assy., Brown W/ Stream Straightener (Used With #31 Main Nozzle)
12	102-6884	1	Intermediate Nozzle, Yellow (Used With #32-34 Main Nozzles)
12	102-6885	1	Intermediate Nozzle, Green (Used With #35-37 Main Nozzles)
13	102-5978	1	O-Ring, Nozzle Housing
14	102-5597	1	Nozzle Housing Assy.
15	363-4978	1	O-Ring, Main Nozzle
16	102-2208	1	Nozzle, Main, #30, Blank, White
16	102-6906	1	Nozzle, Main, #31, Yellow
16	102-0726	1	Nozzle, Main, #32, Blue
16	102-6907	1	Nozzle, Main, #33, Brown
16	102-0728	1	Nozzle, Main, #34, Orange
16	102-6955	1	Nozzle, Main, #35, Green
16	102-6935	1	Nozzle, Main, #36, Gray
16	102-6936	1	Nozzle, Main, #37, Black
16	118-1521	1	Adapter, Main Nozzle
17	363-4236	1	Screw, Drive
18	102-4504	1	Drive Assy., 12-Pack
19	102-6929	1	Stator, Low Flow, High Velocity, Blue (Used With #30 Main Nozzle)
19	102-1939	1	Stator Assembly, Low Flow, Yellow (Used With #31-34 Main Nozzles)
19	102-1940	1	Stator Assembly, Medium Flow, White (Used With #35-37 Main Nozzles)
20	102-1715	1	Screen, Riser
21		1	Body Assembly (See Golf Body Assembly Section.) ▲
	995-08	1	Valve Removal Tool ■●
	118-1844	1	Valve Insertion Tool ■●
	995-15	1	Selector Tool (Flag Key) ■●
	995-99	1	Nut Driver, 5/8" (For Main Nozzle) ■●
	995-105	1	Nut Driver, 5/16" (For Inner & Intermediate Nozzles And Plugs) ■●
	995-83	1	Multi-Purpose Tool ■●
	995-85	1	Riser Removal Tool ■●
	995-100	1	Valve Snap Ring Pliers With Screen Remover ■●
	995-102	1	Riser Hold-Up Tool, Universal ■●
	118-0954	1	Riser Hold-Up Tool, Red ■●

● SERVICE ITEMS
▲ Not serviced separately
■ Not illustrated

INF35-6 Series Golf Sprinkler w/ 24-Pos TruJectory



INF35-6 Series Golf Sprinkler w/ 24-Pos TruJectory (continued)

Ref.	Part Number	Qty.	Description
1	102-6138	1	Screw, Cap, Black
2	118-3090	1	Cap, Black
2	118-3094	1	Cap, Effluent
3	89-1385	1	Snap Ring, Riser
4	363-4102	1	O-Ring, Paraffin As-568 232
5	102-0134	1	Retainer, Seal
6	102-0151	1	Spring, Return
7	102-2619	1	Ratchet Ring, 1"
8	102-5971	1	Trajectory Adjuster
9	102-2925	1	Intermediate Nozzle, Blue (Used With #30, #31, #35 And #36 Main Nozzles)
9	102-2926	1	Intermediate Nozzle, Orange (Used With #33, #34 And #37 Main Nozzles)
9	102-2928	1	Intermediate Nozzle, Red (Used With #32 Main Nozzle)
10	102-2910	1	Nozzle Assembly, Inner
11	102-2208	1	Nozzle, Main, #30, Blank, White
11	102-4587	1	Nozzle, Main, #31, Yellow
11	102-4588	1	Nozzle, Main, #52, Blue
11	102-4589	1	Nozzle, Main, #53, Brown
11	102-0728	1	Nozzle, Main, #34, Orange
11	102-0729	1	Nozzle, Main, #55, Green
11	102-0730	1	Nozzle, Main, #36, Gray
11	102-4261	1	Nozzle, Main, #37, Black
11	118-1521	1	Adapter, Main Nozzle
12	363-4978	1	O-Ring, Main Nozzle
13	102-4335	1	Plug, Nozzle
14	102-2892	1	Riser Assembly
15	363-4236	1	Screw, Drive
16	102-4504	1	Drive Assy., 12-Pack
17	102-6929	1	Stator, Low Flow, High Velocity, Blue (Used With #30 Main Nozzle And Nozzle Adapter)
17	102-1939	1	Stator Assembly, Low Flow, Yellow (Used With #31-34 Main Nozzles)
17	102-1940	1	Stator Assembly, Medium Flow, White (Used With #35-37 Main Nozzles)
18	102-1715	1	Screen, Riser
19		1	Body Assembly (See Golf Body Assembly Section.) ▲
	995-08	1	Valve Removal Tool ■●
	118-1844	1	Valve Insertion Tool ■●
	995-15	1	Selector Tool (Flag Key) ■●
	995-99	1	Nut Driver, 5/8" (For Main Nozzle) ■●
	995-105	1	Nut Driver, 5/16" (For Inner & Intermediate Nozzles And Plugs) ■●
	995-83	1	Multi-Purpose Tool ■●
	995-85	1	Riser Removal Tool ■●
	995-100	1	Valve Snap Ring Pliers With Screen Remover ■●
	995-102	1	Riser Hold-Up Tool, Universal ■●
	118-0954	1	Riser Hold-Up Tool, Red ■●

● SERVICE ITEMS
▲ Not serviced separately
■ Not illustrated

Notes:

Notes:



Count on it.