



**Count on it.**

Form No. 3384-813 Rev A

# Parts Catalog

## RT1200 Traction Unit

Model No. 25450W—Serial No. 314000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HP:** high pressure

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** low pressure

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard


**TAP:** self tapping

**TTH:** torx truss head

# Contents

|                                                                        |    |
|------------------------------------------------------------------------|----|
| Main Frame, Hood and Fender Mounting Assembly . . . . .                | 4  |
| Engine Assembly . . . . .                                              | 6  |
| Engine Heat Shield and Hose Assembly . . . . .                         | 8  |
| Wheel and Drive Assembly . . . . .                                     | 10 |
| Constant Velocity Joint Assembly No. AU106121-03 . . . . .             | 12 |
| Drive Shaft Assembly No. AU106109-03 . . . . .                         | 14 |
| Air Cleaner and Mounting Assembly . . . . .                            | 16 |
| Muffler and Mounting Assembly . . . . .                                | 18 |
| Operator Platform and Seat Assembly . . . . .                          | 20 |
| Seat Assembly No. AU118589 . . . . .                                   | 22 |
| Operator Dash and Panel Assembly . . . . .                             | 24 |
| Pedal Assembly No. AU106377 . . . . .                                  | 26 |
| Operator Storage Assembly . . . . .                                    | 28 |
| Backfill Blade and Mounting Assembly . . . . .                         | 30 |
| Hydraulic Cylinder Assembly No. 127-1797 . . . . .                     | 32 |
| Hydraulic Cylinder Assembly No. 127-1798 . . . . .                     | 34 |
| Hydraulic Cylinder Assembly No. 127-1799 . . . . .                     | 36 |
| Backfill Blade Hydraulic Plumbing Assembly . . . . .                   | 38 |
| ROPS Assembly . . . . .                                                | 40 |
| Fuel Tank Assembly . . . . .                                           | 42 |
| Main Valve and Manifold Assembly . . . . .                             | 44 |
| Fan Drive Valve and Flow Divider Assembly . . . . .                    | 46 |
| Hydraulic Tank Assembly . . . . .                                      | 48 |
| Hydraulic Tank Assembly No. AU118190 . . . . .                         | 50 |
| Tandem Pump Plumbing Assembly . . . . .                                | 52 |
| Tandem Pump and Main Valve Hydraulic Plumbing Assembly . . . . .       | 54 |
| Tandem Pump and Main Valve Hydraulic Plumbing Assembly No. 2 . . . . . | 56 |
| Steering Column and Hydraulic Plumbing Assembly . . . . .              | 58 |
| Hydraulic Plumbing Assembly . . . . .                                  | 60 |
| Main Electrical Harness Assembly . . . . .                             | 62 |
| Controller and Display Assembly . . . . .                              | 64 |
| Seat Harness and Joystick Control Assembly . . . . .                   | 66 |
| Battery Assembly . . . . .                                             | 68 |
| Cooling System Assembly . . . . .                                      | 70 |
| Coolant Recovery Tank and Plumbing Assembly . . . . .                  | 72 |
| Tilt Frame Assembly . . . . .                                          | 74 |
| Hydraulic Cylinder Assembly No. AU126558 . . . . .                     | 76 |
| Attachments and Accessories . . . . .                                  | 78 |


# Main Frame, Hood and Fender Mounting Assembly



# Main Frame, Hood and Fender Mounting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|-----------------------------------|
| 1           | 127-1705           | 1           | Main Frame ASM               | 25:2        | 125-8480           | 1           | Decal-Warning, No Riders          |
| 1:2         | 125-8481           | 1           | Decal-Fluid, Hydraulic (Out) | 26          | 130-8412           | 1           | Support Mount ASM                 |
| 1:3         | 125-8482           | 1           | Decal-Fluid, Hydraulic (In)  | 26:2        | 125-8480           | 1           | Decal-Warning, No Riders          |
| 1:4         | 125-6139           | 2           | Decal-Lift/Tie Down          | 28          | 33104-035          | 2           | Screw-HHF                         |
| 1:5         | 127-1829           | 1           | Decal-Drain, Oil             | 30          | 104-3082           | 3           | Nut-Lock, HHF                     |
| 2           | 131-0453-03        | 1           | Hoop-Support                 | 31          | AU100331           | 4           | Screw-HHF                         |
| 3           | AU118197           | 1           | Fender-RH                    | 32          | 103-9511           | 8           | Nut-Lock, NI                      |
| 4           | AU118198           | 1           | Fender-LH                    | 33          | 130-7458-03        | 2           | Handle-Operator                   |
| 5           | AU118199-03        | 2           | Support-Fender               | 34          | AU109540-03        | 1           | Plate-Skid                        |
| 6           | 131-0476           | 1           | Hood Plate ASM               | 35          | 115-1115           | 11          | Nut-Lock, HHF                     |
| 6:2         | 125-4963           | 1           | Decal-Surface, Hot           | 36          | AU122083-03        | 2           | Plate-Reinforcement,<br>Fender    |
| 6:3         | 125-8479           | 1           | Decal-Warning, Radiator      | 37          | 127-1769           | 2           | Seal-Hood                         |
| 7           | 127-1702           | 1           | Front Hood ASM               | 38          | 127-1770           | 1           | Seal-Hood                         |
| 7:2         | 125-6689           | 2           | Decal-Warning, Fan           | 40          | 33106-040          | 5           | Screw-HHF                         |
| 7:3         | 67-1300            | 1           | Decal                        | 41          | 2412-4             | 1           | Clamp                             |
| 7:4         | 125-8479           | 1           | Decal-Warning, Radiator      | 42          | AU232-41120        | 4           | Nut-Hex                           |
| 9           | 131-0443           | 1           | Seal-Hood                    | 44          | 114-0990           | 2           | Decal                             |
| 10          | 131-1281           | 1           | RH Hood ASM                  | 45          | 125-4963           | 1           | Decal-Surface, Hot                |
| 10:2        | 131-0462-03        | 1           | Tube-Bent                    | 46          | 127-1825           | 2           | Decal                             |
| 10:3        | 131-0454-03        | 2           | Bracket-Hood                 | 49          | 131-0460-03        | 2           | Plate-Bent                        |
| 10:4        | 321-13             | 10          | Screw-HH                     | 51          | 131-0467-01        | 1           | Cover ASM                         |
| 10:5        | 119-4040           | 10          | Nut-Flange, NI               | 54          | 3234-42            | 11          | Screw-HHF                         |
| 11          | 131-1282           | 1           | LH Hood ASM                  | 55          | 121-4600           | 8           | Nut-Lock, NI                      |
| 11:2        | 131-0452-03        | 1           | Tube-Bent                    | 56          | AU50GB2302         | 4           | Latch-Trigger, Raised<br>(W/Lock) |
| 11:3        | 131-0454-03        | 2           | Bracket-Hood                 | 57          | 112-4576           | 3           | Nut-Clip, U                       |
| 11:4        | 321-13             | 10          | Screw-HH                     | 58          | 119-4042           | 4           | Nut-Flange, NI                    |
| 11:5        | 119-4040           | 10          | Nut-Flange, NI               | 59          | 3234-14            | 2           | Screw-HHF                         |
| 12          | 33105-030          | 21          | Screw-HHF                    | 60          | 99-6810            | 2           | Screw-HHF                         |
| 13          | AU119006-03        | 2           | Support-Cover, Engine        | 61          | 106-8737           | 2           | Nut-Retainer                      |
| 14          | AU100863           | 13          | Nut-U                        | 62          | 131-0478           | 1           | Seal-Hood                         |
| 16          | AU107716-03        | 1           | Plate-Skid                   | 63          | 119-4041           | 2           | Nut-Flange, NI                    |
| 17          | 33106-035          | 9           | Screw-HHF                    | 64          | 125-8295           | 1           | Decal-Eac                         |
| 23          | AU112099           | 1           | Seal-Bottom, Nose            |             |                    |             |                                   |
| 24          | AU124404-03        | 1           | Plate-Cover, Rear            |             |                    |             |                                   |
| 25          | 130-8411           | 1           | Support Mount ASM            |             |                    |             |                                   |

# Engine Assembly




## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-----------------------|
| 1           |                    | 1           | Engine ASM ●               | 12          | 120-7252           | 1           | Nut-Lock              |
| 2           | 127-1781-03        | 1           | Bracket-Engine Support, LH | 13          | AU100333           | 4           | Screw-Flange          |
| 3           | 127-1782-03        | 1           | Bracket-Engine Support, RH | 14          | AU100527           | 4           | Nut-Flange, Nylock    |
| 4           | AU116622-03        | 2           | Mount-Engine, Rear         | 17          | AU8PD92006         | 1           | Coupling-Drive, Nylon |
| 5           | 33106-030          | 8           | Screw-HHF                  | 18          | 323-43             | 8           | Screw-HH              |
| 6           | AU116662           | 2           | Isolator-Wear Plate, Green | 19          | AU360643A1         | 1           | Plate-Mounting, Pump  |
| 7           | AU496-81025        | 2           | Washer                     | 20          | AU100877           | 12          | Screw-HH              |
| 8           | AU100366           | 2           | Screw-Flange               | 21          | AU120770           | 1           | Fitting-Reducer       |
| 9           | AU100529           | 2           | Nut-HHF                    | 22          | 127-3870           | 2           | Fitting-Elbow, 90     |
| 10          | AU496-11081        | 2           | Washer                     | 23          | AU123748           | 1           | Fitting-Reducer       |
| 11          | AU426-1296         | 1           | Screw-HH                   | 23:1        | AU121717           | 1           | Seal-Fitting, Fuel    |

● Not serviced separately


# Engine Heat Shield and Hose Assembly



## Engine Heat Shield and Hose Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | AU123748           | 2           | Fitting-Reducer        | 12          | 2412-74            | 2           | R-Clamp                  |
| 1:1         | AU121717           | 1           | Seal-Fitting, Fuel     | 13          | 2412-34            | 3           | Clamp-Hose               |
| 2           | 33105-035          | 2           | Screw-HHF              | 14          | 127-1773           | 1           | Hose                     |
| 3           | 103-9511           | 2           | Nut-Lock, NI           | 15          | 33104-020          | 1           | Screw-HHF                |
| 4           | 33104-035          | 4           | Screw-HHF              | 16          | 99-7375            | 1           | Hose-Breather            |
| 5           | 104-3082           | 4           | Nut-Lock, HHF          | 17          | 115-7642           | 1           | Hose-Breather            |
| 6           | 127-3870           | 2           | Fitting-Elbow, 90      | 18          | 131-0449           | 1           | Valve-Check              |
| 7           | 127-1777           | 1           | Hose-Fuel              | 19          | 131-0447           | 1           | Plate-Heat Shield, Lower |
| 8           | 2412-119           | 2           | Clamp-Hose, Worm Drive | 20          | 131-0448           | 1           | Plate-Heat Shield, Upper |
| 10          | 2412-108           | 4           | Clamp-Worm             | 21          | 33105-020          | 6           | Screw-HHF                |
| 11          | 127-1774           | 1           | Hose                   | 22          | 104-2611           | 2           | Nut-HF                   |

# Wheel and Drive Assembly




## Wheel and Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | AU106863-03        | 2           | Axle ASM                            | 14          | 127-1813           | 2           | Adapter-Locating   |
| 1:1         |                    | 1           | Axle ●                              | 15          | 302-5              | 2           | Fitting-Grease     |
| 1:1:1       | AU118806           | 20          | Nut-Lug, Wheel Stud                 | 16          | AU217-414          | 1           | Plug-HYD           |
| 1:1:2       | AU120121           | 20          | Stud-Wheel                          | 17          | 33105-035          | 24          | Screw-HHF          |
| 1:1:3       | AU120122           | 20          | Washer-Lock, Wheel Stud             | 18          | 103-9511           | 24          | Nut-Lock, NI       |
| 2           | AU106132           | 1           | Transmission-2 Speed,<br>Powershift | 19          | AUH426858          | 4           | Washer             |
| 3           | AU106160-03        | 1           | Mount-Transmission, RH              | 20          | AU426-2048         | 4           | Bolt               |
| 4           | AU106134-03        | 1           | Mount-Transmission, LH              | 21          | 108-1531           | 8           | Screw-HHF          |
| 5           | 33106-025          | 8           | Screw-HHF                           | 22          | AUH433359          | 1           | Shim-Mount, Axle   |
| 6           | AU106121-03        | 1           | Constant Velocity Joint ASM         | 23          | 125-6846           | 2           | RH Tire ASM        |
| 7           | AU106109-03        | 1           | Front Axle Drive Shaft ASM          | 23:1        | 125-6842           | 1           | Wheel              |
| 8           | AU106161-03        | 2           | Mount-Transmission                  | 23:2        | 125-6843           | 1           | Tire-Trencher      |
| 9           | AU407398A1-03      | 1           | Housing-Mount, Trunion              | 23:3        | 232-24             | 1           | Stem-Valve         |
| 10          | AUK965265          | 2           | Bushing-Pivot                       | 24          | 125-6845           | 2           | LH Tire ASM        |
| 11          | AUK965267          | 4           | O-Ring                              | 24:1        | 125-6842           | 1           | Wheel              |
| 12          | AUK395023          | 1           | Washer-Thrust                       | 24:2        | 125-6843           | 1           | Tire-Trencher      |
| 13          | AUH433408-03       | 1           | Housing-Mount, Trunion              | 24:3        | 232-24             | 1           | Stem-Valve         |

● Not serviced separately


# Constant Velocity Joint Assembly No. AU106121-03



## Constant Velocity Joint Assembly No. AU106121-03 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | AU106123           | 1           | Connector-Center   |
| 2           | AU106122           | 2           | Joint-Universal    |
| 3           | AU106124           | 2           | Flange-Connection  |


Drive Shaft Assembly No. AU106109-03



## Drive Shaft Assembly No. AU106109-03 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | AU106124           | 2           | Flange-Connection  |
| 2           | AU106122           | 2           | Joint-Universal    |
| 3           | AU106125           | 1           | Shaft              |


# Air Cleaner and Mounting Assembly



## Air Cleaner and Mounting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 127-1844           | 1           | Air Cleaner ASM           | 7           | 131-0450-03        | 1           | Mount-Box, Air     |
| 2           | 127-1779           | 1           | Hose-Intake               | 8           | 33103-020          | 4           | Screw-HHF          |
| 3           | AU130446           | 1           | Elbow-Intake, Air Cleaner | 10          | 3234-42            | 2           | Screw-HHF          |
| 4           | 127-1778           | 1           | Connector-Intake, Air     | 11          | 112-4576           | 2           | Nut-Clip, U        |
| 5           | 127-1737           | 1           | Precleaner-Intake, Air    | 13          | AU100861           | 4           | Nut-U              |
| 6           | 2412-140           | 4           | Clamp-Hose                |             |                    |             |                    |

# Muffler and Mounting Assembly




## Muffler and Mounting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 127-1845           | 1           | Muffler              |
| 2           | 127-1780           | 1           | Pipe-Turbo           |
| 3           | 127-1731-03        | 1           | Mount-Muffler        |
| 4           | 131-0475-03        | 1           | Plate-Bent           |
| 5           | AU100330           | 4           | Screw-Flange, Metric |
| 6           | 104-3082           | 4           | Nut-Lock, HHF        |
| 7           | 127-1739           | 1           | Tube-Exhaust         |
| 8           | AU121736           | 1           | Cap-Rain             |
| 9           | AU130579           | 2           | Clamp-Torctite       |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 10          | AU8NG28118         | 1           | Clamp-Guillotine   |
| 11          | 127-1783-03        | 1           | Shield-Muffler     |
| 12          | 33103-025          | 6           | Screw-HHF          |
| 13          | AU217-1050         | 1           | Fitting-Elbow, 90  |
| 14          | AU293797A1         | 1           | Switch ASM         |
| 15          | AU108120           | 8           | Nut-U              |
| 16          | 127-1709-03        | 2           | Strap-Muffler      |
| 17          | 33103-030          | 2           | Screw-HHF          |

# Operator Platform and Seat Assembly




## Operator Platform and Seat Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 127-1740-03        | 1           | Platform-Operator  |
| 2           | AU118589           | 1           | Seat ASM           |
| 3           | AU30-760-5018      | 4           | Mount-Rubber       |
| 4           | AUH426833          | 8           | Washer             |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | AU426-1696         | 4           | Bolt-HH            |
| 6           | AU101521           | 4           | Washer-Snubber     |
| 7           | AU232-41116        | 4           | Nut-Hex            |
| 8           | AU100876           | 4           | Screw-Flange       |


# Seat Assembly No. AU118589



## Seat Assembly No. AU118589 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|----------------------------------|
| 1           | AU107706           | 1           | Armchair-Operator      | 9           | 240-5              | 1           | Grommet                          |
| 2           | AU108507-03        | 2           | Plate-Spacer           | 10          | 131-0485-03        | 1           | Mount-Joystick                   |
| 5           | AU100526           | 4           | Nut-Torque, Prevailing | 11          | 125-8496           | 1           | Decal-Joystick, RH               |
| 6           | AU107510-03        | 2           | Riser-Operator Seat    | 12          | 125-8499           | 1           | Decal-Control, Drive<br>(Ground) |
| 7           | 93-7773            | 4           | Screw-HHF              |             |                    |             |                                  |
| 8           | AU112736-03        | 1           | Cup-Holder             |             |                    |             |                                  |


# Operator Dash and Panel Assembly



## Operator Dash and Panel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 115-7721           | 10          | Nut-Clip, U            | 11          | AU106377           | 1           | Pedal ASM                |
| 2           | AU100862           | 2           | Nut-U                  | 13          | AU353-411          | 2           | Plug-Dome                |
| 3           | 131-0438           | 1           | Dash-Panel             | 14          | AU118602           | 2           | Seal-Hood                |
| 4           | 33104-030          | 4           | Screw-HHF              | 15          | AU353-400          | 2           | Plug-Dome                |
| 5           | AU103959-03        | 1           | Plate-Mount, Display   | 18          | 125-8484           | 1           | Decal                    |
| 6           | AU463-11012        | 4           | Screw-HH               | 19          | 130-7539           | 1           | Decal-Ignition           |
| 7           | 130-8409           | 1           | Kick Panel ASM         | 20          | 131-0439           | 1           | Decal-Lock, Differential |
| 7:2         | 130-7540           | 1           | Decal-Safety           | 21          | 127-1830           | 1           | Decal-Aux Power          |
| 8           | 108-3748           | 12          | Screw-HHF              | 22          | 104-3082           | 2           | Nut-Lock, HHF            |
| 9           | 130-8410           | 1           | Battery Cover ASM      | 23          | 127-1293           | 2           | Trim-Battery             |
| 9:2         | 125-8473           | 1           | Decal-Warning, Battery | 24          | 131-0440           | 1           | Decal-Brake, Parking     |


# Pedal Assembly No. AU106377



## Pedal Assembly No. AU106377 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------|
| 1           | AU106362-03        | 1           | Plate-Floor              | 15          | 65-2720            | 2           | Ring-Clip, Locking  |
| 2           | AUH403816-03       | 1           | Pedal-Foot, Ground Drive | 16          | AU232-4616         | 1           | Nut-Hex             |
| 3           | AUH672181-03       | 1           | Pedal-Heel               | 17          | 3220-3             | 3           | Nut-HJ              |
| 4           | AUD38296           | 2           | Joint-Ball               | 18          | 32144-64           | 2           | Tscrew-HWH          |
| 5           | AU398314A1         | 1           | Rod-Control              | 19          | 1-800805           | 1           | Screw-HH            |
| 6           | AUD128616          | 2           | Bushing-Insert, Plastic  | 20          | AUS108030          | 1           | Rod-End             |
| 7           | AU106453           | 1           | Pivot-W/Bellcrank        | 21          | AU109930           | 1           | Insulation-Floor    |
| 8           | AUH436303          | 1           | Spring                   | 22          | AU126572           | 4           | Washer              |
| 9           | AUH435694          | 1           | Spacer                   | 23          | 32128-43           | 2           | Nut-Flange          |
| 10          | AUH436215          | 1           | Washer-Special           | 24          | 3296-6             | 1           | Nut-Lock            |
| 11          | 325-10             | 1           | Screw-HH                 | 25          | 131-0481           | 1           | Plate-Sensor, Pedal |
| 12          | 97-1206            | 1           | Locknut                  | 26          | 3255-24            | 2           | Washer-Lock / EXT   |
| 13          | 131-0434           | 1           | Sensor-Traction          | 27          | 3249-3             | 2           | Screw-PRH           |
| 14          | AUH403840          | 1           | Pin                      |             |                    |             |                     |


# Operator Storage Assembly



## Operator Storage Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | AU105911           | 2           | Tape-Anti Skid, Upper Step | 7           | AUL102515          | 1           | Latch              |
| 2           | AU105912           | 2           | Tape-Anti Skid, Lower Step | 8           | 103-0138           | 2           | Rivet-Pop          |
| 3           | AU103216           | 1           | Holder-Manual              | 9           | 127-1784           | 1           | Hinge              |
| 4           | 114439             | 4           | Rivet-Pop                  | 10          | 127-1785-03        | 1           | Plate-Door         |
| 5           | AUR46465           | 1           | Lanyard                    | 11          | 3231-1             | 8           | Screw-CARR         |
| 6           | AUR46463           | 1           | Post-Manual                | 12          | 104-8301           | 8           | Nut-Flange, NI     |


# Backfill Blade and Mounting Assembly



## Backfill Blade and Mounting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|------------------------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | AU117156-03        | 1           | Frame-Blade, Backfill                    | 13          | AUH432898          | 2           | Pin-Blade (Arm To Pivot) |
| 2           | AU115400-03        | 1           | Pivot-Blade, Backfill                    | 14          | AU1978738C1        | 4           | Pin-Cotter, Quick Attach |
| 3           | 131-0437           | 1           | Backfill Arm ASM                         | 15          | AUH117606          | 3           | Washer                   |
| 3:2         | 130-7541           | 2           | Decal-Danger, Hazardous Area             | 16          | AUH426833          | 8           | Washer                   |
| 4           | 131-0487-03        | 1           | Blade-Backfill                           | 17          | AU426-1656         | 2           | Screw-Cap, HH            |
| 5           | AU495-81209        | 4           | Washer-Flat                              | 18          | AU426-1640         | 2           | Bolt                     |
| 6           | 127-1797           | 2           | HYD Cylinder ASM (Plow Angle)            | 19          | AU232-41116        | 4           | Nut-Hex                  |
| 7           | AUH432880          | 4           | Pin-Angle, Cylinder (Barrel To Mounting) | 20          | 56-7971            | 4           | Clamp-Tube               |
| 8           | 32151-77           | 8           | Ring-Retaining, External                 | 21          | 69-9760            | 2           | Coverplate               |
| 9           | 127-1798           | 1           | HYD Cylinder ASM (Plow Lift)             | 22          | 100-4852           | 2           | Washer-Hardened          |
| 10          | 127-1799           | 1           | HYD Cylinder ASM (Plow Tilt)             | 23          | AU224-2246         | 2           | Nut-Square               |
| 11          | AUH432906          | 1           | Pin-Blade (Pivot To Mounting Frame)      | 24          | 323-52             | 2           | Screw-HH                 |
| 12          | AUD25279           | 6           | Ring                                     | 25          | AUN14001           | 4           | Pin-Clevis               |
|             |                    |             |                                          | 26          | 125-6694           | 2           | Decal-Tie Down           |
|             |                    |             |                                          | 27          | AUH438278-03       | 8           | Shim-Retainer            |
|             |                    |             |                                          | 28          | AUH438273-03       | 2           | Retainer-Blade           |
|             |                    |             |                                          | 29          | 3256-27            | 6           | Washer-Flat              |
|             |                    |             |                                          | 30          | 327-4              | 6           | Screw-HH                 |


# Hydraulic Cylinder Assembly No. 127-1797



## Hydraulic Cylinder Assembly No. 127-1797 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 131-3822           | 1           | Seal Kit           |
| 2           | 302-2              | 2           | Fitting-Grease     |


# Hydraulic Cylinder Assembly No. 127-1798



## Hydraulic Cylinder Assembly No. 127-1798 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 127-1854           | 1           | Seal Kit           |


# Hydraulic Cylinder Assembly No. 127-1799



## Hydraulic Cylinder Assembly No. 127-1799 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 127-1853           | 1           | Seal Kit           |

# Backfill Blade Hydraulic Plumbing Assembly



## Backfill Blade Hydraulic Plumbing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2           | AU218-5243         | 2           | Fitting-Tee        |
| 2:1         | 237-42             | 1           | O-Ring             |
| 4           | 3334-945           | 1           | Tie-Cable          |
| 5           | 127-1815           | 1           | HYD Hose ASM, HP   |


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 127-1795           | 2           | HYD Hose ASM, HP   |
| 7           | 127-1818           | 1           | HYD Hose ASM, HP   |
| 8           | 127-1817           | 1           | HYD Hose ASM, HP   |
| 9           | 131-0425           | 1           | HYD Hose ASM, HP   |



## ROPS Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------|
| 1           | AU116756-03        | 1           | Main ROPS ASM      | 8           | AU118604           | 1           | Seal-Hood            |
| 2           | AU100861           | 8           | Nut-U              | 9           | AU119456-03        | 1           | Cover-ROPS           |
| 3           | AU105156-03        | 4           | Plate-Cover        | 10          | 33106-025          | 4           | Screw-HHF            |
| 4           | 33103-020          | 8           | Screw-HHF          | 11          | 115-1115           | 4           | Nut-Lock, HHF        |
| 5           | AU100364           | 8           | Screw-Flange       | 12          | 127-1841           | 1           | Decal-ROPS           |
| 6           | AU100529           | 10          | Nut-HHF            | 13          | 125-8495           | 1           | Decal-Switches, Rear |
| 7           | AU100832           | 2           | Screw-Flange       |             |                    |             | Control              |


# Fuel Tank Assembly



## Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 127-1821           | 1           | Fuel Tank ASM                  | 13          | 2412-119           | 4           | Clamp-Hose, Worm Drive |
| 1:2         | 125-6135           | 1           | Decal-Diesel, Ultra-Low        | 14          | AU217-294          | 1           | Stem-90 (Barb Hose)    |
| 2           | AU21000893         | 1           | Sender-Fuel                    | 15          | 32180-030          | 1           | Clip-Tie               |
| 4           | AU8NG28121         | 5           | Isolator-Mounting, Universal   | 17          | 2412-4             | 1           | Clamp                  |
| 5           | 127-1292           | 1           | Cap-Diesel Fuel,<br>Non-Vented | 19          | 115-1447           | 1           | Fitting-Straight       |
| 6           | AU496-81018        | 5           | Washer-Flat                    | 20          | AU217-1101         | 1           | Coupling-Pipe (NPTF)   |
| 7           | 33106-080          | 5           | Screw-HHF                      | 21          | AU31543            | 1           | Breather               |
| 8           | AU119908           | 1           | Plug-Hex, Magnetic             | 22          | 2412-108           | 2           | Clamp-Worm             |
| 9           | AU105912           | 2           | Tape-Anti Skid, Lower Step     | 23          | 3290-379           | 1           | Tie-Cable              |
| 10          | AUH433994          | 1           | Strip-Anti Skid                | 24          | 109-0296           | 1           | Hose-Fuel              |
| 11          | 127-1745           | 1           | Hose-Fuel                      | 25          | 106-1381           | 2           | Fitting-Straight       |
| 12          | 127-1746           | 1           | Hose-Fuel                      | 25:1        | 237-42             | 1           | O-Ring                 |
|             |                    |             |                                | 26          | 116-1127           | 2           | Elbow-90 DEG           |




# Main Valve and Manifold Assembly



## Main Valve and Manifold Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | AU121481-03        | 1           | Plate-Mount, Filter       | 13          | AU218-5063         | 1           | Fitting-Straight      |
| 2           | 131-0421           | 1           | Main Valve ASM            | 14          | 353-369            | 2           | Fitting-Elbow, 90 DEG |
| 3           | 33105-025          | 4           | Screw-HHF                 | 14:1        | 237-81             | 1           | O-Ring                |
| 4           | 33115-035          | 2           | Screw-HH                  | 15          | AU120043-03        | 1           | Spacer                |
| 5           | 33095-00           | 2           | Washer-Flat               | 16          | AU218-5130         | 1           | Elbow-90, Adj         |
| 6           | 103-9511           | 2           | Nut-Lock, NI              | 16:1        | 237-146            | 1           | O-Ring                |
| 7           | AU218-5058         | 6           | Connector                 | 17          | AU218-5069         | 1           | Fitting-Straight      |
| 7:1         | 237-79             | 1           | O-Ring                    | 18          | AU218-5044         | 1           | Adapter-Straight      |
| 8           | 130-7462           | 4           | Fitting-Straight, Long    | 18:1        | 237-81             | 1           | O-Ring                |
| 8:1         | 237-79             | 1           | O-Ring                    | 19          | 33114-100          | 2           | Screw-HH              |
| 9           | 353-388            | 4           | Fitting-Straight          | 20          | 33094-00           | 2           | Washer-Plain          |
| 9:1         | 237-79             | 1           | O-Ring                    | 21          | 104-3082           | 2           | Nut-Lock, HHF         |
| 10          | 353-385            | 2           | Fitting-Straight          | 22          | AU218-335          | 2           | Cap                   |
| 10:1        | 237-80             | 1           | O-Ring                    | 23          | AU218-696          | 2           | Fitting-Elbow, 90     |
| 11          | AU218-5352         | 1           | Adapter-Straight          | 24          | AU218-1256         | 2           | Nut-Lock, Bulkhead    |
| 11:1        | 237-78             | 1           | O-Ring                    | 25          | 125-6856           | 1           | HYD Hose ASM, HP      |
| 12          | AU106457           | 1           | Manifold ASM (HYD Return) |             |                    |             |                       |


# Fan Drive Valve and Flow Divider Assembly



## Fan Drive Valve and Flow Divider Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | AU115763           | 1           | Valve-Flow Divider, Priority | 15          | 92-3505            | 1           | Fitting-Adaptor, 90 DEG |
| 2           | AU218-5278         | 1           | Elbow-90, Adj                | 15:1        | 237-42             | 1           | O-Ring                  |
| 2:1         | 237-78             | 1           | O-Ring                       | 16          | 353-374            | 1           | Fitting-Elbow, 90 DEG   |
| 3           | AU218-5352         | 1           | Adapter-Straight             | 16:1        | 237-42             | 1           | O-Ring                  |
| 3:1         | 237-78             | 1           | O-Ring                       | 17          | 353-370            | 1           | Fitting-Elbow, 90 DEG   |
| 4           | AU218-980          | 3           | Elbow-Swivel, 90 DEG         | 17:1        | 237-80             | 1           | O-Ring                  |
| 5           | 353-369            | 1           | Fitting-Elbow, 90 DEG        | 18          | 353-384            | 3           | Fitting-Straight        |
| 5:1         | 237-81             | 1           | O-Ring                       | 18:1        | 237-42             | 1           | O-Ring                  |
| 6           | AU218-5064         | 2           | Fitting-Straight             | 19          | 33114-120          | 4           | Screw-HH                |
| 6:1         | 237-81             | 1           | O-Ring                       | 20          | 2412-147           | 1           | Clamp                   |
| 7           | 353-388            | 1           | Fitting-Straight             | 21          | AU122191           | 1           | Tube                    |
| 7:1         | 237-79             | 1           | O-Ring                       | 22          | 125-6801           | 1           | HYD Hose ASM, LP        |
| 8           | 33114-090          | 2           | Screw-HH                     | 23          | 125-6805           | 1           | HYD Hose ASM, HP        |
| 9           | 33094-00           | 6           | Washer-Plain                 | 24          | 125-6857           | 1           | HYD Return Hose ASM     |
| 10          | 104-3082           | 6           | Nut-Lock, HHF                | 25          | 125-6789           | 1           | HYD Hose ASM            |
| 11          | AU115768           | 1           | Valve-Fan Drive              | 26          | 125-6870           | 1           | HYD Hose ASM, HP        |
| 12          | 95-0581            | 1           | Fitting-Elbow, 90 DEG        | 27          | 353-426            | 1           | Fitting-90 DEG          |
| 13          | 353-385            | 2           | Fitting-Straight             | 27:1        | 237-80             | 1           | O-Ring                  |
| 13:1        | 237-80             | 1           | O-Ring                       | 28          | AU112950           | 3           | Protector-Hose, 4 Inch  |
| 14          | 353-433            | 1           | Fitting-Straight             | 29          | 3290-379           | 9           | Tie-Cable               |


# Hydraulic Tank Assembly



## Hydraulic Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | AU118190           | 1           | HYD Tank ASM             | 22          | AU218-5243         | 1           | Fitting-Tee           |
| 2           | AU111774A1-03      | 1           | Bracket-Mounting, Filter | 22:1        | 237-42             | 1           | O-Ring                |
| 3           | AUD121629          | 1           | Oil Filter ASM           | 23          | 353-384            | 1           | Fitting-Straight      |
| 3:1         | 110-4146           | 1           | Filter-HYD               | 23:1        | 237-42             | 1           | O-Ring                |
| 4           | AU218-5071         | 1           | Connector ASM            | 24          | 353-374            | 1           | Fitting-Elbow, 90 DEG |
| 4:1         | 237-146            | 1           | O-Ring                   | 24:1        | 237-42             | 1           | O-Ring                |
| 5           | 323-4              | 3           | Screw-HH                 | 25          | AU218-5223         | 1           | Tee-Swivel            |
| 6           | 33115-035          | 2           | Screw-HH                 | 26          | AU218-724          | 1           | Reducer               |
| 7           | 33095-00           | 2           | Washer-Flat              | 27          | AU218-5176         | 1           | Fitting-Elbow, 45     |
| 8           | 103-9511           | 2           | Nut-Lock, NI             | 28          | AU91-202702-32-3   | 1           | Adapter               |
| 9           | 110-6245           | 1           | Clamp-R                  | 28:1        | 237-189            | 1           | O-Ring(3-932)         |
| 10          | 127-1862-03        | 1           | Bracket-Filter           | 29          | AU91-2071-32-32S   | 1           | Adapter-90 DEG        |
| 11          | 114-4681           | 4           | Screw-HHF                | 30          | 130-7530           | 1           | Fitting-Straight      |
| 12          | AUH674791          | 1           | HYD Return Filter ASM    | 31          | AU218-674          | 1           | Union                 |
| 13          | 323-6              | 3           | Screw-HH                 | 32          | AU218-1255         | 1           | Nut-Lock              |
| 14          | AU218-5110         | 1           | Elbow-90 DEG             | 33          | AU218-755          | 1           | Cap                   |
| 14:1        | 237-146            | 1           | O-Ring                   | 34          | AU214-1408         | 1           | Clamp-Hose            |
| 15          | 130-7531           | 1           | Fitting-Tee              | 35          | 125-6882           | 1           | HYD Hose ASM, LP      |
| 15:1        | 237-146            | 1           | O-Ring                   | 37          | 131-0407           | 1           | Fitting-Elbow, 90     |
| 16          | AU91-2215-16-8S    | 1           | Adapter-Reducer          | 37:1        | 237-146            | 1           | O-Ring                |
| 17          | AU187505C91        | 1           | Solenoid Valve ASM       | 38          | 115-1447           | 1           | Fitting-Straight      |
| 18          | 33093-00           | 6           | Washer-Flat              | 39          | AU31543            | 1           | Breather              |
| 19          | 33113-060          | 2           | Screw-HH                 | 40          | 2412-4             | 1           | Clamp                 |
| 20          | 81-0130            | 2           | Nut-Flange, NI           | 41          | 2412-108           | 2           | Clamp-Worm            |
| 21          | 353-508            | 1           | Plug-HH                  | 42          | 109-0296           | 1           | Hose-Fuel             |
| 21:1        | 237-42             | 1           | O-Ring                   | 43          | AU217-1101         | 1           | Coupling-Pipe (NPTF)  |

# Hydraulic Tank Assembly No. AU118190




# Hydraulic Tank Assembly No. AU118190 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>               |
|-------------|--------------------|-------------|----------------------------------|
| 1           | 127-1837-01        | 1           | Tank-Hydraulic                   |
| 2           | AU105820           | 1           | Cap-HYD Fluid (W/ Lock)          |
| 3           | AUL116247          | 1           | Gauge-Sight                      |
| 4           | AU119908           | 1           | Plug-Hex, Magnetic               |
| 5           | AU8NG28121         | 5           | Isolator-Mounting, Universal     |
| 6           | AU496-81018        | 5           | Washer-Flat                      |
| 7           | AU100353           | 5           | Screw-HHF                        |
| 9           | AU118209           | 2           | Strainer-Mounted, Tank           |
| 10          | AU119493           | 1           | Sensor-Sender, Oil/Water<br>Temp |
| 11          | AU637-63153        | 1           | O-Ring                           |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|
| 12          | AU91-202713-16-1   | 1           | Adapter                    |
| 12:1        | 237-146            | 1           | O-Ring                     |
| 13          | AU218-5086         | 2           | Adapter-Straight           |
| 13:1        | 237-101            | 1           | O-Ring                     |
| 14          | AU105912           | 2           | Tape-Anti Skid, Lower Step |
| 15          | AUH433994          | 1           | Strip-Anti Skid            |
| 16          | AU8FL10013         | 1           | Strainer-Suction           |
| 17          | AU217-294          | 1           | Stem-90 (Barb Hose)        |
| 18          | AU218-5069         | 2           | Fitting-Straight           |
| 19          | 125-8483           | 1           | Decal-HYD Fluid            |


# Tandem Pump Plumbing Assembly



## Tandem Pump Plumbing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|-----------------------|
| 1           | AU115782           | 1           | Tandem Pump ASM       | 15          | AU91-500024-32S    | 1           | Adapter-Flange, Split |
| 2           | 100-6116           | 8           | Screw-HHF             | 16          | 130-7530           | 1           | Fitting-Straight      |
| 3           | AUH439280          | 3           | Fitting-Elbow         | 17          | 125-4538           | 1           | Flange Kit            |
| 5           | AU114285A1         | 4           | HYD Flange Kit        | 17:2        | 125-6148           | 1           | O-Ring                |
| 5:1         | 121-3904           | 1           | O-Ring                | 17:3        | 325-6              | 4           | Screw-HH              |
| 5:2         | 3253-6             | 4           | Washer-Lock           | 17:4        | 3253-7             | 4           | Washer-Lock           |
| 5:3         | AU113-372          | 4           | Screw-HH              | 18          | 87-8170            | 1           | Fitting               |
| 6           | AU375462A1         | 2           | Connector             | 18:1        | 237-80             | 1           | O-Ring                |
| 6:1         | 237-81             | 1           | O-Ring                | 19          | AU218-5352         | 1           | Adapter-Straight      |
| 7           | 353-374            | 1           | Fitting-Elbow, 90 DEG | 19:1        | 237-78             | 1           | O-Ring                |
| 7:1         | 237-42             | 1           | O-Ring                | 20          | AU218-980          | 1           | Elbow-Swivel, 90 DEG  |
| 8           | 340-134            | 2           | Fitting-Elbow, 90     | 22          | AU124968           | 1           | Hose-Fuel, Tank Fill  |
| 8:1         | 237-42             | 1           | O-Ring                | 23          | 125-6802           | 1           | HYD Hose ASM, HP      |
| 9           | AU443897A1         | 2           | Switch-Pressure       | 24          | 125-6812           | 1           | HYD Hose ASM, LP      |
| 10          | AU358988A1         | 1           | Hub-Coupler           | 25          | 125-6773           | 1           | HYD Hose ASM          |
| 11          | AU115760           | 1           | HYD Pump ASM          | 26          | 125-6815           | 2           | HYD Return Hose ASM   |
| 12          | AU70-9004104-158   | 1           | Seal-O Ring           | 28          | 2412-34            | 3           | Clamp-Hose            |
| 13          | AU91-500024-16S    | 1           | Adapter-Flange, Split | 29          | 2412-42            | 4           | Clamp-Hose            |
| 14          | AU91-FF593-16      | 1           | Flange Kit            | 30          | 125-6853           | 1           | Hose                  |
| 14:1        | 121-3904           | 1           | O-Ring                | 32          | AU218-5069         | 2           | Fitting-Straight      |
| 14:2        | AU426-728          | 4           | Bolt                  | 33          | AU218-5234         | 2           | Fitting-Elbow, 90     |
| 14:3        | 3253-6             | 4           | Washer-Lock           |             |                    |             |                       |


# Tandem Pump and Main Valve Hydraulic Plumbing Assembly



## Tandem Pump and Main Valve Hydraulic Plumbing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | AU218-673          | 6           | Union-Bulkhead     | 18          | AU112950           | 2           | Protector-Hose, 4 Inch |
| 1:1         | AU218-1254         | 1           | Nut-Lock, Bulkhead | 19          | 3290-379           | 6           | Tie-Cable              |
| 3           | 130-7450           | 1           | Clamp-Twin         | 20          | 131-0435           | 1           | HYD Hose ASM, HP       |
| 4           | 56-7976            | 2           | Clamp-Tube         | 21          | 131-0436           | 1           | HYD Hose ASM, HP       |
| 6           | 322-22             | 1           | Screw-HH           | 22          | 353-369            | 2           | Fitting-Elbow, 90 DEG  |
| 7           | 125-6855           | 1           | HYD Hose ASM, HP   | 22:1        | 237-81             | 1           | O-Ring                 |
| 9           | 125-6877           | 2           | HYD Hose ASM, HP   | 23          | 131-0433           | 1           | Valve-Blocking         |
| 10          | 125-6878           | 2           | HYD Hose ASM, HP   | 24          | 33114-080          | 2           | Screw-HH               |
| 11          | 125-6880           | 4           | HYD Hose ASM, HP   | 25          | 104-3082           | 2           | Nut-Lock, HHF          |
| 12          | AU107409           | 1           | Boot-Hose          | 26          | 33094-00           | 2           | Washer-Plain           |
| 15          | 3334-945           | 2           | Tie-Cable          | 27          | 94-8105            | 2           | Clamp-Tube             |
| 16          | 01-201-4520        | 2           | Cap                | 28          | 56-7971            | 2           | Clamp-Tube             |
| 17          | 69-9760            | 2           | Coverplate         | 29          | 322-13             | 1           | Screw-HH               |






# Tandem Pump and Main Valve Hydraulic Plumbing Assembly No. 2



## Tandem Pump and Main Valve Hydraulic Plumbing Assembly No. 2 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|---------------------------------|-------------|--------------------|-------------|--------------------------------|
| 1           | 2412-34            | 1           | Clamp-Hose                      | 18          | 125-6851           | 1           | HYD Return Hose ASM            |
| 2           | AU118263-03        | 1           | Plate-Mounting, HYD<br>Fittings | 19          | 125-6866           | 1           | HYD Hose ASM, HP               |
| 3           | AU218-678          | 2           | Union-Bulkhead                  | 20          | 125-6867           | 1           | HYD Hose ASM, HP               |
| 4           | 130-7535           | 1           | Fitting-Straight                | 21          | 125-6879           | 1           | HYD Hose ASM, HP               |
| 4:1         | 340-65             | 1           | O-Ring                          | 22          | 125-6881           | 2           | HYD Hose ASM, HP               |
| 5           | 92-7645            | 1           | Fitting-Swivel, 90 DEG          | 23          | 125-6811           | 1           | HYD Hose ASM, HP               |
| 5:1         | 340-65             | 1           | O-Ring                          | 24          | 130-7506           | 1           | HYD Hose ASM                   |
| 6           | AU218-1250         | 2           | Nut-Lock, Bulkhead              | 29          | AU218-774          | 1           | Plug                           |
| 7           | AU218-758          | 2           | Cap                             | 30          | AU218-776          | 2           | Plug                           |
| 8           | AU218-675          | 1           | Union-Bulkhead                  | 31          | AU124405-03        | 1           | Plate-Cover                    |
| 9           | AU91-2215-10-12S   | 1           | Adapter-Reducer                 | 32          | 33106-050          | 1           | Screw-HHF                      |
| 10          | AU91-2215-12-16S   | 1           | Adapter-Reducer                 | 33          | 2412-102           | 1           | Clamp-R                        |
| 11          | AU218-1251         | 1           | Nut-Lock, Bulkhead              | 34          | 127-1828           | 1           | Decal-Attachment<br>Connection |
| 12          | AU218-756          | 1           | Fitting-Cap                     | 35          | 130-7450           | 2           | Clamp-Twin                     |
| 13          | AU218-1254         | 2           | Nut-Lock, Bulkhead              | 36          | 127-8425           | 2           | Plate-Reatainer, Clamp         |
| 14          | 130-7463           | 2           | Fitting-Bulkhead, Elbow 45      | 37          | 120-1959           | 3           | Clamp-R, Double                |
| 15          | 01-201-4520        | 2           | Cap                             | 38          | 2412-126           | 1           | R-Clamp                        |
| 16          | 33106-040          | 3           | Screw-HHF                       | 39          | 322-13             | 2           | Screw-HH                       |
| 17          | 115-1115           | 1           | Nut-Lock, HHF                   |             |                    |             |                                |



# Steering Column and Hydraulic Plumbing Assembly



# Steering Column and Hydraulic Plumbing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|------------------------|
| 1           | AU115762           | 1           | Steering Valve ASM    | 19:3        | AU113-372          | 4           | Screw-HH               |
| 2           | 353-537            | 4           | Fitting-Elbow, 90 DEG | 20          | AUH439280          | 2           | Fitting-Elbow          |
| 2:1         | 237-79             | 1           | O-Ring                | 21          | 131-0492           | 1           | Fitting-Tee, Run       |
| 3           | 353-388            | 1           | Fitting-Straight      | 21:1        | 237-81             | 1           | O-Ring                 |
| 3:1         | 237-79             | 1           | O-Ring                | 22          | 353-374            | 1           | Fitting-Elbow, 90 DEG  |
| 4           | AU218-5058         | 2           | Connector             | 22:1        | 237-42             | 1           | O-Ring                 |
| 4:1         | 237-79             | 1           | O-Ring                | 26          | 353-212            | 1           | Fitting-Elbow, 45 DEG  |
| 5           | AU218-980          | 1           | Elbow-Swivel, 90 DEG  | 26:1        | 237-42             | 1           | O-Ring                 |
| 6           | 01-201-2410        | 1           | Fitting-Elbow, 90     | 27          | 125-6804           | 1           | HYD Hose ASM, HP       |
| 7           | AU218-5278         | 1           | Elbow-90, Adj         | 28          | 125-6816           | 1           | HYD Hose ASM, HP       |
| 7:1         | 237-78             | 1           | O-Ring                | 29          | 125-6817           | 1           | HYD Hose ASM, HP       |
| 8           | 100-4852           | 4           | Washer-Hardened       | 30          | 125-6779           | 1           | HYD Hose ASM           |
| 9           | 323-43             | 4           | Screw-HH              | 31          | 125-6773           | 1           | HYD Hose ASM           |
| 10          | 353-371            | 1           | Fitting-Elbow, 90     | 32          | 131-0493           | 1           | Hose                   |
| 10:1        | 237-79             | 1           | O-Ring                | 33          | 125-6858           | 1           | HYD Hose ASM, HP       |
| 11          | AUH672220          | 1           | Steering Column ASM   | 36          | 125-6862           | 1           | HYD Hose ASM, HP       |
| 11:1        | 120-2593           | 1           | Boot-Rubber, Bearing  | 37          | 130-7499           | 1           | HYD Hose ASM           |
| 12          | AUA65544           | 1           | Wheel-Steering        | 39          | 125-6864           | 1           | HYD Hose ASM, HP       |
| 13          | AUF19646           | 1           | Nut                   | 40          | 125-6879           | 2           | HYD Hose ASM, HP       |
| 14          | AU238-5227         | 1           | O-Ring                | 41          | 125-6810           | 2           | HYD Hose ASM, HP       |
| 15          | AU114882A2         | 1           | Cap-Steering Wheel    | 42          | 94-8105            | 6           | Clamp-Tube             |
| 16          | 2412-34            | 2           | Clamp-Hose            | 43          | 322-9              | 3           | Screw-HH               |
| 17          | AU385343A2         | 1           | HYD Motor ASM         | 44          | 69-9761            | 3           | Plate-Cover            |
| 18          | AU864-14040        | 4           | Screw-HSH             | 45          | 2412-4             | 2           | Clamp                  |
| 19          | AU114285A1         | 2           | HYD Flange Kit        | 46          | AU112950           | 2           | Protector-Hose, 4 Inch |
| 19:1        | 121-3904           | 1           | O-Ring                | 47          | 3290-379           | 4           | Tie-Cable              |
| 19:2        | 3253-6             | 4           | Washer-Lock           |             |                    |             |                        |


# Hydraulic Plumbing Assembly



## Hydraulic Plumbing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|------------------------|
| 1           | AU121451           | 1           | Gear Pump ASM         | 20          | 125-6807           | 1           | HYD Hose ASM, HP       |
| 3           | AU862-10030        | 2           | Screw-HSH             | 21          | 125-6808           | 1           | HYD Hose ASM, LP       |
| 4           | 100-4852           | 2           | Washer-Hardened       | 22          | 125-6809           | 1           | HYD Hose ASM, HP       |
| 5           | 353-426            | 1           | Fitting-90 DEG        | 24          | 125-6872           | 2           | HYD Hose ASM, LP       |
| 5:1         | 237-80             | 1           | O-Ring                | 25          | 130-8401           | 1           | HYD Tube ASM           |
| 6           | 353-369            | 2           | Fitting-Elbow, 90 DEG | 26          | 130-8402           | 1           | HYD Tube ASM           |
| 6:1         | 237-81             | 1           | O-Ring                | 27          | 125-6873           | 1           | HYD Hose ASM, HP       |
| 8           | 2412-34            | 1           | Clamp-Hose            | 28          | 125-6874           | 1           | HYD Hose ASM, LP       |
| 10          | 127-0519           | 1           | Fitting-Elbow, 45 DEG | 29          | 125-6875           | 1           | HYD Hose ASM, HP       |
| 11          | 127-1850           | 1           | Fitting-Tee, Bulkhead | 30          | 125-6876           | 1           | HYD Hose ASM, LP       |
| 12          | AU218-1250         | 1           | Nut-Lock, Bulkhead    | 31          | 125-6819           | 1           | HYD Hose ASM, HP       |
| 13          | 130-7534           | 1           | Fitting-Straight      | 32          | 130-8405           | 2           | HYD Hose ASM, HP       |
| 14          | 127-1852           | 1           | Valve-Check           | 33          | 56-7976            | 2           | Clamp-Tube             |
| 15          | 127-1851           | 1           | Fitting-Tee, Bulkhead | 34          | 69-9760            | 1           | Coverplate             |
| 16          | AU218-1256         | 1           | Nut-Lock, Bulkhead    | 35          | 322-7              | 1           | Screw-HH               |
| 18          | 125-6803           | 1           | HYD Hose ASM, LP      | 36          | 3290-379           | 4           | Tie-Cable              |
| 19          | 125-6806           | 1           | HYD Hose ASM, HP      | 37          | AU112950           | 1           | Protector-Hose, 4 Inch |


# Main Electrical Harness Assembly



## Main Electrical Harness Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | AU116154           | 1           | Box-Vehicle, Main         | 15          | 122-0291           | 1           | Cable-Battery, Positive    |
| 2           | AU126233           | 1           | Holder-Fuse               | 16          | 122-0365           | 1           | Cable-Battery, Positive    |
| 3           | 99-7430            | 1           | Relay                     | 17          | AUD127018          | 2           | Strap-Grounding            |
| 4           | AU126234           | 1           | Solenoid-Relay 12V, 300A  | 18          | 3255-9             | 2           | Washer-Lock                |
| 5           | AUR52278           | 1           | Switch-Disconnect, Master | 19          | 33105-030          | 2           | Screw-HHF                  |
| 6           | AU105186           | 1           | Post-Battery, Remote      | 20          | 103-9511           | 2           | Nut-Lock, NI               |
| 7           | AU63-81012         | 3           | Screw-HWH                 | 21          | AU126232           | 1           | Fuse-100A                  |
| 8           | 3296-27            | 3           | Nut-Lock, NI              | 22          | 125-6157           | 1           | Decal-Disconnect, Battery  |
| 9           | 33104-030          | 4           | Screw-HHF                 | 23          | 122-0289           | 1           | Cable-Battery, Positive    |
| 10          | 104-3082           | 4           | Nut-Lock, HHF             | 24          | 122-0293           | 1           | Cable-Battery, Positive    |
| 11          | 33103-020          | 4           | Screw-HHF                 | 25          | 122-0294           | 1           | Cable-Battery, Negative    |
| 12          | 120-9645           | 4           | Nut-HHF                   | 26          | 122-0295           | 1           | Cable-Battery, Positive    |
| 13          | 127-1748           | 1           | Harness-Main              | 27          | 122-0084           | 1           | Harness-Wire, Fusible Link |
| 14          | 122-0290           | 1           | Cable-Battery, Positive   |             |                    |             |                            |


# Controller and Display Assembly



## Controller and Display Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | AU117890           | 1           | Controller ASM (88 Pin, Unprogrammed) | 10          | 33103-035          | 4           | Screw-HHF          |
| 2           | 121-5159           | 1           | Ignition Switch ASM                   | 11          | 120-9645           | 4           | Nut-HHF            |
| 2:2         | 121-5160           | 1           | Nut-Hex                               | 12          | 104-9368           | 1           | Plug-Dome          |
| 2:3         | 121-5161           | 1           | Nut-Face                              | 13          | AU353-400          | 2           | Plug-Dome          |
| 2:4         | 121-5162           | 1           | Ignition Key Set                      | 14          | 3249-3             | 8           | Screw-PRH          |
| 3           | AU22000121         | 1           | Receptical-12V Dc                     | 15          | 3296-9             | 8           | Nut-Lock           |
| 4           | AU113662           | 2           | Switch-Rocker, 2 Pole (On/Off)        | 16          | 125-6884           | 1           | Harness-Dash       |
| 7           | AU124043           | 1           | Plug-Panel                            | 17          | 130-8444           | 1           | Plug-Dome          |
| 8           | 103-8018           | 1           | Plug-Dome                             | 18          | 130-8439           | 1           | Plug-Dome          |
| 9           | AU103384           | 1           | Display-Dp600, Unprogrammed           | 19          | 32180-030          | 2           | Clip-Tie           |


# Seat Harness and Joystick Control Assembly



## Seat Harness and Joystick Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------------------|-------------|--------------------|-------------|---------------------|
| 1           | AU118424           | 2           | Single Axis Joystick ASM             | 8           | 32180-030          | 1           | Clip-Tie            |
| 2           | AU118423           | 1           | Joystick-Control (W/<br>Handle)      | 9           | 2412-71            | 1           | Clamp-R             |
| 3           | AU113664           | 1           | Switch-Rocker, 2 Pole<br>(On)Off(On) | 10          | 33105-025          | 1           | Screw-HHF           |
| 4           | 125-6883           | 1           | Harness-Wire, Seat                   | 11          | 103-9511           | 1           | Nut-Lock, NI        |
| 5           | 32105-29           | 4           | Screw-SHWH                           | 15          | 127-1843           | 1           | Plug-Dome           |
| 6           | AU63-81012         | 8           | Screw-HWH                            | 16          | 131-0481           | 2           | Plate-Sensor, Pedal |
| 7           | 112-6349           | 4           | Screw-HWH                            | 17          | 3255-24            | 4           | Washer-Lock / EXT   |
|             |                    |             |                                      | 18          | 3249-3             | 4           | Screw-PRH           |
|             |                    |             |                                      | 99          | 3290-378           | 10          | Tie-Cable           |


# Battery Assembly



## Battery Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 127-0968           | 2           | Battery (950Cca, Wet)    | 6           | 122-0106           | 1           | Cable-Battery, Negative |
| 2           | AU117616-03        | 2           | Plate-Hold Down, Battery | 7           | 32149-10           | 4           | Nut-Keps                |
| 3           | AUH436311          | 4           | Bolt-Holddown, Battery   | 8           | 127-1293           | 2           | Trim-Battery            |
| 4           | 104-8301           | 4           | Nut-Flange, NI           | 9           | AU124043           | 8           | Plug-Panel              |
| 5           | 122-0105           | 1           | Cable-Battery, Positive  | 10          | 32180-149          | 4           | Tie-Button Head         |


# Cooling System Assembly



## Cooling System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|------------------------|
| 1           | AUL13142           | 4           | Isolator-Mount, Rubber    | 16          | 125-9088           | 2           | Fitting-Elbow, 90      |
| 2           | 127-1753-03        | 1           | Plate-Mount, Radiator     | 17          | AU21001153         | 6           | Clamp-Torque, Constant |
| 3           | 127-1750           | 1           | Cooling Package ASM       | 18          | 33106-040          | 2           | Screw-HHF              |
| 3:1         | 127-1730           | 1           | Coolant Recovery Tank ASM | 19          | 115-1115           | 6           | Nut-Lock, HHF          |
| 3:2         | 130-7415           | 1           | Fan-Cooling, 22"          | 20          | 353-379            | 1           | Fitting-Elbow, 45 DEG  |
| 4           | AU118007           | 1           | HYD Motor ASM             | 20:1        | 237-79             | 1           | O-Ring                 |
| 5           | 3296-67            | 1           | Nut-Lock, NI              | 21          | AU218-5137         | 2           | Fitting-Elbow-45 DEG   |
| 6           | 127-1760           | 1           | Elbow-Cooler, Air         | 21:1        | 237-80             | 1           | O-Ring                 |
| 7           | AU130820           | 1           | Elbow-Cooler, Air         | 22          | 2412-36            | 5           | Clamp-Hose             |
| 8           | 127-1758           | 1           | Tube ASM                  | 23          | 33106-060          | 4           | Screw-HHF              |
| 9           | AU21000205         | 1           | Adapter-Hump              | 24          | AU496-81018        | 4           | Washer-Flat            |
| 10          | AU120127           | 1           | Sensor-Level, Coolant     | 25          | 33106-025          | 2           | Screw-HHF              |
| 11          | 108-0342           | 3           | Fitting-Straight          | 26          | 3234-42            | 6           | Screw-HHF              |
| 12          | 127-1762           | 1           | Hose-Coolant              | 27          | 119-4042           | 4           | Nut-Flange, NI         |
| 13          | AU129089           | 1           | Transducer-Temperature    | 30          | 131-0430           | 1           | Hose-Coolant           |
| 14          | 127-1756-03        | 1           | Bracket-Cooling, LH       | 31          | 131-0432           | 1           | Hose-Coolant           |
| 15          | 127-1757-03        | 1           | Bracket-Cooling, RH       | 32          | 112-4576           | 2           | Nut-Clip, U            |


# Coolant Recovery Tank and Plumbing Assembly



## Coolant Recovery Tank and Plumbing Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|-----------------------|
| 1           | 127-1730           | 1           | Coolant Recovery Tank<br>ASM | 12          | 353-433            | 1           | Fitting-Straight      |
| 2           | 127-1751           | 1           | Hose-Radiator, Top           | 13          | 2412-92            | 3           | Clamp-Hose            |
| 3           | 127-1761           | 1           | Hose-Radiator, Bottom        | 14          | 2412-4             | 2           | Clamp                 |
| 4           | 127-1765           | 1           | Hose-Inlet                   | 15          | 3290-379           | 4           | Tie-Cable             |
| 6           | AU112950           | 2           | Protector-Hose, 4 Inch       | 17          | 353-426            | 1           | Fitting-90 DEG        |
| 7           | AU103754A1         | 1           | Fitting-HYD, Special         | 17:1        | 237-80             | 1           | O-Ring                |
| 7:1         | 237-146            | 1           | O-Ring                       | 18          | 2412-34            | 2           | Clamp-Hose            |
| 9           | 2412-41            | 2           | Clamp                        | 19          | 2412-147           | 1           | Clamp                 |
| 10          | AU131469           | 1           | Seal-Foam                    | 20          | AU217-375          | 1           | Fitting-Straight      |
| 11          | AU218-5110         | 1           | Elbow-90 DEG                 | 21          | 127-6221           | 1           | Fitting-Elbow, 90 DEG |
| 11:1        | 237-146            | 1           | O-Ring                       | 22          | 2412-42            | 1           | Clamp-Hose            |


# Tilt Frame Assembly



## Tilt Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                   |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------------------------|
| 1           | AU104865-01        | 1           | Mount-Cylinder, Frame    | 21          | AU426-16160        | 4           | Screw-HH                             |
| 2           | AU104861-01        | 1           | Mount-Axle, Rear         | 22          | 120-0888           | 4           | Nut-HH                               |
| 3           | AU126558           | 1           | HYD Cylinder ASM         | 23          | AU106861           | 1           | Pin                                  |
| 4           | AU105394-01        | 2           | Plate-Mounting           | 24          | AUH32292           | 1           | Pin-Hair                             |
| 5           | AUH434493          | 1           | Pin-Plow                 | 25          | AUK395023          | 1           | Washer-Thrust                        |
| 6           | AUH434556          | 1           | Pin-Clevis               | 26          | AUK965265          | 2           | Bushing-Pivot                        |
| 7           | 32151-77           | 4           | Ring-Retaining, External | 27          | AUK965267          | 4           | O-Ring                               |
| 8           | 353-537            | 2           | Fitting-Elbow, 90 DEG    | 28          | 127-1813           | 2           | Adapter-Locating                     |
| 8:1         | 237-79             | 1           | O-Ring                   | 29          | 302-5              | 2           | Fitting-Grease                       |
| 9           | AUH433408-03       | 1           | Housing-Mount, Trunion   | 30          | AU104200           | 1           | Meter-Slope                          |
| 10          | AUH426858          | 4           | Washer                   | 31          | 127-1867           | 1           | HYD Hose ASM                         |
| 11          | AU426-2048         | 4           | Bolt                     | 32          | 127-1868           | 1           | HYD Hose ASM                         |
| 12          | AU407398A1-03      | 1           | Housing-Mount, Trunion   | 33          | AU113664           | 1           | Switch-Rocker, 2 Pole<br>(On)Off(On) |
| 13          | AUH433359          | 1           | Shim-Mount, Axle         | 34          | 3290-378           | 6           | Tie-Cable                            |
| 14          | AU105590-01        | 1           | Lockout-Frame            | 35          | 302-40             | 1           | Fitting-Grease, 90 DEG               |
| 15          | AU105593-01        | 1           | Lockout-Axle             | 36          | 56-7976            | 2           | Clamp-Tube                           |
| 17          | AU496-11081        | 10          | Washer                   | 37          | 69-9760            | 1           | Coverplate                           |
| 18          | 328-2              | 10          | Screw-HH                 | 38          | 322-7              | 1           | Screw-HH                             |
| 19          | 32128-45           | 10          | Locknut-Flange           |             |                    |             |                                      |
| 20          | AU496-21106        | 8           | Washer                   |             |                    |             |                                      |

# Hydraulic Cylinder Assembly No. AU126558



## Hydraulic Cylinder Assembly No. AU126558 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 302-2              | 2           | Fitting-Grease     |
| 2           | 131-2749           | 1           | Seal Kit           |

# Attachments and Accessories

## For 25450W RT1200 Traction Unit

| Product Name                            | Model/Part |
|-----------------------------------------|------------|
| Backhoe.....                            | 25452E     |
| Center Trencher.....                    | 25453E     |
| Sliding Attachment Kit.....             | 25454E     |
| 48in Rock Boom .....                    | 25456E     |
| 60in Rock Boom .....                    | 25457E     |
| Counterweight Kit .....                 | 25458E     |
| Counterweight And Reel Kit.....         | 25459E     |
| Auxiliary Hydraulics Kit .....          | 25460E     |
| Track Kit.....                          | 25462E     |
| Plow Kit.....                           | 25463E     |
| Work Light Kit .....                    | 25464E     |
| 4ft Manual Crumber .....                | 25465E     |
| 5ft Manual Crumber .....                | 25466E     |
| Auxiliary Control Kit, 762 Backhoe..... | 25467E     |
| Block Heater Kit.....                   | 25468E     |
| Load Control Kit.....                   | 25510E     |
| Auto Tilt Chassis Kit.....              | 25511E     |
| Advanced Steering Control Kit.....      | 25512E     |

**Notes:**



**Count on it.**