Form No. 3387-144 Rev A

TORO®

Count on it.

Parts Catalog

Verticutter

Reelmaster® 5010-H Series Cutting Unit with 5in Reel

Model No. 03618—Serial No. 315000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3387-144 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping


TTH: torx truss head

Contents

Frame Assembly 4
Verticutter Mounting Assembly 5
Verticutter Assembly 6
Roller and Scraper Assembly 7
Optional Long Roller Assembly No. 114-5404 8
Full Front Roller Assembly No. 114-5419 9
Shield Assembly 10

© 2014—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved




Frame Assembly

Ref.	Part Number	Qty.	Description
1	131-0521	1	RH Side Plate ASM
1:1		1	RH Side Plate Sub ASM ●
1:1:2	127-7149	2	Insert-Threaded, Side Plate
1:2	302-39	1	Fitting-Plug
1:3	3245-35	1	Screw-Set, HSH
1:4	117-8177	1	O-Ring
2	131-0520	1	LH Side Plate ASM
2:1		1	LH Side Plate Sub ASM ●
2:1:2	127-7149	2	Insert-Threaded, Side Plate
2:2	302-39	1	Fitting-Plug
2:3	3245-35	1	Screw-Set, HSH
2:4	117-8177	1	O-Ring
3	104-3396	1	Screw-HH
4	99-8662	1	Tube-Spring
5	3218-5	3	Nut-Jam
6	87-7270	1	Washer-Thrust

Ref.	Part Number	Qty.	Description
7	104-8301	7	Nut-Flange, NI
8	3290-357	5	Nut-HHF, Whiz
9	108-4960	1	Spring-Compression
12	110-4069	1	Bracket
13	108-4959	1	Rod-Turf
14	92-2762	1	Pin-Hair
15	3231-25	4	Bolt-CARR
18	110-4058	1	Bracket-Chain
19	107-2951	1	Frame
20	107-2979	4	Bolt-Shoulder
21	3234-19	2	Screw-HHF
22	130-8094	2	Washer
23	108-4279	2	Spacer-Frame
25	106-3937	1	Carrier Frame ASM
25:2	93-2877	2	Bushing
26	302-5	1	Fitting-Grease

● Not serviced separately




Verticutter Mounting Assembly

Ref.	Part Number	Qty.	Description
1	3234-11	2	Screw-HHF
2	237-68	1	O-Ring
3	127-4284	2	Washer-Special
4	115-3299	2	Seal-Flocked
5	115-3296	2	Bearing-Sealed
6	115-5258	1	Spring-Wire, Flat
7		1	5 In Vericutter Shaft And Blade ASM ●
50	127-4283	1	5 Inch Weight Kit (Electric)

Ref.	Part Number	Qty.	Description
50:1	237-68	5	O-Ring
50:2	127-4266-01	5	Weight-5 Inch End
50:3	3234-11	10	Screw-HHF
50:4	127-7122	5	Bolt-Shoulder, Flange Hex Socket
51	130-4148	1	5 Inch Weight Kit (Hydraulic)
51:1	237-68	5	O-Ring
51:2	108-9090-01	5	Weight-End
51:3	323-12	10	Screw-HH


● Not serviced separately



Verticutter Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	131-0504	1	Shaft-Verticutter, 5 Inch
2	17-1590	25	Blade-11 Tooth ●
2	106-6355	25	Blade-11 Tooth (Carbide)
3	17-1600	1	Spacer (0.25 Inch)
3	82-6600	24	Spacer (0.73 Inch)
3	17-1580	1	Spacer (0.5 Inch)
4	17-1580	1	Spacer (0.5 Inch)
5	108-4994	1	Spacer
6	67-5840	1	Nut-Jam
7	131-0506	1	Insert-Verticutter, RH
8	131-0505	1	Insert-Verticutter, LH

● Optional Equipment




Roller and Scraper Assembly

Ref.	Part Number	Qty.	Description
1	114-5404	1	Roller ASM (Long)
2	107-3279	1	Bracket-Scraper, LH
3	107-3281	1	Bracket-Scraper, RH
4	119-0626	4	Shim-Roller
5	106-3924	2	Bracket-Roller, Rear
6	3230-7	4	Bolt-CARR
7	114-5419	1	Full Front Roller ASM
8	108-4475-03	1	Scraper-Roller, Full Front
9	32128-20	2	Nut-HF
10	322-16	2	Screw-HH
11	3231-4	2	Screw-CARR

Ref.	Part Number	Qty.	Description
12	125-2796	2	Bracket-Front HOC
13	104-8301	6	Nut-Flange, NI
14	48-9220	4	Washer
15	112-7451	2	Screw-TAP
16	3290-357	2	Nut-HHF, Whiz
17	104-8300	4	Nut-Flange, NI
18	107-2999	1	Scraper Rod ASM
25	115-0803	1	Roller Rebuild Tool Kit ●
25:1	115-0852	1	Tool-Inner Seal
25:2	107-8133	1	Washer-Flat
25:3	115-0853	1	Tool-Bearing/Outer Seals


● Optional Equipment



Optional Long Roller Assembly
No. 114-5404

Ref.	*Part Number*	*Qty.*	*Description*
1	115-8294-03	1	Tube-Roller (Long)
2	114-5407	1	Shaft-Long, Rear Roller
3	114-3717	2	Seal-Oil
4	112-5290	2	Bearing-Steel, Stainless
5	112-7494	4	Seal
6	114-5411	2	Nut-Lock, Bearing
7	302-5	2	Fitting-Grease
50	114-5430	1	Roller Rebuild Kit ●
50:1	114-3717	2	Seal-Oil
50:2	112-5290	2	Bearing-Steel, Stainless
50:3	112-7494	4	Seal
50:4	114-5411	2	Nut-Lock, Bearing


● Optional Equipment



Full Front Roller Assembly No. 114-5419

Ref.	*Part Number*	*Qty.*	*Description*
1	115-8295-03	1	Roller Tube ASM (Full)
2	114-5403	1	Shaft-Roller, Front
3	114-3717	2	Seal-Oil
4	112-5290	2	Bearing-Steel, Stainless
5	112-7494	4	Seal
6	114-5411	2	Nut-Lock, Bearing
7	302-5	2	Fitting-Grease
50	114-5430	1	Roller Rebuild Kit ●
50:1	114-3717	2	Seal-Oil
50:2	112-5290	2	Bearing-Steel, Stainless
50:3	112-7494	4	Seal
50:4	114-5411	2	Nut-Lock, Bearing

● Optional Equipment



Shield Assembly

Ref.	Part Number	Qty.	Description
1	107-7773	1	Screw-HSH
2	3234-7	4	Screw-HHF
3	107-2996	1	Front Grass Shield ASM
3:2	93-6688	1	Decal-Danger
4	125-2098	1	Shield-Grass, Rear (5 Inch)
5	125-2107	1	Tab-Shield, Stop
6	3256-74	1	Washer-Flat
7	322-14	1	Screw-HH
8	3231-33	2	Screw-CARR
9	3290-355	2	Pin-Hair
10	3296-59	2	Nut-Lock, NI
11	48-9220	4	Washer
12	59-2580	2	Spacer-Tubular
13	108-4293	2	Roller
14	104-8301	2	Nut-Flange, NI
15	108-4286	2	Bracket-Adjustment
16	108-4289	2	Pin-Mount, Roller
17	3254-21	2	Washer-Lock/Int
18	3256-5	4	Washer-Flat
19	3296-28	2	Nut-Lock, NI
20	32128-20	4	Nut-HF

Notes:



Count on it.