Form No. 3388-375 Rev A

TORO®

Count on it.

Parts Catalog

53cm Mulching/Rear Bagging/Side Discharging Lawn Mower

Model No. 29734—Serial No. 315000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3388-375 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head


Contents

Housing Assembly 4
Grass Bag Assembly 6
Engine Assembly 8
Front Wheel Assembly 10
Rear Wheel Assembly 12
Handle Assembly 14
Electrical Assembly 16
Attachments and Accessories 18

© 2014—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


Housing Assembly



Housing Assembly (continued)

Ref.	Part Number	Qty.	Description
1	130-6745	1	Housing ASM
1:2	112-8760	1	Decal-Danger
3	130-6656	1	Chute ASM
4	127-6831	3	Screw-HWH
5	130-2368	1	Rear Deflector ASM
5:2	117-4143	1	Decal-Warning
6	127-6807	1	Spring-Torsion
7	127-6808	1	Spring-Torsion
8	127-0698	1	Rod-Door
9	127-0724	1	Shield-Trailing
11	127-0723	1	Cover-Belt
12	127-0730	1	Bracket-Cable
16	127-0677	1	Bumper
17	130-2355	6	Stud
18	130-6658	7	Screw-Flange, Serrated
19	130-6659	2	Screw-Flange, Serrated
20	130-2378	2	Spacer-Flange
21	131-0820-03	1	Shield-Front
31	130-6740	1	Decal, Deck


Grass Bag Assembly



Grass Bag Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-0702-03	1	Frame-Bag
2	130-6744	1	Bag-Grass
3	127-6815	1	Rod
4	127-6806	1	Deflector-Chute
4:2	117-4143	1	Decal-Warning
5	3256-23	1	Washer-Flat
6	32151-72	1	Ring-Retaining

Engine Assembly




Engine Assembly (continued)

Ref.	Part Number	Qty.	Description
7		1	Engine-Briggs, 126M050121F1 ●■
9	95-1726	3	Screw-Taptite
10	106-3999	1	Spacer-Driver
11	106-3987	1	Driver-Blade
13	108-0954-03	1	Blade-21 Inch
14	108-3766-03	1	Support-Blade
15	125-2466	1	Bolt-Blade
16	110-9429	1	V-Belt
18	104-7577-03	1	Shield-Muffler
19	32144-1	3	Screw-Taptite
24	120-1935	1	Decal-Shroud

● Not serviced separately

■ Obtain parts from www.briggsandstratton.com


Front Wheel Assembly



Front Wheel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-0668-03	1	Axle-Front
2	127-6800	1	Stop-Axle
3	127-6831	1	Screw-HWH
4	127-0693	1	Arm-Spring
5	105-3042	1	Knob-Lever, HOC
6	40-1940	2	Washer
7	92-1057	2	Bolt-Shoulder
8	127-0683	2	7 Inch Wheel ASM
9	125-5069	2	Nut-Hex


Rear Wheel Assembly



Rear Wheel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-0708-03	1	Axle-Rear
2	127-0707	2	Retainer-Bearing
3	104-8699	2	Bearing-Ball
4	127-6831	4	Screw-HWH
5	127-6896	2	Bushing-Sleeve
6	131-0881	1	Transmission
7	114-7977-03	1	Bracket-Transmission
8	108-7476	3	Screw-Plastite
9	115-4668	2	Gear-Pinion
10	32151-61	2	Ring-Retaining
11	127-6840	2	Wheel Cover ASM
11:2	614426	1	Washer-Stepped
12	92-1057	2	Bolt-Shoulder
13	127-0692	2	8 Inch Wheel Gear ASM
14	127-0711	1	Arm-Spring
15	105-3042	1	Knob-Lever, HOC
16	125-5069	2	Nut-Hex
17	36-4780	2	Washer-Plain
18	65-2720	2	Ring-Clip, Locking


Handle Assembly



Handle Assembly (continued)

Ref.	Part Number	Qty.	Description
1	127-0657-05	1	Handle-Lower, LH
2	127-0658-05	1	Handle-Lower, RH
3	130-6654	4	Screw-CARR
4	130-6655	4	Nut-Flange, NI
5	127-0699	2	Bracket-Chute
6	130-6659	2	Screw-Flange, Serrated
7	92-2260	2	Screw-Handle
8	117-5976	2	Knob-Handle
9	127-0659-05	1	Handle-Upper
10	86-9671	1	Guide-Rope
11	127-0718-03	1	Bail-Brake
13	112-8818	1	Cable-Brake
15	3296-73	2	Nut-Lock, NI
16	3256-1	1	Washer-Flat
17	127-0719-03	1	Bail-Traction
18	127-0733	1	Cable-Traction
19	114-7988	1	Guide-Cable
21	120-5216	1	Grip-Handle, Comfort

Electrical Assembly



Electrical Assembly (continued)

Ref.	Part Number	Qty.	Description
1	321-57	1	Screw-HH
2	108-9760	1	Mount-Switch
3	46-5780	1	Starter Switch ASM
3:1	3254-5	1	Washer-Tooth, Internal
3:2	218-461	1	Nut-HH
4	700918	1	Key
5	127-6837	1	Harness-Wire
5:1	99-6124	1	Fuse-40 Amp
6	127-0694	1	Battery-Nonspillable, 12 V
7	127-0695	1	Battery Box ASM
8	127-6835-03	1	Bracket-Battery
9	127-6831	3	Screw-HWH
10	107-3774	1	Foam-Battery, Top
11	120-3947	1	Charger-Ce
12	104-7953	1	Decal
13	614249	2	Tie-Cable
14	130-6743	1	Decal-Battery Box
15	130-6686	1	Harness-Wire

Attachments and Accessories

For 29734 53cm Mulching/Rear Bagging/Side Discharging Lawn Mower

Product Name	Model/Part
Lawn Striping Kit with 22in Roller	20601

Notes:



Count on it.