Form No. 3388-785 Rev A



Count on it.

**Parts Catalog** 

# **14in Electric Dual-line Trimmer**

Model No. 51480A—Serial No. 315000001 and Up



## **Ordering Replacement Parts**

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

#### **Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

#### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

List of Abbreviations

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

#### **Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

AR: as required ASM: assembly BBC: blade brake control BHTF: button head thread forming **CARR:** carriage CCW: counter clockwise CW: clockwise **DEG:** degrees **DPA:** Dual Point Adjustment ECM: electronic control module **EXT:** external FH: flat head GA: gauge HD: heavy-duty HF: hex flange HH: hex head HHF: hex head flange HHFTF: hex head flange thread forming HJ: hex jam HLH: hex lag head

HOC: height-of-cut

HP: high pressure HSBH: hex socket button head HSFH: hex socket flat head HSH: hex socket head HWH: hex washer head HWHTF: hex washer head thread forming HYD: hydraulic LH: left hand LP: low pressure LPG: Liquefied Petroleum Gas NI: nylon insert NPTF: national pipe thread fine PFH: phillips flat head PPH: phillips pan head PPHTF: phillips pan head thread forming PRH: phillips round head PTH: phillips truss head PTO: power-take-off RH: right hand


**ROPS:** roll-over protection system

RRB: rear roller brush SFH: slotted fillister head SHH: slotted hex head SHWH: slotted hex washer head SPH: slotted pan head SQH: square head SRH: slotted round head STD: standard TAP: self tapping TTH: torx truss head

## Contents

14 Inch Electric Dual-line Trimmer Assembly	4
Attachments and Accessories	6

## 14 Inch Electric Dual-line Trimmer Assembly



## 14 Inch Electric Dual-line Trimmer Assembly (continued)

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	119-9750	1	Assist Handle ASM	4	125-8275	1	Cap-Retainer, Spool
2	119-9751	1	Shield ASM	5	88512	1	Trimmer Spool-Dual Line,
3	125-8274	1	Clip-Guide, Edger				1-Pack

\_\_\_\_

## **Attachments and Accessories**

### For 51480A 14in Electric Dual-line Trimmer

Product Name	Model/Part
Dual-line Trimmer Spool	
3-Pack of Dual-line Trimmer Spool	

### Notes:



## Count on it.