



Form No. 3389-442 Rev A

**Count on it.**

# Parts Catalog

## 100in Rear Discharge Deck Groundsmaster® 360 Series Traction Unit

Model No. 31101—Serial No. 315000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HP:** high pressure

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** low pressure

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard

**TAP:** self tapping

**TTH:** torx truss head

# Contents

Center Deck Assembly ..... 4

Double Driven Spindle Assembly No. 119-4548 ..... 6

Double Spindle Assembly No. 121-5255 ..... 7

Center Deck Chamber and Cover Assembly ..... 8

LH Wing Deck Assembly..... 10

RH Wing Deck Assembly ..... 12

Wing Deck Spindle Assembly No. 121-5257 ..... 14

Wheel Assembly No. 93-9938 ..... 15

Lift Arm and Linkage Assembly ..... 16


Gearbox and Hydraulics Assembly ..... 17

Gearbox Assembly No. 130-8659 ..... 18

Hydraulic Cylinder Assembly No. 125-9400 ..... 19


Hydraulic Cylinder Assembly No. 125-9401 ..... 20

# Center Deck Assembly



## Center Deck Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 127-4840           | 1           | Deck ASM                       | 18          | 72-9361            | 3           | Cup-Scalp, Anti     |
| 1:2         | 93-6696            | 2           | Decal-Warning                  | 19          | 23-1640            | 1           | Bushing-Taperlock   |
| 2           | 121-5481-01        | 1           | Plate-Spindle                  | 19:1        | 3247-4             | 2           | Screw-Set           |
| 3           | 127-4843           | 1           | RH Plate ASM                   | 20          | 93-4871            | 1           | Gearbox Pulley ASM  |
| 3:2         | 117-4979           | 1           | Decal-Warning, Shields         | 21          | 3257-5             | 1           | Key-Woodruff        |
| 4           | 127-4844           | 1           | LH Plate ASM                   | 22          | 108-1926           | 2           | Washer              |
| 4:2         | 117-4979           | 1           | Decal-Warning, Shields         | 23          | 100-3102           | 5           | Washer-Flat         |
| 5           | 3230-22            | 12          | Screw-CARR                     | 24          | 1-613098           | 4           | Pulley-Idler        |
| 6           | 104-8300           | 12          | Nut-Flange, NI                 | 25          | 108-1993           | 1           | Screw-HSBH          |
| 7           | 114-0997           | 2           | Idler Pivot ASM                | 26          | 3296-45            | 2           | Nut-Lock, NI        |
| 8           | 125-9433           | 1           | Idler Arm ASM                  | 27          | 92-2651            | 1           | Washer              |
| 8:2         | 93-4510            | 2           | Bushing-Caster                 | 28          | 121-5253           | 1           | Belt-V              |
| 9           | 117-9176           | 1           | Idler Arm ASM                  | 29          | 121-5254           | 1           | Belt-V              |
| 9:2         | 93-4510            | 2           | Bushing-Caster                 | 30          | 302-5              | 2           | Fitting-Grease      |
| 10          | 127-4911           | 1           | Spring-Extension               | 31          | 01-182-0816        | 1           | TAP Bolt-HH         |
| 11          | 108-1921           | 1           | Spring-Torsion                 | 32          | 3218-5             | 2           | Nut-Jam             |
| 12          | 121-5274           | 2           | Spacer-Idler                   | 33          | 42257              | 2           | Spacer-Tubular      |
| 13          | 119-4548           | 1           | Double Driven Spindle ASM      | 34          | SG271517           | 3           | Screw-HH            |
| 14          | 121-5255           | 2           | Double Spindle ASM             | 35          | 3253-7             | 5           | Washer-Lock         |
| 15          | 104-8301           | 30          | Nut-Flange, NI                 | 36          | 3231-22            | 6           | Screw-CARR          |
| 16          | 106-7166-03        | 3           | Blade-Combination (19<br>Inch) | 37          | 63-1540-03         | 2           | Pulley-Idler        |
| 17          | 92-5816            | 3           | Bolt-Blade                     | 38          | 117-3266           | 2           | Screw-HH            |
|             |                    |             |                                | 39          | 32120-84           | 2           | Ring-Snap, External |



## Double Driven Spindle Assembly No. 119-4548

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 104-3554    | 1    | Shaft-Spindle         |
| 2     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 3     | 119-4775    | 1    | Spindle Housing ASM   |
| 3:1   |             | 1    | Spindle ASM ●         |
| 3:1:2 | 114-8195    | 8    | Bolt-Ribbed Neck      |
| 3:2   | 120-5577    | 1    | Bearing Spacer Set    |
| 3:3   | 110-8297    | 1    | Bearing ASM           |
| 3:4   | 253-154     | 2    | Seal-Oil              |
| 3:5   | 302-60      | 1    | Fitting-Grease        |
| 4     | 106-7159    | 1    | O-Ring                |
| 5     | 104-3547    | 1    | Pulley-Driven, Double |
| 6     | 120-5576    | 1    | Washer-Hardened       |
| 7     | 3296-60     | 1    | Nut-Lock, NI          |

● Not serviced separately




## Double Spindle Assembly No. 121-5255

| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 119-4775    | 1    | Spindle Housing ASM   |
| 1:1   |             | 1    | Spindle ASM ●         |
| 1:1:2 | 114-8195    | 8    | Bolt-Ribbed Neck      |
| 1:2   | 120-5577    | 1    | Bearing Spacer Set    |
| 1:3   | 110-8297    | 1    | Bearing ASM           |
| 1:4   | 253-154     | 2    | Seal-Oil              |
| 1:5   | 302-60      | 1    | Fitting-Grease        |
| 2     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 3     | 104-3554    | 1    | Shaft-Spindle         |
| 4     | 121-5256    | 1    | Pulley-Driven, Double |
| 5     | 120-5576    | 1    | Washer-Hardened       |
| 6     | 3296-60     | 1    | Nut-Lock, NI          |
| 7     | 106-7159    | 1    | O-Ring                |

● Not serviced separately


# Center Deck Chamber and Cover Assembly



## Center Deck Chamber and Cover Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-----------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 121-5268-01        | 1           | LH Center Chamber ASM       | 18          | 3296-45            | 4           | Nut-Lock, NI       |
| 2           | 121-5267-01        | 1           | RH Outer Center Chamber ASM | 19          | 325-33             | 2           | Screw-HH           |
| 3           | 121-5266-01        | 1           | Center Chamber ASM          | 20          | 325-22             | 2           | Screw-HH           |
| 4           | 3230-22            | 19          | Screw-CARR                  | 21          | 302-60             | 2           | Fitting-Grease     |
| 5           | 104-8300           | 21          | Nut-Flange, NI              | 24          | 125-9436           | 1           | Decal-Regulatory   |
| 6           | 104-0108           | 4           | U-Bolt                      | 25          | 110-5070           | 2           | Bumper             |
| 7           | 32128-49           | 16          | Nut-HHF                     | 26          | 103-4080           | 2           | Latch-Rubber       |
| 8           | 68-6840            | 5           | Shaft-Roller                | 27          | 3274-39            | 6           | Screw-HSBH         |
| 9           | 68-6710            | 5           | Roller                      | 28          | 127-4957           | 2           | Cover ASM          |
| 10          | 3234-42            | 5           | Screw-HHF                   | 28:2        | 119-6807           | 1           | Decal-Warning      |
| 11          | 104-8301           | 5           | Nut-Flange, NI              | 29          | 127-4959           | 1           | LH Cover ASM       |
| 12          | 121-5473-01        | 1           | Shield-RH                   | 29:2        | 119-6807           | 1           | Decal-Warning      |
| 13          | 121-5474-01        | 1           | Shield-LH                   | 30          | 75-5780            | 2           | Hinge-Steel        |
| 14          | 112-1625           | 2           | Pull Link ASM               | 31          | 240-9              | 6           | Grommet            |
| 14:2        | 107-2328           | 1           | Bushing                     | 32          | 103-4081           | 2           | Latch-Keeper       |
| 14:3        | 114-5680           | 2           | Bushing-Flange              | 33          | 302-5              | 2           | Fitting-Grease     |
| 15          | 120-5570           | 2           | Pin-Retainer                | 34          | 3274-31            | 12          | Screw-HSBH         |
| 16          | 110-9828           | 2           | Spring-Torsion              | 35          | 104-7201           | 12          | Nut-HF             |
| 17          | 110-9845           | 2           | Spacer-Plain                | 36          | 127-4958           | 1           | RH Cover ASM       |
|             |                    |             |                             | 36:2        | 119-6807           | 1           | Decal-Warning      |


# LH Wing Deck Assembly



## LH Wing Deck Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 127-4842           | 1           | LH Deck ASM              | 21          | 32120-84           | 1           | Ring-Snap, External |
| 1:2         | 125-9403           | 1           | Decal-HOC                | 22          | 302-5              | 2           | Fitting-Grease      |
| 1:3         | 120-6604           | 1           | Decal-Danger             | 23          | 116506             | 1           | Spring-Extension    |
| 1:4         | 93-7818            | 1           | Decal-Torque, Blade Bolt | 24          | 127-4901-03        | 1           | Bracket-Stop, Idler |
| 1:5         | 117-4979           | 1           | Decal-Warning, Shields   | 25          | 100-3102           | 2           | Washer-Flat         |
| 2           | 121-5265-01        | 1           | LH Chamber ASM           | 26          | 63-1540-03         | 1           | Pulley-Idler        |
| 3           | 3230-22            | 5           | Screw-CARR               | 27          | 1-613098           | 1           | Pulley-Idler        |
| 4           | 3230-5             | 1           | Screw-CARR               | 28          | 108-1993           | 1           | Screw-HSBH          |
| 5           | 112-1479           | 2           | Skid-Bumper, Deck        | 29          | 108-1924           | 1           | Spacer-Idler        |
| 6           | 3231-33            | 4           | Screw-CARR               | 30          | 3296-45            | 1           | Nut-Lock, NI        |
| 7           | 104-8301           | 11          | Nut-Flange, NI           | 31          | 117-3266           | 1           | Screw-HH            |
| 8           | 121-5472           | 1           | Cover-LH                 | 32          | 3253-7             | 2           | Washer-Lock         |
| 9           | 103-4080           | 4           | Latch-Rubber             | 33          | 125-9424-01        | 1           | Latch Support ASM   |
| 10          | 3274-39            | 8           | Screw-HSBH               | 34          | 127-4830           | 1           | Latch ASM           |
| 11          | 121-5465-03        | 2           | Support-Step             | 35          | 65-8770            | 2           | Bushing-Bellcrank   |
| 12          | 104-8300           | 6           | Nut-Flange, NI           | 36          | 32120-19           | 1           | E-Ring              |
| 13          | 127-4820-01        | 2           | Plate-Step               | 37          | 3234-47            | 4           | Screw-HHF           |
| 14          | 3229-1             | 4           | Bolt-CARR                | 38          | 107938             | 1           | Spring-Extension    |
| 15          | 104-7201           | 4           | Nut-HF                   | 39          | 125-9415-01        | 1           | Castor Arm ASM      |
| 16          | 127-4902-03        | 1           | Plate-Stiffener, LH      | 39:1:1:2    | 69-6470            | 2           | Bushing-Castor      |
| 17          | 114-0997           | 1           | Idler Pivot ASM          | 40          | 86-6560            | 1           | Washer-Thrust       |
| 18          | 3231-22            | 7           | Screw-CARR               | 41          | 3256-29            | 1           | Washer-Flat         |
| 19          | 121-5275           | 1           | Idler Arm ASM            | 42          | 3296-60            | 1           | Nut-Lock, NI        |
| 19:2        | 93-4510            | 2           | Bushing-Caster           | 43          | 121-5471           | 1           | Cover-RH            |
| 20          | 108-1926           | 1           | Washer                   |             |                    |             |                     |

# RH Wing Deck Assembly



## RH Wing Deck Assembly (continued)


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 104-8300           | 6           | Nut-Flange, NI           | 21:3        | 93-7818            | 1           | Decal-Torque, Blade Bolt |
| 2           | 121-5257           | 2           | Upper Spindle ASM        | 21:4        | 120-6604           | 1           | Decal-Danger             |
| 3           | 127-4903-03        | 1           | Plate-Stiffener, RH      | 21:5        | 117-4979           | 1           | Decal-Warning, Shields   |
| 4           | 104-8301           | 23          | Nut-Flange, NI           | 22          | 121-5264-01        | 1           | RH Chamber ASM           |
| 5           | 125-9444-03        | 2           | Blade-Combination, 25.18 | 23          | 3230-22            | 3           | Screw-CARR               |
| 6           | 72-9361            | 2           | Cup-Scalp, Anti          | 24          | 3230-5             | 1           | Screw-CARR               |
| 7           | 92-5816            | 2           | Bolt-Blade               | 25          | 121-5252           | 2           | Belt-V                   |
| 8           | 121-5263-01        | 3           | Castor Arm ASM           | 26          | 114-0997           | 1           | Idler Pivot ASM          |
| 8:1:1:2     | 69-6470            | 2           | Bushing-Castor           | 27          | 3231-22            | 7           | Screw-CARR               |
| 9           | 104-0762-01        | 4           | Fork-Castor              | 28          | 121-5275           | 1           | Idler Arm ASM            |
| 10          | 92-8862            | 4           | HOC Cap ASM              | 28:2        | 93-4510            | 2           | Bushing-Caster           |
| 10:1        | 92-5581            | 1           | Ring-Retaining           | 29          | 108-1926           | 1           | Washer                   |
| 10:2        | 92-5583            | 1           | Washer-Cap               | 30          | 32120-84           | 1           | Ring-Snap, External      |
| 10:3        | 92-5584            | 1           | Spring-Compression       | 31          | 127-4911           | 2           | Spring-Extension         |
| 10:4        | 92-8861            | 1           | Cap-HOC                  | 32          | 85-9910            | 2           | Eyebolt                  |
| 11          | 302-5              | 5           | Fitting-Grease           | 33          | 3217-6             | 2           | Nut-Hex                  |
| 12          | 93-9938            | 4           | Wheel ASM                | 34          | 63-1540-03         | 1           | Pulley-Idler             |
| 13          | 327-24             | 4           | Screw-HH                 | 35          | 1-613098           | 1           | Pulley-Idler             |
| 14          | 3296-53            | 4           | Nut-Lock, NI             | 36          | 108-1993           | 1           | Screw-HSBH               |
| 15          | 69-1510            | 16          | Spacer                   | 37          | 121-5274           | 1           | Spacer-Idler             |
| 16          | 121-5485           | 8           | Spacer                   | 38          | 3296-45            | 1           | Nut-Lock, NI             |
| 17          | 69-6860            | 8           | Washer-Thrust            | 39          | 117-3266           | 1           | Screw-HH                 |
| 18          | 325-13             | 6           | Screw-HH                 | 40          | 3253-7             | 2           | Washer-Lock              |
| 19          | 99-5107            | 6           | Nut-Lock                 | 41          | 100-3102           | 2           | Washer-Flat              |
| 20          | 3256-26            | 6           | Washer-Flat              | 42          | 121-3874           | 1           | Wrench ASM               |
| 21          | 127-4841           | 1           | RH Deck ASM              | 42:2        | 119-1846           | 1           | Grip                     |
| 21:2        | 125-9403           | 1           | Decal-HOC                |             |                    |             |                          |



## Wing Deck Spindle Assembly No. 121-5257


| Ref.  | Part Number | Qty. | Description           |
|-------|-------------|------|-----------------------|
| 1     | 119-4775    | 1    | Spindle Housing ASM   |
| 1:1   |             | 1    | Spindle ASM ●         |
| 1:1:2 | 114-8195    | 8    | Bolt-Ribbed Neck      |
| 1:2   | 120-5577    | 1    | Bearing Spacer Set    |
| 1:3   | 110-8297    | 1    | Bearing ASM           |
| 1:4   | 253-154     | 2    | Seal-Oil              |
| 1:5   | 302-60      | 1    | Fitting-Grease        |
| 2     | 69-6950     | 1    | Spacer-Shaft, Spindle |
| 3     | 104-3554    | 1    | Shaft-Spindle         |
| 4     | 121-5258    | 1    | Pulley-Driven, Upper  |
| 5     | 120-5576    | 1    | Washer-Hardened       |
| 6     | 3296-60     | 1    | Nut-Lock, NI          |
| 7     | 106-7159    | 1    | O-Ring                |

● Not serviced separately




## Wheel Assembly No. 93-9938

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 93-9939     | 1    | Tire                  |
| 2    | 68-8950     | 1    | Tube-Inner (W/Valve)  |
| 3    | 93-4241     | 1    | Spacer-Bearing, Inner |
| 4    | 120-3366    | 2    | Bearing               |
| 6    | 32128-16    | 4    | Nut-HHF               |
| 7    | 93-4242     | 1    | Plate                 |
| 8    | 93-4239     | 1    | Rim-Wheel, Half       |
| 9    | 93-5980     | 1    | Hub                   |
| 10   | 95-2741     | 1    | Rim-Wheel, Half       |



## Lift Arm and Linkage Assembly


| Ref. | Part Number | Qty. | Description               | Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|---------------------------|------|-------------|------|-----------------------------|
| 1    | 125-9407    | 2    | Lift Arm ASM              | 12   | 130-9169    | 2    | Sensor-Switch               |
| 1:2  | 127-4912    | 4    | Bushing                   | 13   | 325-8       | 2    | Screw-HH                    |
| 1:3  | 110-6198    | 4    | Washer-Flat               | 14   | 99-5107     | 2    | Nut-Lock                    |
| 1:4  | 105-7441    | 2    | Bearing-Spherical         | 15   | 3256-26     | 2    | Washer-Flat                 |
| 1:5  | 32151-34    | 2    | Ring-Retaining            | 16   | 115-5300    | 2    | Proximity Switch ASM        |
| 1:6  | 105-7443    | 4    | Spacer-Pilot              | 16:1 | 117-3207    | 2    | Nut-Hex                     |
| 1:7  | 302-52      | 2    | Fitting-Grease            | 16:2 | 117-3208    | 2    | Washer-Lock, Internal Tooth |
| 1:8  | 127-4825    | 4    | Bushing-Str (.500 Nom Id) | 17   | 121-5279    | 2    | Shield-Flex                 |
| 2    | 104-0108    | 4    | U-Bolt                    | 18   | 117-2382    | 8    | Plug-Plastic                |
| 3    | 32128-49    | 16   | Nut-HHF                   | 19   | 325-6       | 2    | Screw-HH                    |
| 4    | 323-4       | 4    | Screw-HH                  | 20   | 3217-9      | 2    | Nut-HH                      |
| 5    | 121-5486    | 4    | Pivot Pin ASM             | 21   | 127-4971    | 8    | Seal-Foam                   |
| 6    | 302-5       | 6    | Fitting-Grease            | 22   | 104-5895    | 4    | Screw-HH                    |
| 7    | 92-7845     | 8    | Spacer-Hardened           | 23   | 3296-61     | 4    | Nut-Lock                    |
| 8    | 9547        | 8    | Washer-Thrust             | 24   | 127-4818    | 4    | Chain-6 Link                |
| 9    | 3230-22     | 4    | Screw-CARR                | 25   | 605256      | 8    | Washer-Plain                |
| 10   | 104-8300    | 4    | Nut-Flange, NI            | 26   | 702093      | 4    | Screw-HH                    |
| 11   | 53-6380     | 4    | Washer-Flat               | 27   | 32153-5     | 4    | Nut-Hex                     |



## Gearbox and Hydraulics Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 115-1388-03 | 1    | Mount-Gearbox, LH   |
| 2    | 121-5259-03 | 1    | Bracket-Gearbox, RH |
| 3    | 93-6697     | 1    | Decal-Lube          |
| 4    | 3231-26     | 3    | Screw-CARR          |
| 5    | 63-9750     | 3    | Mount               |
| 6    | 63-8410     | 3    | Washer              |
| 7    | 104-8301    | 3    | Nut-Flange, NI      |
| 8    | 3253-21     | 4    | Washer-Lock         |
| 9    | 130-8659    | 1    | Gearbox ASM         |
| 10   | 98-4590     | 1    | Hose-HYD            |
| 11   | 106-9674    | 1    | Hose ASM            |
| 12   | 340-125     | 2    | Fitting-Tee         |
| 12:1 | 237-21      | 2    | O-Ring              |
| 12:2 | 237-78      | 1    | O-Ring              |
| 13   | 340-132     | 2    | Fitting-HYD, 90 DEG |
| 13:1 | 237-78      | 1    | O-Ring              |
| 13:2 | 237-21      | 1    | O-Ring              |
| 14   | 2412-126    | 2    | R-Clamp             |
| 15   | 104-8300    | 4    | Nut-Flange, NI      |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 16   | 3230-5      | 2    | Screw-CARR         |
| 17   | 3290-378    | 1    | Tie-Cable          |
| 18   | 119-8104    | 2    | Pin ASM            |
| 19   | 3230-22     | 2    | Screw-CARR         |
| 20   | 121-5488-03 | 2    | Latch-Wing         |
| 21   | 3256-6      | 2    | Washer-Flat        |
| 22   | 3290-483    | 2    | Washer-Conical     |
| 23   | 3296-25     | 2    | Nut-Lock, NI       |
| 24   | 325-7       | 2    | Screw-HH           |
| 25   | 32121-24    | 2    | Pin-Spring         |
| 26   | 323-4       | 4    | Screw-HH           |
| 27   | 125-9400    | 1    | Cylinder-Hydraulic |
| 28   | 99-5105     | 2    | Bolt-Shoulder      |
| 29   | 127-4822    | 2    | Pin ASM            |
| 30   | 125-9401    | 1    | Cylinder-Hydraulic |
| 31   | 48-7081     | 2    | Grip-Plastic       |
| 32   | 122-0176    | 1    | Harness-Wire       |
| 33   | 130-8661    | 1    | Plug-Breather      |



## Gearbox Assembly No. 130-8659

| Ref. | Part Number | Qty. | Description   |
|------|-------------|------|---------------|
| 1    |             | 1    | Gearbox ASM ● |
| 1:1  | 107-2932    | 1    | Cap-Oil       |
| 1:2  | 107-2933    | 2    | Plug          |
| 1:3  | 117-9247    | 2    | Seal          |
| 1:4  | 107-2935    | 1    | Cap-Oil       |
| 2    | 130-8661    | 1    | Plug-Breather |
| 3    | 130-4899    | 1    | Washer        |


● Not serviced separately



## Hydraulic Cylinder Assembly No. 125-9400

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 1    | 127-4953    | 1    | Seal Kit    |
| 1:1  |             | 1    | O-Ring ●    |
| 1:2  |             | 1    | Backup ●    |
| 1:3  |             | 1    | Bp Seal ●   |
| 1:4  |             | 1    | Wear Ring ● |
| 1:5  |             | 1    | Bt Seal ●   |
| 1:6  |             | 1    | Dust Seal ● |
| 1:7  |             | 1    | O-Ring ●    |

● Not serviced separately



## Hydraulic Cylinder Assembly No. 125-9401

| Ref. | Part Number | Qty. | Description |
|------|-------------|------|-------------|
| 1    | 127-4953    | 1    | Seal Kit    |
| 1:1  |             | 1    | O-Ring ●    |
| 1:2  |             | 1    | Backup ●    |
| 1:3  |             | 1    | Bp Seal ●   |
| 1:4  |             | 1    | Wear Ring ● |
| 1:5  |             | 1    | Bt Seal ●   |
| 1:6  |             | 1    | Dust Seal ● |
| 1:7  |             | 1    | O-Ring ●    |

● Not serviced separately

**Notes:**

**Notes:**

**Notes:**



**Count on it.**