Form No. 3389-669 Rev A

TORO®

Count on it.

Parts Catalog

# Greensmaster® eFlex® 1800 Traction Unit

**Model No. 04043—Serial No. 315000001 and Up**

Register at www.Toro.com.
Original Instructions (EN)

CE

*3389-669* A

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HP:** high pressure

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** low pressure

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard

**TAP:** self tapping

**TTH:** torx truss head


# Contents

Frame and Handle Mount Assembly . . . . . 4
Grass Basket Assembly . . . . . 5
Basket Assembly No. 130-6750 . . . . . 6
Left Side Transmission Assembly . . . . . 7
Right Side Transmission Assembly . . . . . 8
Motor Adapter Assembly . . . . . 9
Differential and Traction Drum Assembly . . . . . 10
Differential Assembly No. 115-6711 . . . . . 11
Drum Drive Assembly . . . . . 12
Motor Installation Assembly . . . . . 13
Electric Motor Assembly No. 120-4501 . . . . . 14
Electric Motor Assembly . . . . . 15
Shift Lever Assembly . . . . . 16
Handle Assembly . . . . . 17
Throttle and Console Assembly . . . . . 18
Battery Base and Controller Assembly . . . . . 19
Wire Harness Assembly . . . . . 20
Miscellaneous Parts Assembly . . . . . 21
Charger Assembly No. 121-4674 . . . . . 22
Attachments and Accessories . . . . . 23

**© 2014—The Toro® Company**
**8111 Lyndale Avenue South**
**Bloomington, MN 55420**




**Contact us at www.Toro.com.**
**Printed in the USA.**
**All Rights Reserved**




# Frame and Handle Mount Assembly


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 120-9241 | 2 | Retainer-Handle |
| 2 | 120-9717 | 2 | Pin-Hair |
| 3 | 115-7295 | 5 | Bushing-Straight |
| 4 | 119-4042 | 8 | Nut-Flange, NI |
| 5 | 120-9723-01 | 1 | Frame |
| 6 | 115-7179-01 | 1 | Frame-Rear |
| 7 | 120-9720-01 | 1 | Frame-Roll |
| 8 | 115-7160 | 1 | Plate-Side, LH |
| 9 | 115-7293 | 8 | Washer-Hardened |
| 10 | 115-7024 | 6 | Screw-HHF |
| 11 | 117-1396 | 4 | Link |
| 12 | 125-5239 | 8 | Bushing-Flange |
| 13 | 121-4623-03 | 1 | Kickstand |
| 14 | 115-7258 | 1 | Spring-Torsion, RH |
| 15 | 120-9715 | 2 | Screw-CARR |
| 16 | 120-9696 | 1 | Screw-HH |
| 17 | 120-9739 | 1 | Pin-Lock |
| 18 | 107-8885 | 1 | Spring-Compression |
| 19 | 119-4041 | 1 | Nut-Flange, NI |
| 20 | 120-9697 | 1 | Spacer |
| 21 | | 1 | Grass Basket ASM ● |
| 22 | 115-7108 | 2 | Screw-HHF |
| 23 | 115-7234-03 | 1 | Weight-Counter |
| 24 | 131-6150 | 3 | Screw-HWHTF |
| 25 | 125-3522 | 2 | Clamp-Handle |
| 26 | 125-3524 | 2 | Clamp-Handle, Offset |
| 27 | 120-9698 | 4 | Screw-CARR |
| 28 | 120-9699 | 2 | Screw-CARR |
| 29 | 119-4040 | 6 | Nut-Flange, NI |
| 30 | 125-3525 | 4 | Bumper-Handle |
| 31 | 127-1510 | 2 | Screw-Shoulder |
| 32 | 701197 | 1 | E-Ring |
| 37 | 120-9740 | 1 | Spacer |

● Not serviced separately





# Grass Basket Assembly

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 130-6750 | 1 | Basket ASM |
| 2 | 125-3546-03 | 1 | Bracket-Basket |
| 3 | 119-4040 | 6 | Nut-Flange, NI |
| 4 | 119-4012 | 6 | Screw-HWHTF |
| 5 | 120-9646 | 2 | Washer-Flat |




# Basket Assembly No. 130-6750


| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 2 | 121-4730 | 2 | Bumper-Basket |
| 3 | 3274-69 | 2 | Screw-HSBH |
| 4 | 120-9679 | 2 | Washer-Flat |
| 5 | 130-6752 | 1 | Channel |
| 6 | 3290-382 | 5 | Rivet-Pop |




# Left Side Transmission Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 115-7150 | 1 | Housing-Transmission |
| 2 | 120-9749 | 1 | Housing-Extension |
| 3 | 251-82 | 2 | Bearing-Ball |
| 4 | 115-7189 | 1 | Pulley-Driven |
| 5 | 119-1138 | 4 | Screw-HWH |
| 6 | 95-0715 | 2 | Pin-Dowel |
| 7 | 32151-47 | 1 | Ring-Retaining |
| 8 | 125-5239 | 2 | Bushing-Flange |
| 9 | 108-2973 | 2 | Bushing-Flange |
| 10 | 115-7126 | 1 | Lever-Clutch, Reel |
| 11 | 115-7131 | 1 | Ring-Brake, Reel |
| 12 | 115-6869 | 1 | Bearing-Ball, Stainless |
| 13 | 115-7243 | 1 | Ring-Retaining, EXT |
| 14 | 115-7130 | 1 | Disc-Brake, Reel |
| 15 | 115-7123 | 2 | Pin-Pivot, Clutch |
| 16 | 115-7124 | 1 | Fork-Clutch, Reel |
| 17 | 115-7125 | 1 | Hub-Clutch, Reel |


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 18 | 115-7127 | 1 | Hub-Drive, Reel |
| 19 | 115-7138 | 1 | Shaft-Clutch |
| 20 | 115-7222 | 1 | Spacer |
| 21 | 115-6870 | 2 | Bearing-Ball, Sealed |
| 22 | 115-7139 | 1 | Pulley-Clutch, Reel |
| 23 | 115-6811 | 1 | Collar-Bearing |
| 24 | 115-6923 | 1 | Shield-Bearing, Flocked |
| 25 | 115-7143 | 1 | Spring-Wave |
| 26 | 115-7144 | 1 | Washer-Flat |
| 27 | 115-6755 | 1 | Ring-Retaining |
| 28 | 3257-30 | 1 | Key-Woodruff |
| 29 | 3290-485 | 1 | Washer-Wave |
| 30 | 38-7820 | 1 | Bearing-Ball |
| 31 | 115-7251 | 1 | Spacer |
| 32 | 115-7288 | 1 | Plug |
| 33 | 32120-47 | 1 | Ring-Retaining, External |
| 34 | 120-9571 | 1 | Decal-Release, Traction |




# Right Side Transmission Assembly


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 120-9597 | 1 | Transmission Cover ASM |
| 1:2 | 120-9570 | 1 | Decal-Warning |
| 2 | 115-7140 | 1 | Gasket-Housing, Main |
| 3 | 115-6743 | 1 | Belt-Drive, Main |
| 4 | 115-5142 | 2 | Screw-HHF |
| 5 | 115-7292 | 2 | Washer-Hardened |
| 6 | 115-7285 | 1 | Pulley-Driven |
| 7 | 115-7209 | 1 | Washer-Wave |
| 8 | 120-9686 | 2 | Screw-HH |
| 9 | 115-7129 | 2 | Bushing-Pulley, Idler |
| 10 | 38-7820 | 6 | Bearing-Ball |
| 11 | 115-6873 | 2 | Pulley-Idler |
| 12 | 115-7133 | 1 | Pulley-Idler |
| 13 | 127-1509 | 1 | Screw-Shoulder |
| 14 | 32151-12 | 1 | Ring-Retaining |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 15 | 125-5239 | 4 | Bushing-Flange |
| 16 | 115-6847 | 1 | Idler-Drive, Main |
| 17 | 115-6842 | 1 | Spring-Extension |
| 18 | 115-7128 | 1 | Lever-Spring |
| 19 | 119-4041 | 1 | Nut-Flange, NI |
| 20 | 1239 | 1 | Setscrew |
| 21 | 120-9695 | 1 | Nut-Jam |
| 22 | 119-1138 | 8 | Screw-HWH |
| 23 | 119-4033 | 2 | Pin-Spring |
| 24 | 130-9410 | 1 | Coupling-Flex, 2 Beam |
| 25 | 125-3541 | 1 | Shaft-Hex |
| 26 | 125-3542 | 1 | Pin-Spring |
| 27 | 110-2390 | 1 | Tube-Hex |
| 28 | 119-4040 | 1 | Nut-Flange, NI |
| 30 | 120-9738 | 1 | Screw-HH |




# Motor Adapter Assembly


| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 115-7166 | 1 | Adapter-Motor |
| 2 | 119-1138 | 4 | Screw-HWH |
| 3 | 115-7209 | 1 | Washer-Wave |
| 4 | 251-310 | 1 | Bearing-Ball |
| 5 | 105-5775 | 1 | Ring-Retaining |
| 6 | 94-4507 | 1 | Coupler-Splined |
| 7 | 115-7164 | 1 | Spline-Drive |
| 8 | 115-7163 | 1 | Pulley-Driver |
| 9 | 115-6869 | 1 | Bearing-Ball, Stainless |
| 10 | 115-6923 | 1 | Shield-Bearing, Flocked |
| 11 | 115-7143 | 1 | Spring-Wave |
| 12 | 115-7144 | 1 | Washer-Flat |
| 13 | 115-6755 | 1 | Ring-Retaining |
| 14 | 99-0195 | 1 | Screw-Set, HSH |




# Differential and Traction Drum Assembly


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 115-7154 | 1 | Housing-Drive, Drum |
| 2 | 115-7295 | 1 | Bushing-Straight |
| 3 | 125-5239 | 4 | Bushing-Flange |
| 4 | 115-7119 | 1 | Lever-Brake |
| 5 | 115-7118 | 1 | Lever-Traction |
| 6 | 115-6769 | 2 | Key-Square |
| 7 | 115-7182 | 1 | Drum Shaft ASM |
| 8 | 115-7181 | 1 | Shaft-Drive, Drum |
| 9 | 115-6711 | 1 | Differential ASM |
| 10 | 115-7173 | 1 | Drum-Traction, RH |
| 11 | 115-7025 | 1 | Nut-Jam |
| 12 | 253-134 | 1 | Seal-Grease |
| 13 | 115-7174 | 1 | Drum-Traction, LH |
| 14 | 115-6860 | 2 | Bearing-Ball, Stainless |
| 15 | 115-6784 | 1 | Nut-Bearing |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 16 | 115-6785 | 1 | Shaft-Hex, LH |
| 17 | 115-7019 | 2 | Bushing-Straight |
| 18 | 95-0715 | 2 | Pin-Dowel |
| 19 | 120-9688 | 1 | Screw-HH |
| 20 | 120-9691 | 1 | Washer-Flat |
| 21 | 115-7121 | 1 | Lever-Traction, Engage |
| 22 | 32120-47 | 2 | Ring-Retaining, External |
| 23 | 115-7120 | 1 | Lever-Brake, Cable |
| 24 | 32151-47 | 1 | Ring-Retaining |
| 26 | 131-6150 | 1 | Screw-HWHTF |
| 27 | 115-7023 | 1 | Collar-Lock |
| 28 | 125-3529 | 1 | Pin-Shear |
| 29 | 115-7210 | 1 | Washer-Thrust |
| 30 | 340-64 | 1 | O-Ring |




# Differential Assembly No. 115-6711


| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 115-7017 | 1 | Housing-Differential |
| 2 | 115-6865 | 1 | Cover-Differential |
| 4 | 115-6866 | 6 | Pin-Differential |
| 5 | 115-6715 | 6 | Gear-Spur, Dual |
| 6 | 115-6862 | 9 | Spacer-Differential, Natural |
| 7 | 115-6716 | 3 | Gear-Spur |
| 8 | 3274-101 | 6 | Screw-HSH |
| 9 | 251-310 | 2 | Bearing-Ball |




# Drum Drive Assembly


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 115-7156 | 1 | Cover-Drive, Drum |
| 2 | 119-1138 | 11 | Screw-HWH |
| 3 | 115-7141 | 1 | Gasket-Housing, Drum |
| 4 | 115-6786 | 1 | Shaft-Hex, RH |
| 6 | 115-6717 | 1 | Gear-Spur |
| 7 | 115-6846 | 1 | Brake-Band |
| 8 | 32120-46 | 1 | Ring-Retaining |
| 9 | 115-7211 | 1 | Bushing-Flanged |
| 10 | 115-6841 | 1 | Spring-Extension |
| 11 | 115-6744 | 1 | Belt-Drive, Drum |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 12 | 115-7116 | 1 | Pin-Mount, Brake |
| 13 | 120-9687 | 1 | Pin-Clevis, Brake |
| 14 | 32151-12 | 1 | Ring-Retaining |
| 15 | 38-7820 | 2 | Bearing-Ball |
| 16 | 115-7133 | 1 | Pulley-Idler |
| 17 | 127-1509 | 1 | Screw-Shoulder |
| 18 | 125-5239 | 2 | Bushing-Flange |
| 19 | 115-7235 | 1 | Drum Idler ASM |
| 20 | 115-6860 | 1 | Bearing-Ball, Stainless |
| 21 | 115-7294 | 1 | Washer-Wave |




# Motor Installation Assembly


| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 120-4501 | 1 | Electric Motor ASM |
| 2 | 110-5052 | 2 | Screw-HHF |
| 3 | 115-7081 | 1 | Clamp-Switch |
| 4 | 119-1138 | 2 | Screw-HWH |
| 5 | 119-4040 | 2 | Nut-Flange, NI |
| 6 | 115-3298 | 1 | O-Ring |
| 7 | 115-5300 | 1 | Proximity Switch ASM |
| 7:1 | 117-3207 | 2 | Nut-Hex |
| 7:2 | 117-3208 | 2 | Washer-Lock, Internal Tooth |




# Electric Motor Assembly No. 120-4501

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | | 1 | Motor-Electric ● |
| 2 | 119-7480 | 1 | Ferrule |
| 3 | 119-7477 | 1 | Nut-Fitting, Ferrule -8 |
| 4 | 119-7497 | 1 | Backshell-90 Degree |
| 5 | 32160-245 | 1 | Connector |
| 6 | 32160-315 | 1 | Connector |
| 7 | 32180-083 | 1 | Wedge |
| 8 | 32180-084 | 1 | Wedge |
| 9 | 3290-378 | 4 | Tie-Cable |
| 10 | 120-4538 | 1 | Tubing-Convoluted, Slit |


● Not serviced separately




# Electric Motor Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 120-4559 | 12 | Screw-Bhcs |
| 2 | 115-4779 | 1 | Cover-Motor |
| 3 | 112-9609 | 1 | O-Ring |
| 4 | 112-5163 | 2 | Washer-Wave |
| 6 | 119-7450 | 1 | Rotor ASM |
| 6:2 | 112-5158 | 1 | Bearing-Ball |
| 6:3 | 120-4557 | 1 | Bearing |
| 8 | 112-9616 | 2 | O-Ring |
| 14 | 112-9611 | 1 | O-Ring |


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 15 | 127-1599 | 1 | Output Gear ASM |
| 15:1:1 | 112-5153 | 1 | Gear-Output |
| 15:1:2 | 120-4557 | 1 | Bearing |
| 15:1:3 | 112-5158 | 1 | Bearing-Ball |
| 15:2 | 127-1501 | 1 | Grease-Synthetic |
| 16 | 115-4777 | 1 | Cover-Gearbox |
| 17 | 119-1156 | 1 | O-Ring |
| 19 | 119-7451 | 1 | Seal-Oil |




# Shift Lever Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 104-2065 | 1 | Screw-HWH |
| 2 | 105-2442 | 1 | Ball-Detent |
| 3 | 105-2443 | 1 | Spring-Detent |
| 4 | 115-6992 | 1 | Link-Arm, Shift |
| 5 | 115-6997 | 2 | Screw-Shoulder |
| 6 | 115-7066 | 1 | Link-Shifter |
| 7 | 115-7071 | 2 | Bumper-Sleeve, Rubber |
| 9 | 115-7073 | 1 | Spacer |
| 10 | 115-7206 | 1 | Spring Lever ASM |
| 11 | 115-7098 | 1 | Handle-Shift |
| 12 | 131-3072 | 1 | Spring-Extention |
| 13 | 120-9703 | 1 | Pin-Latch |
| 14 | 120-9708 | 10 | Bushing |
| 15 | 120-9746 | 1 | Latch-Shifter |
| 16 | 115-7099 | 1 | Lever-Transport |


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 17 | 120-9711 | 1 | Lever-Shift, Reel |
| 18 | 120-9712 | 1 | Lever-Cam, Reel |
| 19 | 251-259 | 1 | Bearing-Ball |
| 20 | 119-4067 | 1 | Screw-HH |
| 21 | 120-9693 | 1 | Screw-PPH |
| 22 | 120-9683 | 1 | Washer-Flat |
| 23 | 120-9680 | 2 | Washer-Flat |
| 24 | 120-9747 | 1 | Screw-Shoulder |
| 25 | 120-9681 | 2 | Nut-Lock, NI |
| 26 | 120-9684 | 1 | Nut-Lock |
| 27 | 32121-68 | 1 | Pin-Roll |
| 28 | 613328 | 3 | Ring-Retaining |
| 29 | 120-9704 | 1 | Spring-Extension |
| 30 | 120-9729 | 1 | Collar-Spring |




# Handle Assembly


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 99-6247 | 2 | Bushing-Bronze |
| 2 | 104-2065 | 2 | Screw-HWH |
| 3 | 119-4040 | 7 | Nut-Flange, NI |
| 4 | 120-9676 | 4 | Screw-Plastite |
| 5 | 115-6966 | 2 | Shift Lever Pin ASM |
| 6 | 115-7055-03 | 1 | Bracket-Shifter |
| 7 | 115-7063-03 | 1 | Mount-Shift |
| 8 | 115-7068 | 1 | Bracket-Mount, Switch |
| 9 | 115-7078-03 | 1 | Handle-Lower |
| 10 | 115-7299 | 1 | Spring-Extension |
| 11 | 115-7172 | 1 | Cable-Clutch, Reel |
| 12 | 130-9372-03 | 1 | Lift Bail ASM |
| 13 | 115-7229 | 1 | Latch-Brake |
| 14 | 115-7230 | 1 | Spring-Extension |
| 15 | 115-7231 | 1 | Washer |
| 16 | 115-7232 | 1 | Lever-Brake |
| 17 | 115-7238 | 1 | Keeper-Lever, Brake |
| 18 | 131-3097 | 1 | Cover-Console |
| 19 | 120-9726 | 1 | Upper Handle ASM |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 19:2 | 120-9593 | 1 | Decal-Warning |
| 20 | 115-7291 | 1 | Spacer-Latch, Brake |
| 21 | 119-1224 | 1 | Screw-HSBH |
| 22 | 120-9551 | 4 | Screw-HWH |
| 23 | 120-9678 | 6 | Screw-HHF |
| 24 | 115-7260 | 5 | Screw-HSBH |
| 25 | 119-4041 | 5 | Nut-Flange, NI |
| 26 | 120-7950 | 1 | Screw-Shoulder |
| 27 | 120-9681 | 1 | Nut-Lock, NI |
| 28 | 115-7171 | 1 | Cable-Brake |
| 29 | 115-7271 | 1 | Decal-Shift, Gear |
| 30 | 131-3111 | 1 | Decal-Throttle |
| 31 | 115-7270 | 1 | Decal |
| 32 | 120-9598 | 1 | Decal-Brake |
| 33 | 3290-378 | 1 | Tie-Cable |
| 34 | 130-9374 | 1 | Screw-Shoulder |
| 35 | 120-9695 | 1 | Nut-Jam |
| 36 | 3296-12 | 1 | Nut-Lock, NI |
| 37 | 130-9373 | 1 | Cover-Lever, Bail |




# Throttle and Console Assembly


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 115-7241-03 | 1 | Panel-Switches |
| 2 | 120-6310 | 1 | Lcd Display ASM |
| 2:1 | 120-4630 | 1 | Nut-Display |
| 2:2 | 120-6311 | 1 | Decal-Display |
| 3 | 120-6319 | 1 | Ignition Switch ASM |
| 3:2 | 108-8660 | 1 | Nut-Mounting |
| 3:3 | 106-5270 | 1 | Ignition Key Set |
| 3:4 | 108-8659 | 1 | Washer-Backup |
| 4 | 104-2065 | 5 | Screw-HWH |
| 5 | 115-7052 | 1 | Tab-Spring |
| 6 | 131-3089-03 | 1 | Bracket-Throttle |
| 7 | 115-6941 | 2 | Spacer |
| 8 | 115-6942 | 1 | Seal |
| 9 | 131-3073 | 1 | Wheel-Throttle |
| 10 | 119-0737 | 1 | Sensor-Position |
| 11 | 115-6943 | 1 | Disc-Clutch |
| 12 | 115-7291 | 2 | Spacer-Latch, Brake |
| 13 | 115-6944 | 1 | Spring-Clutch |
| 14 | 120-9677 | 2 | Screw-HH |
| 15 | 120-9714 | 1 | Spring-Extension |
| 16 | 106-9288 | 2 | Sensor-Proximity, Ferrous |
| 17 | 107-0255 | 1 | Switch |
| 18 | 99-7420 | 1 | Plug-Hole |
| 19 | 120-9748 | 6 | Screw-HWH |
| 20 | 120-9681 | 8 | Nut-Lock, NI |
| 21 | 120-9551 | 2 | Screw-HWH |
| 23 | 121-4685 | 1 | Decal-Console |
| 24 | 120-6385 | 1 | Sensor-Ferrous Proximity, No |
| 25 | 130-6755 | 1 | Plate-Switch |
| 26 | 3256-22 | 2 | Washer-Flat |




# Battery Base and Controller Assembly


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 121-4662-01 | 1 | Base ASM |
| 2 | 121-4660-03 | 1 | Rear Base ASM |
| 3 | 115-5142 | 2 | Screw-HHF |
| 4 | 119-4041 | 4 | Nut-Flange, NI |
| 5 | 120-9738 | 2 | Screw-HH |
| 6 | 115-7292 | 2 | Washer-Hardened |
| 7 | 121-4683 | 1 | Strip-Foam |
| 8 | 120-9551 | 4 | Screw-HWH |
| 9 | 120-9596 | 1 | Power Center Cover ASM |
| 9:2 | 120-9573 | 1 | Decal-Warning, Power Center |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 9:3 | 127-1530 | 1 | Pad-Foam |
| 10 | 117-4730 | 1 | Controller |
| 11 | 115-4765 | 1 | Contactor |
| 12 | 119-4040 | 4 | Nut-Flange, NI |
| 13 | 120-9574 | 1 | Decal-Fuse |
| 14 | 120-9599 | 1 | Nut-Tall |
| 15 | 107-0279 | 2 | Washer |
| 16 | 121-4698 | 2 | Nut-Keps |
| 17 | 120-9680 | 2 | Washer-Flat |
| 18 | 364-0371 | 2 | Nut-HJ, NI |





# Wire Harness Assembly

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 119-7768 | 1 | Harness-Wire, Battery |
| 2 | 117-4749 | 1 | Harness-Wire, Adapter |
| 3 | 117-4708 | 1 | Harness-Wire, Main |
| 3:2 | 117-4720 | 2 | Fuse-Blade, 3A |
| 3:3 | 117-4728 | 1 | Fuse-Blade, 30A |
| 3:4 | 32180-043 | 1 | Resistor-120 Ohm |
| 4 | 120-9693 | 4 | Screw-PPH |
| 5 | 120-9684 | 4 | Nut-Lock |
| 6 | 120-9683 | 6 | Washer-Flat |
| 7 | 120-9682 | 6 | Screw-HH |
| 8 | 120-4646 | 1 | Handle-Connector |
| 9 | 3290-378 | 5 | Tie-Cable |




# Miscellaneous Parts Assembly

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 11 | 120-6339 | 1 | Harness-Wire, Li+ Diagnostic |
| 13 | 125-5610 | 1 | Paper-Reel, Toro (10 Pack) |
| 14 | 125-5611 | 1 | Shim-Toro Reel (0.002 Inch) |
| 15 | 130-6760 | 1 | Rear Weight ASM |
| 15:2 | 360-0497 | 1 | O-Ring |
| 16 | 115-5142 | 1 | Screw-HHF |
| 17 | 120-9675 | 1 | Spring-Leaf |




# Charger Assembly No. 121-4674

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | | 1 | Charger-Lithium Ion ● |
| 1:1 | 121-4653 | 1 | Decal-Charger, Li+ |
| 1:2 | 120-4646 | 1 | Handle-Connector |
| 1:3 | 120-9693 | 2 | Screw-PPH |
| 1:4 | 120-9684 | 2 | Nut-Lock |
| 1:5 | 3290-378 | 4 | Tie-Cable |
| 1:6 | 121-4673 | 2 | Fuse-6.3 Amp, 250 Volt |
| 1:7 | 107-0382 | 1 | Powercord-Ac, Europe |
| 1:7 | 107-0384 | 1 | Powercord-Ac |
| 1:8 | 121-4705 | 1 | Decal-Caution |
| 1:9 | 125-1413 | 1 | Decal-Ce |
| 1:10 | 125-1414 | 1 | Decal-Ground, Earth |

● Not serviced separately

# Attachments and Accessories

## For 04043 Greensmaster eFlex 1800 Traction Unit

| Product Name | Model/Part |
|---|---|
| 11-Blade Cutting Unit | 04253 |
| 14-Blade Cutting Unit | 04254 |
| Narrow Wiehle Roller Kit | 120-9607 |
| Wide Wiehle Roller Kit | 120-9609 |
| Full 2.5in Diameter Roller Kit | 120-9611 |
| Extended Full Roller ASM | 121-4680 |
| Extended Narrow Wiehle Roller ASM | 121-4681 |
| Front Scraper Kit for Narrow Wiehle Roller | 120-9615 |
| Front Scraper Kit for Wide Wiehle Roller | 120-9616 |
| Front Scraper Kit for Full Roller | 120-9617 |
| Front Brush Kit for Narrow Wiehle Roller | 120-9621 |
| Front Brush Kit for Wide Wiehle Roller | 120-9622 |
| Front Brush Kit for Full Roller | 120-9623 |
| Front Comb Kit for Narrow Wiehle Roller | 120-9624 |
| Front Comb Kit for Wide Wiehle Roller | 120-9625 |
| Front Comb Kit for Full Roller | 120-9626 |
| Full 2.0in Diameter Roller Kit | 120-9605 |
| Steel Rear Roller ASM | 121-4682 |
| Rear Roller Scraper Kit with Roller | 120-9627 |
| Flex Groomer Drive, Forward Rotating | 04259 |
| Flex Groomer Drive, Counter Rotating | 04260 |
| 18in Carbide Grooming Reel | 04263 |
| 18in Grooming Brush | 04264 |
| 18in Soft Perfection Grooming Brush, DPA | 04272 |
| 18in Stiff Perfection Grooming Brush, DPA | 04273 |
| 18in Thin Blade Grooming Reel | 04743 |
| 18in Soft Perfection Grooming Brush Kit | 127-1545 |
| 18in Stiff Perfection Grooming Brush Kit | 127-1546 |
| Roller Extension Kit | 115-7361 |
| High Height-of-Cut Arms (Qty 1) | 120-9600 |
| Rear Roller Adjustment (Qty 1) | 120-9602 |
| Groomer Quick Up Kit | 127-6119 |
| Bedbar-Aggressive | 110-2281-03 |
| Bedbar | 110-2282-01 |
| Bedknife-Microcut, Extended | 110-2300 |
| Bedknife-Low Cut | 110-2301 |
| Bedknife-Edgemax, Microcut | 117-1530 |
| Bedknife-EdgeMax, Tournament | 117-1532 |
| Bedknife-Tournament | 98-7260 |
| Bedknife-Microcut | 98-7261 |
| 18in 11 Blade Reel ASM | 119-4101 |
| 18in 14 Blade Reel ASM | 119-4102 |
| Blade-Groomer, Helix | 110-2333 |
| Blade-Groomer, Thin (Carbide) | 121-9531 |
| Wheel Kit | 04123 |
| Lithium Battery Pack | 04232 |

# Attachments and Accessories (continued)

LED Light Kit ..... 04265
Out-Front Brush Kit ..... 04266
Hourmeter, Wireless Hourmeter System ..... 115-4754
Roller Seal Replacement (Qty 1) ..... 107-1594
MVP Kit, Cutting Unit Re-Build ..... 121-2637
MVP Kit, Forward Rotating Groomer Re-Build ..... 121-9517
Turf Evaluator ..... 04399
Toro Reel Paper (10 Pack) ..... 125-5610
Toro Reel Shim (0.002in) ..... 125-5611
Height-of-Cut Bar ..... 94-9010
Trans Pro 80 Tow-Behind Trailer ..... 04238
Trans Pro 100 Tow-Behind Trailer ..... 04240
Flat Ramp ..... 04245
Rail Ramp Kit (Update) ..... 04247
Rail Ramp Conversion Kit (Update) ..... 04248
18in Rail Conversion Kit ..... 110-7345
18in Transport Conversion Kit ..... 110-7355

## Notes:

## Notes:

## Notes:




**Count on it.**