Form No. 3391-538 Rev A

TORO®

Count on it.

Parts Catalog

Pivoting Hose Reel Kit

Multi-Pro 5800 Turf Sprayer

Model No. 41621—Serial No. 315000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3391-538 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping


TTH: torx truss head

Contents

Hose Reel and Spray Gun Assembly 4
Hose Reel Frame Assembly No. 127-3910 5
Spray Gun Assembly No. 120-8610 6
Hose Reel Mount and Supply Hose Assembly 8
Hose Reel Valve Assembly No. 130-7321 9

© 2014—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420


Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved



Hose Reel and Spray Gun Assembly

Ref.	Part Number	Qty.	Description
1	46-8092	2	Screw-Plastite
2	62-2170	1	Washer-Thrust
3	65-5100	1	Handle-Door
4	93-4510	2	Bushing-Caster
5	99-7435	1	Relay-Power
6	100-1535	1	Switch
7	104-8300	4	Nut-Flange, NI
8	104-8301	4	Nut-Flange, NI
9	105-4551	1	Washer-Flat
10	107-8756	1	Hose-Hose Reel
11	110-5065	1	Hosebarb
12	112-3313	1	Nut-Weatherproof
13	112-3324	1	Switch-Horn
14	116-0104	1	Pin-Spring
15	120-8610	1	Spray Gun ASM
16	121-4982	1	Hosebarb-Spray Gun
17	121-4983	1	Bracket-Roller
18	125-4080-03	1	Plate-Pivot

Ref.	Part Number	Qty.	Description
19	125-8051	1	Slide-Plastic
20	125-8086-03	1	Box-Switch, Hose Reel
21	127-3910	1	Hose Reel ASM
22	127-3953	1	Decal-Hose Reel
23	127-9713-03	1	Hand Gun Bracket ASM
24	240-7	1	Grommet-Rubber
25	302-11	1	Fitting-Lube, 45 DEG
26	2412-36	1	Clamp-Hose
27	3230-23	6	Screw-CARR
28	3234-42	4	Screw-HHF
29	3234-47	6	Screw-HHF
30	3256-4	4	Washer-Flat
31	3290-321	1	Screw-HWH
32	3296-2	1	Nut-Lock, NI
33	3296-47	4	Nut-Lock, NI
34	32120-84	1	Ring-Snap, External
35	122-0362	1	Harness-Wire, Hose Reel
35:4	99-6124	1	Fuse-40 Amp




Hose Reel Frame Assembly No. 127-3910

Ref.	*Part Number*	*Qty.*	*Description*
1	104-8803	1	Frame-Hose Reel
2	104-8804	1	Disc And Gear
3	104-8805	1	Disc-Crank, Side
4	104-8806	1	Drum-Center
5	104-8807	1	Axle
6	104-8808	1	Swivel ASM
6:1	104-8812	1	Ring-Retainer
6:2	104-8864	1	Swivel Seal Kit
7	104-8809	2	Block-Pillow, Top
8	104-8810	2	Block-Pillow, Bottom
9	104-8811	2	Bearing
10	104-8812	4	Ring-Retainer
11	104-8813	1	Cap-Pipe
12	322-3	8	Screw-HH
13	104-8814	1	Trim-Edge, Drum
14	3296-29	8	Nut-Lock, NI

Ref.	*Part Number*	*Qty.*	*Description*
15	3256-23	16	Washer-Flat
16	3253-21	4	Washer-Lock
17	323-6	4	Screw-HH
18	32128-21	1	Nut-HF
19	104-8815	1	Bracket-Motor, 12V Dc
20	131-0282	1	Motor 12V Dc
21	104-8817	1	Pinion
22	104-8818	4	Key
23	322-5	8	Screw-HH
24	3253-4	1	Washer-Lock
25	104-8819	4	Screw-Set
26	3256-23	4	Washer-Flat
27	104-8715	1	Chainguard-Reel, Hose
27:1	322-5	4	Screw-HH
27:2	3256-23	4	Washer-Flat
27:3	3296-29	4	Nut-Lock, NI


Spray Gun Assembly No. 120-8610



Spray Gun Assembly No. 120-8610 (continued)


Ref.	Part Number	Qty.	Description
1	121-4950	1	Nozzle-2.3Mm
1:1	121-4951	1	O-Ring
2	121-4952	1	Head-Nozzle Holder
4	121-4954	1	Ring-Spacer
5	121-4955	1	Spreader-Micro Jet
6	121-4956	1	Tube-Spray Gun
7	121-4957	1	Conveyor-Inner
8	121-4958	1	Tube-Spray Gun, Inner
9	121-4959	1	Drum-Regulation
10	121-4960	1	Spring-Spray Gun
14	121-4964	1	Pin-Hinge
16	121-4966	2	Washer-Teflon
18	121-4968	1	Lever-Drum, Spray Gun
19	121-4969	1	Screw
20	121-4970	1	Grip-Spray Gun
21	121-4971	1	Fork
22	121-4973	1	Hose-Tail
22:1	121-4972	2	O-Ring
23	121-4974	1	Slide-Lever
24	121-4975	1	Lever-Spraygun
25	121-4977	1	Spring
26	121-4978	1	Pin-Lever
27	121-4979	1	Cover-Drum
28	121-4980	1	Drum-Regulation
99	121-4981	1	Spray Gun Seal Kit ●
99:1	121-4951	1	O-Ring
99:2	121-4953	2	Gasket
99:3	121-4967	2	O-Ring
99:4	121-4972	2	O-Ring
99:5	121-4962	1	Plunger-Cone
99:6	121-4961	1	O-Ring
99:7	121-4963	1	Box And Seat
99:8	121-4965	1	Seal

● Not illustrated



Hose Reel Mount and Supply Hose Assembly

Ref.	Part Number	Qty.	Description
1	100-2592	2	Screw-HHF
2	100-8665	1	Reducer-Gauge, Pressure
3	100-8667	1	Coupler-Reducer
4	100-8674	1	Coupler-Tube
5	100-9880	4	Bolt-Shoulder
6	104-7201	2	Nut-HF
7	104-8300	5	Nut-Flange, NI
8	104-8301	13	Nut-Flange, NI
9	116-4701	2	Screw-HHF
10	119-0491	1	Hose-Supply
11	127-9829	1	Clamp/Gasket Kit
12	130-7321	1	Hose Reel Valve ASM
13	120-8546	1	Gauge-Pressure
14	131-3726	1	Fitting-Elbow, 90 DEG
15	322-5	2	Screw-HH
16	2412-107	1	Clamp-R
17	2412-129	2	Clamp-Hose
18	3218-2	2	Nut-Jam
19	3234-11	5	Screw-HHF
20	3234-17	1	Screw-HHF
21	3234-4	2	Screw-HHF
22	3234-42	2	Screw-HHF
23	3290-378	3	Tie-Cable
24	99-8444	1	U-Bolt
25	130-7154-03	1	Bracket-Support, Upper
26	130-7155-03	1	Bracket-Suport
27	130-7160-03	1	Base-Frame
28	130-7163-03	1	Bracket-Lower
29	130-7164-03	1	Bracket-Lower
30	130-7223	1	Tube-Pressure Gauge
31	2815-16	1	Fitting-HYD, Tee



Hose Reel Valve Assembly No. 130-7321

Ref.	*Part Number*	*Qty.*	*Description*
1	131-0250	1	2-Way Valve On/Off Kit
1:1	130-8248	1	Vavle Stem Kit
1:1:1	127-1197	2	O-Ring-Stem
1:2	131-0252	1	Ball-2-Way
1:3	130-8249	1	Endcap Kit
1:3:1	127-1192	1	Seat-Ball
1:3:2	127-1188	1	O-Ring-Seat, Ball
1:3:3	127-1189	1	O-Ring-Endcap
1:4	130-7317	1	Endcap Kit
1:4:1	127-1192	1	Seat-Ball

Ref.	*Part Number*	*Qty.*	*Description*
1:4:2	127-1188	1	O-Ring-Seat, Ball
1:4:3	127-1189	1	O-Ring-Endcap
1:4:4	127-1187	1	O-Ring-Endcap
1:5	127-1196	1	Washer-Stem, Valve
1:6	127-1195	1	Seat-Steam, Valve
1:7	127-1190	1	Fork-Steam, Valve
2	131-0268	1	Hose Reel Handle Kit
2:1	131-0263	1	Screw-Handle
3	127-9807	1	Straight Fitting Kit
3:1	127-1175	1	Fork

Notes:

Notes:



Count on it.