



**Count on it.**

# Parts Catalog

## **P85 Vibratory Plow RT600 Traction Unit**

**Model No. 25401—Serial No. 313000001 and Up**

**Model No. 25401E—Serial No. 313000001 and Up**



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HP:** high pressure

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** low pressure

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard

**TAP:** self tapping

**TTH:** torx truss head

# Contents

Plow Mount Assembly ..... 4

Control Valve Assembly No. AU106520..... 6

Hydraulic Cylinder Assembly No. AU126558 ..... 8

Plow Lift Assembly..... 10

Blade Mount Assembly ..... 12

Hydraulic Cylinder Assembly No. AU121737 ..... 14


Hydraulic Cylinder Assembly No. AU123872 ..... 16

Hydraulic Motor Assembly No. AU87430035 ..... 18

Shaker Box Assembly No. AUH563619-03 ..... 20

Hydraulic Assembly ..... 22

## Plow Mount Assembly




## Plow Mount Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|-------------------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 97-1204            | 1           | Nut-Hex                             | 20          | 32151-77           | 8           | Ring-Retaining, External   |
| 2           | AU103-16200        | 2           | Ring-Retaining, External            | 22          | AU106520           | 1           | Valve-3-Bank Control, Plow |
| 3           | 105-0369           | 2           | Nut-Crownlock                       | 23          | AU112759A1-03      | 1           | Mount-Plow                 |
| 4           | 110-4614           | 2           | Screw-HH                            | 24          | AU41-1020          | 2           | Plug-Freezer               |
| 5           | 120-7252           | 5           | Nut-Lock                            | 25          | AUD90990           | 1           | Bumper                     |
| 6           | 127-1083           | 1           | Plate-Model/Serial (25401)<br>●     | 26          | AUH359216          | 1           | Mount-Radiator             |
| 7           | 131-2822           | 1           | Frame-Swing W/Decal                 | 27          | AUH426817          | 10          | Washer-Flat                |
| 7:2         | 125-6671           | 1           | Decal-Danger, Underground<br>Hazard | 28          | AUH433644          | 2           | Bearing-Pivot              |
| 8           | 127-1090           | 1           | Pedestal-Plow Valve<br>W/Decal      | 29          | AUH434493          | 2           | Pin-Plow                   |
| 8:1         | 125-8489           | 1           | Decal-Plow Control                  | 30          | AUH434801          | 2           | Pin                        |
| 8:2         | 125-8490           | 1           | Decal-Plow Float                    | 31          | AUH436862          | 1           | Pin-Plow Arm, Upper        |
| 9           | AU138-2068         | 2           | Pin-Roll                            | 32          | AU123308           | 1           | Pin-Flagged                |
| 10          | 302-57             | 2           | Fitting-Grease                      | 33          | AUH436865          | 2           | Pin-Rod                    |
| 11          | 33104-035          | 3           | Screw-HHF                           | 34          | AUH436866          | 1           | Pin-Plow Swing             |
| 12          | 323-44             | 1           | Screw-HH                            | 35          | AUH438536          | 4           | Shim-Bumper                |
| 13          | AU426-1240         | 5           | Bolt                                | 36          | AU126558           | 2           | HYD Cylinder ASM           |
| 14          | AU495-81209        | 6           | Washer-Flat                         | 37          | AUH673804-03       | 1           | Latch-Transport            |
| 16          | 3256-24            | 1           | Washer-Flat                         | 38          | AU38-34064         | 2           | Pin-Spiral                 |
| 17          | 3256-27            | 4           | Washer-Flat                         | 39          | AU113437           | 1           | Spacer-Pin Flag            |
| 18          | 32128-20           | 1           | Nut-HF                              | 40          | AU495-81259        | 1           | Washer-Flat                |
| 19          | 104-3082           | 3           | Nut-Lock, HHF                       | 41          | 3253-23            | 1           | Washer-Lock/Sp             |
|             |                    |             |                                     | 42          | AU426-1028         | 1           | Screw-HH                   |

● Not illustrated

# Control Valve Assembly No. AU106520




## Control Valve Assembly No. AU106520 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---------------------------|
| 1           | AU117535           | 2           | Plug-Control Valve        |
| 2           | AU117536           | 1           | Valve Tie Rod Kit         |
| 3           | AU128747           | 1           | Valve-Relief              |
| 4           | AU117538           | 1           | Plow Intel Cover Seal Kit |
| 5           | AU117539           | 2           | Spring-Float              |
| 6           | AU117540           | 1           | Seal Kit                  |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 7           | AU117541           | 2           | Support W/Lever     |
| 8           | AU117542           | 3           | Valve-Load Check    |
| 9           | AU117543           | 1           | Lever               |
| 10          | AU117544           | 1           | Spring-Center       |
| 11          | AU117546           | 1           | Sleeve-Power Beyond |


# Hydraulic Cylinder Assembly No. AU126558



## Hydraulic Cylinder Assembly No. AU126558 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 302-2              | 2           | Fitting-Grease     |
| 2           | 131-2749           | 1           | Seal Kit           |

## Plow Lift Assembly




## Plow Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 60-9870            | 7           | Screw-HH                   | 24          | AU116328A1-03      | 1           | Cradle-Plow Lift         |
| 2           | 97-1206            | 8           | Locknut                    | 25          | AU121737           | 1           | Cylinder-Plow Lift       |
| 3           | 325-5              | 2           | Screw-HH                   | 26          | AU123872           | 1           | Cylinder-Blade           |
| 4           | 131-2823           | 1           | Arm-Plow, Upper W/Decals   | 27          | AU144169C2         | 1           | Gasket-HYD Pump          |
| 4:1         |                    | 1           | Arm-Plow, Upper ■●         | 28          | AU87430035         | 1           | HYD Motor ASM            |
| 4:1:1       |                    | 1           | Arm-Plow ■●                | 29          | AUD130037          | 2           | Pin-Klik                 |
| 4:1:1:1     | 302-57             | 2           | Fitting-Grease             | 30          | AUH274894          | 14          | Washer                   |
| 4:1:1:2     | AU248445A1         | 4           | Bushing-Arm, Plow          | 31          | AUH435357          | 3           | Washer-Lock              |
| 4:2         | 125-6684           | 2           | Decal-Danger, Plow         | 32          | AUH435475          | 3           | Tube-Spacer, Sod Cutter  |
| 5           | AU232-41116        | 5           | Nut-Hex                    | 33          | AUH436862          | 1           | Pin-Plow Arm, Upper      |
| 6           | 302-57             | 1           | Fitting-Grease             | 34          | AUH436864          | 1           | Pin-Plow Arm, Lower Rear |
| 7           | 323-14             | 1           | Screw-HH                   | 35          | AU123180           | 2           | Pin-Mounting, Blade      |
| 8           | 323-43             | 4           | Screw-HH                   | 36          | AUH437946-03       | 2           | Plate-Shoe Wear          |
| 9           | AU426-840          | 1           | Screw-HH                   | 37          | AUH438533          | 2           | Mount-Isolator           |
| 10          | 115-8487           | 2           | Screw-HH                   | 38          | AUH438537          | 4           | Stud                     |
| 11          | AU419-2624         | 8           | Screw-Plow                 | 39          | AUH563619-03       | 1           | Box-Shaker               |
| 12          | AU426-1028         | 8           | Screw-HH                   | 40          | AUH673809-03       | 1           | Arm-Plow, Lower          |
| 13          | AU426-1660         | 2           | Bolt-HH                    | 40:1        |                    | 1           | Arm-Plow, Lower ■●       |
| 14          | AU426-1696         | 3           | Bolt-HH                    | 40:1:3      | AUH434903          | 4           | Bushing                  |
| 15          | AU495-11066        | 16          | Washer-Flat                | 40:1:6      | 302-57             | 2           | Fitting-Grease           |
| 16          | 32128-49           | 4           | Nut-HHF                    | 41          | AUH426833          | 4           | Washer                   |
| 17          | AU105966A1-03      | 1           | Mount-Blade                | 42          | AU38-34064         | 2           | Pin-Spiral               |
| 18          | AU104797A2         | 1           | Axle-Pivot, Blade Mounting | 43          | 97-1204            | 15          | Nut-Hex                  |
| 19          | AU104799A2         | 2           | Shim-Plow Pivot            | 44          | 323-44             | 2           | Screw-HH                 |
| 20          | AU105866A2         | 2           | Shim-Plow Pivot (Thick)    | 45          | 3256-24            | 12          | Washer-Flat              |
| 21          | AU114879A1         | 1           | Tube-Rod End Spacer        | 46          | AUH436865          | 1           | Pin-Rod                  |
| 22          | 131-2821-03        | 1           | Frame-Shaker ●             | 47          | AUD90990           | 2           | Bumper                   |
| 23          | AU116158A1-03      | 2           | Plate-Isolator Mounting    | 48          | 608834             | 8           | Washer                   |

● Not illustrated

■ Not serviced separately

# Blade Mount Assembly




## Blade Mount Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Mount-Blade ●                   | 1:6:2       | AU105870A1         | 2           | Bushing            |
| 1:4         |                    | 2           | Plow Shoe ASM ●                 | 1:6:6       | AUH437099          | 2           | Bushing            |
| 1:6         |                    | 1           | Holder-Blade Mounting, Sub<br>● |             |                    |             |                    |

● Not serviced separately

Hydraulic Cylinder Assembly No. AU121737




## Hydraulic Cylinder Assembly No. AU121737 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | AU121883           | 1           | Tube-Cylinder           |
| 2           | AU121884           | 1           | Rod-Cylinder            |
| 3           | AU121885           | 1           | Gland-Cylinder          |
| 4           | AU121886           | 1           | Cylinder Gland Seal Kit |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 5           | AU121887           | 1           | Piston-Cylinder          |
| 6           | AU121888           | 1           | Cylinder Piston Seal Kit |
| 7           | AU121889           | 1           | Nut-Piston, Cylinder     |

Hydraulic Cylinder Assembly No. AU123872




## Hydraulic Cylinder Assembly No. AU123872 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | AU124045           | 1           | Gland              |
| 2           | AU124046           | 1           | Gland Seal Kit     |
| 3           | AU124047           | 1           | Piston             |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | AU124048           | 1           | Piston Seal Kit    |
| 5           | AU124049           | 1           | Nut                |

# Hydraulic Motor Assembly No. AU87430035




# Hydraulic Motor Assembly No. AU87430035 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | AUA29183           | 1           | Bearing            | 11          | 92-5717            | 3           | Plug-Pipe          |
| 2           | AUN13994           | 2           | Pin-Spring         | 12          | 69-3130            | 2           | Plug               |
| 3           | 127-6214           | 1           | Seal-Lip           | 12:1        |                    | 1           | O-Ring ●           |
| 4           | 69-3200            | 2           | Ring-Retaining     | 13          | AU234383A1         | 1           | Cylinder Block Kit |
| 5           | AU100700A1         | 1           | Plate-Thrust       | 14          | 95-4400            | 1           | Washer-Backup      |
| 6           | AU100701A1         | 1           | Gasket-End Cap     | 15          | 131-3800           | 1           | Pin-Slotted        |
| 7           | AU100702A1         | 1           | Plate-Valve        | 16          | 127-6213           | 4           | Screw-HH           |
| 8           | AU100703A1         | 1           | Bracket-Lifting    | 17          |                    | 1           | Housing ●          |
| 9           | 69-3170            | 2           | Ring-Retaining     | 18          | AU87431908         | 1           | Shaft              |
| 10          | AU132391A1         | 1           | Bearing-Needle     | 19          | AU87431909         | 1           | Cap-End            |

● Not serviced separately

# Shaker Box Assembly No. AUH563619-03




# Shaker Box Assembly No. AUH563619-03 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 1           | 302-40             | 4           | Fitting-Grease, 90 DEG   |
| 2           | 322-47             | 16          | Screw-HH                 |
| 3           | 323-4              | 2           | Screw-HH                 |
| 4           | 3218-5             | 2           | Nut-Jam                  |
| 5           | 3253-21            | 2           | Washer-Lock              |
| 6           | 3253-4             | 16          | Washer-Lock              |
| 7           | 9547               | 10          | Washer-Thrust            |
| 8           | 32151-102          | 1           | Ring-Retaining, External |
| 9           | 32151-35           | 2           | Ring-Retaining, External |
| 10          | 32151-76           | 1           | Ring-Retaining, Internal |
| 11          | AU103-11225        | 2           | Ring-Retaining           |
| 12          | AU135587A1         | 2           | Cap-Bearing              |
| 13          | AU222-762          | 1           | Fitting-Elbow, 90        |
| 14          | AU83-65032         | 2           | Screw-Set, HSH           |
| 15          | AU86993944         | 1           | Gear-Drive, Plow         |
| 16          | AUG13609           | 4           | Bearing                  |
| 17          | AUH189506          | 1           | Weight-Counter           |
| 18          | AUH189514          | 1           | Weight-Counter           |
| 19          | AUH189746          | 1           | Gear                     |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 20          | AUH189753          | 1           | Gear               |
| 21          | AUH189761          | 2           | Shaft-Bearing      |
| 22          | AUH189795          | 1           | Spacer             |
| 23          | AUH189811          | 2           | Cap-Bearing        |
| 24          | AUH189852          | 2           | Gasket             |
| 25          | AUH189860          | 2           | Gasket             |
| 26          | AUH189878          | 2           | Gasket-Shim        |
| 27          | AUH189886          | 2           | Gasket-Shim        |
| 28          | AUH189910          | 1           | Gasket-Gearcase    |
| 29          | AUH202176          | 1           | Plate-Cover        |
| 30          | AUH205559          | 1           | Housing-Gearbox    |
| 31          | AUH380030          | 2           | Key-Square         |
| 32          | AUH753145          | 4           | Bearing            |
| 33          | AUH753152          | 4           | Bearing            |
| 34          | AUH753160          | 4           | Bearing            |
| 35          | AUH753194          | 2           | Bearing            |
| 36          | AUT38017           | 4           | Washer-Thrust      |
| 37          | AUH189803          | 2           | Spacer             |

# Hydraulic Assembly



## Hydraulic Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|------------------------|
| 2           | 94-7146            | 1           | Adapter ●             | 28:1        | 237-80             | 1           | O-Ring                 |
| 3           | 95-0581            | 1           | Fitting-Elbow, 90 DEG | 29          | 353-426            | 1           | Fitting-90 DEG         |
| 4           | 100-4749           | 6           | Adapter-HYD           | 29:1        | 237-80             | 1           | O-Ring                 |
| 4:1         | 237-80             | 1           | O-Ring                | 30          | 353-537            | 2           | Fitting-Elbow, 90 DEG  |
| 5           | 127-0519           | 1           | Fitting-Elbow, 45 DEG | 30:1        | 237-79             | 1           | O-Ring                 |
| 6           | 127-0542           | 2           | Fitting-Elbow, 45 DEG | 31          | AU426-644          | 2           | Bolt-HH                |
| 8           | 127-1057           | 1           | HYD Hose ASM          | 32          | AU496-21041        | 5           | Washer-Flat            |
| 9           | 127-1058           | 2           | HYD Hose ASM          | 33          | 2412-96            | 1           | Clamp-R                |
| 10          | 127-1059           | 1           | HYD Hose ASM          | 34          | AU218-980          | 4           | Elbow-Swivel, 90 DEG   |
| 11          | 127-1060           | 1           | HYD Hose ASM          | 35          | AU218-5281         | 2           | Fitting-Elbow, 90 DEG  |
| 12          | 127-1061           | 1           | HYD Hose ASM          | 35:1        | 237-80             | 1           | O-Ring                 |
| 13          | 127-1062           | 1           | HYD Hose ASM          | 36          | AU91-203003-12-1   | 1           | Fitting-Tee            |
| 14          | 127-1065           | 1           | HYD Hose ASM          | 36:1        | 237-81             | 1           | O-Ring                 |
| 15          | 127-1066           | 1           | HYD Hose ASM          | 37          | 56-7971            | 6           | Clamp-Tube             |
| 16          | 127-1067           | 1           | HYD Hose ASM          | 38          | AUH428623          | 2           | Tee-Special            |
| 17          | 127-1068           | 1           | HYD Hose ASM          | 39          | AUH438204-03       | 1           | Bar                    |
| 18          | 127-1069           | 1           | HYD Hose ASM          | 40          | AUH439256          | 2           | Block-Clamp (Hose-HYD) |
| 19          | 127-1214           | 1           | HYD Hose ASM          | 41          | AUH439323          | 1           | Fitting-Restrictor     |
| 20          | AU218-5172         | 2           | Fitting-Elbow, 45 DEG | 42          | 3334-945           | 7           | Tie-Cable              |
| 21          | AU218-5382         | 1           | Elbow-Swivel, 90 DEG  | 43          | AU121447           | 2           | Orifice                |
| 22          | AU224-2246         | 3           | Nut-Square            | 44          | 130-8419           | 1           | Valve-Check            |
| 23          | 323-4              | 1           | Screw-HH              | 45          | 114-5509           | 1           | Fitting-Elbow 90       |
| 24          | 322-17             | 3           | Screw-HH              | 45:1        | 237-58             | 1           | O-Ring                 |
| 25          | 353-369            | 1           | Fitting-Elbow, 90 DEG | 46          | 340-148            | 2           | Fitting-Tee            |
| 25:1        | 237-81             | 1           | O-Ring                | 46:1        | 237-81             | 1           | O-Ring                 |
| 26          | 353-370            | 2           | Fitting-Elbow, 90 DEG | 46:2        | 237-58             | 2           | O-Ring                 |
| 26:1        | 237-80             | 1           | O-Ring                | 47          | 130-7381           | 1           | HYD Hose ASM           |
| 27          | 353-374            | 2           | Fitting-Elbow, 90 DEG | 48          | 130-7382           | 1           | HYD Hose ASM           |
| 27:1        | 237-42             | 1           | O-Ring                | 49          | 130-7383           | 1           | HYD Hose ASM           |
| 28          | 353-385            | 1           | Fitting-Straight      | 50          | 130-7384           | 1           | HYD Hose ASM           |

● Not illustrated



**Count on it.**