

## Addendum to Table 1, page 33, Mow & Feed Spreader Operator's Manual

MODEL NO. 52070 – 4900001 &amp; UP

**OPERATOR'S MANUAL  
ADDENDUM**

# IMPORTANT

The setting for Toro Nurture Intensive Care (12–3–9) is incorrect in the table on page 33 of your operator's manual. Please use this addendum table for correct settings.

FERTILIZER TYPE	SPREADER SETTING	APPROXIMATE APPLICATION RATE
Toro Nurture Intensive Care (12–3–9)	#7 <sup>1</sup> / <sub>4</sub>	7.5 lbs. /1,000 square feet
Toro Nurture Intensive Care Dry (9–3–7)	#9	10 lbs. /1,000 square feet
Toro Nurture Regular Care Dry (16–4–6)	#7	5 lbs. /1,000 square feet
Toro Nurture Premium Care Dry (22–2–3)	#6	3.76 lbs. /1,000 square feet
Scotts® (29–3–4)	#5	3 lbs. /1,000 square feet