



Form No. 3396-282 Rev A

Count on it.

Parts Catalog

CE Light Kit

**Groundsmaster® 4500/4700 or Reelmaster®
7000 Traction Unit**

Model No. 30491



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Contents

CE Light Assembly..... 4

Headlight and Rear Beacon Mounting Assembly 6

Rear Light and Switch Assembly 7


Non Cab Beacon Assembly 8

This technical drawing is an exploded view of a vehicle chassis and suspension system. It shows the main frame, two wheels with tires, and various suspension components. The parts are labeled with numbers and leader lines:

- 1**: Front wheel assembly (tire and hub).
- 2**: A small rectangular component, possibly a sensor or actuator.
- 3**: A long, curved structural member, likely a control arm or steering knuckle.
- 4**: A small circular component, possibly a bush or washer.
- 5**: A large, curved structural member, likely a rear control arm or steering knuckle.
- 6**: A circular component, possibly a hub or brake disc.
- 7**: A circular component, possibly a hub or brake disc.
- 8**: A small rectangular component, possibly a sensor or actuator.
- 9**: A small rectangular component, possibly a sensor or actuator.
- 10**: A small rectangular component, possibly a sensor or actuator.
- 11**: A small rectangular component, possibly a sensor or actuator.
- 12**: A small rectangular component, possibly a sensor or actuator.
- 13**: A small rectangular component, possibly a sensor or actuator.
- 14**: A small rectangular component, possibly a sensor or actuator.
- 15**: A small rectangular component, possibly a sensor or actuator.
- 16**: A small rectangular component, possibly a sensor or actuator.
- 17**: A small rectangular component, possibly a sensor or actuator.
- 18**: A small rectangular component, possibly a sensor or actuator.
- 19**: A small rectangular component, possibly a sensor or actuator.
- 20**: A small rectangular component, possibly a sensor or actuator.
- 21**: A small rectangular component, possibly a sensor or actuator.
- 22**: A small rectangular component, possibly a sensor or actuator.
- 23**: A small rectangular component, possibly a sensor or actuator.
- 24**: A small rectangular component, possibly a sensor or actuator.

CE Light Assembly (continued)



<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	125-4624-03	1	Bracket-Light, RH	13	104-7201	2	Nut-Flange, NI
2	119-8093	2	Rear Lamp ASM	14	122-0578	1	Ce Light Wire Harness Kit
2:1	120-7552	1	Bulb-12V	14:8	218-578	3	Fuse-Blade, 10 Amp
2:2	120-6657	1	Bulb-5W	14:9	100-4918	2	Diode-Over Molded
2:3	120-6656	1	Lens-Red	14:10	121-8864	4	Fuse-Mini Blade, 5 Amp
2:4	60-6910	2	Screw-HH	14:17	109355	1	Fuse-Blade, 15 Amp
2:5	48-7880	4	Nut-Hex	14:18	122-0145	1	Harness-Wire, Beacon
3	125-4625-03	1	Bracket-Light, LH	14:19	122-0146	1	Harness-Wire, Registration Plate
4	125-4628-03	1	Bracket-Front, RH	15	99-7667	4	Washer-Flat
5	125-4629-03	1	Bracket-Front, LH	16	3218-6	2	Nut-Jam
6	119-8324	1	LH Headlamp ASM	17	115-4841	4	Screw-HH
6:1	33025-00	1	Nut-Lock, NI	18	323-12	6	Screw-HH
6:2	120-0475	2	Shell-Articulated	19	100-2894	8	Tie-Cable
6:3	120-0474	2	Joint-Articulated	20	32144-87	2	Screw-HWHTF
6:4	120-0471	1	Bulb-Halogen	22	99-7430	1	Relay
6:5	120-0472	1	Bulb-Lamp	23	3296-54	1	Nut-Lock
6:6	120-0473	1	Bulb-Lamp	24	112-3169	1	Screw-HHF, Serrated
7	119-8323	1	RH Headlamp ASM	25	3234-4	2	Screw-HHF
7:1	33025-00	1	Nut-Lock, NI	26	32128-33	2	Nut-HF
7:2	120-0475	2	Shell-Articulated	27	95-8900	1	Switch
7:3	120-0474	2	Joint-Articulated	28	3296-9	2	Nut-Lock
7:4	120-0471	1	Bulb-Halogen	29	3256-21	4	Washer-Flat
7:5	120-0472	1	Bulb-Lamp	30	32105-9	2	Screw
7:6	120-0473	1	Bulb-Lamp	31	3296-2	1	Nut-Lock, NI
8	125-4645-03	1	Bracket-Horn	32	3229-34	1	Screw-CARR
9	116749	1	Horn	33	131-7753-03	1	Bracket-Mount, Sensor
10	323-34	1	Screw-HH	34	131-7754	1	Plate-Switch
11	104-8301	7	Nut-Flange, NI	35	131-7767	1	Decal-Fusebox
12	321-11	2	Screw-HH				



Headlight and Rear Beacon Mounting Assembly

Ref.	Part Number	Qty.	Description
1	3256-3	8	Washer-Flat
2	95-5622	2	Hanger-Rubber
3	93-5023	4	Spacer
4	322-8	4	Screw-HH
5	104-8300	6	Nut-Flange, NI
6	127-6368-03	1	Mount-Beacon
7	322-4	2	Screw-HH
8	119-8095	1	Socket-Beacon


Ref.	Part Number	Qty.	Description
9	119-8096	1	Beacon ASM
9:1	120-7553	1	Bulb
9:2	120-7554	1	Reflector
9:3	120-7555	1	Cover-Dome, Amber
9:4	120-7556	1	Motor-Beacon
10	32180-030	2	Clip-Tie
11	100-2894	5	Tie-Cable
12	95-0690	3	Pad-Mounting



Rear Light and Switch Assembly

Ref.	Part Number	Qty.	Description
1	125-4643-03	1	Panel-Light
2	119-7769	1	Switch-Rocker, On-None-On
3	107-8034	1	Switch-Rocker, On-Off-On
4	112-3324	1	Switch-Horn
5	125-4644-03	1	Panel-Cover
6	3290-321	3	Screw-HWH
7	119-9880	1	Module-Flasher
8	32144-1	1	Screw-Taptite
9	32144-4	3	Screw-HWH

Ref.	Part Number	Qty.	Description
10	107-1013	3	Nut-Speed, U-Type
11	112-3313	1	Nut-Weatherproof
12	95-8999	1	Switch
13	127-6350	1	Decal-Control
14	9266934	2	Screw
15	119-9861-03	1	Bracket-Plate
16	119-8091	1	Light-Plate
16:1	120-7564	1	Bulb-12W
17	3290-500	2	Screw-PPH
18	3296-2	2	Nut-Lock, NI



Non Cab Beacon Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	120-9856-03	1	Bracket-Beacon, ROPS
2	119-6727	1	U-Bolt
3	104-8301	2	Nut-Flange, NI

Notes:

Notes:

Notes:



Count on it.