
Parts Manual

METRO®

Model No. MGS481CKA48300—Serial No. 316000000 and Up

Picture below may not reflect actual product.



Part No. 4502-562 Rev. A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Touch Up Paint

Exmark black touch up spray paint – gloss black.

Exmark red touch up paint (spray paint – P/N 1-850337 - .6 oz liquid bottle – P/N 103-9140).

© 2015—Exmark Mfg. Co., Inc.
Industrial Park Box 808
Beatrice, NE 68310

Contact us at www.Exmark.com.
Printed in the USA.
All Rights Reserved




If your Exmark dealer does not have the Exmark part in stock, Exmark will get the parts to the dealer the next business day or the part will be FREE Guaranteed!! (Some restrictions apply. See your participating Exmark Dealer for details.)

Contents

Complete Deck Assembly 4
Deck Assembly 6
Deck W/Decals Assembly No. 1-404257 8
Caster Mount W/Weight Assembly No. 116-8245 10
Caster Wheel Assembly No. 103-1236 12
Caster Wheel Support W/Bearings 103-2296 14
Engine Deck W/Transmission 16
Engine Deck W/Transmission (cont.) 18
Engine Deck W/Decals Assembly No. 116-6131 20
Wheel and Tire Assembly 22
Engine Assembly 24
ECS Upper Handle and Controls 26
Console W/Decals Assembly 28
Fuel Assembly 30
Electrical Assembly 32

Complete Deck Assembly




Complete Deck Assembly (continued)

Ref.	Part Number	Qty.	Description
1		1	Deck ASM-48 ●

● Not serviced separately

Deck Assembly



Deck Assembly (continued)

Ref.	Part Number	Qty.	Description
1	1-404257	1	Deck W/Decals And Dogleg
2	116-1729-01	1	Baffle-Dogleg
3	322-2	3	Screw-HH 5/16-18 X 5/8
4	32128-20	11	Nut-Whizlock 5/16-18
5	3296-29	1	Nut-Nyloc 5/16-18
6	323-7	18	Screw-HH 3/8-16 X 1 1/4
7	3290-357	8	Nut-Whizlock 3/8-16
8	98-5975	12	Washer-Spring Disc 3/8
9	1-808280	1	Pin-Clevis 5/16 X 1 49/64
10	1-303105	1	Yoke-Adjustable
11	109-0977	2	Pulley,Idler 5"
12	32151-103	1	E-Ring
13	116-5178	3	Blade-Extreme 2, 16.25"
13	103-6738	3	Blade,Low Lift 16.25
13	103-6583	3	Blade, 16.25 Notched
13	103-6581	3	Blade, 16.25 Mulching ▲
13	103-1577	3	Blade, 16.25 Solid
14	1-323303	1	Arm-Assist, Linkage
15	323-13	2	Screw-HH 3/8-16 X 2 3/4
16	3296-42	2	Nut-Nyloc 1/4-20
17	103-8387	3	Asm, Cutter Housing Complete
18	702809	1	Screw-HH
19	32120-35	1	E-Ring
20	3296-39	18	Nut-Nyloc 3/8-16
21	1-322235	1	Arm-Assist
22	1-303434	1	Bushing-Engagement
23	1-303348	1	Eyebolt-Thread, LH
24	1-303236	1	Body-Turnbuckle
25	1-303238	1	Eyebolt-Thread, RH
26	1-323747	1	Spring-Compression
27	1-806003	3	Hairpin-Cotter
28	1-303352	1	Washer-Spindle
29	322-10	1	Screw-HH 5/16-18 X 2
30	1-303334	1	Washer-Spring Disc 5/16
31	103-3600	1	Idler Arm ASM
31:2	1-323729	2	Sleeve-Bearing
32	116-3515	1	Screw,HH Special 5/16-18 X 1.25
33	302-19	1	Zerk-1/4-28 Str
34	323-20	1	Screw-HH 3/8-16 X 3-1/4
35	3296-56	1	Nut-Nyloc 1/4-20 Thin
36	109-5151	1	Deflector-Discharge
37	1-403179	1	Tube-Pivot
38	3256-3	1	Washer-5/16 Std
39	1-323714	1	Rod-Brake
40	1-324372	1	Pad And Spring ASM
40:1	1-323709	1	Pad-Brake
40:2	1-323710	1	Spring,Brakeserv By #324372
40:3	103-0138	2	Rivet 3/16 X 1/2
41	3256-23	1	Washer-5/16 Sae
42	116-3626	1	Pulley-Idler
43	1-403174	1	Drive Belt (Main Deck) 48"
44	1-323746	1	Spacer-Flanged
45	1-413113	2	Bushing-Idler
46	109-8854	1	Pin-Chute
47	1-323071	1	Spring-Extension
48	116-8245	2	ASM-Caster Mnt W/Weight
49	321-4	2	Screw-HH 1/4-20 X 3/4
50	1-323748	1	Ring-Push On
51	1-323417	5	Washer-Belt Shield
52	323-4	8	Screw-HH 3/8-16 X 3/4
53	1-303537	2	Stud-Shield, Belt (Short)
54	1-303536	3	Stud-Shield, Belt (Long)
55	1-323385	5	Knob-3 Prong
56	116-2707	1	ASM,Shield W/Decals 48 Metro
57	1-403188	1	Spacer
58	323-8	8	Screw-HH 3/8-16 X 1 1/2
59	116-0962	1	Spring, Torsion
60	104-8301	2	Nut-Nyloc 3/8-16 Flg
61	126-6890	1	Decal-Metro
62	106-5517	2	Decal-Warning, Hot Surface
63	1-323529	3	Tube-Spindle, Short ◆
64	103-2535	3	Spacer-Guard Bottom
65	1-403183	3	Sheave ◆
66	1-800861	3	Screw-Cap, HH
67	1-323539	12	Spacer-Blade Drive
68	1-513208	3	Washer-Spring Disc 5/8
69	1-323339	3	Washer
70	1-807267	3	Key-Machine 1/4 X 3/16 X 1 1/4
71	103-1330	3	Guard-Bearing Top ◆
72	3219-6	3	Nut-Hex 5/8-18
73	3246-18	3	Setscrew-5/16-18 X 3/8 ■
74		3	Cutter Housing ASM ●
74	103-8280	3	Asm, Cutter Housing W/Bearings ◆
74:2	103-2477	2	Bearing-Jackshaft
74:3	103-2534	1	Spacer-Bearing
74:4	32120-8	1	Ring-Retaining


● Not serviced separately

■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

▲ Requires installation of mulch kit for proper mulching. See your Exmark dealer for details.

◆ Apply Mobil HTS grease (P/N 103-5217 1.5 oz packet) (or a food-grade anti-seize). See operator s manual for locations.


Deck W/Decals Assembly No. 1-404257



Deck W/Decals Assembly No. 1-404257 (continued)

Ref.	Part Number	Qty.	Description
2	116-1729-01	1	Baffle-Dogleg
3	109-5151	1	Deflector-Discharge
4	109-8854	1	Pin-Chute
5	116-0962	1	Spring, Torsion
6	322-2	4	Screw-HH 5/16-18 X 5/8
7	32128-20	4	Nut-Whizlock 5/16-18
8	126-6746	1	Decal-Ultracut 48 Series 3
9	114-3489	1	Decal-Warning, Bagger
10	99-3943	1	Decal-Routing, Belt
11	112-8760	2	Decal-Danger
12	112-9028	1	Decal-Missing, Cover


Caster Mount W/Weight Assembly No. 116-8245



Caster Mount W/Weight Assembly No. 116-8245 (continued)

Ref.	Part Number	Qty.	Description
1	103-2296	1	Caster Whl Support W/Bearings, Weighted
2	1-303314	4	Spacer-Caster
3	103-1236	1	Caster Wheel Assembly
4	1-513338	1	Washer
5	1-809020	1	Pin

Caster Wheel Assembly No. 103-1236




Caster Wheel Assembly No. 103-1236 (continued)

Ref.	Part Number	Qty.	Description
1	116-7942-01	1	Fork-Caster
2	1-513547	1	Spacer
3		1	Wheel And Tire ASM ●
3:1		1	Tire ●
3:2	1-513809	1	Bearing
3:3	1-513810	2	Bushing
3:4	302-61	1	Fitting-Grease
3:5		1	Wheel ●
4	3296-45	1	Nut-Lock, NI
5	325-20	1	Screw-HH

● Not serviced separately


Caster Wheel Support W/Bearings 103-2296



Caster Wheel Support W/Bearings 103-2296 (continued)

Ref.	*Part Number*	*Qty.*	*Description*
1	103-2297-01	1	Caster Whl Support Wldmnt, Weighted
2	1-303514	2	Bearing-Flanged
3	302-52	1	Fitting-Grease

Engine Deck W/Transmission




Engine Deck W/Transmission (continued)

Ref.	Part Number	Qty.	Description
1	116-6131	1	ASM, Metro Engine Deck W/Decals
2	103-1611-03	2	Arm-Brake
2:1		1	Wld,Brake Arm ■
2:1:1	1-324154	1	Asm,Bushing/Zerk
3	1-322117-03	1	Axle
4	2412-104	2	Clamp-R
5	32151-47	4	Ring-Retaining
6	1-323288	2	Belt, Wheel Drive
7	32128-20	4	Nut-HF
8	1-323262	2	Band-Brake
9	110-5866	2	Swivel-Brake
10	1-323277	2	Idler-Wheel, Drive
11	116-3515	2	Screw-HH, Special
12	99-8664	2	Screw-HH
13	3290-357	14	Nut-HHF, Whiz
14	3296-39	4	Nut-Lock, NI
15	1-323287-01	2	Shield-Wheel, Drive
16	1-323283	4	Spacer-Shield
17	1-603402	2	Spring-Extension
19	103-1619	1	Linkage,LH Brake
20	103-1620	1	Linkage,RH Brake
21	1-513959	2	Wingnut-Nylock
22	323-39	4	Screw-HH
23	1-523157	6	Washer-Spacer ●
23	1-543436	8	Washer-Spacer ●
24	98-5975	4	Washer-Belleville
25	1-323307	2	Pin-Clevis
26	103-1618	2	Swivel, Short
27	323-6	4	Screw-HH
28	126-4482	2	Drive Wheel ASM
29	32120-47	2	Ring-Retaining, External
31	1-808519	2	Ring-Snap
33	98-3259	1	Shield-Trailing
34	322-3	2	Screw-HH
35	116-7542-03	1	Arm-Idler, LH
35:1		1	Idler Arm LH Assy ■
35:1:4	302-19	1	Fitting-Grease
36	1-806003	2	Pin-Cotter
37	116-7543-03	1	Arm-Idler, RH
37:1		1	Idler Arm RH Assy ■
37:1:4	302-19	1	Fitting-Grease
38	1-412358	2	Scraper
39	3296-29	4	Nut-Lock, NI
40	1-803051	2	Nut-Push

● QTY As Required

■ Not serviced separately

Engine Deck W/Transmission (cont.)




Engine Deck W/Transmission (cont.) (continued)

Ref.	Part Number	Qty.	Description
1	1-323500	1	Transmission
2	1-324340	2	Coupling, W/Guard And Zerk
2:1	1-323680	1	Coupler
2:2	302-19	1	Zerk-1/4-28 Str
2:3	51-4220	1	Guard-Coupler
3	1-323502	2	Shaft-Transmission
4	1-323252	2	Bearing-Shaft ●
5	1-323254	2	Flange-Output
6	103-6511	2	Sheave-Transmission ●
7	32151-62	2	Ring-Retaining
8	1-805005	4	Washer-Lock 5/16 Heavy
9	3245-41	2	Setscrew-1/4-20 X 3/8 ■
10	1-323280	1	Belt, Transmission Drive
11	3296-39	1	Nut-Nyloc 3/8-16
12	103-3498	1	Asm, Shifter Plate (1-323387-03) W/ Decals
12:2	98-3264	1	Decal-Speed, Ground
13	1-323389-03	2	Bracket-Plate, Shift
14	3230-1	2	Bolt-Carriage 5/16-18 X 3/4
15	104-8300	2	Nut-Nyloc 5/16-18 Flg
16	3246-18	2	Setscrew-5/16-18 X 3/8 ■
17	32144-11	4	Screw-HWH 5/16-18 X 3/4 Tf
18	1-323278	1	Sheave-Transmission ●
19	1-323379	1	Washer
20	98-5975	1	Washer-Spring Disc 3/8
21	3296-6	1	Nut-Nyloc 3/8-24
22	3257-5	3	Key-Woodruff #9 3/4 X 3/16
23	1-303282	1	Switch-Start, Neutral
24	3231-6	1	Bolt-Carriage 3/8-16 X 2
25	3256-5	2	Washer-7/16 Std
26	130-8362	1	Pulley-Idler, Flat
27	3256-24	1	Washer-3/8 Sae
28	321-3	4	Screw-HH 1/4-20 X 5/8
29	3296-42	4	Nut-Nyloc 1/4-20
30	322-3	4	Screw-HH 5/16-18 X 3/4
31	103-1606	1	Lever, Shift W/Grip
31:2	103-1733	1	Grip Foam
32	1-303186	1	Bellcrank
33	3290-357	1	Nut-Whizlock 3/8-16
34	1-603403	1	Bolt-Shoulder
35	1-513051	1	Switch-N.O.
36	3290-500	2	Screw-PPH #10-24 X 5/8
37	1-633181	1	Plate-Tapped
39	126-4345	1	Decal-Patent Ttco.Com

● Apply anti-seize compound in bore.
■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.


Engine Deck W/Decals Assembly No. 116-6131



Engine Deck W/Decals Assembly No. 116-6131 (continued)

Ref.	Part Number	Qty.	Description
2	98-1977	1	Decal-Warning
3	126-1400	1	Decal-Warning, Sulky
4	323-13	1	Screw-HH
5	3290-357	2	Nut-HHF, Whiz
6	117-2718	1	Decal-Arrester, Spark


Wheel and Tire Assembly



Wheel and Tire Assembly (continued)

Ref.	Part Number	Qty.	Description
1	109-4359	1	Drum And Sheave ASM
2	130-8364	1	Wheel And Tire ASM
2:1	130-8367	1	Tire
2:2	1-323328	1	Wheel And Hub ASM
2:3	1-323329	2	Bearing-Flanged
3	322-5	4	Screw-HH 5/16-18 X 1
4	1-805005	4	Washer-Lock 5/16 Heavy

Engine Assembly




Engine Assembly (continued)

Ref.	Part Number	Qty.	Description
1		1	Engine-Kawasaki ● ▲
2	114-3550	4	Washer-Lock, Spring
3	114-3549	4	Nut-M8
4	1-653313	2	Gasket-Exhaust
5	116-3735	1	Muffler-Horizontal
6	104-8301	4	Nut-Nyloc 3/8-16 Flg
7	116-6278-03	1	Guard-Muffler
8	323-6	4	Screw-HH 3/8-16 X 1
9	103-1667	1	Sheave ■
10	1-373034	1	Washer
11	103-4177	1	Key
12	1-633453	1	Spacer-Clutch
13	1-603610	2	Washer-Spring Disc 7/16
14	116-3702	1	Screw-HH ◆
15	103-1666	1	Sheave-Transmission ■
16	103-2587	1	Adapter
17	323-7	4	Screw-HH 3/8-16 X 1 1/4
18	98-5975	4	Washer-Spring Disc 3/8

● Not serviced separately
▲ Obtain parts from www.kawpowerepc.com
◆ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.
■ Apply anti-seize compound in bore.

ECS Upper Handle and Controls




ECS Upper Handle and Controls (continued)

Ref.	Part Number	Qty.	Description
1	103-0770-03	1	Handle Weldment (1-412449)
2	103-0489-03	1	Bracket, Opc Axle
3	3256-22	10	Washer-1/4 Sae
4	321-3	10	Screw-HH 1/4-20 X 5/8
5	32128-33	12	Nut-Whizlock 1/4-20
6	1-303365	2	Bushing-Nylon
7	103-0769-03	1	Rod Weldment, Opc
8	116-4079	1	Wld,LH Opc Lever ■
8:1:2	1-803322	1	Setscrew-5/16-24 X 5/16 ●
9	116-4080	1	Wld,RH Opc Lever ■
9:1:2	1-803322	1	Setscrew-5/16-24 X 5/16 ●
10	1-303363	1	Spring-Extension
11	103-0815	2	Grip-Bar, Handle
12	126-2925	2	Pin-Spring
13	103-1631	1	Latch, Thumb LH
14	103-1630	1	Latch, Thumb RH
15	1-303435	6	Washer-Spring Disc 1/4
16	103-0235	2	Screw-HH 1/4-20 X 1 1/8 W/Nylon
17	321-14	2	Screw-HH 1/4-20 X 2 3/4
18	103-0027	2	Bushing-Lever, Drive
19	103-2514	1	Asm, Drive Lever LH
19:1	116-4081	1	Wld,LH Drive Lever
19:2	1-413152	2	Bushing-Sleeve
20	103-2513	1	Asm, Drive Lever RH
20:1	116-4082	1	Wld,RH Drive Lever
20:2	1-413152	2	Bushing-Sleeve
21	322-9	2	Screw-HH 5/16-18 X 1 3/4
22	323-6	4	Screw-HH 3/8-16 X 1
23	3296-39	5	Nut-Nyloc 3/8-16
24	109-4934	1	Asm, Console (109-4649-03) W/Decals
25	1-633080	1	Spacer
26	323-14	1	Screw-HH 3/8-16 X 3
27	103-1629	1	Clutch Lever W/Grip
28	3256-4	1	Washer-3/8 Std
29	103-1627	1	Linkage, Upper
30	1-806003	2	Hairpin-Cotter
31	116-2426	1	Control, Throttle
31	116-2426RT02	1	Control, Throttle
32	1-807513	2	Bolt-Carriage #10-24 X 1/2
33	3296-2	2	Nut-Nyloc #10-24
34	103-1797-01	1	Bracket-Cable, Choke
35	1-303088	1	Clip-Cable
36	103-1796	1	Cable-Choke
36	103-1796RT01	1	Cable-Choke
37	1-303335	1	Tie-Cable 7 15/16 (Large)
38	103-2463	2	Balljoint
39	3296-29	2	Nut-Nyloc 5/16-18
40	103-1604	2	Linkage, Wheel Drive
41	3220-3	4	Nut-Jam 3/8-24
42	3219-3	2	Nut-Hex 3/8-24

● Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.
■ Use Pro-Lock retaining type, Part no. 1-840023 (.5cc tube) on inside of bore of OPC hub.


Console W/Decals Assembly



Console W/Decals Assembly (continued)

Ref.	Part Number	Qty.	Description
1	116-7879	1	Decal-Console Metro Ecs
2	106-2733	1	Decal-Throttle
3	126-6877	1	Decal, Exmark Logo
4	103-2244	1	Decal, LH Ecs Instruction
5	103-2245	1	Decal, RH Ecs Instruction

Fuel Assembly




Fuel Assembly (continued)

Ref.	Part Number	Qty.	Description
1	126-1525	1	ASM, Fuel Tank
1:2	120-5461	1	Cap-Fuel, Ratcheting
1:3	114-0284	1	Grommet
1:4	119-3547	1	Valve-Vent, Fuel
1:5	103-2605	1	Fitting-Fuel, Bulkhead ◆
2	107-4543	2	Clamp
3	3256-3	2	Washer-Flat
4	322-10	2	Screw-HH
5	104-8300	2	Nut-Flange, NI
7	109-0650	1	Hose-Fuel
8	2412-98	4	Clamp-Hose
9	1-603770	1	Valve-Fuel
10	99-9415	1	Hose-Fuel
14	1-303335	3	Tie-Plastic
15	114-0286	1	Hose-Vent
16	117-1221	1	Canister-Carbon, 800Cc
17	115-0962	1	Hose-Vent, Canister
18	116-2231	1	Hose-Vent, Formed
19	114-0292	1	Bracket-Canister, Carbon
20	321-2	2	Screw-HH
21	115-4486-01	1	Bracket-Canister, Carbon
22	104-7201	4	Nut-Flange, NI
23	3229-1	2	Bolt-CARR
24	116-2232	1	Valve-Control, Vacuum
25	116-2233	1	Hose-Vent, Formed
26	116-2394	1	Hose-Vent, Formed
28		1	Pn 41019-1055 Filter W/6In Fuel Line ●■▲

● Not illustrated
▲ Obtain parts from www.kawpowerepc.com
◆ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.
■ Not serviced separately

Electrical Assembly



Electrical Assembly (continued)

Ref.	Part Number	Qty.	Description
1	116-2661	1	Harness-Wire ●
2	321-4	1	Screw-HH 1/4-20 X 3/4
3	1-323430	1	Module-Interlock
4	1-513762	1	Clip-Loom 1/2
5	3256-22	1	Washer-1/4 Sae
6	3296-42	1	Nut-Nyloc 1/4-20
7	1-543296	1	Grommet
8	1-403121	1	Switch & Key (Includes Nut & Washer)
9	33094-00	1	Washer
10	33114-016	1	Screw-HH M8-1.25 X 16Mm
11	1-513051	1	Switch-N.O.
12	1-633181	1	Plate-Tapped
14	3290-500	2	Screw-PPH #10-24 X 5/8
15	1-303287	3	Tie-Cable 5 1/2 (Small)
16	1-303287	2	Tie-Cable 5 1/2 (Small)
17	103-0498	1	Nut-Ignition

● Use dielectric grease on all unsealed connectors and terminals only. Do not apply in sealed connectors.

Notes:

EXMARK® MAINTENANCE

MAXIMIZE THE PERFORMANCE OF YOUR EXMARK.

4-CYCLE PREMIUM ENGINE OIL
Part No. 116-3373

Both SAE 30 and SAE 10W-30 in one bottle.

Contains increased levels of zinc and phosphorus for better lubricity.

No Viscosity Index Improvers that tend to shear down in high heat.

Synthetic formulation.

Gas & Diesel compatible.

Anti-corrosion additives.


API 'SL' and JASO rated with wet clutch compatibility for other machines.

PREMIUM HYDRO OIL
Part No. 109-9828

Commercial quality for tough, high-heat conditions.

Designed specifically for zero-turn mower hydraulic systems.

Superior shear resistance under heavy loads.



Available from your local Exmark dealer. Find your closest dealer at exmark.com

EXMARK ACCESSORIES AND OPTIONS*

MID-MOUNT RIDING ACCESSORIES AND OPTIONS

CUSTOM RIDE SEAT SUSPENSION SYSTEM
FULL SUSPENSION SEAT
DECK LIFT ASSIST KIT
HITCH KIT
LIGHT KIT
12V POWER PORT
MICRO-MULCH SYSTEM
OPERATOR CONTROLLED DISCHARGE
SUN SHADE
TRASH CONTAINER
TURF STRIPER
ULTRA VAC COLLECTION SYSTEM
ULTRA VAC QUICK DISPOSAL SYSTEM

OUT-FRONT RIDING ACCESSORIES AND OPTIONS

CUSTOM RIDE SEAT SUSPENSION SYSTEM
DUAL-TAIL WHEEL
FLOOR PAN EXTENDER
HITCH KIT
LIGHT KIT
MICRO-MULCH SYSTEM
ROLL OVER PROTECTION SYSTEM (ROPS)
SNOW BLADE
SNOWBLOWER
SUN SHADE
TRASH CONTAINER
ULTRA VAC COLLECTION SYSTEM
ULTRA VAC QUICK DISPOSAL SYSTEM
WEATHER CAB

WALK-BEHIND ACCESSORIES AND OPTIONS

GRASS CATCHER
MICRO-MULCH SYSTEM
TURF STRIPER
STANDON

*Some accessories and options not available for some models.

Place Model No. and Serial No. Label Here (Included in the Literature Pack) or Fill in Below

Model No. _____

Serial No. _____

Date Purchased _____

Engine Model No. and Spec. No. _____

Engine Serial No. (E/No) _____

© 2015 Exmark Mfg. Co., Inc.
All Rights Reserved

Industrial Park Box 808
Beatrice, NE 68310
(402) 223-6300
Fax (402) 223-5489

Part No. 4502-562 Rev. A
Printed in the USA.





www.exmark.com