




VANTAGE® S-SERIES

Model No. VTS541CKA36300—Serial No. 316000000 and Up

Picture below may not reflect actual product.



Parts Manual

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required	HLH: hex lag head	PTH: phillips truss head
ASM: assembly	HOC: height-of-cut	PTO: power-take-off
BBC: blade brake control	HP: high pressure	RH: right hand
BHTF: button head thread forming	HSBH: hex socket button head	ROPS: roll-over protection system
CARR: carriage	HSFH: hex socket flat head	RRB: rear roller brush
CCW: counter clockwise	HSH: hex socket head	SFH: slotted fillister head
CW: clockwise	HWH: hex washer head	SHH: slotted hex head
DEG: degrees	HWHTF: hex washer head thread forming	SHWH: slotted hex washer head
DPA: Dual Point Adjustment	HYD: hydraulic	SPH: slotted pan head
ECM: electronic control module	LH: left hand	SQH: square head
EXT: external	LP: low pressure	SRH: slotted round head
FH: flat head	LPG: Liquefied Petroleum Gas	STD: standard
GA: gauge	NI: nylon insert	TAP: self tapping
HD: heavy-duty	NPTF: national pipe thread fine	TTH: torx truss head
HF: hex flange	PFH: phillips flat head	
HH: hex head	PPH: phillips pan head	
HHF: hex head flange	PPHTF: phillips pan head thread forming	
HHFTF: hex head flange thread forming	PRH: phillips round head	
HJ: hex jam		

Touch Up Paint

Exmark black touch up spray paint – gloss black.

Exmark red touch up paint (spray paint – P/N 1-850337 - .6 oz liquid bottle – P/N 103-9140).




If your Exmark dealer does not have the Exmark part in stock, Exmark will get the parts to the dealer the next business day or the part will be FREE Guaranteed!! (Some restrictions apply. See your participating Exmark Dealer for details.)

Contents

Complete Deck Assembly.....	4
Deck Assembly.....	6
Deck W/Decals Assembly No. 116-3662.....	8
Idler Arm Assembly No. 116-3680.....	10
Main Frame Assembly.....	12
Control Tower W/Decals Assembly No. 116-6323.....	14
Wheel and Bearing Assembly No. 112-3810.....	16
Park Brake Assembly.....	18
Brake Linkage Assembly No. 116-4166.....	20
Deck Lift Assembly.....	22
Height of Cut Link Assembly No. 116-3975.....	24
Platform Assembly.....	26
Cushion Assembly No. 126-1210.....	28
Platform Assembly No. 116-3523.....	30
Ground Drive Assembly.....	32
Pump Idler Assembly No. 116-9980.....	34
Control Assembly.....	36
Vertical Adjust Link Assembly No. 116-4210.....	38
LH Tracking Control Linkage Assembly No. 116-4213.....	40
RH Tracking Control Linkage Assembly No. 116-4214.....	42
Engine Assembly.....	44
Fuel Tank Mounting Assembly.....	46
Fuel Tank Assembly No. 116-4577.....	48
Electrical Assembly.....	50


Complete Deck Assembly



Complete Deck Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-4301	1	ASM,Deck Complete 363

Deck Assembly




Deck Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-3662	1	Deck ASM - 36	15	116-0675	2	Sheave, Blade Drive 6.50 ■
2	116-4244-01	1	Baffle-Dogleg	16	116-7306	2	Nut-Hex
3	3230-16	2	Bolt-Carriage 5/16-18 X 7/8	17	3231-5	1	Bolt-Carriage 3/8-16 X 1 3/4
4	3230-18	2	Bolt-Carriage 5/16-18 X 5/8	18	43-0940	1	Spacer
5	104-8300	4	Nut-Nyloc 5/16-18 Flg	19	93-1622	1	Pulley-Idler
6	116-3680	1	Idler Arm ASM -	20	109-2872	1	Spacer-Pulley
7	116-6317	1	Spring-Extension	21	116-3592	1	Pulley-Idler
8	116-3344	2	ASM-Cutter Hsg With Bearings	22	3231-31	1	Bolt-Carriage 3/8-16 X 2 1/2
8:2	116-0720	2	Bearing-Ball	23	103-2916	1	Guard-Top
8:3	116-3312	1	Spacer-Bearing	24	116-3675-01	1	Push-Tower, LH 36
9	116-3342	2	ASM-Spindle And Seal ■	25	116-3676-01	1	Push-Tower, RH 36
10	103-6402	2	Blade-Notched	26	116-3703	1	Belt-V
10	103-6397	2	Blade, Extreme	27	116-1502	1	Bolt-Carriage Shoulder 3/8-16 X 3 1/2
10	103-6392	2	Blade, Mulching ●	28	116-4230	1	Chute - Discharge ASM
10	103-6387	2	Blade, Low Lift	28:1	109-2738	1	Chute, Discharge
10	103-6382	2	Blade, Solid	28:2	116-4229-01	1	Bracket-Chute, Discharge
11	103-3037	2	Bushing, Splined	28:3	3231-22	3	Bolt-Carriage 3/8-16 X 1
12	109-9220	2	Screw-Sems 1/2-20 X 2.19	28:4	109-6658	3	Nut-Nyloc 3/8-16 Flg
13	116-1286	2	Guard, Bearing Top .989	29	3231-28	6	Bolt-Carriage 3/8-16 X 1 1/4
14	109-6658	21	Nut-Nyloc 3/8-16 Flg	30	103-2802	2	Washer-Spring Disc 3/4

● Requires installation of mulch kit for proper mulching. See your Exmark dealer for details.

■ Apply Mobil HTS grease (P/N 103-5217 1.5 oz packet) (or a food-grade anti-seize). See operator's manual for locations.

Deck W/Decals Assembly No. 116-3662




Deck W/Decals Assembly No. 116-3662 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	112-8760	1	Decal-Danger
3	116-8283	1	Decal-Bolt Torque
4	116-4298	1	Decal-Belt Routing 36

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	126-6745	1	Decal-Ultracut 36 Series 3
6	121-6049	1	Decal-Danger

Idler Arm Assembly No. 116-3680




Idler Arm Assembly No. 116-3680 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	106-7159	2	O-Ring
3	32120-10	2	Ring-Retaining
4	103-3504	2	Bearing-Spherical

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	103-3506	1	Seal-Single Lip
6	103-3505	1	Seal-Double Lip


Main Frame Assembly



Main Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-4650-01	1	Frame ASM	14	116-8739	1	Muffler Guard ASM
2	1-811010	2	Plug	14:2	106-5517	1	Decal-Warning, Hot Surface
3	116-6323	1	Control Tower ASM	15	119-7303-01	2	Bracket-Mounting, Guard
4	108-3742	4	Screw-HH Flg 3/8-16 X 2	16	3231-31	4	Bolt-Carriage 3/8-16 X 2 1/2
5	121-1760	4	Spacer	17	32128-21	4	Nut-3/8-16 Flanged Side Lock
6	104-8301	4	Nut-Nyloc 3/8-16 Flg	18	2412-87	1	Clamp-Cable
7	1-543509	4	Cone-Bearing Tapered Roller	19	321-4	1	Screw-HH 1/4-20 X 3/4
8	116-5647	2	Seal-Grease	20	104-7201	1	Nut-Nyloc 1/4-20 Flg
9	121-7988-01	2	Fork-Caster	22	126-7200	1	Decal-Vantage Logo
10	1-633508	6	Washer-Spring Disc	25	126-4345	1	Decal-Patent Ttco.Com
11	3296-51	2	Nut-Nyloc 3/4-10	26	32180-040	2	Clip-Harness
12	103-4882	2	Cap-Grease	28	126-6572	2	Decal-S-Series
13	112-3810	2	Wheel/Tire And Bearing ASM				

Control Tower W/Decals Assembly No. 116-6323




Control Tower W/Decals Assembly No. 116-6323 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	116-8779	1	Decal-Control Panel
3	116-8781	1	Decal-Motion Control
4	116-8780	1	Decal-Warning
5	126-7202	1	Decal-LH Panel
6	126-7203	1	Decal-RH Panel

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
7	116-8819	1	Decal-Service Aid
8	116-4270	1	Decal-Height Of Cut
9	116-8772	1	Decal-Fuse
10	126-6971	2	Decal-Exmark Logo

Wheel and Bearing Assembly No. 112-3810



Wheel and Bearing Assembly No. 112-3810 (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Wheel And Bearing ASM ●
1:1	1-633585	2	Bearing-Cone, Taper
1:2	103-0063	2	Seal-Caster
1:3	103-3051	2	Spacer-Nut ■
1:4	103-3157	1	Axle-Caster

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1:5	110-9965	1	Wheel And Tire ASM
2	103-2768	2	Guard-Seal
3	3296-45	1	Nut-Lock, NI
4	325-20	1	Screw-HH

● Not serviced separately

■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on spacer nut


Park Brake Assembly



Park Brake Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	3231-10	1	Bolt-Carriage 3/8-16 X 3	14	116-4600-03	1	Bar-Brake
2	116-4928	1	Bushing-Handle	15	614672	1	Screw-Shoulder 3/8-16 X 1.295
3	116-4680	1	Handle-W/Grip ASM	16	5-0652	1	Spacer
3:2	1-633268	1	Grip-Lever	17	104-8301	2	Nut-Nyloc 3/8-16 Flg
4	109-6658	4	Nut-Nyloc 3/8-16 Flg	18	116-4166	1	ASM-Brake Linkage
5	116-4929	3	Bushing-Flanged	19	103-2399	1	Pin-Clevis Spring 3/8
6	116-4806	1	Arm-Brake Bellcrank	20	92-5791	1	Spacer
7	98-5975	1	Washer-Spring Disc 3/8	21	117-9684	1	Spacer
8	323-8	4	Screw-HH 3/8-16 X 1 1/2	22	3256-24	1	Washer-3/8 Sae
9	116-4805	1	Link-Brake Handle	23	323-20	1	Screw-HH 3/8-16 X 3-1/4
10	116-4681-01	1	Bracket-Brake Mount, LH	24	117-9683	1	Spacer
11	116-4682-01	1	Bracket-Brake Mount, RH	25	108-4052	1	Spring-Torsion
12	322-4	8	Screw-HH 5/16-18 X 7/8	26	1-373034	1	Washer
13	104-8300	8	Nut-Nyloc 5/16-18 Flg				

Brake Linkage Assembly No. 116-4166




Brake Linkage Assembly No. 116-4166 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-4818	1	Rod-Brake Linkage
2	103-1167	1	Joint-Ball End, .38X.38Fe LH

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	1-633131	1	Yoke-Linkage, Brake
4	3220-3	1	Nut-Jam 3/8-24
5	3220-16	1	Nut-Jam 3/8-24 LH


Deck Lift Assembly



Deck Lift Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-4638-01	2	Support-Bearing	27	116-4661-03	1	Link-Decklift, RH
2	109-9410	2	Bearing-Cross Shaft, Front	28	3256-29	3	Washer-7/8 Sae
3	116-3725-01	1	Rear Crossshaft ASM	29	32151-103	3	E-Ring
4	116-3733-01	2	Cover-Bearing Support	30	116-5602	1	ASM-HOC Handle
5	325-20	2	Screw-HH 1/2-13 X 6	31	116-4021	1	Bearing-HOC Pivot
6	99-5107	3	Nut-Lock 1/2-13	32	323-42	1	Screw-HH 3/8-16 X 3 3/4
7	100-1668	2	Screw-Flange	34	114-1878-03	1	Lever-HOC
9	116-4663-01	1	Decklift Arm ASM-LH	35	1-633268	1	Grip-Lever
10	116-4664-01	1	Decklift Arm ASM-RH	36	66-0561	1	Screw-Shoulder
11	302-5	3	Zerk 1/4-28 Str Thrd Forming	37	3256-26	1	Washer-1/2 Sae
12	237-77	2	O Ring	38	65-9940	1	Spring
13	69-8910	2	Washer	39	111044	2	Bushing
14	32120-2	2	Ring-Retaining	40	116-3971	1	Bracket-HOC
15	109-9066	4	Yoke-Adjust, Deck	41	323-7	1	Screw-HH 3/8-16 X 1 1/4
16	3218-2	8	Nut-Jam 5/16-18	42	3231-22	1	Bolt-Carriage 3/8-16 X 1
17	3274-18	4	Screw-Sh 5/16-18 X 1 1/4	43	3296-59	2	Nut-Nyloc 3/8-16 Thin
18	116-2428	2	Bushing-Flanged	44	116-3975	1	HOC Link ASM
19	3256-4	2	Washer-3/8 Std	45	327-22	1	Screw-HH
20	109-9065	2	Screw-HH 7/16-14 X 2	46	3296-53	2	Nut-Nyloc 5/8-11
21	32128-37	4	Nut-Whizlock 7/16-14	47	327-29	1	Screw-HH
22	116-0756	2	Deck Lift Chain ASM	48	116-0886	1	Extension Spring ASM
22:1	1-633447	1	Chain-Lift, Deck	49	98-5975	1	Washer-Spring Disc 3/8
22:2	109-9065	1	Screw-HH 7/16-14 X 2	50	323-58	1	Bolt-HH 3/8-16 X 6 Tap
22:3	32128-37	1	Nut-Whizlock 7/16-14	51	116-3124	1	Skid-Handle, Lift
23	109-9840	3	Screw-Hex Flange 3/8-16 X .80	52	32144-11	2	Screw-HWH 5/16-18 X 3/4 Tf
24	104-8301	4	Nut-Nyloc 3/8-16 Flg	53	116-4702	1	Bushing-Flanged
25	116-2909	3	Bearing-Flange	54	325-8	1	Screw-HH 1/2-13 X 1 1/4
26	116-3972-03	1	Link-Decklift, LH	55	3256-5	1	Washer-7/16 Std

Height of Cut Link Assembly No. 116-3975




Height of Cut Link Assembly No. 116-3975 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	1-633029	1	Balljoint
2	117-5291	1	Balljoint-Spherical
3	3220-6	1	Nut-Jam

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	117-5293	1	Nut-Jam
5	116-5488	1	Link-Height Of Cut


Platform Assembly



Platform Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	126-1210	1	ASM, Cushion	4	3229-11	1	Bolt-Carriage 1/4-20 X 5/8
2	116-3523	1	Platform ASM	5	104-7201	1	Nut-Nyloc 1/4-20 Flg
3	119-7312	1	Plate-Striker				


Cushion Assembly No. 126-1210



Cushion Assembly No. 126-1210 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-2757-03	1	Hinge-Pad	8	3290-355	2	Pin-Hair
2	116-2061-03	1	Hinge-Pad	9	114-0463	4	Washer-Friction, Composite
3	116-1790	1	Pad,Grey Cushion	10	111044	4	Bushing
4	126-0362	1	Shield, Rear	11	114-1915-03	2	Link-Pad
5	3256-23	4	Washer-5/16 Sae	12	3231-27	2	Bolt-Carriage 3/8-16 X 7/8
6	116-0648	4	Screw-HH 5/16-18 X 1 W/Patch	13	3256-4	4	Washer-3/8 Std
7	116-2886	2	Slide-Bushing	14	3296-59	4	Nut-Nyloc 3/8-16 Thin
				15	3231-2	2	Bolt-Carriage 3/8-16 X 1

Platform Assembly No. 116-3523




Platform Assembly No. 116-3523 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	132-9403-03	1	Platform ASM [black]	9	114-5349	1	Mat-Foot
2	114-1925	2	Bumper-Rubber	10	114-1920-03	1	Clamp-Shield
3	114-1926	2	Bumper-Rubber	11	32144-70	2	Screw-HWH 5/16-18 X 3/4 Tf
4	104-8300	4	Nut-Nyloc 5/16-18 Flg	12	109-8788	2	Bushing-Flanged
5	119-8650	1	Pin-Latch ●	14	83-1040	2	Washer
6	114-5348	1	Spring	15	323-7	2	Screw-HH 3/8-16 X 1 1/4
7	1-603175	1	Knob-Ball	16	104-8301	2	Nut-Nyloc 3/8-16 Flg
8	126-6991	1	Decal-Exmark Logo				

● Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

Ground Drive Assembly



Ground Drive Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	104-1171	2	HYD Motor ASM	28	103-2888	1	Head-Filter
2	3257-8	2	Key-Woodruff	29	109-4180	1	Element, Oil Filter
3	85-7310	2	Nut-Motor, Wheel	30	116-4343	2	Rod-Reservoir Stand
4	325-10	8	Screw-HH	31	1-603991	4	Fitting-Straight
5	32128-23	8	Nut-HF	31:1	237-80	1	O-Ring
6	105-0800	2	Wheel Hub ASM	31:2	1-603992	1	O-Ring
6:2	10-6830	4	Stud-Type, Drive	32	1-603990	4	Fitting-Straight
7	116-4587	2	Wheel/Tire ASM	32:1	1-603920	1	O-Ring
7:1	116-4605	1	Rim-8 Inch	32:2	1-603992	1	O-Ring
7:2	116-4606	1	Tire	33	100-4887	2	Fitting-Barbed, 90 DEG
7:3	232-27	1	Stem-Valve	33:1	237-42	1	O-Ring
8	242-50	8	Nut-Lug	34	103-2155	2	Fitting-90 DEG
9	116-8745-01	1	Base, Engine [red]	34:1	1-603921	1	O-Ring
10	323-18	4	Screw-HH	34:2	103-1020	1	O-Ring
11	104-8301	6	Nut-Flange, NI	35	103-2156	4	Fitting-Straight
12	116-2572	1	Pump - Hydraulic	35:1	1-603921	1	O-Ring
13	116-4635	1	Pump-Hydraulic	35:2	103-1020	1	O-Ring
14	3232-3	4	Bolt-CARR	36	116-5526	1	Hose-Hardline
16	114-8417	4	Nut-HF, NI	37	116-5525	1	Hose-Hardline
17	1-807272	2	Key	38	116-5523	1	Hose-Hardline
18	105-5648	2	Pulley-Pump ■	39	116-5524	1	Hose-Hardline
19	3241-5	4	Screw-Set ◆	40	116-5804	2	Clamp, Stauff 212,7/12,7 W/Retainers
20	116-9980	1	Pump Idler ASM	41	116-5145	1	Hose-ASM Charge
21	116-8526	1	Anchor, Spring	42	116-4252	1	Hose ASM-HYD LP 3/8X14.4
22	119-0174	1	Belt-V	43	116-5460	1	Hose ASM - HYD 3/8
23	108-4056	1	Spring-Extension	44	105-6245	1	Screw-Tapping
24	116-2066	1	ASM,Reservoir W/Decals ▲	45	1-633396	1	Clip-Loom
24:1		1	Reservoir-HYD ●	46	98-5975	4	Washer-Belleville
24:1:1	103-1948	1	Cap-Reservoir, HYD	47	321-3	3	Screw-HH
24:1:2	103-1949	1	Gasket-Cap	48	1-805004	2	Washer-Lock
24:2	115-4212	1	Decal-Warning	50	126-2130	2	Decal-Wheel Torque
25	116-4319-01	1	Plate-Filter Mount				
26	117-8304	4	Screw-HHF				
27	104-7201	1	Nut-Flange, NI				


● Not serviced separately

▲ Use Exmark Premium Hydro Oil P/N 109-9828 (32oz)

◆ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

■ Apply anti-seize compound in bore.


Pump Idler Assembly No. 116-9980



Pump Idler Assembly No. 116-9980 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-8717	1	Idler Arm ASM	6	1-373034	1	Washer
2	109-8054	2	Bushing-Flanged	7	104-8301	2	Nut-Nyloc 3/8-16 Flg
3	116-8718	1	Spacer, Pivot	8	93-1622	1	Pulley-Idler
4	3256-24	3	Washer-3/8 Sae	9	323-9	1	Screw-HH 3/8-16 X 1 3/4
5	323-13	1	Screw-HH 3/8-16 X 2 3/4				


Control Assembly



Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-4195	1	Lever ASM, LH	20	116-4277	1	Control-Choke
1:2	116-2357	1	Grip-Handle, Control	21	1-807533	4	Bolt-Carriage #10-24 X 5/8
2	126-1943-03	1	Weld, Motion Control	22	3290-148	4	Nut-Whizlock #10-24
3	116-9815	1	ASM, Lever W/ Grip, Rt	23	2412-87	1	Clamp-Cable
3:2	116-2357	1	Grip-Handle, Control	24	3229-1	3	Bolt-Carriage 1/4-20 X 3/4
4	116-6985-03	1	Tube ASM, Front Speed Control [	25	116-4740	1	Bellcrank Link ASM
5	103-9928	10	Bearing	26	116-4203	1	Pin-Bellcrank Link Retaining
6	116-4197	2	Shaft-Pivot, Motion Control	27	116-4737	1	Arm-Pump Control
7	116-4198	2	Spacer-Shaft, Drive Lever	28	116-7000	1	Arm-Pump Control RH
8	117-8304	3	Screw-Hex Flange 1/4-20 X 3/4	29	322-4	4	Screw-HH 5/16-18 X 7/8
9	114-0409	1	HOC Pin ASM	30	104-8300	8	Nut-Nyloc 5/16-18 Flg
10	107-1664	2	Lever ASM	31	116-4205	2	Bellcrank-Lower
10:1	106-3239	1	Screw-Lock	32	116-4208	2	Link-Bellcrank, Pump
10:2	107-1644	1	Cap-Lock	33	116-2670	4	Screw-Shoulder HHF 5/16-18 X .96
10:3	106-3241	1	Lever-Lock	34	116-4210	2	Vertical Adjust Link
10:4	3296-29	1	Nut-Nyloc 5/16-18	35	32151-86	2	E-Ring
11	116-2319	2	Spacer-Clamp	36	116-4213	1	Linkage-Tracking Control, LH
12	3296-45	2	Nut-Nyloc 1/2-13 Thin	37	116-4214	1	Linkage-Tracking Control, RH
13	114-0239	1	Screw-Shoulder 5/16-18 X 1/2	38	323-7	4	Screw-HH 3/8-16 X 1 1/4
14	3296-47	1	Nut-Nyloc 5/16-18 Thin	39	104-8301	4	Nut-Nyloc 3/8-16 Flg
15	126-1499	1	Cam	40	321-5	2	Screw-HH 1/4-20 X 7/8
16	3256-22	2	Washer-1/4 Sae	41	116-4739	2	Clamp-Switch
17	104-7201	5	Nut-Nyloc 1/4-20 Flg	42	116-2832	2	Actuator-Switch, Reed
18	114-0249	1	Spring-Extension	43	52-2480	2	Spacer-Wheel
19	116-4276	1	Control-Throttle				

Vertical Adjust Link Assembly No. 116-4210




Vertical Adjust Link Assembly No. 116-4210 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	2411-41	1	Rod End-Ball Joint
2	104-4013	1	Joint-Ball, LH
3	3220-1	1	Nut-Jam 1/4-28

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	104-3941	1	Nut-Jam
5	116-4209	1	Rod-Vertical Adjust

LH Tracking Control Linkage Assembly No. 116-4213




LH Tracking Control Linkage Assembly No. 116-4213 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	103-0608	2	Balljoint
2	116-4742	1	Link-Lower, Motion Control
3	116-4755	1	Rod-Adjustment

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	116-7560	2	Spring-Compression
5	3220-3	1	Nut-Jam 3/8-24

RH Tracking Control Linkage Assembly No. 116-4214




RH Tracking Control Linkage

Assembly No. 116-4214 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	103-0608	2	Balljoint
2	116-4742	1	Link-Lower, Motion Control
3	116-4755	1	Rod-Adjustment

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	3220-16	1	Nut-Jam 3/8-24 LH
5	3220-3	2	Nut-Jam 3/8-24

Engine Assembly



Engine Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1		1	Engine-Kawasaki, Fs541V ■◆	13	116-3610	1	Pulley ▲
1:1	92-2153	1	Spark Plug	14	1-807259	1	Key-Machine 1/4 X 1/4 X 1
1:2	119-5852	1	Filter-Oil	15	116-4395	1	Clutch-175 Ft-Lb ▲
1:3	120-2235	1	Filter-Fuel	16	107-4136	1	Washer
1:4	120-7447	1	Element-Filter, Air	17	1-603610	1	Washer-Spring Disc 7/16
2	1-653313	2	Gasket-Exhaust	18	3212-10	1	Screw-HH 7/16-20 X 2 1/2 ○
3	116-8746	1	Muffler	19	116-3565-01	1	Anchor-Clutch
4	114-3550	4	Washer-Lock, Spring	20	105-6245	1	Screw-Tapping
5	114-3549	4	Nut-M8	22	116-6126	1	Valve-Drain Oil □
6	116-4752	1	Bracket-Muffler Mount, LH	23	33094-00	1	Washer
7	116-4750	1	Bracket-Muffler Mount, RH	24	98-5975	4	Washer-Spring Disc 3/8
8	104-7658	2	Spacer	25	323-7	4	Screw-HH 3/8-16 X 1 1/4
9	3234-29	2	Screw-HH Flg 5/16-18 X 1	26	3290-378	1	Tie-Cable
10	32128-25	2	Nut-Hex 5/16-18 Side Lock	27	116-4751	1	Guard-Cable, Spark Plug
11	3253-4	4	Washer-Lock 5/16	28	32144-10	2	Screw-HWH 1/4-20 X .62
12	33114-016	5	Screw-HH M8-1.25 X 16Mm	29	1-303287	1	Tie-Cable 5 1/2 (Small)
				99	103-1964	1	Hose-Drain, Oil ●

● Not illustrated

▲ Apply anti-seize compound in bore.


□ Use a Teflon Pipe Sealant or equivalent on threads.

○ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.

■ Not serviced separately

◆ Obtain parts from www.kawpowerepc.com


Fuel Tank Mounting Assembly



Fuel Tank Mounting Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	116-4577	1	Tank ASM- Exmark	15	104-8300	2	Nut-Nyloc 5/16-18 Flg
2	112-7069	2	Grommet	16	32180-040	2	Clip-Harness
3	107-9297	1	Hose-Fuel	17	116-5055-03	1	Bracket, Carb Canister
4	1-603770	1	Valve-Fuel	19	114-0292	1	Bracket-Canister, Carbon
5	110-1872	1	Hose-Fuel	20	117-1221	1	Canister-Carbon, 800Cc
6	2412-98	10	Clamp-Hose	21	116-5053	1	Hose-Fuel .25 X 60.00, J30R7
7	1-303287	1	Tie-Cable 5 1/2 (Small)	22	104-7201	2	Nut-Nyloc 1/4-20 Flg
8	116-3088	1	Bracket-Tank	23	116-5879	2	Screw-CARR
8:2	116-8775	1	Decal-Fill, Fuel	24	116-2232	1	Valve-Control, Vacuum
10	32144-70	4	Screw-HWH 5/16-18 X 3/4 Tf	25	119-8502	1	Hose-Vent, Formed
11	116-5054	1	Vent ASM	26	119-8501	1	Hose-Vent, Formed
12	3290-378	5	Tie-Cable	27	116-2469	1	Strap-Velcro, Cable Tie


Fuel Tank Assembly No. 116-4577



Fuel Tank Assembly No. 116-4577 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	46-6560	3	Bushing	7	116-3408	1	Fitting-Fuel, Bulkhead
3	1-643172	3	Elbow-90 DEG	99	116-7264	1	Kit, Vantage Fuel Gage Replacement
4	95-8972	1	Grommet				
6	126-1789	1	Cap-Fuel, Ratcheting				

Electrical Assembly



Electrical Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	116-4756-01	1	Cover-Battery	20:13	116-0053	1	Cap-Plug
3	1-633651	2	Bolt-Holddown	20:14	103-3895	1	Diode
4	3256-22	3	Washer-1/4 Sae	21	3229-20	2	Screw-CARR
5	1-543792	2	Wingnut-Nyloc 1/4-20	22	3290-148	2	Nut-Whizlock #10-24
6	117-1197	1	Solenoid	23	3256-23	2	Washer-5/16 Sae
7	32144-4	2	Screw-HWH 1/4-20 X 1/2 Taptite	24	322-3	2	Screw-HH 5/16-18 X 3/4
8	114-0279	1	Switch-PTO	25	109-5715	2	Nut-Hex Flange 5/16-18
9	117-2222	1	Switch-Ignition	26	109-7608	1	Cable, Battery (+)
10	117-3886	1	Module-Hour Meter	26:1	109-2407	1	Insulator-Battery
11	82-2190	1	Switch	26:2	1-543393	1	Insulator-Solenoid
14	119-8231	1	Switch-Plunger, Nc, Spst	27	54-3093	1	Cable-Battery, Negative
16	116-4739	2	Clamp-Switch	28	105-1853	1	Clamp-Hose
17	116-2833	1	Harness-Switch, Reed	29	106-8268	1	Cable-Battery, Red
18	3229-1	1	Bolt-Carriage 1/4-20 X 3/4	30	3253-4	2	Washer-Lock 5/16
19	3296-56	1	Nut-Nyloc 1/4-20 Thin	31	3220-2	2	Nut-Jam 5/16-24
20	126-1214	1	Harness, Wire ●	32	32128-33	1	Nut-Whizlock 1/4-20
20:7	109103	1	Fuse-Blade, 30 Amp	33	117-2781	1	Grommet
20:8	109102	1	Fuse-Blade, 25 Amp	34	103-2106	1	Key-Exmark Logo
20:9	218-578	1	Fuse-Blade, 10 Amp	35	1-303287	3	Tie-Cable 5 1/2 (Small)
				36	116-4388	2	Plate-Spacer

● Use dielectric grease on all unsealed connectors and terminals only. Do not apply in sealed connectors.

Notes:

Notes:

Notes:



MAXIMIZE THE PERFORMANCE OF YOUR EXMARK MACHINE.



EXMARK® PREMIUM ENGINE OIL

Exmark now offers a family of engine oil viscosities to perform well in any environment. Each viscosity has the same synthetic formulation to give you what you need in punishing conditions. We designed each grade to the highest quality, making it ideal even for diesel applications. Coupled with Exmark Premium Fuel Treatment, we have the performance products to make your machine hum.

EXMARK PREMIUM ENGINE OIL SAE 30/10W-30

- Meets zero shear requirements of a straight grade SAE 30 as well as the cold temp properties of a 10W-30.
- Most versatile oil in the industry.
- Superior corrosion protection over conventional oil - even in corrosive, humid environments.

EXMARK PREMIUM ENGINE OIL SAE 20W-50

- Perfect for your big block engine, or any application in severe service.
- Same full synthetic formulation as all other Exmark Premium viscosities.
- Also effective for use in severe service small block engines.

EXMARK PREMIUM ENGINE OIL SAE 10W-50

- Full synthetic formulation gives you peak performance. Don't settle for less.
- Wide span multi-grade combines easy starting in cold weather with maximum protection in high temperature operation.
- Reduce friction & wear over standard mineral formulations.

EXMARK PREMIUM ENGINE OIL SAE 0W-40

- The perfect choice for when the weather turns cold or unpredictable, and your Exmark UTV has to perform.
- Commercial quality for severe service.
- Advanced additive package helps prevent corrosion from long-term storage.

EXMARK PREMIUM ENGINE OIL UTV FORMULATION

- 4-cycle high-temp formulation.
- Heavier viscosity, full synthetic, perfect for your UTV.

EXMARK PREMIUM UTV EXTREME CONDITIONS GEAR OIL

- SAE 80W-90, designed to keep your UTV performing at its peak.
- Shear stable, hypoid gear lube.
- Includes a premium additive system to combat wear, oxidation, rust & corrosion.

Available from your local Exmark dealer. Find your closest dealer at exmark.com

EXMARK ACCESSORIES AND OPTIONS*

MID-MOUNT RIDING ACCESSORIES AND OPTIONS

CUSTOM RIDE SEAT SUSPENSION SYSTEM	OPERATOR CONTROLLED DISCHARGE
FULL SUSPENSION SEAT	SUN SHADE
DECK LIFT ASSIST KIT	TRASH CONTAINER
HITCH KIT	TURF STRIPER
LIGHT KIT	ULTRA VAC COLLECTION SYSTEM
12V POWER PORT	ULTRA VAC QUICK DISPOSAL SYSTEM
MICRO-MULCH SYSTEM	

OUT-FRONT RIDING ACCESSORIES AND OPTIONS

CUSTOM RIDE SEAT SUSPENSION SYSTEM	SNOW BLADE
DUAL-TAIL WHEEL	SNOWBLOWER
FLOOR PAN EXTENDER	SUN SHADE
HITCH KIT	TRASH CONTAINER
LIGHT KIT	ULTRA VAC COLLECTION SYSTEM
MICRO-MULCH SYSTEM	ULTRA VAC QUICK DISPOSAL SYSTEM
ROLL OVER PROTECTION SYSTEM (ROPS)	WEATHER CAB

WALK-BEHIND ACCESSORIES AND OPTIONS

GRASS CATCHER	TURF STRIPER
MICRO-MULCH SYSTEM	STANDON

*Some accessories and options not available for some models.

Place Model No. and Serial No.
Label Here (Included in the Literature
Pack) or Fill in Below

Model No. _____

Serial No. _____

Date Purchased _____

Engine Model No. and Spec. No. _____

Engine Serial No. (E/No) _____

© 2015 Exmark Mfg. Co., Inc.
Industrial Park Box 808
Beatrice, NE 68310
All Rights Reserved

Part No. 4502-639 Rev. A
(402) 223-6300
Fax (402) 223-5489
Printed in the USA.



* 4 5 0 2 - 6 3 9 * A

www.exmark.com