




# **LAZER Z<sup>®</sup> X-SERIES**

**Model No. LZX940EKC72RT0—Serial No. 316000000 and Up**

Picture below may not reflect actual product.



# **Parts Manual**

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

|                                              |                                                |                                          |
|----------------------------------------------|------------------------------------------------|------------------------------------------|
| <b>AR:</b> as required                       | <b>HLH:</b> hex lag head                       | <b>PTH:</b> phillips truss head          |
| <b>ASM:</b> assembly                         | <b>HOC:</b> height-of-cut                      | <b>PTO:</b> power-take-off               |
| <b>BBC:</b> blade brake control              | <b>HP:</b> high pressure                       | <b>RH:</b> right hand                    |
| <b>BHTF:</b> button head thread forming      | <b>HSBH:</b> hex socket button head            | <b>ROPS:</b> roll-over protection system |
| <b>CARR:</b> carriage                        | <b>HSFH:</b> hex socket flat head              | <b>RRB:</b> rear roller brush            |
| <b>CCW:</b> counter clockwise                | <b>HSH:</b> hex socket head                    | <b>SFH:</b> slotted fillister head       |
| <b>CW:</b> clockwise                         | <b>HWH:</b> hex washer head                    | <b>SHH:</b> slotted hex head             |
| <b>DEG:</b> degrees                          | <b>HWHTF:</b> hex washer head thread forming   | <b>SHWH:</b> slotted hex washer head     |
| <b>DPA:</b> Dual Point Adjustment            | <b>HYD:</b> hydraulic                          | <b>SPH:</b> slotted pan head             |
| <b>ECM:</b> electronic control module        | <b>LH:</b> left hand                           | <b>SQH:</b> square head                  |
| <b>EXT:</b> external                         | <b>LP:</b> low pressure                        | <b>SRH:</b> slotted round head           |
| <b>FH:</b> flat head                         | <b>LPG:</b> Liquefied Petroleum Gas            | <b>STD:</b> standard                     |
| <b>GA:</b> gauge                             | <b>NI:</b> nylon insert                        | <b>TAP:</b> self tapping                 |
| <b>HD:</b> heavy-duty                        | <b>NPTF:</b> national pipe thread fine         | <b>TTH:</b> torx truss head              |
| <b>HF:</b> hex flange                        | <b>PFH:</b> phillips flat head                 |                                          |
| <b>HH:</b> hex head                          | <b>PPH:</b> phillips pan head                  |                                          |
| <b>HHF:</b> hex head flange                  | <b>PPHTF:</b> phillips pan head thread forming |                                          |
| <b>HHFTF:</b> hex head flange thread forming | <b>PRH:</b> phillips round head                |                                          |
| <b>HJ:</b> hex jam                           |                                                |                                          |

# Touch Up Paint

Exmark black touch up spray paint – gloss black.

Exmark red touch up paint (spray paint – P/N 1-850337 - .6 oz liquid bottle – P/N 103-9140).




If your Exmark dealer does not have the Exmark part in stock, Exmark will get the parts to the dealer the next business day or the part will be FREE Guaranteed!! (Some restrictions apply. See your participating Exmark Dealer for details.)

## Contents

|                                                         |    |
|---------------------------------------------------------|----|
| Complete Deck Assembly .....                            | 4  |
| Deck Assembly .....                                     | 6  |
| Deck W/Decals Assembly No. 116-9827 .....               | 8  |
| Cutter Housing Assembly No. 103-9539 .....              | 10 |
| Idler Assembly No. 126-0853 .....                       | 12 |
| Deck Idler Assembly No. 126-1720 .....                  | 14 |
| Rear Discharge Tunnel .....                             | 16 |
| Discharge Tunnel Assembly No. 126-4933 .....            | 18 |
| Main Frame Assembly .....                               | 20 |
| X-Series Decal .....                                    | 22 |
| Roll-Over Protection System .....                       | 24 |
| Roll-Over Protection System Assembly No. 116-0230 ..... | 26 |
| Front Caster and Fork Assembly .....                    | 28 |
| Caster Wheel and Fork Assembly .....                    | 30 |
| Deck Lift Assembly .....                                | 32 |
| Height-of-Cut Assembly No. 109-7438 .....               | 34 |
| Control Assembly .....                                  | 36 |
| Motion Control Assembly .....                           | 38 |
| Rear Wheel Assembly .....                               | 40 |
| Park Brake Assembly .....                               | 42 |
| Seat Assembly .....                                     | 44 |
| Seat W/Tracks Assembly No. 116-8912 .....               | 46 |
| Fuel Assembly .....                                     | 48 |
| Fuel Tank Assembly No. 116-3979 .....                   | 50 |
| Engine Assembly .....                                   | 52 |
| Hydraulic Assembly .....                                | 54 |
| LH Hydro Assembly No. 126-1319 .....                    | 56 |
| RH Hydro Assembly No. 126-1320 .....                    | 58 |
| Pump Idler Assembly No. 116-1255 .....                  | 60 |
| Electrical Assembly .....                               | 62 |


# Complete Deck Assembly



## Complete Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|--------------------------------|
| 1           | 126-3244           | 1           | ASM-Deck Complete Rd726<br>Nlz |

# Deck Assembly




## Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>              | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                 |
|-------------|--------------------|-------------|---------------------------------|-------------|--------------------|-------------|------------------------------------|
| 1           | 116-9827           | 1           | Deck-Rd72 Nlz, W/Decals         | 19          | 302-19             | 1           | Zerk-1/4-28 Str                    |
| 2           | 108-5388           | 1           | Screw-HH 3/8-16 X 7 3/8         | 20          | 103-2916           | 1           | Guard-Top                          |
| 3           | 104-8301           | 9           | Nut-Nyloc 3/8-16 Flg            | 21          | 323-23             | 3           | Screw-HH 3/8-16 X 4-1/2            |
| 4           | 98-5967            | 1           | Spacer-Wheel                    | 22          | 126-1478           | 2           | Sheave                             |
| 5           | 1-603299           | 4           | Roller-Scalp, Anti              | 23          | 323-13             | 1           | Screw-HH 3/8-16 X 2 3/4            |
| 6           | 109-6917           | 3           | ASM,Spindle Housing             | 24          | 3234-11            | 1           | Screw-HH Flg 3/8-16 X 1            |
| 6:1         | 103-9504           | 1           | Guard, Bottom                   | 25          | 116-8501           | 1           | Belt                               |
| 6:2         | 103-9539           | 1           | Asm, Cutter Housing             | 26          | 112-1479           | 2           | Skid-Bumper, Deck                  |
| 6:3         | 109-0916           | 1           | Nut, Spindle 7/8-14             | 27          | 3231-7             | 6           | Bolt-Carriage 3/8-16 X 2 1/4       |
| 6:4         | 109-6881           | 1           | Spindle,Double Spline ●         | 28          | 109-8070           | 1           | Belt                               |
| 7           | 103-9522           | 3           | Spacer, Splined Stepped         | 29          | 98-7912            | 2           | Tube-Spanner                       |
| 8           | 109-6658           | 21          | Nut-Nyloc 3/8-16 Flg            | 30          | 1-633456           | 1           | Bushing, Idler                     |
| 9           | 109-2180           | 2           | Sheave,Blade Drive 9.00         | 31          | 116-2253           | 2           | Plug,Black Nylon 1.75              |
| 10          | 116-8193           | 2           | Sheave-Rd, Reverse Drive        | 32          | 126-1720           | 1           | Deck Idler ASM                     |
| 11          | 109-7033           | 3           | Nut-Flange 5/8-18<br>Centerlock | 33          | 116-6317           | 1           | Spring-Extension                   |
| 12          | 103-6389           | 2           | Blade, Low Lift (72")           | 34          | 116-4670           | 1           | Pulley-Idler, Flat                 |
| 12          | 103-6404           | 2           | Blade, Notched (72")            | 35          | 125-9374-01        | 1           | Cover-Reverse Drive                |
| 12          | 116-5171           | 2           | Blade-Extreme 2, 24.50"         | 36          | 116-0094           | 1           | Cover-Belt, RH                     |
| 13          | 116-8503           | 1           | Blade-Extreme 2-24.50,<br>Rd72  | 37          | 9266934            | 3           | Screw-HWH 5/16 X 1/2 Tf            |
| 13          | 116-8502           | 1           | Blade-Low Lift 24.50, Rd72      | 38          | 125-9380           | 2           | Guard-Tire                         |
| 14          | 103-3037           | 3           | Bushing, Splined                | 39          | 126-0414-01        | 2           | Support-Outer Flap                 |
| 15          | 109-9220           | 3           | Screw-Sems 1/2-20 X 2.19        | 40          | 104-8300           | 12          | Nut-Nyloc 5/16-18 Flg              |
| 16          | 109-6938           | 1           | Cover-Belt, LH                  | 41          | 3230-16            | 8           | Bolt-Carriage 5/16-18 X 7/8        |
| 17          | 126-0853           | 1           | Idler ASM                       | 42          | 3274-55            | 4           | Screw-Button Head 5/16-18<br>X 3/4 |
| 18          | 108-1921           | 1           | Spring-Torsion                  | 43          | 103-9523           | 1           | Spacer, Splined                    |

● Apply Mobil HTS grease (P/N 103-5217 1.5 oz packet) (or a food-grade anti-seize). See operator s manual for locations.

# Deck W/Decals Assembly No. 116-9827




## Deck W/Decals Assembly No. 116-9827 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|--------------------------|
| 2           | 126-6599           | 2           | Decal-Danger Thrown Obj  |
| 3           | 109-6036           | 1           | Decal-Roller, Anti-Scalp |
| 4           | 116-8283           | 1           | Decal-Bolt Torque        |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---------------------------|
| 5           | 112-9028           | 2           | Decal-Missing, Cover      |
| 6           | 126-0768           | 1           | Decal-Belt Routing Nlz Rd |
| 7           | 126-6597           | 1           | Decal, 72Rd               |


Cutter Housing Assembly No. 103-9539



## Cutter Housing Assembly No. 103-9539 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 92-5581            | 1           | Ring-Retaining         | 4           | 103-9506           | 1           | Spacer, Bearing      |
| 2           | 109-2064           | 1           | Asm, Bearing W/O-Rings | 5           | 109-0764           | 1           | Asm, Housing W/Studs |
| 3           | 103-5895           | 4           | O-Ring                 |             |                    |             |                      |

# Idler Assembly No. 126-0853




## Idler Assembly No. 126-0853 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Idler-Deck ●       |
| 2           | 106-7159           | 2           | O-Ring             |
| 3           | 32120-10           | 2           | Ring-Snap          |
| 4           | 103-3504           | 2           | Bearing-Spherical  |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 108-6544           | 1           | Spacer             |
| 6           | 103-3505           | 1           | Seal-Double Lip    |
| 7           | 103-3506           | 1           | Seal-Lip, Single   |

● Not serviced separately


# Deck Idler Assembly No. 126-1720



## Deck Idler Assembly No. 126-1720 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|------------------------|
| 1           | 43-0940            | 1           | Spacer                | 10          | 109-6658           | 2           | Nut-Flange, NI         |
| 2           | 103-2916           | 1           | Guard-Top             | 11          | 109-7409           | 1           | Screw-Shoulder, HH     |
| 3           | 103-3504           | 2           | Bearing-Spherical     | 12          | 104-3396           | 1           | Screw-HH               |
| 4           | 103-3505           | 1           | Seal-Double Lip       | 13          | 32120-10           | 2           | Ring-Snap              |
| 5           | 103-3506           | 1           | Seal-Lip, Single      | 14          | 302-19             | 1           | Fitting-Grease         |
| 6           | 116-4668           | 1           | Idler-Pulley, Flanged | 15          | 88-4590            | 1           | Bolt-Shoulder          |
| 7           | 106-7159           | 2           | O-Ring                | 16          | 104-8300           | 1           | Nut-Flange, NI         |
| 9           | 126-0423           | 1           | Pin-Spring, Anchor    | 17          | 126-1704           | 1           | Spring-Belt Guide Leaf |


# Rear Discharge Tunnel



## Rear Discharge Tunnel (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 125-9369-03        | 1           | Bracket-Discharge Mount,<br>LH | 3           | 126-4933           | 1           | Discharge Tunnel ASM    |
| 2           | 125-9370-03        | 1           | Bracket-Discharge Mount,<br>RH | 4           | 126-1705           | 2           | Bushing-Sleeve          |
|             |                    |             |                                | 5           | 325-9              | 2           | Screw-HH 1/2-13 X 2 1/4 |
|             |                    |             |                                | 6           | 99-5107            | 2           | Nut-Lock                |

# Discharge Tunnel Assembly No. 126-4933




## Discharge Tunnel Assembly No. 126-4933 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 126-4932-03        | 1           | Discharge Tunnel ASM |
| 2           | 125-9366-03        | 1           | Bracket-Flap, LH     |
| 3           | 125-9367-03        | 1           | Bracket-Flap, RH     |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 4           | 125-9368           | 2           | Flap-Rubber        |
| 5           | 3230-16            | 6           | Screw-CARR         |
| 6           | 104-8300           | 6           | Nut-Flange, NI     |


# Main Frame Assembly



## Main Frame Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 116-9720           | 1           | Mainframe ASM                | 11          | 116-5899           | 1           | RH Motion Control Cover ASM |
| 1:2         | 106-5517           | 2           | Decal-Warning, Hot Surface   | 11:2        | 99-8936            | 1           | Decal-Control, Motion       |
| 1:3         | 132-0871           | 1           | Decal-Danger                 | 11:3        | 116-5988           | 1           | Decal-Park Brake, Ce        |
| 1:4         | 106-2655           | 2           | Decal-Hazard, Pinched Finger | 12          | 116-0580           | 1           | LH Motion Control Cover ASM |
| 1:5         | 116-4858           | 1           | Decal-Spark Arrester         | 12:2        | 99-8936            | 1           | Decal-Control, Motion       |
| 2           | 109-8863-03        | 1           | Plate,Rear Guard             | 13          | 126-2067-03        | 1           | Guard-Muffler               |
| 3           | 116-8898-01        | 1           | Floorpan                     | 14          | 126-6969           | 1           | Decal-Exmark Logo           |
| 4           | 1-513658           | 2           | Bumper                       | 15          | 32144-10           | 4           | Screw-HWH 1/4-20 X .62      |
| 5           | 1-811010           | 2           | Plug                         | 18          | 126-6965           | 1           | Decal-Exmark Logo           |
| 6           | 116-0180           | 1           | LH Bumper ASM                | 19          | 126-4345           | 1           | Decal-Patent Ttco.Com       |
| 6:2         | 106-5517           | 1           | Decal-Warning, Hot Surface   | 20          | 107-3154           | 2           | Nut-Push 3/8-16             |
| 7           | 116-0057-03        | 1           | Bumper-RH                    | 21          | 117-3864           | 1           | Decal-Fuel Fill, Ce         |
| 8           | 104-8301           | 11          | Nut-Nyloc 3/8-16 Flg         | 22          | 1-543508           | 4           | Cup-Bearing Tapered Roller  |
| 9           | 3231-22            | 8           | Bolt-Carriage 3/8-16 X 1     | 23          | 2412-147           | 1           | Clamp                       |
| 10          | 3231-21            | 3           | Bolt-Carriage 3/8-16 X 3/4   |             |                    |             |                             |


# X-Series Decal



## X-Series Decal (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 126-6573           | 2           | Decal-X-Series     |


# Roll-Over Protection System



## Roll-Over Protection System (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 116-0230           | 1           | ASM,ROPS Service Exmark |

# Roll-Over Protection System Assembly No. 116-0230




# Roll-Over Protection System Assembly No. 116-0230 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|--------------------------------|
| 3           | 109-6653           | 2           | Spacer                         |
| 4           | 116-0019           | 1           | Upper ROPS ASM                 |
| 4:2         | 107-3069           | 1           | Decal-Warning, Folding<br>ROPS |
| 5           | 109-5337           | 2           | Bumper-ROPS                    |
| 6           | 116-0104           | 2           | Pin-Spring                     |
| 7           | 99-5107            | 6           | Nut-Lock 1/2-13                |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|------------------------------|
| 8           | 3233-10            | 2           | Bolt-Carriage 1/2-13 X 3 1/2 |
| 9           | 325-35             | 4           | Screw-HH                     |
| 10          | 109-9505           | 4           | Washer, Spring Disc 1/2      |
| 11          | 109-9233           | 1           | Bumper-Push-In, Rubber       |
| 12          | 117-0346           | 1           | Decal-Caution, Fuel Vent     |
| 14          | 116-0960           | 2           | Spacer                       |

## Front Caster and Fork Assembly




## Front Caster and Fork Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           |                    | 2           | Caster Wheel ASM ● |

● Not serviced separately

# Caster Wheel and Fork Assembly




## Caster Wheel and Fork Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 1-543509           | 2           | Bearing-Roller, Tapered | 5:2:3       | 103-3051           | 1           | Spacer-Nut ■         |
| 2           | 116-5647           | 1           | Seal-Grease             | 5:2:4       | 126-5361           | 1           | Axle ASM-Caster      |
| 3           | 1-633508           | 3           | Washer-Bellville        | 5:2:5       |                    | 1           | Wheel And Tire ASM ● |
| 4           | 116-6707-01        | 1           | Caster                  | 5:2:5:1     | 1-633584           | 2           | Bearing-Cup          |
| 5           | 109-9127           | 1           | Wheel & Tire ASM        | 5:3         | 325-39             | 1           | Screw-HH             |
| 5:1         | 103-2768           | 2           | Guard-Seal              | 5:4         | 3296-23            | 1           | Nut-Lock, NI         |
| 5:2         |                    | 1           | Wheel And Tire ASM ●    | 6           | 103-4882           | 1           | Cap-Grease           |
| 5:2:1       | 1-633585           | 2           | Bearing-Cone, Taper     | 7           | 3296-51            | 1           | Nut-Lock, NI         |
| 5:2:2       | 103-0063           | 2           | Seal-Caster             |             |                    |             |                      |

● Not serviced separately

■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.


# Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                       |
|-------------|--------------------|-------------|--------------------------------------|-------------|--------------------|-------------|------------------------------------------|
| 1           | 86-1990            | 6           | Washer                               | 17          | 325-12             | 2           | Screw-HH 1/2-13 X 3                      |
| 2           | 99-5107            | 12          | Nut-Lock 1/2-13                      | 18          | 325-17             | 1           | Screw-HH 1/2-13 X 4                      |
| 3           | 104-8301           | 12          | Nut-Nyloc 3/8-16 Flg                 | 19          | 3231-2             | 2           | Bolt-Carriage 3/8-16 X 1                 |
| 4           | 109-5013           | 1           | Panhard Rod ASM                      | 20          | 3231-4             | 2           | Bolt-Carriage 3/8-16 X 1 1/2             |
| 4:2         | 109-5009           | 2           | Bushing-Suspension,<br>Rubber        | 21          | 3231-7             | 4           | Bolt-Carriage 3/8-16 X 2 1/4             |
| 4:3         | 109-5010           | 2           | Spacer                               | 22          | 3233-34            | 1           | Bolt-Carriage 1/2-13 X 2 1/2             |
| 5           | 109-7173           | 2           | Bearing-Cross Shaft, Rear            | 23          | 3296-23            | 1           | Nut-Nyloc 1/2-13                         |
| 6           | 116-1919-01        | 1           | Lever-Foot                           | 24          | 116-1700           | 4           | Bolt-Carriage 1/2-13 X 2 1/2<br>Spl Neck |
| 7           | 109-7438           | 1           | HOC ASM                              | 25          | 116-0559           | 1           | Bolt-HH 1/2-13 X 4 Tap                   |
| 8           | 126-2477-03        | 1           | Decklift-Front                       | 26          | 116-2022           | 2           | Screw-Hex Flange 1/2-13 X<br>1.90        |
| 9           | 127-0553           | 2           | Support-Cross Shaft,<br>Bearing Rear | 27          | 92-7674            | 1           | Screw-Shcs 3/8-16 X 2.212                |
| 10          | 109-7952           | 2           | Deck Strut ASM                       | 28          | 116-0000           | 1           | Spring-Extension                         |
| 10:2        | 109-5009           | 2           | Bushing-Suspension,<br>Rubber        | 29          | 109-9065           | 1           | Screw-HH 7/16-14 X 2                     |
| 10:3        | 109-5010           | 2           | Spacer                               | 30          | 32128-37           | 2           | Nut-Whizlock 7/16-14                     |
| 11          | 116-0797-03        | 1           | Link-Lift, Deck                      | 31          | 3256-28            | 2           | Washer-3/4 Sae                           |
| 12          | 116-2645-03        | 1           | Lift-Deck, Rear                      | 32          | 116-2695           | 1           | Spacer                                   |
| 13          | 116-5584           | 1           | Pin-HOC                              | 33          | 109-8007           | 4           | Link-Adjuster, Deck Lift                 |
| 14          | 109-9409           | 2           | Support-Cross Shaft,<br>Bearing      | 34          | 109-7840           | 4           | Adjuster-Lift, Deck                      |
| 15          | 109-9410           | 2           | Bearing-Cross Shaft, Front           | 35          | 109-8353           | 4           | Trunnion                                 |
| 16          | 109-9840           | 4           | Screw-Hex Flange 3/8-16 X<br>.80     | 36          | 3218-5             | 4           | Nut-Jam 1/2-13                           |
|             |                    |             |                                      | 37          | 325-10             | 2           | Screw-HH 1/2-13 X 2 1/2                  |
|             |                    |             |                                      | 38          | 126-2916           | 1           | Nut-Push                                 |

Height-of-Cut Assembly No. 109-7438




## Height-of-Cut Assembly No. 109-7438 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 1           | 62-1330            | 1           | Bolt-Shoulder       |
| 2           | 109-7130           | 1           | Grommet             |
| 3           | 104-8301           | 1           | Nut-Flange, NI      |
| 4           | 109-7124           | 1           | Spring-Extension    |
| 5           | 109-7128           | 1           | Rod-Lock, Transport |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 6           | 116-0118           | 1           | Pawl-Transport, HOC |
| 7           | 109-7335           | 1           | HOC Plate ASM       |
| 7:2         | 126-4398           | 1           | Decal-HOC           |
| 8           | 109-8250           | 1           | Grip-Lever          |


# Control Assembly



## Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 116-9416           | 1           | Control Panel W/Decal      | 3:3         | 109-9345           | 3           | Screw-HWH #10-14 X 3/4 Tf  |
| 1:2         | 126-4108           | 1           | Decal-Console Red          | 3:4         | 32105-15           | 2           | Screw-Machine 1/4-20 X 3/4 |
| 1:3         | 114-4466           | 1           | Decal-Fuses                | 3:5         | 107069             | 4           | Nut-Retainer-Panel 1/4-20  |
| 2           | 32105-15           | 4           | Screw-Machine 1/4-20 X 3/4 | 4           | 109-9342           | 1           | Console.LH Narrow ASM      |
| 3           | 109-9341           | 1           | Console,RH Narrow ASM      | 4:2         | 109-9345           | 4           | Screw-HWH #10-14 X 3/4 Tf  |
| 3:1         | 104-7201           | 2           | Nut-Nyloc 1/4-20 Flg       |             |                    |             |                            |

# Motion Control Assembly




## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|-----------------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 116-0880           | 1           | RH Motion Control And Bushing ASM | 14          | 109-6589           | 1           | RH Steering Handle ASM |
| 1:2         | 109-8054           | 4           | Bushing-Flange                    | 14:1        | 109-5668           | 1           | Grip-Control, Lever    |
| 2           | 116-0881           | 1           | LH Motion Control And Bushing ASM | 15          | 109-6590           | 1           | LH Steering Handle ASM |
| 2:2         | 109-8054           | 4           | Bushing-Flange                    | 15:1        | 109-5668           | 1           | Grip-Control, Lever    |
| 3           | 116-0648           | 2           | Screw-HH, Thread Locking ●        | 16          | 104-8301           | 4           | Nut-Flange, NI         |
| 4           | 109-4581           | 2           | Arm-Control, Pump                 | 17          | 323-7              | 4           | Screw-HH               |
| 5           | 9080046            | 2           | Screw-HH ●                        | 18          | 109-5575           | 2           | Spring-Leaf            |
| 6           | 1-303435           | 2           | Washer-Spring                     | 19          | 109-8106           | 2           | Front Pump Linkage ASM |
| 7           | 116-0027           | 2           | Damper-Control, Motion            | 19:2        | 3219-2             | 2           | Nut-Hex                |
| 8           | 104-8300           | 8           | Nut-Flange, NI                    | 19:3        | 1-323245           | 2           | Spring-Compression     |
| 9           | 3230-2             | 2           | Bolt-CARR                         | 19:4        | 1-633152           | 1           | Balljoint-LH           |
| 10          | 109-5891           | 2           | Hub-Threaded                      | 19:5        | 1-543017           | 1           | Balljoint-RH           |
| 11          | 325-12             | 2           | Screw-HH                          | 20          | 109-9505           | 4           | Washer-Spring          |
| 12          | 116-0039           | 1           | Lever-Control Motion, RH          | 21          | 3256-6             | 2           | Washer-Flat            |
| 13          | 116-0040           | 1           | Lever-Control Motion, LH          | 22          | 32128-56           | 2           | Nut-HF                 |
|             |                    |             |                                   | 23          | 3256-23            | 2           | Washer-Flat            |
|             |                    |             |                                   | 24          | 3218-5             | 2           | Nut-Jam                |
|             |                    |             |                                   | 25          | 115-1794           | 2           | Screw-HHF              |

● Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.


# Rear Wheel Assembly



## Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 109-8972           | 2           | Wheel And Tire ASM | 2           | 242-50             | 8           | Nut-Lug 1/2-20          |
| 1:1         | 1-633993           | 1           | Tire               | 3           | 126-2055           | 2           | Decal-Torque, Wheel Hub |
| 1:2         | 109-3156           | 1           | Rim                |             |                    |             | Lug                     |
| 1:3         | 232-27             | 1           | Stem-Valve         |             |                    |             |                         |

# Park Brake Assembly




REAR VIEW OF  
RIGHT HAND HYDRO

## Park Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                    |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|---------------------------------------|
| 1           | 126-4248           | 1           | Mount-Bellcrank, LH           | 26          | 116-9085           | 2           | Spring-Compression                    |
| 2           | 126-4249           | 1           | Mount-Bellcrank, RH           | 27          | 3220-2             | 2           | Nut-Jam 5/16-24                       |
| 3           | 116-9681           | 1           | Mount-Pivot, LH               | 28          | 104-8300           | 4           | Nut-Nyloc 5/16-18 Flg                 |
| 4           | 116-9682           | 1           | Mount-Pivot, RH               | 29          | 1-808280           | 2           | Pin-Clevis 5/16 X 1 49/64             |
| 5           | 32144-70           | 4           | Screw-HWH 5/16-18 X 3/4<br>Tf | 30          | 3256-23            | 4           | Washer-5/16 Sae                       |
| 6           | 109-8054           | 2           | Bushing-Flanged               | 31          | 116-6639           | 2           | Pin-Cotter, Locking                   |
| 7           | 116-9096-01        | 1           | Bracket-Mount                 | 32          | 116-9102           | 1           | Front Linkage ASM                     |
| 8           | 126-0970           | 1           | Brake Lever ASM               | 32:2        | 94-7572            | 1           | End-Tie Rod, RH                       |
| 8:2         | 109-8054           | 2           | Bushing-Flanged               | 32:3        | 3220-3             | 1           | Nut-Jam 3/8-24                        |
| 8:3         | 1-633268           | 1           | Grip-Lever                    | 33          | 119-1415           | 2           | Pin-Cotter, Locking                   |
| 9           | 116-9117           | 1           | Handle-Pivot, Brake           | 34          | 3296-6             | 1           | Nut-Nyloc 3/8-24                      |
| 10          | 323-11             | 1           | Screw-HH 3/8-16 X 2 1/4       | 35          | 126-7587           | 2           | ASM-Rear Linkage                      |
| 11          | 104-8301           | 1           | Nut-Nyloc 3/8-16 Flg          | 35:1        | 126-7588           | 2           | Yoke                                  |
| 12          | 126-6199           | 4           | Bushing-Igus                  | 35:2        | 116-9069           | 1           | Linkage, Rear                         |
| 13          | 3256-24            | 2           | Washer-3/8 Sae                | 35:3        | 3220-1             | 1           | Nut-Jam 1/4-28                        |
| 14          | 109-0958           | 2           | Plate-Mount, Brake            | 36          | 32120-19           | 2           | E-Ring                                |
| 15          | 109-2889           | 1           | Caliper-Brake                 | 37          | 3230-2             | 2           | Bolt-Carriage 5/16-18 X 1             |
| 16          | 116-9103           | 1           | Caliper-Brake, RH             | 38          | 323-6              | 2           | Screw-HH 3/8-16 X 1                   |
| 17          | 126-4251           | 2           | Bellcrank                     | 39          | 3296-39            | 2           | Nut-Nyloc 3/8-16                      |
| 18          | 126-3715           | 1           | Arm-Inner, LH                 | 40          | 116-1746           | 2           | Wheel Hub ASM                         |
| 19          | 126-3716           | 1           | Arm-Inner, RH                 | 40:2        | 116-1696           | 4           | Stud-Wheel                            |
| 20          | 116-9080           | 1           | Shaft-Cross                   | 41          | 116-1399           | 2           | Locknut                               |
| 21          | 115-7109           | 2           | Washer-Flat                   | 42          | 126-6395           | 4           | Pin-Clevis, Spring                    |
| 22          | 98-9940            | 4           | Screw                         | 43          | 92-5727            | 2           | Screw-HH 3/8-16 X 1 1/4<br>Patch Lock |
| 23          | 116-9609           | 2           | Bracket-L                     | 44          | 126-6200           | 2           | Spacer                                |
| 24          | 116-9086           | 2           | Linkage-Mid                   |             |                    |             |                                       |
| 25          | 126-3693           | 2           | Yoke-Offset                   |             |                    |             |                                       |


# Seat Assembly



## Seat Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            |
|-------------|--------------------|-------------|----------------------------------------|-------------|--------------------|-------------|-------------------------------|
| 1           | 116-8912           | 1           | Kit-Suspension Seat                    | 10          | 109-9881-03        | 1           | Plate-Latch, Seat             |
| 2           | 109-9034           | 4           | Isolator-Seat                          | 11          | 3230-4             | 1           | Bolt-Carriage 5/16-18 X 1 1/2 |
| 3           | 104-8301           | 4           | Nut-Nyloc 3/8-16 Flg                   | 12          | 107-3017           | 1           | Spring-Compression            |
| 4           | 116-3860-03        | 1           | Plate-Tilt, Seat Support               | 13          | 9266934            | 2           | Screw-HWH 5/16 X 1/2 Tf       |
| 5           | 3230-23            | 11          | Bolt-Carriage 5/16-18 X 3/4 Short Neck | 14          | 126-6574           | 1           | Decal, Lazer Model            |
| 6           | 104-8300           | 18          | Nut-Nyloc 5/16-18 Flg                  | 15          | 116-1297           | 2           | Screw-Shoulder                |
| 7           | 116-3859-03        | 1           | Plate-Frame, Seat                      | 16          | 116-0070           | 1           | Rod-Prop                      |
| 8           | 26-4840            | 4           | Spacer-Pin, Mounting                   | 17          | 3256-23            | 1           | Washer-5/16 Sae               |
| 9           | 116-2130-03        | 1           | Panel-Front, Seat Mount                | 18          | 114-4465           | 1           | Decal-Service Aid             |

# Seat W/Tracks Assembly No. 116-8912




## Seat W/Tracks Assembly No. 116-8912 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|------------------------------|
| 2           | 116-8910           | 1           | Seat Track Set               |
| 3           | 116-8908           | 1           | Cover-Back 311463Vn500       |
| 4           | 116-8909           | 1           | Cover-Cushion<br>311464Vn500 |
| 5           | 116-8911           | 1           | Knob-Adjuster                |
| 6           | 116-5659           | 1           | Cover-Suspension Bellows     |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    |
|-------------|--------------------|-------------|-----------------------|
| 7           | 126-2061           | 1           | Seat Belt Service Kit |
| 8           | 116-8906           | 1           | Kit-Arm Rest Set      |
| 9           | 116-8905           | 1           | Kit-Arm Rest Pads     |
| 10          | 82-2190            | 1           | Switch-Bail           |
| 11          | 116-9329           | 4           | Spacer                |


# Fuel Assembly



## Fuel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 116-3979           | 1           | Fuel Tank ASM           | 7           | 116-5087           | 1           | Hose-Fuel                 |
| 2           | 3218-1             | 2           | Nut-Jam 1/4-20          | 8           | 105-1853           | 1           | Clamp-Hose                |
| 3           | 116-6380           | 2           | Bumper-Rubber (W/ Stud) | 9           | 116-6005           | 1           | Retainer-Line, Vapor      |
| 4           | 116-3977           | 1           | Hose ASM                | 11          | 126-0224           | 1           | Insulation-Fuel Tank Foam |
| 5           | 109-9491           | 1           | Fuel Manifold Vent ASM  | 12          | 126-0032-01        | 1           | Guard-Exhaust             |
| 6           | 98-2952            | 1           | Fitting-Straight        |             |                    |             |                           |


# Fuel Tank Assembly No. 116-3979



## Fuel Tank Assembly No. 116-3979 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|-----------------------------------|
| 2           | 46-6560            | 4           | Bushing                      | 8           | 116-2460           | 1           | RH Vent Line Kit (With Grommet)   |
| 3           | 116-2459           | 1           | Fuel Line Kit (With Grommet) | 9           | 116-2461           | 1           | LH Vent Line Kit (With Grommet)   |
| 3:1         | 46-6560            | 1           | Bushing                      | 10          | 116-2462           | 1           | Rear Vent Line Kit (With Grommet) |
| 4           | 9107944            | 5           | Screw-Pan                    | 11          | 1-603770           | 1           | Valve-Fuel                        |
| 5           | 3253-17            | 5           | Washer-Lock                  | 12          | 2412-98            | 2           | Clamp-Hose                        |
| 6           | 116-0003           | 1           | Sender-Level, Fuel           | 13          | 109-0650           | 1           | Hose-Fuel                         |
| 6:1         | 109-9620           | 1           | Gasket-Sender, Fuel          |             |                    |             |                                   |
| 7           | 126-1789           | 1           | Cap-Fuel, Ratcheting         |             |                    |             |                                   |

# Engine Assembly




## Engine Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|---------------------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           |                    | 1           | Engine-Kohler Ecv940-3015<br>●        | 20          | 126-4645           | 1           | Muffler-940-980 Koh Efi     |
| 3           | 116-1608           | 1           | Clutch, Cms250                        | 20          | 126-5423           | 1           | Muffler-Kit                 |
| 3           | 116-1621           | 1           | Clutch Kit                            | 20:2        | 126-0359           | 2           | Gasket-Exhaust              |
| 4           | 109-6919           | 1           | Washer-Clutch                         | 20:3        | 116-9626           | 4           | Nut-Flange, Lock            |
| 5           | 1-603610           | 2           | Washer-Spring Disc 7/16               | 21          | 116-3331-01        | 1           | Belt-Guide                  |
| 6           | 109-9761           | 1           | Screw-HH 7/16-20 X 1 1/2<br>W/Loctite | 22          | 116-3318           | 1           | Spacer                      |
| 7           | 3231-42            | 1           | Bolt-Carriage 3/8-16 X 3              | 23          | 116-3319           | 1           | Spacer                      |
| 8           | 98-5975            | 4           | Washer-Spring Disc 3/8                | 24          | 104-8300           | 1           | Nut-Nyloc 5/16-18 Flg       |
| 9           | 116-5316           | 1           | Oil Drain Hose ASM                    | 25          | 323-8              | 1           | Screw-HH 3/8-16 X 1 1/2     |
| 9:2         | 353-508            | 1           | Plug-W/O-Ring                         | 26          | 322-4              | 1           | Screw-HH 5/16-18 X 7/8      |
| 9:2:1       | 237-42             | 1           | O-Ring                                | 27          | 93-5108            | 2           | Grommet-Rubber              |
| 10          | 323-7              | 4           | Screw-HH 3/8-16 X 1 1/4               | 29          | 126-5708           | 1           | Rear Baffle ASM             |
| 12          | 116-3317-01        | 1           | Link-Anchor, Clutch                   | 30          | 126-1414           | 1           | Fuel Line ASM               |
| 13          | 109-6658           | 2           | Nut-Nyloc 3/8-16 Flg                  | 30:1        | 109-0286           | 1           | Hose-Fuel Line 35"          |
| 14          | 116-9048           | 1           | Bracket-Muffler                       | 30:2        | 126-1417           | 1           | Sleeve-Thermal              |
| 15          | 3234-5             | 3           | Screw-HH Flg 5/16-18 X 3/4            | 30:3        | 2412-98            | 2           | Clamp-Hose                  |
| 16          | 94-2413            | 3           | Nut-U                                 | 31          | 1-303435           | 4           | Washer-Spring Disc 1/4      |
| 17          | 103-1390           | 1           | Bushing                               | 32          | 104-2628           | 1           | Screw-HWH M6-1 X 12Mm<br>Tf |
| 18          | 105-1853           | 1           | Clamp-Hose                            | 33          | 126-5620           | 1           | Bracket-Muffler, Front      |
| 19          | 116-4295           | 4           | Screw-HH M6-1 X 20Mm<br>W/Patch       | 34          | 126-8136           | 1           | Conduit, Convolutd .88 X 4  |

● Not serviced separately

# Hydraulic Assembly




## Hydraulic Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                 |
|-------------|--------------------|-------------|------------------------------------------|-------------|--------------------|-------------|------------------------------------|
| 1           | 116-1255           | 1           | Pump Idler ASM                           | 13          | 116-0171           | 1           | RH Hydro Guard ASM                 |
| 2           | 109-6658           | 1           | Nut-Nyloc 3/8-16 Flg                     | 13:2        | 116-8726           | 1           | Decal-Oil, Hydro                   |
| 3           | 126-1319           | 1           | LH Hydro ASM (16Cc W/<br>Shock)          | 14          | 109-9709           | 1           | Guard-Hydro Rear, LH Trim          |
| 4           | 109-3388           | 1           | Belt                                     | 15          | 109-9058           | 1           | Guard-Hydro, Rear (RH)             |
| 5           | 116-6317           | 1           | Spring-Extension                         | 16          | 1-803035           | 2           | Rivet 3/16 X 1/4                   |
| 6           | 116-7558           | 1           | Cradle-Hydro                             | 17          | 116-2362           | 1           | Deflector-Air Flow                 |
| 7           | 116-1502           | 1           | Bolt-Carriage Shoulder<br>3/8-16 X 3 1/2 | 18          | 109-9905           | 1           | Sheave                             |
| 8           | 126-0095           | 6           | Screw-CARR                               | 19          | 1-807259           | 1           | Key-Machine 1/4 X 1/4 X 1          |
| 9           | 99-5107            | 6           | Nut-Lock 1/2-13                          | 99          | 109-9828           | 1           | Bottle-Oil, 32Oz Hydraulic ●       |
| 10          | 325-8              | 4           | Screw-HH 1/2-13 X 1 1/4                  | 99          | 116-0164           | 1           | Filter-Hydro ●                     |
| 11          | 126-1320           | 1           | RH Hydro ASM (16Cc W/<br>Shock)          | 99          | 116-1218           | 1           | Bottle,Oil 1 Gallon Hydraulic<br>● |
| 12          | 116-0170           | 1           | LH Hydro Guard ASM                       | 99          | 116-3270           | 1           | Kit, Hydro Service ●               |
| 12:2        | 116-8726           | 1           | Decal-Oil, Hydro                         | 99:1        | 109-9828           | 4           | Bottle-Oil, 32Oz Hydraulic ●       |
|             |                    |             |                                          | 99:2        | 109-3388           | 1           | Belt                               |
|             |                    |             |                                          | 99:3        | 116-0164           | 2           | Filter-Hydro ●                     |

● Not illustrated

# LH Hydro Assembly No. 126-1319




## LH Hydro Assembly No. 126-1319 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|----------------------------|
| 2           | 116-0233           | 1           | Fan Kit                       | 13          | 3257-42            | 1           | Key-Woodruff               |
| 3           | 116-0234           | 1           | Pulley Kit                    | 15          | 116-3287           | 1           | Housing-LH                 |
| 4           | 116-0235           | 1           | Handle-Bypass Valve,<br>Hydro | 16          | 116-8917           | 1           | Motor-Hydraulic, LH 280Cc  |
| 5           | 116-0236           | 1           | Dipstick-Hydro W/Gasket       | 17          | 116-7901           | 1           | Magnetic Plugs Service Kit |
| 6           | 116-0237           | 1           | Gasket-Dipstick, Hydro        | 18          | 76-1900            | 2           | O-Ring                     |
| 7           | 116-1367           | 1           | Swash Block Kit               | 19          | 116-8662           | 2           | O-Ring-Check Valve         |
| 8           | 116-1368           | 1           | Pump Seal Kit                 | 20          | 116-8974           | 4           | Screw HH                   |
| 9           | 116-1369           | 1           | Motor Seal Kit                | 21          | 116-8975           | 2           | Screw-HSH                  |
| 10          | 116-1370           | 1           | Tube Seal Kit                 | 22          | 116-9922           | 2           | Hydraulic Tube Kit         |
| 11          | 116-1371           | 1           | Output Shaft Seal Kit         | 23          | 126-7467           | 2           | Shock Valve, 16Cc Hydro    |
| 12          | 116-5469           | 1           | Nose Cup-Uht                  | 24          | 126-7711           | 1           | Seal-Fan Drive             |
|             |                    |             |                               | 99          | 116-1373           | 1           | Flow Test Kit ●            |

● Not illustrated

# RH Hydro Assembly No. 126-1320




## RH Hydro Assembly No. 126-1320 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 116-9063           | 1           | Mount-Shoe, Horse             | 13          | 3257-42            | 1           | Key-Woodruff               |
| 2           | 116-0233           | 1           | Fan Kit                       | 15          | 116-3288           | 1           | Housing-RH                 |
| 3           | 116-0234           | 1           | Pulley Kit                    | 16          | 116-8918           | 1           | Motor-Hydraulic, RH 280Cc  |
| 4           | 116-0235           | 1           | Handle-Bypass Valve,<br>Hydro | 17          | 116-7901           | 1           | Magnetic Plugs Service Kit |
| 5           | 116-0236           | 1           | Dipstick-Hydro W/Gasket       | 18          | 76-1900            | 2           | O-Ring                     |
| 6           | 116-0237           | 1           | Gasket-Dipstick, Hydro        | 19          | 116-8662           | 2           | O-Ring-Check Valve         |
| 7           | 116-1367           | 1           | Swash Block Kit               | 20          | 116-8974           | 4           | Screw HH                   |
| 8           | 116-1368           | 1           | Pump Seal Kit                 | 21          | 116-8975           | 2           | Screw-HSH                  |
| 9           | 116-1369           | 1           | Motor Seal Kit                | 22          | 116-9922           | 2           | Hydraulic Tube Kit         |
| 10          | 116-1370           | 1           | Tube Seal Kit                 | 23          | 126-7467           | 2           | Shock Valve, 16Cc Hydro    |
| 11          | 116-1371           | 1           | Output Shaft Seal Kit         | 24          | 126-7711           | 1           | Seal-Fan Drive             |
| 12          | 116-5469           | 1           | Nose Cup-Uht                  | 99          | 116-1373           | 1           | Flow Test Kit ●            |
|             |                    |             |                               | 99          | 116-4245           | 1           | Puller-Pulley Uht ●        |

● Not illustrated


Pump Idler Assembly No. 116-1255



## Pump Idler Assembly No. 116-1255 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 2           | 43-0940            | 1           | Spacer             | 8           | 323-8              | 1           | Screw-HH           |
| 3           | 103-3504           | 2           | Bearing-Spherical  | 9           | 32120-10           | 2           | Ring-Snap          |
| 4           | 103-3505           | 1           | Seal-Double Lip    | 10          | 302-19             | 1           | Fitting-Grease     |
| 5           | 103-3506           | 1           | Seal-Lip, Single   | 11          | 109-8076           | 1           | Pulley-Idler       |
| 6           | 109-6658           | 1           | Nut-Flange, NI     | 12          | 116-3467           | 1           | Pin-Spring, Anchor |
| 7           | 106-7159           | 2           | O-Ring             |             |                    |             |                    |

# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|---------------------------|
| 2           | 126-1682           | 1           | Harness-Wire ●             | 16          | 117-2221           | 1           | Switch-Ignition           |
| 2:2         | 218-578            | 1           | Fuse-Blade, 10 Amp         | 17          | 116-0124           | 1           | Switch-PTO, 10 Amp        |
| 2:3         | 109355             | 1           | Fuse-Blade, 15 Amp         | 18          | 104-2065           | 1           | Screw-HWH #10-24 X 3/8    |
| 2:4         | 109102             | 2           | Fuse-Blade, 25 Amp         | 19          | 115-3864           | 1           | Cable-Battery, Positive   |
| 2:5         | 116-0053           | 1           | Cap-Plug                   | 20          | 3256-24            | 1           | Washer-3/8 Sae            |
| 3           | 117-3882           | 1           | Fuel/Hour Meter ASM        | 21          | 1-303335           | 1           | Tie-Cable 7 15/16 (Large) |
| 4           | 1-603511           | 1           | Key-Ignition               | 23          | 1-643267           | 1           | Indicator-Red Led         |
| 4           | 103-2106           | 1           | Key-Exmark Logo            | 26          | 109-9376           | 1           | Receptacle-12V            |
| 6           | 110-6765           | 2           | Switch                     | 27          | 109-9693           | 1           | Harness, Receptacle 12V   |
| 7           | 116-0042-03        | 1           | Strap-Tie Down, Battery    | 28          | 126-2722           | 1           | Controller-Red            |
| 8           | 1-633651           | 2           | Bolt-Holddown              | 29          | 116-9669           | 1           | Switch-Rocker             |
| 9           | 1-543792           | 2           | Wingnut-Nyloc 1/4-20       | 30          | 116-9651           | 1           | Light-Led, Red            |
| 10          | 1-643275           | 1           | Relay-12Vdc 40 Amp         | 31          | 116-9652           | 1           | Light-Led, Red            |
| 11          | 114-1218           | 1           | Cable-Battery, Negative    | 32          | 3229-34            | 2           | Screw-CARR                |
| 12          | 3234-5             | 2           | Screw-HH Flg 5/16-18 X 3/4 | 33          | 3296-2             | 2           | Nut-Nyloc #10-24          |
| 13          | 104-8300           | 2           | Nut-Nyloc 5/16-18 Flg      | 34          | 109-2407           | 1           | Insulator-Battery         |
| 14          | 1-303287           | 2           | Tie-Cable 5 1/2 (Small)    | 35          | 1-543393           | 1           | Insulator-Solenoid        |
| 15          | 82-2190            | 1           | Switch                     |             |                    |             |                           |

● Use dielectric grease on all unsealed connectors and terminals only. Do not apply in sealed connectors.

**Notes:**

**Notes:**

**Notes:**



# MAXIMIZE THE PERFORMANCE OF YOUR EXMARK MACHINE.



## EXMARK® PREMIUM ENGINE OIL

Exmark now offers a family of engine oil viscosities to perform well in any environment. Each viscosity has the same synthetic formulation to give you what you need in punishing conditions. We designed each grade to the highest quality, making it ideal even for diesel applications. Coupled with Exmark Premium Fuel Treatment, we have the performance products to make your machine hum.

### EXMARK PREMIUM ENGINE OIL SAE 30/10W-30

- Meets zero shear requirements of a straight grade SAE 30 as well as the cold temp properties of a 10W-30.
- Most versatile oil in the industry.
- Superior corrosion protection over conventional oil - even in corrosive, humid environments.

### EXMARK PREMIUM ENGINE OIL SAE 20W-50

- Perfect for your big block engine, or any application in severe service.
- Same full synthetic formulation as all other Exmark Premium viscosities.
- Also effective for use in severe service small block engines.

### EXMARK PREMIUM ENGINE OIL SAE 10W-50

- Full synthetic formulation gives you peak performance. Don't settle for less.
- Wide span multi-grade combines easy starting in cold weather with maximum protection in high temperature operation.
- Reduce friction & wear over standard mineral formulations.

### EXMARK PREMIUM ENGINE OIL SAE 0W-40

- The perfect choice for when the weather turns cold or unpredictable, and your Exmark UTV has to perform.
- Commercial quality for severe service.
- Advanced additive package helps prevent corrosion from long-term storage.

### EXMARK PREMIUM ENGINE OIL UTV FORMULATION

- 4-cycle high-temp formulation.
- Heavier viscosity, full synthetic, perfect for your UTV.

### EXMARK PREMIUM UTV EXTREME CONDITIONS GEAR OIL

- SAE 80W-90, designed to keep your UTV performing at its peak.
- Shear stable, hypoid gear lube.
- Includes a premium additive system to combat wear, oxidation, rust & corrosion.

***Available from your local Exmark dealer. Find your closest dealer at [exmark.com](http://exmark.com)***

## EXMARK ACCESSORIES AND OPTIONS\*

### MID-MOUNT RIDING ACCESSORIES AND OPTIONS

|                                    |                                 |
|------------------------------------|---------------------------------|
| CUSTOM RIDE SEAT SUSPENSION SYSTEM | OPERATOR CONTROLLED DISCHARGE   |
| FULL SUSPENSION SEAT               | SUN SHADE                       |
| DECK LIFT ASSIST KIT               | TRASH CONTAINER                 |
| HITCH KIT                          | TURF STRIPER                    |
| LIGHT KIT                          | ULTRA VAC COLLECTION SYSTEM     |
| 12V POWER PORT                     | ULTRA VAC QUICK DISPOSAL SYSTEM |
| MICRO-MULCH SYSTEM                 |                                 |

### OUT-FRONT RIDING ACCESSORIES AND OPTIONS

|                                    |                                 |
|------------------------------------|---------------------------------|
| CUSTOM RIDE SEAT SUSPENSION SYSTEM | SNOW BLADE                      |
| DUAL-TAIL WHEEL                    | SNOWBLOWER                      |
| FLOOR PAN EXTENDER                 | SUN SHADE                       |
| HITCH KIT                          | TRASH CONTAINER                 |
| LIGHT KIT                          | ULTRA VAC COLLECTION SYSTEM     |
| MICRO-MULCH SYSTEM                 | ULTRA VAC QUICK DISPOSAL SYSTEM |
| ROLL OVER PROTECTION SYSTEM (ROPS) | WEATHER CAB                     |

### WALK-BEHIND ACCESSORIES AND OPTIONS

|                    |              |
|--------------------|--------------|
| GRASS CATCHER      | TURF STRIPER |
| MICRO-MULCH SYSTEM | STANDON      |

\*Some accessories and options not available for some models.

Place Model No. and Serial No.  
Label Here (Included in the Literature  
Pack) or Fill in Below

Model No. \_\_\_\_\_

Serial No. \_\_\_\_\_

Date Purchased \_\_\_\_\_

Engine Model No. and Spec. No. \_\_\_\_\_

Engine Serial No. (E/No) \_\_\_\_\_

© 2016 Exmark Mfg. Co., Inc.  
Industrial Park Box 808  
Beatrice, NE 68310  
All Rights Reserved

Part No. 4502-710 Rev. A  
(402) 223-6300  
Fax (402) 223-5489  
Printed in the USA.



\* 4 5 0 2 - 7 1 0 \* A

[www.exmark.com](http://www.exmark.com)