




MODEL NO. 44524 - 60001 & UP

PARTS CATALOG

DEBRIS BLOWER 2670

Attachment for 200 & 300 Series Groundsmaster®




BLOWER ASSEMBLY

67-001

Ref. No.	Part No.	Description	No. Used
1	67-005-2814	Blower Front	1
2	67-005-0072	Blower Back	1
3	67-005-0102	Ring Weldment	1
4	67-005-0062	Fan Blower	1
5	01-100-0180	Bearing	2
6	26-1530	Fork - Front Castor	2
7	92-1655	Wheel - Castor	2
8	83-4740	Bearing - Roller	2
9	63-0070	Spacer	6
10	3-6781	Thrust Washer	2
11	325-22	Capscrew - Hex Hd.	2
12	32128-23	Flange Lock Nut	2
13	67-005-0181	Fan Shaft Guard	1
14	01-168-2014	Machinery Bushing	4(var)
15	3272-25	Cotter Pin	1

Ref. No.	Part No.	Description	No. Used
16	3253-5	Lock Washer	19
17	3217-7	Hex Nut	14
18	01-168-2018	Machinery Bushing	3(var)
19	3296-39	Lock Nut	2
20	323-24	Capscrew - Hex Hd.	16
21	3256-4	Flat Washer	31
22	62-4340	Spanner	2
23	3256-6	Flat Washer	4
24	58-6520	Decal - Grease	5
25	01-261-0340	Spring	1
26	67-005-0092	Deflector	1
27	3253-7	Lock Washer	8
28	3217-9	Hex Nut	8
29	62-5580	Bushing	4
30	3290-384	Pin - Lynch	2
31	62-7400	Decal - Toro	1




BLOWER ASSEMBLY (Continued)

67-001

Ref. No.	Part No.	Description	No. Used
32	01-506-0860	Decal - Debris Blower 2670	2
33	62-5550	Decal - Toro	1
34	01-506-0110	Decal - Warning	1

Ref. No.	Part No.	Description	No. Used
35	01-215-0050	Grease Zerk	2
36	94-1291	Bushing - Special	4



DEFLECTOR HANDLE & MANUAL TUBE ASSEMBLY

67-007

Ref. No.	Part No.	Description	No. Used
1	67-005-1551	Deflector Handle	1
2	01-259-0010	Handle Grip	1
3	01-178-0872	Capscrew - Hex Hd.	1
4	3256-6	Flat Washer	7
5	3218-5	Jam Nut	2
6	67-004-0451	Linkage Rod	1
7	3272-11	Cotter Pin	2

Ref. No.	Part No.	Description	No. Used
8	2412-133	Tube Clamps	2
9	74-0720	Tube	1
10	321-4	Capscrew - Hex Hd.	2
11	3256-2	Flat Washer	4
12	3253-3	Lock Washer	2
13	3217-5	Hex Nut	2

PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
01-100-0180	Bearing	1	5	2	3256-4	Flat Washer	1	21	31
01-168-2014	Machinery Bushing	1	14	4	3256-6	Flat Washer	1	23	4
01-168-2018	Machinery Bushing	1	18	3	3256-6	Flat Washer	3	4	7
01-178-0872	Capscrew - Hex Hd.	3	3	1	3272-11	Cotter Pin	3	7	2
01-215-0050	Grease Zerk	2	35	2	3272-25	Cotter Pin	1	15	1
01-259-0010	Handle Grip	3	2	1	3290-384	Pin - Lynch	1	30	2
01-261-0340	Spring	1	25	1	3296-39	Lock Nut	1	19	2
01-506-0110	Decal - Warning	2	34	1	58-6520	Decal - Grease	1	24	5
01-506-0860	Decal - Debris Blower 2670	2	32	2	62-4340	Spanner Bushing	1	22	2
2412-133	Tube Clamps	3	8	2	62-5550	Decal - Toro	2	33	1
26-1530	Fork - Front Castor	1	6	2	62-5580	Bushing	1	29	4
3-6781	Thrust Wasaher	1	10	2	62-7400	Decal - Toro	1	31	1
321-4	Capscrew - Hex Hd.	3	10	2	63-0070	Spacer	1	9	6
32128-23	Flange Lock Nut	1	12	2	67-004-0451	Linkage Rod	3	6	1
3217-5	Hex Nut	3	13	2	67-005-0062	Fan Blower	1	4	1
3217-7	Hex Nut	1	17	14	67-005-0072	Blower Back	1	2	1
3217-9	Hex Nut	1	28	8	67-005-0092	Deflector	1	26	1
3218-5	Jam Nut	3	5	2	67-005-0102	Ring Weldment	1	3	1
323-24	Capscrew - Hex Hd.	1	20	16	67-005-0181	Fan Shaft Guard	1	13	1
325-22	Capscrew - Hex Hd.	1	11	2	67-005-2814	Blower Front	1	1	1
3253-3	Lock Washer	3	12	2	83-4740	Bearing - Roller	1	8	2
3253-5	Lock Washer	1	16	19	92-1655	Wheel - Castor	1	7	2
3253-7	Lock Washer	1	27	8	94-1291	Bushing - Special	2	36	4
3256-2	Flat Washer	3	11	4					

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit which is not reflected in your manual see your TORO Distributor or an Authorized Service Dealer for information and part numbers.

IDENTIFICATION & ORDERING

MODEL AND NUMBERS

The Debris Blower 2670 has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate which is located on the main frame. In any correspondence concerning the Debris Blower 2670, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from your TORO Distributor or an Authorized Service Dealer, supply the following information:

1. Model and serial number of the unit.
2. Part number description and the quantity of part (s) desired.

NOTE: Do not order by reference number if a parts catalog is being used: use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Blower Assembly	1 - 2	Part Number Index	4
Deflector Handle & Manual Tube Assembly	3		

NOTES

NOTES

MAINTENANCE RECORD

[illegible]