



**Count on it.**

# Parts Catalog

## TimeCutter® SS 4225 Riding Mower

Model No. 74721—Serial No. 316000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HP:** high pressure

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** low pressure

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard


**TAP:** self tapping

**TTH:** torx truss head

# Contents

|                                                        |    |
|--------------------------------------------------------|----|
| Frame, Front Axle and Caster Wheel Assembly .....      | 4  |
| Caster Wheel Assembly No. 130-0736.....                | 6  |
| Deck Lift Assembly.....                                | 8  |
| Motion Control Assembly .....                          | 10 |
| Brake Assembly.....                                    | 12 |
| Seat Assembly .....                                    | 14 |
| Belt and Idler Assembly.....                           | 16 |
| Hydo Transaxle Drive and Rear Wheel Assembly.....      | 18 |
| 2 Ply Wheel and Tire Assembly No. 131-3671 .....       | 20 |
| Left Hand Hydro Transaxle Assembly No. 119-3330 .....  | 22 |
| Right Hand Hydro Transaxle Assembly No. 119-3331 ..... | 24 |
| Clutch Assembly.....                                   | 26 |
| Engine and Muffler Assembly.....                       | 28 |
| Body Styling and Fuel Tank Assembly .....              | 30 |
| Fuel Delivery Assembly.....                            | 32 |
| Battery and Electrical Assembly.....                   | 34 |
| Fuse and Wire Harness Assembly.....                    | 36 |
| 42 Inch Deck Assembly.....                             | 38 |
| 42 Inch Deck Assembly No. 131-3604 .....               | 40 |
| 42 Inch Deck, Belt and Blade Assembly.....             | 42 |
| Attachments and Accessories .....                      | 44 |

**Frame, Front Axle and Caster Wheel Assembly**




## Frame, Front Axle and Caster Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 127-3444-01        | 1           | Frame ASM          |
| 4           | 125-1742-01        | 1           | Axle-Front, Narrow |
| 5           | 130-0736           | 2           | Caster Wheel ASM   |
| 6           | 104-3667           | 2           | Spanner-Wheel      |
| 7           | 325-22             | 2           | Screw-HH           |
| 8           | 3296-45            | 2           | Nut-Lock, NI       |
| 9           | 120-2266-01        | 2           | Fork-Caster        |
| 10          | 117-7394           | 2           | Washer-Thrust      |
| 11          | 109-3678           | 4           | Bearing-Ball       |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 12          | 3256-68            | 2           | Washer-Flat        |
| 13          | 3234-47            | 2           | Screw-HHF          |
| 15          | 116-4348           | 2           | Cap-Grease         |
| 16          | 132-0890           | 1           | Footrest ASM       |
| 16:2        | 105-8278           | 1           | Decal              |
| 16:3        | 132-0869           | 1           | Decal-Danger       |
| 18          | 32144-70           | 2           | Screw-HWHTF        |
| 20          | 3234-42            | 6           | Screw-HHF          |
| 21          | 104-8301           | 6           | Nut-Flange, NI     |

# Caster Wheel Assembly No. 130-0736




## Caster Wheel Assembly No. 130-0736 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 130-0735           | 1           | Tire               |
| 3           | 114-1640           | 2           | Bushing-Flange     |
| 4           | 232-27             | 1           | Stem-Valve         |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 5           | 302-5              | 1           | Fitting-Grease     |
| 6           | 105-0844           | 1           | Tube-Inner ●       |

● Optional Equipment


Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|---------------------------|-------------|--------------------|-------------|--------------------------------|
| 1           | 1-806005           | 1           | Pin-Cotter                | 19          | 131-0902-01        | 1           | Mount-Hydro, Front Left        |
| 2           | 120-5499           | 2           | Screw-HSBH                | 20          | 3234-29            | 6           | Screw-HHF                      |
| 4           | 119-3427-03        | 1           | Lever-Lift                | 21          | 3296-19            | 1           | Nut-Hex                        |
| 5           | 132-6872-03        | 1           | Lift-Deck, Narrow         | 22          | 32144-70           | 16          | Screw-HWHTF                    |
| 6           | 119-3435-03        | 1           | Brace-Seat, Rear (Narrow) | 24          | 131-3945           | 1           | Rod-Mount, Deck                |
| 7           | 119-8875           | 2           | Bracket-Lift              | 25          | 119-8810           | 1           | Pin-Pivot                      |
| 8           | 131-0914-03        | 1           | Bracket-Battery           | 34          | 121-5684           | 1           | Decal-Location, Service Dealer |
| 9           | 3296-29            | 2           | Nut-Lock, NI              | 35          | 121-2989           | 2           | Decal-Bypass                   |
| 10          | 108-7840           | 2           | Link-Lift                 | 36          | 127-3353-03        | 1           | Guard-Engine, Narrow           |
| 11          | 108-7839           | 1           | Arm-Lift, Rear            | 37          | 130-6950-01        | 1           | Crossmember-Rear, Narrow       |
| 12          | 108-7845           | 2           | Block-Pivot               | 38          | 3234-47            | 8           | Screw-HHF                      |
| 14          | 1-633268           | 1           | Grip-Lever                | 39          | 117-1232-03        | 1           | Bracket-Hitch                  |
| 15          | 3272-11            | 2           | Pin-Cotter                | 40          | 131-4036           | 1           | Decal                          |
| 16          | 3256-26            | 3           | Washer-Flat               | 43          | 99-4693            | 1           | Decal                          |
| 17          | 104-8300           | 14          | Nut-Flange, NI            |             |                    |             |                                |
| 18          | 131-0901-01        | 1           | Mount-Hydro, Front Right  |             |                    |             |                                |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|------------------------|
| 1           | 121-0731           | 1           | Handle-Control, RH     | 21          | 3296-56            | 2           | Nut-Lock, NI           |
| 1:1         | 121-0726           | 1           | Grip                   | 22          | 115-5098-05        | 2           | Lever-Control          |
| 2           | 121-0730           | 1           | Handle-Control, LH     | 23          | 120-2273           | 2           | Washer-Nylon           |
| 2:1         | 121-0726           | 1           | Grip                   | 26          | 115-5099           | 2           | Bolt-Pivot             |
| 3           | 3256-24            | 4           | Washer-Flat            | 27          | 119-8876           | 2           | Spring-Return          |
| 4           | 323-6              | 4           | Screw-HH               | 28          | 117-5388           | 2           | Rod-Hydro              |
| 5           | 120-7950           | 2           | Screw-Shoulder         | 29          | 119-8842           | 2           | Mount-Rod, Hydro       |
| 6           | 119-3470           | 2           | Actuator Arm ASM       | 30          | 119-8952           | 2           | Washer                 |
| 6:2         | 256-156            | 2           | Bushing-Flange         | 31          | 321-3              | 2           | Screw-HH               |
| 7           | 110-6810           | 2           | Stud-Damper            | 33          | 117-5385           | 2           | Retainer               |
| 8           | 103-2913           | 2           | Damper-Control, Motion | 34          | 32144-1            | 4           | Screw-Taptite          |
| 9           | 3296-42            | 4           | Nut-Lock, NI           | 40          | 1-603807           | 2           | Spring-Return, Neutral |
| 10          | 104-8300           | 10          | Nut-Flange, NI         | 43          | 93-6079            | 2           | Spacer-Nylon           |
| 11          | 3256-23            | 2           | Washer-Flat            | 44          | 119-8935           | 1           | Knob-RH                |
| 13          | 104-8301           | 4           | Nut-Flange, NI         | 45          | 119-8936           | 1           | Knob-LH                |
| 14          | 119-8925           | 2           | Washer-Belleville      | 46          | 94-4496            | 1           | Screw-PPH              |
| 15          | 117-1240           | 2           | Washer                 | 47          | 3234-47            | 6           | Screw-HHF              |
| 16          | 131-1094           | 1           | Speed Control ASM      | 48          | 131-3947           | 1           | Decal-Speed Control    |
| 17          | 119-3303           | 2           | Pin-Rod, Hydro         | 49          | 32144-70           | 4           | Screw-HWHTF            |
| 19          | 117-1198           | 2           | Bolt-Pivot             | 50          | 119-8871           | 1           | Decal                  |
| 20          | 131-1093-03        | 1           | Control Box ASM        |             |                    |             |                        |


# Brake Assembly



## Brake Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------|
| 1           | 132-0935           | 1           | Brake Box ASM      | 7           | 130-6974           | 1           | Cover-Connector      |
| 2           | 121-2974           | 1           | Rod-Brake, RH      | 8           | 32144-4            | 2           | Screw-HWH            |
| 3           | 121-2975           | 1           | Rod-Brake, LH      | 10          | 3296-42            | 2           | Nut-Lock, NI         |
| 4           | 117-1169           | 4           | Spring-Compression | 11          | 119-8952           | 6           | Washer               |
| 5           | 3290-307           | 2           | Pin-Cotter         | 12          | 130-0790-03        | 1           | Bracket-Mount, Brake |
| 6           | 32144-36           | 4           | Screw-PPH          | 13          | 94-4496            | 2           | Screw-PPH            |

# Seat Assembly



## Seat Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 131-4037-01        | 1           | Pan-Seat           | 14          | 131-3650           | 1           | Decal-Timecutter   |
| 2           | 119-8828           | 1           | Seat-15 Inch       | 15          | 119-8972           | 1           | Stop-Seat          |
| 3           | 119-3433           | 1           | Rod-Pivot, Narrow  | 18          | 106-8717           | 1           | Decal-Service      |
| 5           | 3290-250           | 2           | Pin-Cotter         | 19          | 131-1040-03        | 1           | Support-Pod        |
| 6           | 92-7054            | 3           | Spring-Compression | 20          | 32144-70           | 4           | Screw-HWHTF        |
| 7           | 104-8300           | 5           | Nut-Flange, NI     | 21          | 3234-29            | 3           | Screw-HHF          |
| 8           | 5-4460             | 2           | Washer-Pivot       | 22          | 3256-23            | 1           | Washer-Flat        |
| 9           | 322-2              | 2           | Screw-HH           | 23          | 3290-307           | 1           | Pin-Cotter         |
| 12          | 37-8771            | 2           | Bolt-Shoulder      | 26          | 3274-55            | 2           | Screw-HSBH         |
| 13          | 119-3431-03        | 2           | Support-Tank, Rear |             |                    |             |                    |


# Belt and Idler Assembly



## Belt and Idler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|-------------|--------------------|-------------|--------------------|
| 3           | 3230-8             | 1           | Screw-CARR           | 11          | 119-8822           | 1           | Pulley-Idler       |
| 6           | 104-8300           | 2           | Nut-Flange, NI       | 12          | 106-2176           | 1           | Pulley-Idler       |
| 7           | 322-7              | 1           | Screw-HH             | 13          | 119-3326           | 1           | Arm-Idler          |
| 8           | 104-6415           | 1           | Spring-Return, Pedal | 14          | 119-3353           | 1           | Spacer             |
| 9           | 5-4460             | 1           | Washer-Pivot         | 15          | 119-3327           | 1           | Spacer-Arm, Idler  |
| 10          | 130-6975           | 1           | V-Belt               | 25          | 3256-3             | 1           | Washer-Flat        |


# Hydo Transaxle Drive and Rear Wheel Assembly



# Hydo Transaxle Drive and Rear Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 119-3331           | 1           | RH Hydro Transaxle ASM   | 21          | 119-3339-03        | 1           | Plate-Cross, Hydro |
| 2           | 119-3330           | 1           | LH Hydro Transaxle ASM   | 22          | 3234-29            | 4           | Screw-HHF          |
| 4           | 322-11             | 4           | Screw-HH                 | 23          | 3290-307           | 2           | Pin-Cotter         |
| 5           | 322-13             | 4           | Screw-HH                 | 24          | 130-7049           | 1           | Rod-Bypass, RH     |
| 6           | 104-8300           | 12          | Nut-Flange, NI           | 26          | 3296-48            | 6           | Nut-Lock, NI       |
| 16          | 131-3671           | 2           | 2 Ply Wheel And Tire ASM | 27          | 3256-25            | 6           | Washer-Flat        |
| 17          | 242-50             | 8           | Nut-Lug                  | 28          | 324-8              | 2           | Screw-HH           |
| 18          | 117-7264-03        | 2           | Mount-Hydro              | 29          | 119-8952           | 2           | Washer             |
| 19          | 131-0900           | 1           | Rod-Bypass, LH           | 30          | 3256-23            | 6           | Washer-Flat        |
| 20          | 324-10             | 4           | Screw-HH                 |             |                    |             |                    |

## 2 Ply Wheel and Tire Assembly No. 131-3671




## 2 Ply Wheel and Tire Assembly No. 131-3671 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 131-3678           | 1           | Tire-2 Ply         |
| 3           | 232-27             | 1           | Stem-Valve         |
| 99          | 107-2491           | 1           | Tube-Tire ●        |

● Not illustrated

# Left Hand Hydro Transaxle Assembly No. 119-3330




# Left Hand Hydro Transaxle Assembly No. 119-3330 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 120-5532           | 1           | Main Housing ASM      | 83          | 104-5329           | 1           | Pin-Jackshaft             |
| 2           | 120-5534           | 1           | Housing Side Kit      | 91          | 120-5539           | 1           | Gear-Bull                 |
| 5           | 104-2189           | 1           | Plug-Thread, Straight | 92          | 104-2142           | 1           | Nut-HJ                    |
| 7           | 117-5359           | 16          | Screw-HHF             | 93          | 115-8314           | 1           | Bushing-Inboard           |
| 13          | 104-2147           | 1           | Sealant ●             | 94          | 120-5540           | 1           | Shaft-Axle                |
| 32          | 106-8678           | 2           | Rod-Bypass            | 95          | 120-5541           | 1           | Bearing-Sleeve            |
| 40          | 104-5304           | 1           | Swashplate-Trunnion   | 100         | 106-8694           | 1           | Disc-Brake, Cog           |
| 42          | 104-2116           | 1           | Stud                  | 130         | 103-2666           | 1           | Cylinder Block Kit        |
| 43          | 112-9853           | 1           | Puck-Friction         | 131         | 110-8561           | 1           | Pump Block ASM            |
| 45          | 114-8491           | 1           | Washer                | 132         | 117-5362           | 1           | Arm Control Kit           |
| 50          | 120-5537           | 1           | Spring-Compression    | 133         | 106-8688           | 1           | Brake Arm Kit             |
| 51          | 120-5538           | 1           | Washer                | 134         | 112-9861           | 1           | Center Section Filter Kit |
| 52          | 104-5306           | 1           | Shaft-Input           | 135         | 114-1634           | 1           | Filter Kit                |
| 53          | 104-5311           | 1           | Bearing-Ball          | 136         | 121-5730           | 1           | RH Expansion Tank Kit     |
| 55          | 104-5308           | 1           | Spacer                | 137         | 120-5549           | 1           | Bypass Kit                |
| 60          | 94-6922            | 1           | Bearing-Thrust        | 138         | 121-5731           | 1           | Hub Kit                   |
| 70          | 104-5339           | 1           | Washer-Flat           | 139         | 121-5729           | 1           | Fan Pulley Kit            |
| 72          | 104-5316           | 1           | Gear-Pinnion, 13T     | 150         | 104-5349           | 1           | Fitting-Sae               |
| 73          | 106-8683           | 1           | Shaft-Motor           | 151         | 115-8302           | 1           | Hose                      |
| 74          | 104-5360           | 1           | Washer                | 159         | 121-5728           | 1           | Case-Tube                 |
| 80          | 119-5541           | 2           | Washer                | 160         | 125-0041           | 1           | Cap-Axle                  |
| 81          | 104-5317           | 1           | Gear-10T/48T          | 161         | 114-8467           | 1           | Hub-Puller, 4 Bolt        |
| 82          | 104-5318           | 1           | Gear-Jackshaft, 10T   | 162         | 120-7103           | 1           | Seal And Ring Kit         |

● Not illustrated

# Right Hand Hydro Transaxle Assembly No. 119-3331




# Right Hand Hydro Transaxle Assembly No. 119-3331 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>    | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|-----------------------|-------------|--------------------|-------------|---------------------------|
| 1           | 120-5531           | 1           | Main Housing ASM      | 83          | 104-5329           | 1           | Pin-Jackshaft             |
| 2           | 120-5533           | 1           | Housing Side Kit      | 91          | 120-5539           | 1           | Gear-Bull                 |
| 5           | 104-2189           | 1           | Plug-Thread, Straight | 92          | 104-2142           | 1           | Nut-HJ                    |
| 7           | 117-5359           | 16          | Screw-HHF             | 93          | 115-8314           | 1           | Bushing-Inboard           |
| 13          | 104-2147           | 1           | Sealant ●             | 94          | 120-5540           | 1           | Shaft-Axle                |
| 32          | 106-8678           | 2           | Rod-Bypass            | 95          | 120-5541           | 1           | Bearing-Sleeve            |
| 40          | 104-5304           | 1           | Swashplate-Trunnion   | 100         | 106-8694           | 1           | Disc-Brake, Cog           |
| 42          | 104-2116           | 1           | Stud                  | 130         | 103-2666           | 1           | Cylinder Block Kit        |
| 43          | 112-9853           | 1           | Puck-Friction         | 131         | 110-8561           | 1           | Pump Block ASM            |
| 45          | 114-8491           | 1           | Washer                | 132         | 117-5362           | 1           | Arm Control Kit           |
| 50          | 120-5537           | 1           | Spring-Compression    | 133         | 106-8688           | 1           | Brake Arm Kit             |
| 51          | 120-5538           | 1           | Washer                | 134         | 112-9862           | 1           | Center Section Filter Kit |
| 52          | 104-5306           | 1           | Shaft-Input           | 135         | 114-1634           | 1           | Filter Kit                |
| 53          | 104-5311           | 1           | Bearing-Ball          | 136         | 121-5735           | 1           | LH Expansion Tank Kit     |
| 55          | 104-5308           | 1           | Spacer                | 137         | 107-2489           | 1           | Bypass Arm Kit            |
| 60          | 94-6922            | 1           | Bearing-Thrust        | 138         | 121-5731           | 1           | Hub Kit                   |
| 70          | 104-5339           | 1           | Washer-Flat           | 139         | 121-5729           | 1           | Fan Pulley Kit            |
| 72          | 104-5316           | 1           | Gear-Pinnion, 13T     | 150         | 104-5349           | 1           | Fitting-Sae               |
| 73          | 106-8683           | 1           | Shaft-Motor           | 151         | 115-8302           | 1           | Hose                      |
| 74          | 104-5360           | 1           | Washer                | 159         | 121-5728           | 1           | Case-Tube                 |
| 80          | 119-5541           | 2           | Washer                | 160         | 125-0041           | 1           | Cap-Axle                  |
| 81          | 104-5317           | 1           | Gear-10T/48T          | 161         | 114-8467           | 1           | Hub-Puller, 4 Bolt        |
| 82          | 104-5318           | 1           | Gear-Jackshaft, 10T   | 162         | 120-7103           | 1           | Seal And Ring Kit         |

● Not illustrated


# Clutch Assembly



## Clutch Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 5           | 3234-42            | 1           | Screw-HHF          | 10          | 104-8301           | 1           | Nut-Flange, NI     |
| 6           | 130-6854           | 1           | Pulley-Engine      | 11          | 117-7468           | 1           | Clutch-Electric    |
| 7           | 120-2217           | 1           | Isolator-Clutch    | 13          | 3212-16            | 1           | Screw-HH           |
| 8           | 119-8884           | 1           | Stop-Clutch        |             |                    |             |                    |

# Engine and Muffler Assembly




## Engine and Muffler Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Engine-Kohler 22HP 7000 Series Autochoke ● ■ | 9           | 117-1261           | 1           | Hose-Drain, Oil    |
| 1:1         | 110-6697           | 2           | Gasket-Exhaust                               | 12          | 3253-4             | 4           | Washer-Lock        |
| 1:3         | 281-2              | 1           | Plug-Pipe, SQH                               | 14          | 32144-109          | 4           | Screw-Taptite      |
| 2           | 614249             | 1           | Tie-Cable                                    | 17          | 3256-24            | 3           | Washer-Flat        |
| 3           | 3274-10            | 4           | Screw-HSH                                    | 24          | 131-1071-03        | 1           | Shield-Heat        |
| 4           | 130-0676           | 1           | Muffler                                      | 25          | 46-8560            | 2           | Screw-HHFTF        |

● Not serviced separately

■ Obtain parts from [www.kohlerplus.com](http://www.kohlerplus.com)

# Body Styling and Fuel Tank Assembly



## Body Styling and Fuel Tank Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-------------------------|
| 1           | 119-3335           | 1           | Pod-RH                     | 9:1         | 121-0793           | 1           | Connector-Elbow, 90 DEG |
| 2           | 119-3334           | 1           | Pod-LH                     | 9:2         | 46-6560            | 2           | Bushing                 |
| 3           | 131-4161           | 1           | Decal-Panel, Control       | 9:4         | 117-7400           | 1           | Fitting-Plastic         |
| 4           | 121-5674           | 1           | Cable-Throttle (45.0 Inch) | 10          | 120-7950           | 6           | Screw-Shoulder          |
| 5           | 3258-166           | 3           | Screw-PRH                  | 11          | 609830             | 2           | Spring                  |
| 6           | 107069             | 3           | Clip                       | 17          | 119-3476-03        | 1           | Support-Tank, Front     |
| 7           | 120-5461           | 1           | Cap-Fuel, Ratcheting       | 18          | 32144-70           | 2           | Screw-HWHTF             |
| 8           | 119-3378-03        | 1           | Plate-Control              | 19          | 119-8814           | 1           | Decal-Control Lever, LH |
| 9           | 119-3324           | 1           | Fuel Tank ASM              | 20          | 119-8815           | 1           | Decal-Control Lever, RH |


## Fuel Delivery Assembly

## Fuel Delivery Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 3           | 109-0273           | 1           | Hose-Fuel          |
| 6           | 108-9698           | 1           | Hose-Fuel          |
| 8           | 2412-98            | 3           | Clamp-Hose         |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 10          | 117-5399           | 1           | Adaptor-Orifice    |
| 11          | 110-1876           | 1           | Hose-Fuel          |
| 13          | 3334-945           | 2           | Tie-Cable          |


# Battery and Electrical Assembly



## Battery and Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|----------------------|
| 1           | 105-1692           | 1           | Battery-Dry             | 11          | 121-5726           | 1           | Cable-Battery, Black |
| 2           | 117-2221           | 1           | Switch-Ignition         | 12          | 104-2466           | 1           | Holddown-Battery     |
| 3           | 63-8360            | 1           | Key-Ignition            | 13          | 321-3              | 1           | Screw-HH             |
| 4           | 103-5221           | 1           | Switch-PTO              | 15          | 3256-22            | 2           | Washer-Flat          |
| 5           | 32103-22           | 1           | Nut-Wing                | 17          | 119-8897           | 1           | Cable-Battery, Red   |
| 7           | 100-3524           | 1           | Switch-Seat             | 18          | 32128-33           | 2           | Nut-HF               |
| 8           | 117-1197           | 1           | Solenoid                | 20          | 32144-4            | 2           | Screw-HWH            |
| 9           | 121-0711           | 1           | Cable-Battery, Positive | 21          | 3220-2             | 2           | Nut-Jam              |
| 10          | 3229-1             | 1           | Bolt-CARR               |             |                    |             |                      |

# Fuse and Wire Harness Assembly




## Fuse and Wire Harness Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 110-6765           | 2           | Switch             |
| 2           | 132-0924           | 1           | Harness-Wire ●     |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 2:1         | 109103             | 1           | Fuse-Blade, 30 Amp |
| 2:2         | 109102             | 1           | Fuse-Blade, 25 Amp |

● Use dielectric grease on all unsealed connectors and terminals only. Do not apply in sealed connectors.


## 42 Inch Deck Assembly



## 42 Inch Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>            | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|-------------------------------|-------------|--------------------|-------------|---------------------|
| 1           | 131-3604           | 1           | 42 Inch Deck And Decal<br>ASM | 15          | 112-3977           | 2           | Bolt-Shoulder       |
| 2           | 131-4138           | 1           | Bracket-Hanger, RH            | 16          | 1-603299           | 2           | Roller-Scalp, Anti  |
| 3           | 131-1091           | 1           | Bracket-Hanger, LH            | 17          | 112-4026           | 1           | Rod-Pivot           |
| 4           | 3231-2             | 2           | Bolt-CARR                     | 18          | 110-6694           | 1           | Spring-Torsion      |
| 6           | 104-8301           | 4           | Nut-Flange, NI                | 19          | 112-3951           | 1           | Deflector           |
| 7           | 95-2747            | 1           | Fitting-Washout               | 20          | 3296-59            | 1           | Nut-Lock, NI        |
| 8           | 46-6290            | 1           | O-Ring                        | 21          | 104-8300           | 2           | Nut-Flange, NI      |
| 9           | 46-8560            | 2           | Screw-HHFTF                   | 22          | 110-0618           | 1           | Pin-Clevis          |
| 10          | 117-1222           | 1           | Decal                         | 23          | 120-7024           | 1           | Screw-Shoulder, HHF |
| 11          | 112-3983-03        | 1           | Baffle-Cutoff                 | 24          | 3256-23            | 1           | Washer-Flat         |
| 12          | 95-3270            | 1           | Connector-Hose                | 25          | 1-806003           | 1           | Pin-Cotter          |
| 13          | 108-7889           | 2           | Cover-Belt                    | 26          | 131-0955           | 1           | Rod-Level, Deck     |
| 14          | 32144-1            | 6           | Screw-Taptite                 | 27          | 3230-22            | 1           | Screw-CARR          |

# 42 Inch Deck Assembly No. 131-3604




## 42 Inch Deck Assembly No. 131-3604 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 3           | 93-7009            | 1           | Decal-Danger        |
| 4           | 132-0872           | 2           | Decal-Danger, Deck  |
| 5           | 105-7015           | 1           | Decal-Routing, Belt |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 3290-282           | 2           | Rivet-Blind        |
| 7           | 321-2              | 3           | Screw-HH           |
| 8           | 3296-42            | 3           | Nut-Lock, NI       |

# 42 Inch Deck, Belt and Blade Assembly



## 42 Inch Deck, Belt and Blade Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|----------------------------|-------------|--------------------|-------------|-----------------------------|
| 1           | 119-8819           | 1           | V-Belt                     | 13          | 32144-41           | 8           | Screw-Taptite               |
| 2           | 323-9              | 2           | Screw-HH                   | 14          | 26-0671            | 2           | Screw-HH                    |
| 3           | 3256-24            | 1           | Washer-Flat                | 15          | 3290-465           | 2           | Washer-Belleville           |
| 4           | 106-2175           | 2           | Pulley-Idler, Flat         | 16          | 106-2177           | 1           | Spring-Extension            |
| 5           | 104-8301           | 2           | Nut-Flange, NI             | 17          | 131-3939-03        | 2           | Blade-High Lift, 21.60 Inch |
| 6           | 114-8540           | 1           | Arm-Idler                  | 18          | 88-5970            | 1           | Hook-Return, Spring         |
| 7           | 120-2229           | 2           | Washer                     | 19          | 121-0751           | 2           | Spindle ASM                 |
| 8           | 114-0463           | 2           | Washer-Friction, Composite | 19:1        | 117-7267           | 1           | Spindle                     |
| 9           | 115-4986           | 1           | Spacer                     | 19:2        | 120-7935           | 2           | Spacer                      |
| 10          | 323-7              | 1           | Screw-HH                   | 19:3        | 38-7820            | 2           | Bearing-Ball                |
| 11          | 3219-6             | 2           | Nut-Hex                    | 20          | 117-7268           | 2           | Shaft-Spindle               |
| 12          | 125-5574           | 2           | Pulley                     | 21          | 63-7400            | 1           | Washer-Rebound              |

# Attachments and Accessories

## For 74721 TimeCutter SS 4225 Riding Mower

| Product Name                                                                  | Model/Part   |
|-------------------------------------------------------------------------------|--------------|
| Attachment Mount Kit .....                                                    | 131-3966     |
| Weight Kit .....                                                              | 131-7658     |
| Cargo Carrier .....                                                           | 79040        |
| 42in Bagger, Zero-Turn-Radius Riding Mower .....                              | 79391        |
| 42in Blowout Ring Kit.....                                                    | 114-1620     |
| 42in Recycler Kit.....                                                        | 131-4182     |
| Striping Kit .....                                                            | 120-7905     |
| Replacement Blade Kit .....                                                   | 131-3939-03P |
| Foot Assist Deck Lift Kit, 2011 and After Zero-Turn-Radius Riding Mower ..... | 79010        |
| Floor Mat Kit .....                                                           | 132-6921     |
| Seat With Armrests-18in .....                                                 | 119-8830     |
| Sunshade Kit .....                                                            | 79011        |
| Hourmeter Kit .....                                                           | 116-5461     |
| Assist Handle and Step Kit .....                                              | 79339        |
| Storage Cover .....                                                           | 490-7516     |
| Fuel Stabilizer (4oz).....                                                    | 117-0089     |
| Fuel Stabilizer (16oz).....                                                   | 117-0090     |
| Oil-Synthetic, All Season .....                                               | 117-0066     |
| 10w30 4-cycle Engine Oil (32oz Bottle) .....                                  | 38280        |
| Toro 4-cycle Sae 30 Oil (32oz Bottle).....                                    | 38903        |
| Deluxe Seat Kit .....                                                         | 131-7699     |
| Jack Mount Kit .....                                                          | 126-5251     |
| Jack Kit .....                                                                | 127-6666     |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**