



Count on it.

Parts Catalog

CE Light Kit

**Groundsmaster® 4500-D, 4700-D or
Reelmaster® 7000-D Traction Units**

Model No. 31573

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard


TAP: self tapping

TTH: torx truss head

Contents


CE Light Kit Assembly 4

Switch Assembly 6



CE Light Kit Assembly



Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	125-4624-03	1	Bracket-Light, RH	7:4	120-0471	1	Bulb-Halogen
2	125-4625-03	1	Bracket-Light, LH	7:5	120-0472	1	Bulb-Lamp
3	119-8093	2	Rear Lamp ASM	7:6	120-0473	1	Bulb-Lamp
3:1	120-7552	1	Bulb-12V	8	125-4645-03	1	Bracket-Horn
3:2	120-6657	1	Bulb-5W	9	116749	1	Horn
3:3	120-6656	1	Lens-Red	10	323-34	1	Screw-HH
3:4	60-6910	2	Screw-HH	11	104-8301	7	Nut-Flange, NI
3:5	48-7880	4	Nut-Hex	12	321-11	2	Screw-HH
4	131-7783-03	1	Bracket-Right Front	13	104-7201	2	Nut-Flange, NI
5	131-7782-03	1	Bracket-Left Front	14	122-0747	1	Harness-Wire, Primary
6	119-8324	1	LH Headlamp ASM				Homologation
6:1	33025-00	1	Nut-Lock, NI	14:8	218-578	3	Fuse-Blade, 10 Amp
6:2	120-0475	2	Shell-Articulated	14:9	100-4918	2	Diode-Over Molded
6:3	120-0474	2	Joint-Articulated	14:10	121-8864	4	Fuse-Mini Blade, 5 Amp
6:4	120-0471	1	Bulb-Halogen	14:17	109355	1	Fuse-Blade, 15 Amp
6:5	120-0472	1	Bulb-Lamp	15	99-7667	4	Washer-Flat
6:6	120-0473	1	Bulb-Lamp	16	3218-6	4	Nut-Jam
7	119-8323	1	RH Headlamp ASM	17	115-4841	4	Screw-HH
7:1	33025-00	1	Nut-Lock, NI	18	323-12	6	Screw-HH
7:2	120-0475	2	Shell-Articulated	19	32144-87	2	Screw-HWHTF
7:3	120-0474	2	Joint-Articulated	20	131-7753-03	1	Bracket-Mount, Sensor



CE Light Kit Assembly (continued)

Ref.	Part Number	Qty.	Description
21	131-7754	1	Plate-Switch
22	95-8900	1	Switch
23	3256-21	4	Washer-Flat
24	32105-9	2	Screw
25	3296-9	2	Nut-Lock
26	3234-4	2	Screw-HHF
27	32128-33	2	Nut-HF

Ref.	Part Number	Qty.	Description
28	3229-34	1	Screw-CARR
29	3296-2	1	Nut-Lock, NI
30	99-7430	1	Relay
31	112-3169	1	Screw-HHF, Serrated
32	3296-54	1	Nut-Lock
33	131-7767	1	Decal-Fusebox



Switch Assembly

Ref.	Part Number	Qty.	Description
1	131-7784-03	1	Bracket-Column
2	119-7769	1	Switch-Rocker, On/None/On
3	95-8999	1	Switch
4	119-9880	1	Module-Flasher
5	120-3953	1	Switch-Paddle, On/Off/On
6	112-3324	1	Switch-Horn
7	112-3313	1	Nut-Weatherproof
8	131-7786	1	Mount-Bracket, Column
9	3231-21	2	Screw-CARR
10	1-303287	1	Tie-Cable
11	104-6957	1	Decal-Horn
12	701493	2	Nut-Speed

Ref.	Part Number	Qty.	Description
13	115-9830	3	Screw-HSBH
14	32128-17	1	Nut-Lock, Flange
15	115-5417	1	Strip-Foam
16	131-7785	1	Cover-Column
17	93-5023	4	Spacer
18	95-5622	2	Hanger-Rubber
19	3256-3	8	Washer-Flat
20	322-8	4	Screw-HH
21	132-3262-03	2	Plate-Bent, Bracket
22	104-8300	4	Nut-Flange, NI
23	104-8301	2	Nut-Flange, NI

Notes:



Count on it.