



Form No. 3400-853 Rev A

**Count on it.**

# Parts Catalog

## **TITAN® ZX5400 Zero-Turn-Radius Riding Mower**

Model No. 74862—Serial No. 316000001 and Up



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HP:** high pressure

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** low pressure

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard


**TAP:** self tapping

**TTH:** torx truss head

# Contents

|                                                   |    |
|---------------------------------------------------|----|
| Frame, Front Axle and Caster Wheel Assembly ..... | 4  |
| Control Panel and Body Styling Pod Assembly ..... | 6  |
| Deck Lift Assembly.....                           | 8  |
| Seat Mounting Assembly .....                      | 10 |
| Seat Assembly No. 131-4147 .....                  | 12 |
| Traction Drive Assembly .....                     | 14 |
| LH Hydro Transmission Assembly No. 127-3381 ..... | 16 |
| RH Hydro Transmission Assembly No. 127-3382.....  | 18 |
| Motion Control Assembly .....                     | 20 |
| Brake Link Assembly .....                         | 22 |
| Engine, Muffler and Clutch Assembly .....         | 24 |
| Fuel Delivery Assembly.....                       | 26 |
| Multi Layer Fuel Tank Assembly No. 117-7352 ..... | 28 |
| Roll-Over Protection System Assembly .....        | 30 |
| Electrical Assembly .....                         | 32 |
| Deck Assembly.....                                | 34 |
| 54 Inch Deck Assembly No. 131-4141 .....          | 36 |
| Deck Belt and Blade Assembly .....                | 38 |
| Attachments and Accessories .....                 | 40 |

Frame, Front Axle and Caster Wheel Assembly




## Frame, Front Axle and Caster Wheel Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------|
| 1           | 131-4039-01        | 1           | Frame ASM           | 17          | 120-2248-03        | 1           | Guard-Rear         |
| 2           | 127-3423-01        | 1           | Pan-Floor           | 18          | 67-1300            | 1           | Decal              |
| 3           | 32144-70           | 6           | Screw-HWHTF         | 19          | 105-8278           | 1           | Decal              |
| 4           | 132-0871           | 1           | Decal-Danger        | 20          | 121-0704-01        | 1           | Tube-Guard         |
| 5           | 127-3447           | 2           | Tire And Wheel ASM  | 21          | 322-10             | 2           | Screw-HH           |
| 5:1         | 120-2252           | 1           | Tire-13 Inch Smooth | 22          | 121-2980           | 2           | Cap                |
| 5:3         | 114-1640           | 2           | Bushing-Flange      | 23          | 117-1241           | 1           | Cover-Fan, RH      |
| 5:4         | 232-27             | 1           | Stem-Valve          | 24          | 117-1242           | 1           | Cover-Fan, LH      |
| 5:5         | 302-5              | 1           | Fitting-Grease      | 25          | 46-8560            | 2           | Screw-HHFTF        |
| 5:99        | 232-46             | 1           | Tube ●              | 28          | 127-3330-01        | 2           | Spacer-Caster      |
| 6           | 119-3475           | 2           | Spanner             | 30          | 116-4348           | 2           | Cap-Grease         |
| 7           | 325-37             | 2           | Screw-HH            | 32          | 131-4137-03        | 1           | Shield-Heat        |
| 8           | 3296-45            | 2           | Nut-Lock, NI        | 33          | 322-23             | 2           | Screw-HH           |
| 9           | 127-3309-01        | 2           | Fork-Caster         | 34          | 3256-23            | 4           | Washer-Flat        |
| 10          | 10-8110            | 2           | Washer-Thrust       | 36          | 116-1297           | 2           | Screw-Shoulder     |
| 11          | 109-3678           | 4           | Bearing-Ball        | 37          | 1-513658           | 3           | Bumper             |
| 12          | 3256-68            | 2           | Washer-Flat         | 38          | 112-9771           | 1           | Washer-Teflon      |
| 13          | 3234-47            | 2           | Screw-HHF           | 39          | 130-0733           | 3           | Pad-Rubber         |
| 14          | 121-2953-03        | 1           | Support-Seat        | 40          | 117-1232-03        | 1           | Bracket-Hitch      |
| 15          | 322-12             | 4           | Screw-HH            | 42          | 131-4036           | 1           | Decal              |
| 16          | 104-8300           | 10          | Nut-Flange, NI      |             |                    |             |                    |

● Not illustrated

# Control Panel and Body Styling Pod Assembly




## Control Panel and Body Styling Pod Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 1           | 120-5488           | 1           | Pod-RH               |
| 2           | 120-5489           | 1           | Pod-LH               |
| 3           | 115-9632           | 1           | Decal-Panel, Control |
| 4           | 131-1006           | 1           | Cable-Throttle       |
| 5           | 3258-166           | 4           | Screw-PRH            |
| 6           | 107069             | 4           | Clip                 |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 115-2591-03        | 1           | Panel-Control      |
| 8           | 120-7950           | 6           | Screw-Shoulder     |
| 9           | 115-9656           | 1           | Cable-Choke        |
| 10          | 3253-21            | 1           | Washer-Lock        |
| 11          | 3220-3             | 1           | Nut-HJ             |
| 12          | 105-1853           | 2           | Clamp-Hose         |


Deck Lift Assembly



## Deck Lift Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|---------------------|
| 1           | 131-4058-03        | 1           | Pivot-Front         | 14          | 116-4313           | 4           | Spacer-Step, Double |
| 2           | 131-4059-03        | 1           | Pivot-Rear          | 15          | 104-8301           | 10          | Nut-Flange, NI      |
| 3           | 116-2887           | 4           | Gusset-Lift, Deck   | 16          | 43-0940            | 4           | Spacer              |
| 4           | 115-5065           | 4           | Bushing-Flange      | 17          | 130-0742           | 8           | Bolt-Shoulder       |
| 5           | 322-6              | 8           | Screw-HH            | 18          | 130-0785           | 1           | Decal               |
| 6           | 104-8300           | 8           | Nut-Flange, NI      | 19          | 127-3329-01        | 1           | Pan-Deck, Pivot     |
| 7           | 127-3389-03        | 2           | Plate-Deck, Lift    | 20          | 127-3399           | 1           | Rod-Deck, Pivot     |
| 8           | 127-3391           | 1           | Lock-Transport, HOC | 21          | 3256-26            | 2           | Washer-Flat         |
| 9           | 116-4312           | 1           | Grip-Bar, Flat      | 22          | 1-806005           | 2           | Pin-Cotter          |
| 10          | 127-3390-03        | 1           | Link-HOC            | 23          | 115-9652           | 1           | Spring-Extension    |
| 11          | 116-5584           | 1           | Pin-HOC             | 24          | 130-0668           | 4           | Chain-Decklift      |
| 12          | 130-0654           | 1           | Decal-HOC           | 25          | 130-0734           | 2           | Pad-Rubber          |
| 13          | 114-4681           | 4           | Screw-HHF           |             |                    |             |                     |


# Seat Mounting Assembly



## Seat Mounting Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|---------------------|
| 1           | 131-3944-03        | 1           | Pan-Seat           | 8           | 3290-250           | 2           | Pin-Cotter          |
| 2           | 131-4147           | 1           | Seat ASM           | 9           | 130-6996           | 1           | Decal-Maintenance   |
| 3           | 701178             | 3           | Cap-Protector      | 10          | 107069             | 1           | Clip                |
| 4           | 3234-47            | 3           | Screw-HHF          | 11          | 99-6810            | 1           | Screw-HHF           |
| 5           | 92-7054            | 3           | Spring-Compression | 12          | 131-1038           | 1           | Bracket-Stop, Seat  |
| 6           | 104-8300           | 3           | Nut-Flange, NI     | 13          | 131-4008-03        | 1           | Bracket-Latch, Seat |
| 7           | 115-4966           | 1           | Rod-Stop           | 15          | 32144-70           | 2           | Screw-HWHTF         |

# Seat Assembly No. 131-4147




## Seat Assembly No. 131-4147 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>   |
|-------------|--------------------|-------------|----------------------|
| 2           | 131-4149           | 1           | Cushion-Seat, Back   |
| 3           | 131-4151           | 1           | Cushion-Seat, Bottom |
| 4           | 131-4153           | 1           | Track ASM            |
| 5           | 131-4154           | 1           | Bushing ASM          |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 6           | 131-4155           | 1           | Armrest Kit        |
| 7           | 131-4156           | 1           | Shell              |
| 8           | 82-2190            | 1           | Switch-Bail        |
| 9           | 110-4163           | 2           | Cushion-Rest, Arm  |


# Traction Drive Assembly



## Traction Drive Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 127-3381           | 1           | LH Hydro Transmission<br>ASM | 20          | 1-806003           | 2           | Pin-Cotter         |
| 2           | 127-3382           | 1           | RH Hydro Transmission<br>ASM | 21          | 125-8950           | 2           | Rod-Bypass         |
| 3           | 110-9981           | 1           | Washer-Plain                 | 22          | 119-8952           | 2           | Washer             |
| 4           | 115-4986           | 1           | Spacer                       | 23          | 127-3449           | 2           | Tire And Wheel ASM |
| 5           | 114-0463           | 2           | Washer-Friction, Composite   | 23:2        | 125-1821           | 1           | Tire               |
| 6           | 117-5350           | 1           | Arm-Idler                    | 23:3        | 232-27             | 1           | Stem-Valve         |
| 7           | 104-8301           | 3           | Nut-Flange, NI               | 23:99       | 105-4070           | 1           | Tube-Inner         |
| 9           | 109-3397           | 2           | Pulley-Idler, Flat           | 24          | 242-50             | 8           | Nut-Lug            |
| 10          | 1-603402           | 1           | Spring-Extension             | 25          | 115-9613           | 1           | V-Belt             |
| 11          | 3231-26            | 2           | Screw-CARR                   | 26          | 115-9618           | 1           | HYD Reservoir ASM  |
| 12          | 323-12             | 1           | Screw-HH                     | 26:2        | 109-3320           | 1           | Cap-Reservoir, HYD |
| 13          | 109-3652           | 2           | Spacer-Hydro                 | 27          | 115-4969           | 2           | Hose-Overflow      |
| 14          | 115-2559           | 1           | Shaft-Cross, Hydro           | 28          | 117-1193           | 4           | Clamp-Hose         |
| 15          | 322-13             | 4           | Screw-HH                     | 29          | 46-8560            | 2           | Screw-HHFTF        |
| 16          | 104-8300           | 8           | Nut-Flange, NI               | 30          | 130-6922           | 2           | Decal-Bypass       |
| 17          | 322-38             | 2           | Screw-HH                     | 31          | 3256-23            | 8           | Washer-Flat        |
| 18          | 322-11             | 2           | Screw-HH                     | 32          | 117-5351           | 1           | Spacer             |
| 19          | 323-10             | 2           | Screw-HH                     | 33          | 117-7248-03        | 2           | Plate-Spring       |
|             |                    |             |                              | 34          | 110769             | 2           | Spring-Extension   |


# LH Hydro Transmission Assembly No. 127-3381



# LH Hydro Transmission Assembly No. 127-3381 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|------------------------------|
| 1           | 114-8471           | 1           | Main Housing Kit         | 31          | 120-7974           | 1           | Gear-11T                     |
| 2           | 114-8472           | 1           | Side Cover Kit           | 32          | 104-5329           | 1           | Pin-Jackshaft                |
| 3           | 117-5359           | 16          | Screw-HHF                | 33          | 104-2169           | 1           | Ring-Retaining               |
| 4           | 114-1678           | 4           | O-Ring                   | 34          | 114-1694           | 1           | Gear-54T                     |
| 5           | 104-2189           | 1           | Plug-Thread, Straight    | 35          | 120-7975           | 1           | Spacer                       |
| 6           | 109-3321           | 1           | Element-Oil Filter, HYD  | 36          | 126-0789           | 1           | Bearing-Ball                 |
| 7           | 106-8676           | 1           | Seal-Lip                 | 37          | 120-7976           | 1           | Bearing-Ball                 |
| 8           | 106-8677           | 1           | Ring-Retaining, EXT      | 38          | 104-2144           | 1           | Seal                         |
| 9           | 114-1685           | 1           | Rod-Bypass               | 39          | 109-5939           | 1           | Hub Kit                      |
| 10          | 106-8679           | 1           | Ring-Retaining, Int      | 40          | 114-1697           | 1           | Pawl-Brake                   |
| 11          | 107-2490           | 1           | Arm-Bypass               | 41          | 131-0907           | 1           | Shaft-Brake                  |
| 12          | 106-8681           | 1           | Ring-Retaining, EXT      | 42          | 125-0021           | 1           | Handle-Brake                 |
| 13          | 104-5304           | 1           | Swashplate-Trunnion      | 43          | 131-0906           | 1           | Ring-Retaining, EXT          |
| 14          | 104-5313           | 1           | Seal-Lip                 | 44          | 104-2120           | 3           | Screw                        |
| 15          | 104-2116           | 1           | Stud                     | 45          | 120-7979           | 1           | Guard-Filter, LH             |
| 16          | 112-9853           | 1           | Puck-Friction            | 46          | 109-3278           | 1           | Adapter-Straight             |
| 17          | 104-5308           | 1           | Spacer                   | 46:1        | 237-42             | 1           | O-Ring                       |
| 18          | 104-5310           | 1           | Seal-Lip                 | 47          | 114-8455           | 2           | Tube-Connecting              |
| 19          | 104-5309           | 1           | Ring-Retaining           | 48          | 115-5057           | 1           | Cover-Nut, Axle              |
| 20          | 112-4154           | 1           | Bearing-Thrust           | 49          | 131-0908           | 1           | Seal-Gerotor                 |
| 21          | 114-1689           | 1           | Motor Cylinder Block Kit | 50          | 121-5745           | 1           | Spacer                       |
| 22          | 94-6922            | 1           | Bearing-Thrust           | 51          | 109-3537           | 1           | Seal Kit                     |
| 23          | 110-8561           | 1           | Pump Block ASM           | 52          | 131-0909           | 1           | LH Center Section Charge Kit |
| 24          | 104-5339           | 1           | Washer-Flat              | 53          | 114-8464           | 1           | Charge Relief Kit            |
| 25          | 104-5340           | 1           | Ring-Retaining           | 54          | 114-8465           | 1           | Charge Kit                   |
| 26          | 131-0905           | 1           | Gear-14T                 | 55          | 125-0059           | 1           | Fan And Pulley Kit           |
| 27          | 114-1691           | 1           | Shaft-Motor              | 56          | 117-5361           | 1           | Input Shaft Kit              |
| 28          | 104-5360           | 1           | Washer                   | 57          | 117-5362           | 1           | Arm Control Kit              |
| 29          | 94-1933            | 2           | Washer                   | 58          | 114-8470           | 1           | Axle Shaft Kit               |
| 30          | 114-1692           | 1           | Gear-45T                 |             |                    |             |                              |


RH Hydro Transmission Assembly No. 127-3382



# RH Hydro Transmission Assembly No. 127-3382 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>           |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|------------------------------|
| 1           | 114-1676           | 1           | Main Housing Kit         | 31          | 120-7974           | 1           | Gear-11T                     |
| 2           | 117-5358           | 1           | Housing Side Kit         | 32          | 104-5329           | 1           | Pin-Jackshaft                |
| 3           | 117-5359           | 16          | Screw-HHF                | 33          | 104-2169           | 1           | Ring-Retaining               |
| 4           | 114-1678           | 4           | O-Ring                   | 34          | 114-1694           | 1           | Gear-54T                     |
| 5           | 104-2189           | 1           | Plug-Thread, Straight    | 35          | 120-7975           | 1           | Spacer                       |
| 6           | 109-3321           | 1           | Element-Oil Filter, HYD  | 36          | 126-0789           | 1           | Bearing-Ball                 |
| 7           | 106-8676           | 1           | Seal-Lip                 | 37          | 120-7976           | 1           | Bearing-Ball                 |
| 8           | 106-8677           | 1           | Ring-Retaining, EXT      | 38          | 104-2144           | 1           | Seal                         |
| 9           | 114-1685           | 1           | Rod-Bypass               | 39          | 109-5939           | 1           | Hub Kit                      |
| 10          | 106-8679           | 1           | Ring-Retaining, Int      | 40          | 114-1697           | 1           | Pawl-Brake                   |
| 11          | 107-2490           | 1           | Arm-Bypass               | 41          | 131-0907           | 1           | Shaft-Brake                  |
| 12          | 106-8681           | 1           | Ring-Retaining, EXT      | 42          | 125-0021           | 1           | Handle-Brake                 |
| 13          | 104-5304           | 1           | Swashplate-Trunnion      | 43          | 131-0906           | 1           | Ring-Retaining, EXT          |
| 14          | 104-5313           | 1           | Seal-Lip                 | 44          | 104-2120           | 3           | Screw                        |
| 15          | 104-2116           | 1           | Stud                     | 45          | 120-7981           | 1           | Guard-Filter, RH             |
| 16          | 112-9853           | 1           | Puck-Friction            | 46          | 109-3278           | 1           | Adapter-Straight             |
| 17          | 104-5308           | 1           | Spacer                   | 46:1        | 237-42             | 1           | O-Ring                       |
| 18          | 104-5310           | 1           | Seal-Lip                 | 47          | 114-8455           | 2           | Tube-Connecting              |
| 19          | 104-5309           | 1           | Ring-Retaining           | 48          | 115-5057           | 1           | Cover-Nut, Axle              |
| 20          | 112-4154           | 1           | Bearing-Thrust           | 49          | 131-0908           | 1           | Seal-Gerotor                 |
| 21          | 114-1689           | 1           | Motor Cylinder Block Kit | 50          | 121-5745           | 1           | Spacer                       |
| 22          | 94-6922            | 1           | Bearing-Thrust           | 51          | 109-3537           | 1           | Seal Kit                     |
| 23          | 110-8561           | 1           | Pump Block ASM           | 52          | 131-0910           | 1           | RH Center Section Charge Kit |
| 24          | 104-5339           | 1           | Washer-Flat              | 53          | 114-8464           | 1           | Charge Relief Kit            |
| 25          | 104-5340           | 1           | Ring-Retaining           | 54          | 114-8465           | 1           | Charge Kit                   |
| 26          | 131-0905           | 1           | Gear-14T                 | 55          | 125-0059           | 1           | Fan And Pulley Kit           |
| 27          | 114-1691           | 1           | Shaft-Motor              | 56          | 117-5361           | 1           | Input Shaft Kit              |
| 28          | 104-5360           | 1           | Washer                   | 57          | 117-5362           | 1           | Arm Control Kit              |
| 29          | 94-1933            | 2           | Washer                   | 58          | 114-8470           | 1           | Axle Shaft Kit               |
| 30          | 114-1692           | 1           | Gear-45T                 |             |                    |             |                              |


# Motion Control Assembly



## Motion Control Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>     |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|------------------------|
| 1           | 127-3282-03        | 1           | Box-Control        | 23          | 110-6751           | 2           | Bracket-Return         |
| 2           | 120-7950           | 2           | Screw-Shoulder     | 24          | 110-6750           | 2           | Plate-Return           |
| 3           | 110-6828           | 2           | Activator Arm ASM  | 25          | 110-6752           | 2           | Spring-Compression     |
| 3:2         | 105-3455           | 2           | Bushing            | 26          | 110-6894           | 6           | Washer-Pivot           |
| 4           | 106-2214           | 2           | Bolt-Shoulder      | 27          | 323-4              | 2           | Screw-HH               |
| 5           | 131-0964           | 2           | Damper             | 28          | 110-6784           | 2           | Bolt-Shoulder          |
| 6           | 3296-42            | 4           | Nut-Lock, NI       | 29          | 37-8771            | 2           | Bolt-Shoulder          |
| 7           | 46-8560            | 4           | Screw-HHFTF        | 30          | 104-8300           | 4           | Nut-Flange, NI         |
| 8           | 3296-48            | 2           | Nut-Lock, NI       | 31          | 112-9771           | 2           | Washer-Teflon          |
| 9           | 119-8952           | 2           | Washer             | 32          | 130-0655           | 1           | Decal-Fill, Fuel       |
| 10          | 32128-23           | 2           | Nut-HF             | 33          | 117-1255-03        | 1           | Cover-Control, RH      |
| 11          | 3256-5             | 2           | Washer-Flat        | 34          | 1-603807           | 2           | Spring-Return, Neutral |
| 12          | 117-7422           | 2           | Rod-Control        | 35          | 115-2561-03        | 1           | Cover-Control, LH      |
| 13          | 117-7423           | 2           | Bracket-Control    | 36          | 115-9625           | 1           | Decal-Brake, Parking   |
| 14          | 1-808280           | 2           | Pin-Clevis         | 37          | 99-8936            | 2           | Decal-Control, Motion  |
| 15          | 1-806003           | 2           | Pin-Cotter         | 38          | 127-3384           | 1           | Decal                  |
| 16          | 3256-23            | 2           | Washer-Flat        | 39          | 3256-24            | 4           | Washer-Flat            |
| 17          | 132-9344-05        | 2           | Arm-Actuator, RH   | 40          | 323-6              | 4           | Screw-HH               |
| 19          | 115-5023           | 2           | Tab-Stop           | 41          | 121-0731           | 1           | Handle-Control, RH     |
| 20          | 110-6873           | 2           | Eccentric          | 41:1        | 121-0726           | 1           | Grip                   |
| 21          | 110-6874           | 2           | Screw-Eccentric    | 42          | 121-0730           | 1           | Handle-Control, LH     |
| 22          | 110-6875           | 2           | Bolt-Shoulder      | 42:1        | 121-0726           | 1           | Grip                   |


# Brake Link Assembly



## Brake Link Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|--------------------------|
| 1           | 131-4057           | 1           | Brake Handle ASM    | 12          | 3256-23            | 6           | Washer-Flat              |
| 2           | 63-2650            | 1           | Screw-Shoulder      | 13          | 1-603807           | 2           | Spring-Return, Neutral   |
| 3           | 131-4056-03        | 1           | Brake Bellcrank ASM | 14          | 3272-11            | 2           | Pin-Cotter               |
| 4           | 115-5074           | 1           | Link-Brake          | 15          | 3256-27            | 2           | Washer-Flat              |
| 5           | 117-7322           | 1           | Rod-Brake, LH       | 16          | 40-1940            | 2           | Washer                   |
| 6           | 117-7323           | 1           | Rod-Brake, RH       | 17          | 32144-70           | 4           | Screw-HWHTF              |
| 7           | 115-9681           | 2           | Fitting-Rod         | 18          | 322-10             | 2           | Screw-HH                 |
| 8           | 1-633268           | 1           | Grip-Lever          | 19          | 106-9758           | 2           | Screw-CARR               |
| 9           | 104-8300           | 5           | Nut-Flange, NI      | 20          | 127-3435-01        | 1           | Plate-Support, Floor Pan |
| 10          | 256-292            | 2           | Bushing-Flange, NI  | 21          | 119-0718           | 2           | Spacer                   |
| 11          | 1-806003           | 8           | Pin-Cotter          |             |                    |             |                          |

# Engine, Muffler and Clutch Assembly




## Engine, Muffler and Clutch Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           |                    | 1           | Engine-Kohler, Zt730 ●■ | 8           | 32144-109          | 4           | Screw-Taptite      |
| 2           | 131-8660           | 4           | Nut-Locking, Exhaust    | 9           | 104-8300           | 1           | Nut-Flange, NI     |
| 3           | 125-5576           | 1           | Pulley-Engine           | 10          | 110-6697           | 2           | Gasket-Exhaust     |
| 4           | 127-0084           | 1           | Muffler                 | 11          | 110-9981           | 2           | Washer-Plain       |
| 5           | 117-1269-03        | 1           | Bracket-Stop, PTO       | 12          | 3234-47            | 1           | Screw-HHF          |
| 6           | 127-3410           | 1           | Clutch-PTO              | 13          | 117-1261           | 1           | Hose-Drain, Oil    |
| 7           | 3212-11            | 1           | Screw-HH                | 14          | 614249             | 1           | Tie-Cable          |

● Not serviced separately

■ Obtain parts from [www.kohlerplus.com](http://www.kohlerplus.com)


# Fuel Delivery Assembly



## Fuel Delivery Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|--------------------|
| 1           | 117-7352           | 1           | Fuel Tank ASM      | 11          | 125-1847           | 1           | Cap-Fuel           |
| 2           | 114-3765           | 1           | Hose-Fuel          | 12          | 614249             | 3           | Tie-Cable          |
| 3           | 131-8740           | 1           | Hose-Fuel          | 13          | 109-0299           | 1           | Hose-Fuel          |
| 6           | 121-0743           | 1           | Adapter-Orifice    | 14          | 115-2620           | 1           | Rod-Tank, Gas      |
| 9           | 2412-98            | 2           | Clamp-Hose         | 15          | 117-1298           | 1           | Seal-Tank          |
| 10          | 46-8560            | 1           | Screw-HHFTF        |             |                    |             |                    |


Multi Layer Fuel Tank Assembly No. 117-7352



## Multi Layer Fuel Tank Assembly No. 117-7352 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      |
|-------------|--------------------|-------------|-------------------------|
| 1           | 121-0793           | 1           | Connector-Elbow, 90 DEG |
| 2           | 46-6560            | 2           | Bushing                 |
| 4           | 117-7400           | 1           | Fitting-Plastic         |


# Roll-Over Protection System Assembly



## Roll-Over Protection System Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|-------------|--------------------|-------------|---------------------|
| 1           | 121-2986-03        | 2           | Tube-ROPS, Lower    | 11:2        | 130-6927           | 1           | Decal-ROPS, Warning |
| 2           | 115-4962-03        | 2           | Tube-Support, ROPS  | 13          | 3256-26            | 8           | Washer-Flat         |
| 3           | 115-4963-03        | 2           | Bracket-Reinforcing | 16          | 119-8969           | 2           | Nut-Hex             |
| 4           | 84-1560            | 4           | Washer-Thrust       | 18          | 99-5107            | 12          | Nut-Lock            |
| 5           | 325-18             | 2           | Screw-HH            | 19          | 1-513658           | 2           | Bumper              |
| 6           | 325-14             | 10          | Screw-HH            | 20          | 115-5038-03        | 1           | Bracket-Belt, Seat  |
| 7           | 325-5              | 2           | Screw-HH            | 21          | 115-5060-03        | 1           | Bracket-Belt, Seat  |
| 9           | 127-3326-03        | 4           | Plate-ROPS          | 22          | 3234-38            | 2           | Screw-HHF           |
| 11          | 130-6929           | 1           | Upper ROPS ASM      | 23          | 109-9805           | 1           | Seat Belt Kit       |


# Electrical Assembly



## Electrical Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>      | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 105-1692           | 1           | Battery-Dry             | 12:9        | 100-4918           | 1           | Diode-Over Molded  |
| 2           | 117-2221           | 1           | Switch-Ignition         | 13          | 3256-22            | 2           | Washer-Flat        |
| 3           | 63-8360            | 1           | Key-Ignition            | 14          | 32144-1            | 3           | Screw-Taptite      |
| 4           | 103-5221           | 1           | Switch-PTO              | 15          | 92-6989            | 1           | Wire-21 Inch       |
| 5           | 110-6765           | 2           | Switch                  | 16          | 32128-33           | 3           | Nut-HF             |
| 7           | 117-1197           | 1           | Solenoid                | 17          | 98-7249            | 1           | Relay              |
| 8           | 117-5342           | 1           | Cable-Battery, Positive | 18          | 46-8560            | 2           | Screw-HHFTF        |
| 9           | 117-7240           | 1           | Cable-Battery, Negative | 19          | 3220-2             | 2           | Nut-Jam            |
| 10          | 117-7313-01        | 1           | Strap-Battery           | 22          | 120-2244           | 1           | Hourmeter          |
| 11          | 321-4              | 2           | Screw-HH                | 23          | 99-7408            | 1           | Switch-Reverse     |
| 12          | 130-0651           | 1           | Harness-Wire            | 24          | 117-1283-03        | 1           | Tray-Battery       |
| 12:5        | 109103             | 1           | Fuse-Blade, 30 Amp      | 25          | 1-633651           | 1           | Bolt-Holddown      |
| 12:6        | 109102             | 1           | Fuse-Blade, 25 Amp      | 26          | 1-543792           | 1           | Wingnut            |


# Deck Assembly



## Deck Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>       | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|-------------|--------------------|-------------|--------------------|
| 1           | 131-4141           | 1           | 54 Inch Deck ASM         | 18          | 117-1270           | 1           | Deflector          |
| 2           | 131-4051-05        | 1           | Cover-Belt, RH           | 19          | 115-5048-03        | 1           | Plate-Deflector    |
| 3           | 131-4050-05        | 1           | Cover-Belt, LH           | 20          | 115-9653-03        | 1           | Baffle-Cutoff      |
| 4           | 32144-70           | 4           | Screw-HWHTF              | 21          | 3230-3             | 4           | Screw-CARR         |
| 9           | 104-8301           | 3           | Nut-Flange, NI           | 22          | 3230-22            | 4           | Screw-CARR         |
| 10          | 1-603299           | 3           | Roller-Scalp, Anti       | 23          | 104-8300           | 8           | Nut-Flange, NI     |
| 11          | 130-0763           | 1           | Pivot-Deflector          | 24          | 109-8854           | 1           | Pin-Chute          |
| 11:2        | 130-0731           | 1           | Decal-Danger             | 25          | 121-2983           | 1           | Spring-Torsion     |
| 12          | 323-23             | 3           | Screw-HH                 | 26          | 95-2747            | 2           | Fitting-Washout    |
| 13          | 104-0892           | 3           | Spacer-Axle, Rear        | 27          | 46-6290            | 2           | O-Ring             |
| 14          | 98-7912            | 3           | Tube-Spanner             | 28          | 46-8560            | 4           | Screw-HHFTF        |
| 16          | 3256-68            | 2           | Washer-Flat              | 29          | 95-3270            | 1           | Connector-Hose     |
| 17          | 114-1648-05        | 1           | Bracket-Deflector, Upper | 30          | 117-5302           | 1           | Decal              |

# 54 Inch Deck Assembly No. 131-4141




## 54 Inch Deck Assembly No. 131-4141 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 3           | 130-0731           | 1           | Decal-Danger        |
| 4           | 132-0873           | 2           | Decal-Danger, Deck  |
| 5           | 130-0765           | 1           | Decal-Scalp, Anti   |
| 6           | 117-1194           | 1           | Decal-Routing, Belt |

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 7           | 322-2              | 3           | Screw-HH           |
| 8           | 104-8300           | 3           | Nut-Flange, NI     |
| 9           | 32144-70           | 1           | Screw-HWHTF        |

# Deck Belt and Blade Assembly



## Deck Belt and Blade Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>         |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|----------------------------|
| 1           | 7-4150             | 3           | Washer             | 12          | 110-9981           | 3           | Washer-Plain               |
| 2           | 120-5477           | 3           | Spindle ASM        | 13          | 114-0463           | 2           | Washer-Friction, Composite |
| 2:2         | 116-0720           | 2           | Bearing-Ball       | 14          | 1-413088           | 1           | Bushing-Lever, Lift        |
| 2:3         | 115-2641           | 1           | Spacer-Bearing     | 15          | 115-5054           | 1           | Arm-Idler                  |
| 3           | 32144-41           | 18          | Screw-Taptite      | 16          | 323-10             | 1           | Screw-HH                   |
| 4           | 117-7210           | 3           | Shield-Bearing     | 17          | 104-8301           | 3           | Nut-Flange, NI             |
| 5           | 115-2642           | 3           | Shaft-Spindle      | 18          | 115-2577           | 3           | Bushing-Idler              |
| 6           | 115-5018           | 3           | Pulley             | 19          | 116-3626           | 3           | Pulley-Idler               |
| 7           | 1-603401           | 1           | Spacer-Fender      | 20          | 3231-31            | 1           | Screw-CARR                 |
| 8           | 115-9650-03        | 3           | Blade-Hi Flo       | 21          | 80-6990            | 3           | Washer-Hardened            |
| 9           | 125-1736           | 3           | Washer-Belleville  | 22          | 323-9              | 3           | Screw-HH                   |
| 10          | 51-4060            | 3           | Screw-Blade        | 23          | 108-4056           | 1           | Spring-Extension           |
| 11          | 3219-7             | 3           | Nut-Hex            | 24          | 115-4971           | 1           | V-Belt                     |

# Attachments and Accessories

## For 74862 TITAN ZX5400 Zero-Turn-Radius Riding Mower

| Product Name                                             | Model/Part |
|----------------------------------------------------------|------------|
| 54in Recycler Kit.....                                   | 117-5313   |
| Light Kit.....                                           | 117-5317   |
| 54in/60in Striping Kit.....                              | 117-5319   |
| Leaf Bagging Enhancement Kit .....                       | 117-7202   |
| Transport Seat Hold Down Kit.....                        | 117-7251   |
| 54in Bagger Finishing Kit (Used with 79328 Bagger) ..... | 121-5663   |
| MVP Filter, Belt and Blade Kit .....                     | 127-1629   |
| Seat Kit .....                                           | 130-0788   |
| ROPS Conversion Kit .....                                | 130-6850   |
| Cargo Carrier .....                                      | 79032      |
| Front Weight Kit .....                                   | 79033      |
| Bagger Kit .....                                         | 79328      |
| E-Z Vac Twin Bagger .....                                | 79330      |
| 54in Blower and Drive Kit.....                           | 79341      |

**Notes:**

**Notes:**

**Notes:**



**Count on it.**