

# **LAWN-BOY®**

## **48cm REAR BAGGING MOWER**

**MODEL NO. 10915–8900001 & UP**

---

## **PARTS CATALOG**

## PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

## IDENTIFICATION AND ORDERING

### MODEL AND SERIAL NUMBERS

The Product two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.


To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.

**NOTE:** Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

## TABLE OF CONTENTS


| Description                    | Page | Description               | Page  |
|--------------------------------|------|---------------------------|-------|
| Housing Assembly .....         | 3    | Carburetor Assembly ..... | 10    |
| Engine Assembly .....          | 4    | Rear Axle Assembly .....  | 11    |
| Blade Assembly .....           | 5    | Gear Case Assembly .....  | 12    |
| Shroud & Block Assembly .....  | 6    | Handle Assembly .....     | 13    |
| Brake & Muffler Assembly ..... | 7    | Bag Assembly .....        | 14    |
| Block Assembly .....           | 8    | Numeric Parts Index ..... | 15-16 |
| Recoil Starter Assembly .....  | 9    |                           |       |



C-2671

## HOUSING ASSEMBLY


| Ref. No. | Part No. | Description                         | No. Used | Ref. No. | Part No. | Description                           | No. Used |
|----------|----------|-------------------------------------|----------|----------|----------|---------------------------------------|----------|
| 1        | 16-8889  | Housing – Deck<br>(Incl. Ref. # 35) | 1        | 18       | 17-1569  | Door – Discharge<br>(Incl. Ref. # 28) | 1        |
| 2        | 71-7990  | Ramp – Discharge                    | 1        | 19       | 92-8806  | Screw – HH                            | 2        |
| 3        | 32144-4  | Screw – HH Tap                      | 8        | 20       | 92-9313  | Spacer – Door                         | 2        |
| 4        | 92-9304  | Pivot – Front                       | 1        | 21       | 71-9840  | Spring – Door                         | 2        |
| 5        | 92-8811  | Bolt – Wheel                        | 2        | 22       | 71-7910  | Cap – Bolt Hinge (RH)                 | 1        |
| 6        | 92-8810  | Wheel & Tire Assembly               | 2        | 23       | 71-7900  | Cap – Bolt Hinge (LH)                 | 1        |
| 7        | 40-1940  | Washer                              | 2        | 24       | 65-5210  | Screw – Thread Forming                | 2        |
| 8        | 92-8819  | Nut – Lock                          | 2        | 25       | 93-7161  | Spacer – Handle                       | 2        |
| 9        | 71-8830  | Shaft Retainer Assembly             | 2        | 26       | 93-7162  | Spacer – Handle                       | 2        |
| 10       | 32112-1  | Nut – Push                          | 1        | 27       | 92-8818  | Screw – HH                            | 2        |
| 11       | 71-7920  | Cover – Belt                        | 1        | 28       | 93-4105  | Decal – Danger                        | 1        |
| 12       | 32144-70 | Screw – Tap                         | 1        | 33       | 71-7890  | Guide – Belt Rear                     | 1        |
| 13       | 71-7870  | Grip – Lower                        | 1        | 34       | 32144-4  | Screw – HH Tap                        | 2        |
| 14       | 71-7930  | Trigger – Hoc                       | 1        | 35       | 92-8837  | Decal – Deck                          | 1        |
| 15       | 3284-5   | Pin – Groove                        | 1        | 36       | 92-8808  | Ball – Bearing, Stud                  | 1        |
| 16       | 71-7860  | Grip – Upper                        | 1        | 37       | 3296-29  | Nut – Hex Lock                        | 1        |
| 17       | 32144-97 | Screw – PPH                         | 2        |          |          |                                       |          |



C-2672

ENGINE ASSEMBLY

| Ref. No. | Part No. | Description            | No. Used | Ref. No. | Part No.  | Description        | No. Used |
|----------|----------|------------------------|----------|----------|-----------|--------------------|----------|
| 1        |          | Engine Assembly        | 1        | 10       | 92-8828   | Decal - Shroud Top | 1        |
| 2        | 92-8898  | Shroud & Tank Assembly | 1        | 11       | 92-1701   | Rope - Stop        | 1        |
| 3        | 93-4302  | Screw                  | 3        | 13       | 32144-102 | Screw              | 3        |
| 4        | 93-3660  | Fuel Cap Assembly      | 1        | 14       | 93-1201   | Disc - Foam        | 1        |
| 5        | 612782   | Gas Line               | 1        | 15       | 93-3175   | Baffle             | 1        |
| 6        | 44-3174  | Hose Primer            | 1        | 16       | 609150    | Baffle - Foam      | 1        |
| 7        | 44-2750  | Body - Primer          | 1        | 17       | 93-1230   | Cover              | 1        |
| 8        | 66-7460  | Bulb - Primer          | 1        | 18       | 613311    | Gasket             | 1        |
| 9        | 92-8615  | Applique - Shroud      | 1        |          |           |                    |          |




C-1887

## BLADE ASSEMBLY

| Ref. No. | Part No. | Description    | No. Used |
|----------|----------|----------------|----------|
| 1        | 26-0670  | Bolt - Blade   | 1        |
| 2        | 3253-22  | Washer - Lock  | 1        |
| 3        | 92-8626  | Spacer - Blade | 1        |
| 4        | 612079   | Blade 19"      | 1        |

| Ref. No. | Part No. | Description          | No. Used |
|----------|----------|----------------------|----------|
| 5        | 146046   | Plate - Blade Driver | 1        |
| 6        | 92-8807  | Hub - Blade Driver   | 1        |
| 7        | 93-0278  | Pulley - Driver      | 1        |




C-2438

## SHROUD & BLOCK ASSEMBLY

| Ref. No. | Part No. | Description          | No. Used |
|----------|----------|----------------------|----------|
| 1        | 614699   | Screw                | 3        |
| 2        | 93-4303  | Cover - Air Filter   | 1        |
| 3        | 609493   | Element - Air Filter | 1        |
| 4        | 93-4320  | Shield - Fuel        | 1        |
| 5        | 44-3174  | Hose - Primer        | 1        |
| 6        | 93-4315  | Shield - Carburetor  | 1        |
| 7        | 92-4948  | Gasket - Carburetor  | 2        |
| 9        | 609482   | Screw                | 2        |
| 10       | 94-4331  | Carburetor Assembly  | 1        |
| 11       | 93-4316  | Shield - Governor    | 2        |
| 12       | 94-5731  | Short Block Assembly | 1        |


| Ref. No. | Part No. | Description       | No. Used |
|----------|----------|-------------------|----------|
| 13       | 607199   | Key               | 1        |
| 14       | 614702   | Screw             | 4        |
| 15       | 93-1216  | Base - Shroud     | 1        |
| 16       | 684743   | Flywheel Assembly | 1        |
| 17       | 614640   | Hub - Starter     | 1        |
| 18       | 316959   | Washer - Lock     | 1        |
| 19       | 130743   | Nut               | 1        |
| 20       | 93-4304  | Shroud            | 1        |
| 21       | 613269   | Screw             | 4        |
| 22       | 92-6398  | Cap               | 1        |



C-1899

## BRAKE & MUFFLER ASSEMBLY

| Ref. No. | Part No. | Description              | No. Used | Ref. No. | Part No. | Description                           | No. Used |
|----------|----------|--------------------------|----------|----------|----------|---------------------------------------|----------|
| 1        | 3290-459 | Rivet                    | 2        | 12       | 93-1233  | Gasket - Exhaust                      | 1        |
| 2        | 60-9010  | Strap - Ground           | 1        | 13       | 614008   | Plug - Spark                          | 1        |
| 3        | 92-2925  | Strap - Insulation       | 1        | 14       | 684049   | Ignition Assembly<br>(Incl. Ref. #20) | 1        |
| 4        | 12-5450  | Screw - Thread Forming   | 1        | 15       | 84-7820  | Plate - Brake Mount                   | 1        |
| 5        | 53-4690  | Stop - Ground Strap      | 1        | 16       | 613208   | Screw - Hex Washer Hd.                | 2        |
| 6        | 92-1156  | Wire - Brake Switch Lead | 1        | 17       | 614702   | Screw                                 | 1        |
| 7        | 614654   | Plate - Muffler          | 1        | 18       | 66-5380  | Plate - Brake Assembly                | 1        |
| 8        | 607601   | Screw                    | 4        | 19       | 92-9698  | Screw - Shoulder                      | 1        |
| 9        | 93-1217  | Baffle                   | 1        | 20       | 684179   | Lead & Cover Assembly                 | 1        |
| 10       | 609471   | Screw                    | 3        | 21       | 66-5370  | Spring - Compression                  | 1        |
| 11       | 93-1108  | Cover - Muffler          | 1        |          |          |                                       |          |




C-1295A

## BLOCK ASSEMBLY

| Ref. No. | Part No. | Description                                          | No. Used |
|----------|----------|------------------------------------------------------|----------|
| 1        | 681737   | Set – Rings, Piston                                  | 1        |
| 3        | 92-4925  | Piston & Connecting Rod<br>(Incl. Ref. #1, 3-7 & 13) | 1        |
| 4        | 606608   | Pin – Wrist                                          | 1        |
| 5        | 303712   | Ring – Retaining                                     | 2        |
| 6        | 92-4921  | Connecting Rod Assembly<br>(Incl. Ref. #8, 12 & 13)  | 1        |
| 7        | 92-4927  | Bearing                                              | 1        |
| 8        | 677982   | Liner – Split (Set of 2)                             | 1        |
| 9        | 92-6379  | Crankshaft                                           | 1        |
| 10       | 681830   | Bearing – Upper Main                                 | 1        |
| 11       | 611396   | Seal – Oil                                           | 2        |

| Ref. No. | Part No. | Description               | No. Used |
|----------|----------|---------------------------|----------|
| 12       | 683911   | Bearing – Needle          | 1        |
| 13       | 611393   | Screw – Hex. Hd.          | 2        |
| 14       | 614636   | Screw – Hex. Washer Hd.   | 4        |
| 16       | 602588   | Reed – Carburetor         | 1        |
| 17       | 602587   | Reed – Backup Plate       | 1        |
| 18       | 612872   | Screw                     | 2        |
| 19       | 681831   | Bearing – Needle          | 1        |
| 20       | 609629   | Dowel                     | 1        |
| 21       | 609123   | Plug – Core               | 4        |
| 22       | 252-76   | Bearing – Thrust          | 1        |
| 23       | 252-80   | Washer – Thrust           | 1        |
| *        | 684725   | Cylinder & Crankcase Asm. | 1        |

\* Not Illustrated




C-1309

# **RECOIL STARTER ASSEMBLY**

| Ref. No. | Part No. | Description      | No. Used |
|----------|----------|------------------|----------|
| 1        | 93-4304  | Housing Assembly | 1        |
| 2        | 93-4305  | Rope - Starter   | 1        |
| 3        | 92-4929  | Pulley Assembly  | 1        |
| 4        | 92-4930  | Spring - Dog     | 2        |
| 5        | 92-4931  | Dog              | 2        |

| Ref. No. | Part No. | Description            | No. Used |
|----------|----------|------------------------|----------|
| 6        | 92-9692  | Retainer               | 1        |
| 7        | 92-4933  | Screw                  | 1        |
| 8        | 92-4934  | Spring                 | 1        |
| 9        | 92-4935  | Spring Keeper Assembly | 1        |




C-2130A

## CARBURETOR ASSEMBLY

| Ref. No. | Part No. | Description                                     | No. Used | Ref. No. | Part No. | Description                              | No. Used |
|----------|----------|-------------------------------------------------|----------|----------|----------|------------------------------------------|----------|
| 1        | 92-6376  | Air Vane & Shaft                                | 1        | 13       | 602850   | Gasket                                   | 1        |
| 2        | 610165   | Retainer - Speed Control                        | 1        | 14       | 92-6371  | Nozzle                                   | 1        |
| 3        | 93-1225  | Lever - Speed Adjust                            | 1        | 15       | 611071   | Filter - Fuel                            | 1        |
| 4        | 610834   | Collar - Air Vane                               | 1        | 16       | 678113   | Float & Arm Assembly                     | 1        |
| 5        | 92-4944  | Spring - Governor                               | 1        | 17       | 92-6389  | Pin                                      | 1        |
| 6        | 92-6373  | Disc - Throttle                                 | 1        | 18       | 92-9691  | Float Chamber                            | 1        |
| 7        | 92-4949  | Bracket - Throttle Control                      | 1        | 19       | 608850   | Screw                                    | 4        |
| 8        | 613269   | Screw                                           | 2        | 20       | 612383   | Washer                                   | 1        |
| 9        | 93-4324  | Carburetor Body                                 | 1        | 21       | 92-6370  | Main Jet                                 | 1        |
| 10       | 92-9697  | Kit - Float Valve, Body & Seat (Incl. Ref. #12) | 1        | *        | 92-6385  | Jet - High Altitude                      | 1        |
| 12       | 603145   | Spring                                          | 1        | *        | 93-4331  | Carburetor Assembly (Incl. Ref. #7 pg.6) | 1        |

\*Not Illustrated






C-1292

## GEAR CASE ASSEMBLY #71-9600

| Ref. No. | Part No.  | Description          | No. Used |
|----------|-----------|----------------------|----------|
| 1        | 49-2040   | Screw - Taptite      | 4        |
| 2        | 614668    | Cover - Gear Case    | 1        |
| 3        | 55-3760   | Pinion - 15 Tooth    | 1        |
| 4        | 614696    | Shaft - Intermediate | 1        |
| 5        | 36-4791   | Washer               | 2        |
| 6        | 60-8750   | Bushing              | 2        |
| 7        | 71-9620   | Shaft - Output       | 1        |
| 8        | 32121-114 | Pin - Groove         | 2        |
| 9        | 60-8850   | Bushing - Output     | 2        |
| 10       | 614578    | Cover - Gear Case    | 1        |

| Ref. No. | Part No. | Description              | No. Used |
|----------|----------|--------------------------|----------|
| 11       | 62-6660  | Spacer                   | 1        |
| 12       | 71-9610  | Pulley - Half            | 2        |
| 13       | 3256-24  | Washer                   | 1        |
| 14       | 3296-5   | Nut                      | 1        |
| 15       | 38-7820  | Bearing - Ball           | 1        |
| 16       | 60-8890  | Gear - Bevel Pinion      | 1        |
| 17       | 36-4780  | Washer - Thrust          | 3        |
| 18       | 614596   | Gear 34 Tooth            | 1        |
| *        | 71-9600  | Gear Case Ass'y Complete | 1        |

\* Not Illustrated




C-2673

## HANDLE ASSEMBLY

| Ref. No. | Part No. | Description            | No. Used |
|----------|----------|------------------------|----------|
| 1        | 92-8800  | Handle                 | 1        |
| 2        | 92-1002  | Bail - Fly Wheel Brake | 1        |
| 3        | 92-5412  | Stop - Pivot           | 1        |
| 4        | 93-7383  | Guide - Rope           | 1        |
| 5        | 321-53   | Screw - HH             | 1        |
| 6        | 3296-73  | Nut - Lock Insert      | 2        |
| 7        | 92-9327  | Cable - Throttle       | 1        |
| 8        | 92-9328  | Cable - Brake          | 1        |
| 9        | 612824   | Clip - Rope Insert     | 1        |
| 10       | 612825   | Handle - Starter       | 1        |

| Ref. No. | Part No. | Description       | No. Used |
|----------|----------|-------------------|----------|
| 11       | 3290-378 | Tie - Cable       | 2        |
| 12       | 93-7159  | Knob              | 4        |
| 14       | 3253-33  | Washer - Lock     | 4        |
| 16       | 92-1001  | Bail - Control    | 1        |
| 17       | 92-5412  | Stop - Pivot      | 1        |
| 18       | 92-7729  | Anchor - Cable    | 1        |
| 19       | 92-9316  | Cable - Traction  | 1        |
| 20       | 321-57   | Screw - HH        | 1        |
| 21       | 93-7266  | Decal - Operation | 1        |



C-1890

## BAG ASSEMBLY

| Ref.<br>No. | Part No. | Description      | No.<br>Used |
|-------------|----------|------------------|-------------|
| 1           | 71-3750  | Ramp - Grass Bag | 1           |
| 2           | 71-8180  | Frame            | 1           |

| Ref.<br>No. | Part No. | Description | No.<br>Used |
|-------------|----------|-------------|-------------|
| 3           | 92-8890  | Bag - Grass | 1           |

# TORO PART NUMBER INDEX

3321-117

| Part No. | Description               | Pg. Ref.<br>No. No. Qty. | Part No. | Description                | Pg. Ref.<br>No. No. Qty. |
|----------|---------------------------|--------------------------|----------|----------------------------|--------------------------|
| 130743   | Nut                       | 6 19 1                   | 62-6660  | Spacer                     | 12 11 1                  |
| 146046   | Plate - Blade Driver      | 5 5 1                    | 63-8590  | Screw                      | 11 10 2                  |
| 303712   | Ring - Retaining          | 8 5 2                    | 65-2720  | Ring - Retaining           | 11 31 4                  |
| 316959   | Washer - Lock             | 6 18 1                   | 65-4710  | Ring - Friction            | 11 24 2                  |
| 602587   | Reed - Backup Plate       | 8 17 1                   | 65-4720  | Spring - Compression       | 11 30 2                  |
| 602588   | Reed - Carburetor         | 8 16 1                   | 65-4740  | Washer - Thrust            | 11 29 4                  |
| 602850   | Gasket                    | 10 13 1                  | 65-4750  | Gear - Pinion              | 11 28 2                  |
| 603145   | Spring                    | 10 12 1                  | 65-4760  | Washer                     | 11 25 2                  |
| 606608   | Pin - Wrist               | 8 4 1                    | 65-5210  | Screw - Thread Forming     | 3 24 2                   |
| 607199   | Key                       | 6 13 1                   | 66-5370  | Spring - Compression       | 7 21 1                   |
| 607601   | Screw                     | 7 8 4                    | 66-5380  | Plate - Brake Assembly     | 7 18 1                   |
| 608850   | Screw                     | 10 19 4                  | 66-6040  | Key - Rocking RH           | 11 *27 1                 |
| 609123   | Plug - Core               | 8 21 4                   | 66-6050  | Key - Rocking LH           | 11 26 1                  |
| 609150   | Baffle - Foam             | 4 16 1                   | 66-7460  | Bulb - Primer              | 4 8 1                    |
| 609471   | Screw                     | 7 10 3                   | 71-3750  | Ramp - Grass Bag           | 14 1 1                   |
| 609482   | Screw                     | 6 9 2                    | 71-7770  | Plate - Securing           | 11 11 2                  |
| 609493   | Element - Air Filter      | 6 3 1                    | 71-7840  | Rod - Trigger              | 11 5 1                   |
| 609629   | Dowel                     | 8 20 1                   | 71-7860  | Grip - Upper               | 3 16 1                   |
| 610165   | Retainer - Speed Control  | 10 2 1                   | 71-7870  | Grip - Lower               | 3 13 1                   |
| 610834   | Collar - Air Vane         | 10 4 1                   | 71-7890  | Guide - Belt Rear          | 3 33 1                   |
| 611071   | Filter - Fuel             | 10 15 1                  | 71-7900  | Cap - Bolt Hinge (LH)      | 3 23 1                   |
| 611393   | Screw - Hex. Hd.          | 8 13 2                   | 71-7910  | Cap - Bolt Hinge (RH)      | 3 22 1                   |
| 611396   | Seal - Oil                | 8 11 2                   | 71-7920  | Cover - Belt               | 3 11 1                   |
| 612079   | Blade 19                  | 5 4 1                    | 71-7930  | Trigger - Hoc              | 3 14 1                   |
| 612383   | Washer                    | 10 20 1                  | 71-7980  | Indicator - HOC            | 11 2 1                   |
| 612782   | Gas Line                  | 4 5 1                    | 71-7990  | Ramp - Discharge           | 3 2 1                    |
| 612824   | Clip - Rope Insert        | 13 9 1                   | 71-8060  | Spring - Trigger Retainer  | 11 8 2                   |
| 612825   | Handle - Starter          | 13 10 1                  | 71-8080  | Saddle - HOC               | 11 9 1                   |
| 612872   | Screw                     | 8 18 2                   | 71-8180  | Frame                      | 14 2 1                   |
| 613208   | Screw - Hex Washer Hd.    | 7 16 2                   | 71-8310  | Spring - Compression       | 11 35 1                  |
| 613269   | Screw                     | 10 8 2                   | 71-8830  | Shaft Retainer Assembly    | 3 9 2                    |
| 613269   | Screw                     | 6 21 4                   | 71-9450  | V-Belt                     | 11 19 1                  |
| 613311   | Gasket                    | 4 18 1                   | 71-9600  | Gear Case Ass'y Complete   | 12 * 1                   |
| 614008   | Plug - Spark              | 7 13 1                   | 71-9600  | Gear Case Assembly         | 11 18 1                  |
| 614578   | Cover - Gear Case         | 12 10 1                  | 71-9610  | Pulley - Half              | 12 12 2                  |
| 614596   | Gear 34 Tooth             | 12 18 1                  | 71-9620  | Shaft - Output             | 12 7 1                   |
| 614636   | Screw - Hex. Washer Hd.   | 8 14 4                   | 71-9840  | Spring - Door              | 3 21 2                   |
| 614640   | Hub - Starter             | 6 17 1                   | 74-1660  | Cover - Wheel              | 11 32 2                  |
| 614654   | Plate - Muffler           | 7 7 1                    | 74-1670  | Spacer - Wheel             | 11 33 2                  |
| 614668   | Cover - Gear Case         | 12 2 1                   | 84-7820  | Plate - Brake Mount        | 7 15 1                   |
| 614696   | Shaft - Intermediate      | 12 4 1                   | 92-1001  | Bail - Control             | 13 16 1                  |
| 614699   | Screw                     | 6 1 3                    | 92-1002  | Bail - Fly Wheel Brake     | 13 2 1                   |
| 614702   | Screw                     | 6 14 4                   | 92-1057  | Bolt - Shoulder            | 11 13 2                  |
| 614702   | Screw                     | 7 17 1                   | 92-1156  | Wire - Brake Switch Lead   | 7 6 1                    |
| 677982   | Liner - Split (Set of 2)  | 8 8 1                    | 92-1701  | Rope - Stop                | 4 11 1                   |
| 678113   | Float & Arm Assembly      | 10 16 1                  | 92-2925  | Strap - Insulation         | 7 3 1                    |
| 681737   | Set - Rings, Piston       | 8 1 1                    | 92-4921  | Connecting Rod Assembly    | 8 6 1                    |
| 681830   | Bearing - Upper Main      | 8 10 1                   | 92-4925  | Piston & Connecting Rod    | 8 3 1                    |
| 681831   | Bearing - Needle          | 8 19 1                   | 92-4927  | Bearing                    | 8 7 1                    |
| 683911   | Bearing - Needle          | 8 12 1                   | 92-4929  | Pulley Assembly            | 9 3 1                    |
| 684049   | Ignition Assembly         | 7 14 1                   | 92-4930  | Spring - Dog               | 9 4 2                    |
| 684179   | Lead & Cover Assembly     | 7 20 1                   | 92-4931  | Dog                        | 9 5 2                    |
| 684725   | Cylinder & Crankcase Asm. | 8 * 1                    | 92-4933  | Screw                      | 9 7 1                    |
| 684743   | Flywheel Assembly         | 6 16 1                   | 92-4934  | Spring                     | 9 8 1                    |
| 12-5450  | Screw - Thread Forming    | 7 4 1                    | 92-4935  | Spring Keeper Assembly     | 9 9 1                    |
| 16-8889  | Housing - Deck            | 3 1 1                    | 92-4944  | Spring - Governor          | 10 5 1                   |
| 17-1569  | Door - Discharge          | 3 18 1                   | 92-4948  | Gasket - Carburetor        | 6 7 2                    |
| 26-0670  | Bolt - Blade              | 5 1 1                    | 92-4949  | Bracket - Throttle Control | 10 7 1                   |
| 36-4780  | Washer - Thrust           | 12 17 3                  | 92-5412  | Stop - Pivot               | 13 3 1                   |
| 36-4791  | Washer                    | 12 5 2                   | 92-5412  | Stop - Pivot               | 13 17 1                  |
| 38-7820  | Bearing - Ball            | 12 15 1                  | 92-6370  | Main Jet                   | 10 21 1                  |
| 40-1940  | Washer                    | 3 7 2                    | 92-6371  | Nozzle                     | 10 14 1                  |
| 44-2750  | Body - Primer             | 4 7 1                    | 92-6373  | Disc - Throttle            | 10 6 1                   |
| 44-3174  | Hose - Primer             | 6 5 1                    | 92-6376  | Air Vane & Shaft           | 10 1 1                   |
| 44-3174  | Hose Primer               | 4 6 1                    | 92-6379  | Crankshaft                 | 8 9 1                    |
| 49-2040  | Screw - Taptite           | 12 1 4                   | 92-6385  | Jet - High Altitude        | 10 * 1                   |
| 53-4690  | Stop - Ground Strap       | 7 5 1                    | 92-6389  | Pin                        | 10 17 1                  |
| 55-3760  | Pinion - 15 Tooth         | 12 3 1                   | 92-6398  | Cap                        | 6 22 1                   |
| 60-8750  | Bushing                   | 12 6 2                   | 92-7729  | Anchor - Cable             | 13 18 1                  |
| 60-8850  | Bushing - Output          | 12 9 2                   | 92-8615  | Applique - Shroud          | 4 9 1                    |
| 60-8890  | Gear - Bevel Pinion       | 12 16 1                  | 92-8626  | Spacer - Blade             | 5 3 1                    |
| 60-9010  | Strap - Ground            | 7 2 1                    | 92-8800  | Handle                     | 13 1 1                   |

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

| Part No. | Description             | Pg. Ref.<br>No. No. Qty. | Part No.  | Description          | Pg. Ref.<br>No. No. Qty. |
|----------|-------------------------|--------------------------|-----------|----------------------|--------------------------|
| 92-8806  | Screw - HH              | 3 19 2                   | 93-4316   | Shield - Governor    | 6 11 2                   |
| 92-8807  | Hub - Blade Driver      | 5 6 1                    | 93-4320   | Shield - Fuel        | 6 4 1                    |
| 92-8808  | Ball - Bearing, Stud    | 3 36 1                   | 93-4324   | Carburetor Body      | 10 9 1                   |
| 92-8810  | Wheel & Tire Assembly   | 3 6 2                    | 93-4331   | Carburetor Assembly  | 10 * 1                   |
| 92-8811  | Bolt - Wheel            | 3 5 2                    | 93-7159   | Knob                 | 13 12 4                  |
| 92-8818  | Screw - HH              | 3 27 2                   | 93-7161   | Spacer - Handle      | 3 25 2                   |
| 92-8819  | Nut - Lock              | 3 8 2                    | 93-7162   | Spacer - Handle      | 3 26 2                   |
| 92-8828  | Decal - Shroud Top      | 4 10 1                   | 93-7266   | Decal - Operation    | 13 21 1                  |
| 92-8837  | Decal - Deck            | 3 35 1                   | 93-7383   | Guide - Rope         | 13 4 1                   |
| 92-8890  | Bag - Grass             | 14 3 1                   | 94-4331   | Carburetor Assembly  | 6 10 1                   |
| 92-8898  | Shroud & Tank Assembly  | 4 2 1                    | 94-5731   | Short Block Assembly | 6 12 1                   |
| 92-9300  | Spring - Counterbalance | 11 4 1                   | 95-2740   | Retainer - Belt      | 11 20 1                  |
| 92-9301  | Rod - Link              | 11 1 1                   | 98-2039   | Bracket - Traction   | 11 36 1                  |
| 92-9304  | Pivot - Front           | 3 4 1                    | 252-76    | Bearing - Thrust     | 8 22 1                   |
| 92-9310  | Pivot Arm Assembly RH   | 11 23 1                  | 252-80    | Washer - Thrust      | 8 23 1                   |
| 92-9311  | Pivot Arm Assembly LH   | 11 22 1                  | 302-26    | Grease Zerk          | 11 37 2                  |
| 92-9313  | Spacer - Door           | 3 20 2                   | 321-53    | Screw - HH           | 13 5 1                   |
| 92-9316  | Cable - Traction        | 13 19 1                  | 321-57    | Screw - HH           | 13 20 1                  |
| 92-9318  | Wheel & Tire Assembly   | 11 34 2                  | 3253-22   | Washer - Lock        | 5 2 1                    |
| 92-9327  | Cable - Throttle        | 13 7 1                   | 3253-33   | Washer - Lock        | 13 14 4                  |
| 92-9328  | Cable - Brake           | 13 8 1                   | 3256-24   | Washer               | 12 13 1                  |
| 92-9691  | Float Chamber           | 10 18 1                  | 3284-5    | Pin - Groove         | 3 15 1                   |
| 92-9692  | Retainer                | 9 6 1                    | 3290-378  | Tie - Cable          | 13 11 2                  |
| 92-9697  | Kit - Float Valve, Body | 10 10 1                  | 3290-459  | Rivet                | 7 1 2                    |
| 92-9698  | Screw - Shoulder        | 7 19 1                   | 3296-5    | Nut                  | 12 14 1                  |
| 93-0278  | Pulley - Driver         | 5 7 1                    | 3296-29   | Nut - Hex Lock       | 3 37 1                   |
| 93-1108  | Cover - Muffler         | 7 11 1                   | 3296-59   | Nut - Lock           | 11 14 2                  |
| 93-1201  | Disc - Foam             | 4 14 1                   | 3296-73   | Nut - Lock Insert    | 13 6 2                   |
| 93-1216  | Base - Shroud           | 6 15 1                   | 32112-1   | Nut - Push           | 3 10 1                   |
| 93-1217  | Baffle                  | 7 9 1                    | 32112-13  | Nut - Push           | 11 6 1                   |
| 93-1225  | Lever - Speed Adjust    | 10 3 1                   | 32121-114 | Pin - Groove         | 12 8 2                   |
| 93-1230  | Cover                   | 4 17 1                   | 32144-4   | Screw - HH Tap       | 3 3 8                    |
| 93-1233  | Gasket - Exhaust        | 7 12 1                   | 32144-4   | Screw - HH Tap       | 11 21 2                  |
| 93-3175  | Baffle                  | 4 15 1                   | 32144-4   | Screw - HH Tap       | 3 34 2                   |
| 93-3660  | Fuel Cap Assembly       | 4 4 1                    | 32144-4   | Screw - HH Tap       | 11 12 4                  |
| 93-4105  | Decal - Danger          | 3 28 1                   | 32144-31  | Screw                | 11 7 1                   |
| 93-4302  | Screw                   | 4 3 3                    | 32144-70  | Screw - Tap          | 3 12 1                   |
| 93-4303  | Cover - Air Filter      | 6 2 1                    | 32144-97  | Screw - PPH          | 3 17 2                   |
| 93-4304  | Housing Assembly        | 9 1 1                    | 32144-102 | Screw                | 4 13 3                   |
| 93-4304  | Shroud                  | 6 20 1                   | 32151-93  | Ring - Grip          | 11 3 1                   |
| 93-4305  | Rope - Starter          | 9 2 1                    |           |                      |                          |
| 93-4315  | Shield - Carburetor     | 6 6 1                    |           |                      |                          |

\*Not Illustrated