



Wheelhorse L & GT

48" Rotary Cutting Unit

Model No. 78268 – 8900001 & Up

Parts Catalog

ORDERING REPLACEMENT PARTS

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Contents

Description	Page	Description	Page
Deck Assembly	1	Decals	4
Spindles & Covers	2	Note:	
Discharge Chute & Gage Wheels	3		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HWHTF	hex washer head
ASM	assembly		thread forming
CARR	carriage	INC	incorporated
DEG	degrees	LH	left hand
FH	flat head	PH	pan head
GA	gauge	PPH	Phillips pan head
HF	hex flange	PTO	power take off
HFV	hex flange washer	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SH	square head
HHST	hex head self tapping	SHWH	slotted hex washer head
HJ	hex jam	SPH	slotted pan head
HOC	height-of-cut	STD	standard
HS	hex socket	TAP	self tapping
HSBH	hex socket button head	TH	truss head
HSFH	hex socket flat head	TTH	Torx truss head
HSR	hex socket head	WH	wing head
HWH	hex washer head		

Important Format Explanations

This catalog uses special formats to convey information in illustrations and parts lists. Specifically, one format is used in conjunction with service assemblies and another with quantities associated with reference numbers.

Service Assemblies

Parts within service assemblies have reference numbers in the form X:Y. X is the reference number of the service assembly and Y is a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in part lists and as callouts in illustrations.

Reference Numbers with Quantities

Illustrations may have a quantity in parentheses next to a reference number, in the form X (Y). X is the reference number. Y in parentheses is the quantity of the part identified by the reference number.


For example, the illustration callout 4 (2) indicates that two parts are used in that instance.



Sheet No.: 2

Deck Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	94-9756-01	1	Deck Support Asm	31	103712	1	Grip
2	3296-39	8	Nut-Lock	32	3256-23	1	Washer-Flat
3	32151-29	2	Ring-Retaining	33	322-6	1	Screw-HH
4	9202394	2	Washer				
5	78-7340	2	Roller-Lift				
6	3256-28	2	Washer-Flat				
7	9335074	2	Cotter-Hairpin				
8	92-7082	1	Pulley-Idler				
9	3256-24	2	Washer-Flat				
10	323-11	1	Screw				
11	323-9	1	Screw-HH				
12	78-3140-03	1	Strap-Brace				
13	109859	2	Bushing				
14	79-2760	1	Spacer-Pivot				
15	92-7084	1	Pulley-Idler				
16	302-26	1	Fitting-Grease				
17	78-3150-03	1	Arm				
18	116172	1	Spring-Extension				
19	323-6	5	Screw-HH				
20	323-14	1	Screw-HH				
21	94-9792	1	Deck / Decal Asm				
23	3230-18	3	Bolt-CARR				
24	3296-29	5	Nut-Lock				
26	322-5	2	Screw-HH				
29	88-5010	1	Spacer				
30	94-9738	1	Lever Asm				




Sheet No.: 3

Spindles & Covers

Ref. No.	Part No.	Qty.	Description
1	3220-7	3	Nut-Jam
2	3256-28	3	Washer-Flat
3	106637	3	Kit-Blade, Set of 3
4	9202574	3	Washer-Flat
5	78-6710	3	Shaft-Spindle
6	106067	3	Cup-Spindle
7	106068	3	Spacer
8	32120-42	3	Ring-Retaining
9	109966	6	Bearing-Ball
10	116085	3	Tube
11	114568	3	Housing-Spindle
12	9080326	12	Screw-HH
14	92-7083	3	Pulley
15	92-6958	1	V-Belt
16	3253-8	3	Washer-Lock
17	3220-6	3	Nut-Jam
18	302-5	3	Fitting-Grease
23	32144-4	6	Screw-TAP
24	3256-22	6	Washer-Flat
25	86-9220	1	Cover-Belt
26	86-9210	1	Cover-Belt


Ref. No.	Part No.	Qty.	Description



Sheet No.: 4

Discharge Chute & Gage Wheels

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	3231-25	4	Screw-CARR	27	3256-24	2	Washer-Flat
2	5188	2	Screw-HSH	28	68-2730	2	Wheel-Gage
3	110506	2	Wheel-Gage	29	68-2350	2	Plate-Gage Wheel
4	32146-2	2	Nut-Lock	30	9335054	2	Hairpin
5	110837-03	2	Bracket-Pivot	32	3296-16	2	Nut - Lock
6	3296-39	6	Nut-Lock	33	3256-1	2	Washer - Flat
7	3272-21	6	Pin-Cotter	34	95-2747	1	Fitting Washout
8	3256-26	9	Washer-Flat	35	46-6290	1	O-Ring
9	9335064	3	Hairpin	36	3229-1	2	Bolt - Carriage
10	79-5380	1	Link-Rear				
11	29-4820	3	Roller				
12	3296-42	3	Nut-Lock				
13	118960	3	Shaft-Roller				
14	321-4	3	Screw-HH				
15	79-4140-03	1	Support				
16	3272-10	1	Pin-Cotter				
17	93-1630	1	Spring-Deflector				
18	88-2750-01	1	Chute / Decal Asm				
19	9152366	1	Nut-Jam Lock				
20	93-1633	2	Washer-Nylon				
21	116080	1	Bushing-Pvt				
22	86-9250	2	Bracket				
23	325-13	2	Screw-HH				
24	86-9240	2	Bracket				
25	3218-5	2	Nut-Jam				
26	283-2	2	Pin-Clevis				



Sheet No.: 5

Decals

Ref. No.	Part No.	Qty.	Description
2	93-7317	2	Decal-Danger
4	93-7316	1	Decal-Danger
6	93-7325	1	Decal-Belt
8	93-7282	2	Decal-Wheel Adjustment

Ref. No.	Part No.	Qty.	Description

Toro Part Number Index

Part No.	Page No.	Ref. No.	Qty.	Description
5188	3	2	2	Screw-HSH
103712	1	31	1	Grip
106067	2	6	3	Cup-Spindle
106068	2	7	3	Spacer
106637	2	3	3	Kit-Blade, Set of 3
109859	1	13	2	Bushing-Flg
109966	2	9	6	Bearing-Ball
110506	3	3	2	Wheel-Gage
114568	2	11	3	Housing-Spindle
116080	3	21	1	Bushing
116085	2	10	3	Tube
116172	1	18	1	Spring-Extension
118960	3	13	3	Shaft-Roller
9080326	2	12	12	Screw-HH
9152366	3	19	1	Nut-Jam Lock
9202394	1	4	2	Washer
9202574	2	4	3	Washer
9335054	3	30	2	Hairpin
9335064	3	9	3	Hairpin
9335074	1	7	2	Cotter-Hairpin
29-4820	3	11	3	Roller
46-6290	3	35	1	O-Ring
68-2350	3	29	2	Plate-Gage Wheel
68-2730	3	28	2	Wheel-Gage
78-3140-03	1	12	1	Strap-Brace
78-3150-03	1	17	1	Arm
78-6710	2	5	3	Shaft-Spindle
78-7340	1	5	2	Roller-Lift
79-2760	1	14	1	Spacer-Pivot
79-4140-03	3	15	1	Support
79-5380	3	10	1	Link-Rear
86-9210	2	26	1	Cover-Belt
86-9220	2	25	1	Cover-Belt
86-9240	3	24	2	Bracket
86-9250	3	22	2	Bracket
88-2750-01	3	18	1	Chute / Decal Asm
88-5010	1	29	1	Spacer
92-6958	2	15	1	V-Belt
92-7082	1	8	1	Pulley-Idler
92-7083	2	14	3	Pulley
92-7084	1	15	1	Pulley-Idler
93-7282	4	8	2	Decal-Wheel Adjustment
93-7316	4	4	1	Decal-Danger
93-7317	4	2	2	Decal-Danger
93-1630	3	17	1	Spring-Deflector
93-1633	3	20	2	Washer-Nylon
93-7325	4	6	1	Decal-Belt
94-9738	1	30	1	Lever Asm
94-9756-01	1	1	1	Deck Support Asm
94-9761	3	31	1	Decal-Deck
94-9792	1	21	1	Deck / Decal Asm
95-2747	3	34	1	Fitting Washout
110837-03	3	5	2	Bracket-Pivot
283-2	3	26	2	Pin-Clevis
302-5	2	18	3	Fitting-Grease
302-26	1	16	1	Fitting-Grease
321-4	3	14	3	Screw-HH
322-5	1	26	2	Screw-HH
322-6	1	33	1	Screw-HH
323-6	1	19	5	Screw-HH
323-9	1	11	1	Screw-HH
323-11	1	10	1	Screw

*Not Illustrated

Toro Part Number Index (cont.)

Part No.	Page No.	Ref. No.	Qty.	Description
323-14	1	20	1	Screw-HH
325-13	3	23	2	Screw-HH
3218-5	3	25	2	Nut-Jam
3220-6	2	17	3	Nut-Jam
3220-7	2	1	3	Nut-Jam
3229-1	3	36	2	Bolt-CARR
3230-18	1	23	3	Bolt-CARR
3231-25	3	1	4	Screw-CARR
3253-8	2	16	3	Washer-Lock
3256-1	3	33	2	Washer-Flat
3256-22	2	24	6	Washer-Flat
3256-23	1	32	1	Washer-Flat
3256-24	1	9	2	Washer-Flat
3256-24	3	27	2	Washer-Flat
3256-26	3	8	9	Washer-Flat
3256-28	1	6	2	Washer-Flat
3256-28	2	2	3	Washer-Flat
3272-10	3	16	1	Pin-Cotter
3272-21	3	7	6	Pin-Cotter
3296-16	3	32	2	Nut-Lock
3296-29	1	24	5	Nut-Lock
3296-39	1	2	8	Nut-Lock
3296-39	3	6	6	Nut-Lock
3296-42	3	12	3	Nut-Lock
32120-42	2	8	3	Ring-Int Ret
32144-4	2	23	6	Screw-TAP
32146-2	3	4	2	Nut-Lock
32151-29	1	3	2	Ring-Retaining