



Count on it.

EXTRA™

Quick Reference Guide



Use this guide for quick reference when you want to:

Change Time and Day or Date	page 2
Review or Change Watering Day Schedule	page 2
Review or Change Program Start Times	page 4
Review or Change Zone Run Times	page 5
Use Manual Operations	page 6
Turn Off The Timer	page 7
Use the Rain Delay Feature.....	page 8
Use the Season Adjust Feature	page 8

Questions? Call Toro Customer Support @ 1-800-895-4922

Quick Reference Guide


To Change Time and Date

1. Turn the control dial to the **CURRENT TIME/DAY**  position.
2. To adjust the flashing portion of the display, press the **+ / ON** or **- / OFF** button.
3. Press the **NEXT** button.
4. Repeat steps 2 and 3 to set the following current information:
minutes, year, month and **day**.
5. Return the control dial to the **RUN**  position.


To Review or Change Watering Day Schedule


Calendar Schedule

1. Turn the control dial to the **WATERING DAYS**  position.



2. Set the **PROGRAMS** switch as necessary to select the desired program.
3. Press the **+ / ON** or **- / OFF** button as needed to select **CAL**.
4. Press the **NEXT** button.
5. To select the day (flashing), press the **+ / ON** button. To remove the day, press the **- / OFF** button. Repeat this step until only the desired watering days are shown.
6. Return the control dial to the **RUN**  position.

Interval Schedule

1. Turn the control dial to the **WATERING DAYS**  position.
2. Set the **PROGRAMS** switch as necessary to select the desired program.
3. Press the **+ / ON** or **- / OFF** button to select **Int**.


4. Press the **NEXT** button.
5. To select the Interval day (1–7), press the **+ / ON** or **- / OFF** button.
6. Press the **NEXT** button.
7. To select the Interval start day, press the **+ / ON** or **- / OFF** button.
8. Return the control dial to the **RUN**  position.

Odd or Even Schedule



1. Turn the control dial to the **WATERING DAYS**  position.
2. Set the **PROGRAMS** switch as necessary to select the desired program.
3. Press the **+ / ON** or **- / OFF** button to select **Odd** or **Even**.
4. Return the control dial to the **RUN**  position.

Day Exclusion



Note: The selected program must have an Interval or Odd/Even watering schedule to use the Day Exclusion feature.

1. Turn the control dial to the **WATERING DAYS**  position.
2. Set the **PROGRAMS** switch as necessary to select the desired program.
3. Press the **NEXT** button as needed to display **d E**. The currently eligible days of the week will be displayed and **SU** (Sunday) will begin flashing.
4. To exclude Sunday from the watering schedule, press the **- / OFF** button. To keep Sunday and skip to the next day, press the **+ / ON** button; **MO** (Monday) will now begin flashing. Continue to exclude or skip each day of the week as needed.


4 **Turning Off A Program**

1. Turn the control dial to the **WATERING DAYS**  position.
2. Set the **PROGRAMS** switch as needed to select the desired program.
3. Press the **+ / ON** or **- / OFF** button to select **OFF**.
4. Return the control dial to the **RUN**  position.


To Review or Change Program Start Times

1. Turn the control dial to the **START TIME**  position.
2. Set the **PROGRAMS** switch as needed to select the desired program.
3. Press the **+ / ON** or **- / OFF** button to select the desired program start time number.
4. Press the **NEXT** button.
Note: To remove a start time, select OFF by pressing the **+ / ON** and **- / OFF** buttons **at the same time**, and continue at step 8.
5. To set the hour, press the **+ / ON** or **- / OFF** button.
6. Press the **NEXT** button.
7. To set the minutes, press the **+ / ON** or **- / OFF** button.
8. Press the **NEXT** button. The next program start time number will begin flashing.
9. To review or change another start time, return to step 3.
10. Return the control dial to the **RUN**  position.

To Review or Change Zone Run Times

1. Turn the control dial to the **SET ZONE TIMES**  position.
2. Set the **PROGRAMS** switch as needed to select the desired program.
3. Station number 1 will be flashing and its current run time or OFF will be shown. To select a different station number, press the **+ / ON** or **- / OFF** button.
4. Press the **NEXT** button.
5. To set the run time, press the **+ / ON** or **- / OFF** button.

Note: To remove a station run time, select OFF by pressing the **+ / ON** and **- / OFF** buttons **at the same time**.


6. Press the **NEXT** button.
7. To review or change a run time for another zone, repeat steps 5 and 6.
8. Return the control dial to the **RUN**  position.

Manual Operations

Starting Programs Manually

Note: Watering programs can be started individually or set to start in order.

Additional programs set to start will operate one at a time in alphabetical order regardless of the order selected.

1. Ensure the control dial is in the **RUN**  position.
2. Position the **PROGRAMS** switch to select a program you wish to start.
3. Press the **MANUAL START** button **two times**.
4. To select additional programs, repeat step 2 and 3.

To Pause Watering

Press the **+ / ON** and **- / OFF** buttons **at the same time**.

To Resume Watering (when paused)

Press the **NEXT** button.

To Cancel Watering

Press the **+ / ON** and **- / OFF** buttons **at the same time - two times**.

To Skip Zones


Press the **NEXT** button one time.

To Adjust the Zone Run Time

Press the **+ / ON** button to increase run time or the **- / OFF** button to decrease run time.

Manual Operations (CONTINUED)

Operating Selected Station(s)

1. Ensure the control dial is in the **RUN**  position.
2. Position the **PROGRAMS** switch as necessary to select the program with the assigned station(s).
3. Press the **MANUAL START** button.
4. The first station assigned to the program will begin flashing. To select this station, press the **+ / ON** button. To skip this station, press the **- / OFF** button. Continue selecting any additional stations in this manner.
5. Press the **MANUAL START** button.
6. To select stations from another program, repeat steps 2 through 5.

Turning Off The Timer



When the control dial is turned to the **OFF** position, the timer immediately shuts off any watering operation currently in progress. Leaving the control dial in the **OFF** position will prevent all automatic and manual watering operations.

For extended shutdown of the sprinkler system, leave the control dial in the **OFF** position.

Timer operation is resumed by turning the control dial to the **RUN**  position.

Rain Delay Feature

This feature enables all watering operations to be delayed from 1 to 7 days.


1. Turn the control dial to the **RAIN DELAY**  position.
2. To set the number of Rain Delay days, press the **+ / ON** or **- / OFF** button.
3. Turn the control dial to the **RUN**  position.

Note: To cancel the Rain Delay, turn the control dial momentarily to the **OFF** position.

Note: The Rain Delay number will automatically decrease as each day passes. When the number reaches 0 (zero), automatic operation will resume.

Season Adjust Feature

Note: Please refer to the User's Guide for detailed information regarding the Season Adjust feature.

1. Turn the control dial to the **SEASON ADJUST %** position.
2. Set the **PROGRAMS** switch to select the desired program.
3. Press the **+ / ON** or **- / OFF** until the desired adjustment value (10% to 200%) is flashing.
4. Return the control dial the **RUN**  position.