Your Logo Here

Attachment Holders

Installation Instructions

You can customize the Dingo trailer with many different attachment holders to suit your needs. Install attachment holders to the base trailer by sliding the posts on the attachment holder into the pockets on the trailer (Fig. 1). Tighten the two set screws in each pocket to secure the attachment holder to the trailer.




Figure 1

1. Base trailer
2. Pocket
3. Attachment holder post
4. Set screw

Note: Some attachments require tie down straps.

DANGER

POTENTIAL HAZARD

- **If the tie down straps cannot hold 1600 pounds or are damaged, the traction unit or attachments could fall off of the trailer.**
- **If the attachment racks are damaged, the attachments could fall off of the trailer.**

WHAT CAN HAPPEN

- **If the traction unit or an attachment falls off of the trailer it could cause a traffic accident and possibly kill or severely injure you or other people.**

HOW TO AVOID THE HAZARD

- **Use tie down straps that have a load rating of 1600 pounds or greater, in accordance with federal regulation (DOT Title 49). Inspect the tie down straps regularly to ensure that they are in good condition. Do not use worn or damaged tie down straps.**
- **Be careful when loading and unloading attachments so that you do not damage the attachment holder or the attachment. Inspect the attachment holders regularly to ensure that they are not showing signs of damage or wear. If they are, replace or repair them before using them.**

Copy Parts Catalog Page Here