Form Number 3356-374 Rev B

Rear Broom

Sand/Infield Pro® 3040 and 5040 Traction Unit

Model No. 08753 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2007
All Rights Reserved

Register your product at www.Toro.com


Contents

Description	Page	Description	Page
Broom Mounting Assembly	 3	Link Assembly No. 110-8105	 5
Adapter and Lift Arm Assembly	 4	Attachments and Accessories List	 6

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR. . . . . as required
ASM. . . . . assembly
BBC. . . . . blade brake clutch
CARR. . . . . carriage
DEG. . . . . degrees
EXT. . . . . external
FH. . . . . flat head
GA. . . . . gauge
HD. . . . . heavy-duty
HF. . . . . hex flange
HH. . . . . hex head
HHF. . . . . hex head flange
HHFTF. . . . . hex head flange thread forming
HJ. . . . . hex jam
HLH. . . . . hex lag head
HOC. . . . . height-of-cut
HSBH. . . . . hex socket button head
HSFH. . . . . hex socket flat head
HSH. . . . . hex socket head
HWH. . . . . hex washer head
HWHTF. . . . . hex washer head thread forming
HYD. . . . . hydraulic
LH. . . . . left hand
NI. . . . . nylon insert
NPTF. . . . . national pipe thread fine
PFH. . . . . phillips flat head
PPH. . . . . phillips pan head
PPHTF. . . . . phillips pan head thread forming
PRH. . . . . phillips round head
PTH. . . . . phillips truss head
PTO. . . . . power-take-off
RH. . . . . right hand
ROPS. . . . . roll-over protection system
SFH. . . . . slotted fillister head
SHH. . . . . slotted hex head
SHWH. . . . . slotted hex washer head
SPH. . . . . slotted pan head
SQH. . . . . square head
SRH. . . . . slotted round head
STD. . . . . standard
TAP. . . . . self tapping
TTH. . . . . torx truss head



Broom Mounting Assembly


Ref	Part No.	Qty.	Description
1	110-1381-03	1	Broom Mount ASM
2	112-1401	1	RH Wing ASM
2:2	256-113	2	Bushing-Flange
3	112-1402	1	LH Wing ASM
3:2	256-113	2	Bushing-Flange
4	105-9602	4	Brush
5	105-9625-03	4	Weight-Brush
11	3256-80	12	Washer-Flat
13	710125	2	Spacer
14	32151-48	2	E-Ring
15	322-11	8	Screw-HH
16	3296-29	16	Nut-Lock, NI
17	5-2942	2	Shackle
18	3256-23	16	Washer-Flat
19	283-10	2	Pin-Clevis
20	3272-10	2	Pin-Cotter
21	322-13	8	Screw-HH
24	104-8301	8	Nut-Flange, NI
39	104-0534-03	4	Weight-Reel
40	323-19	4	Screw-HH
41	99-2058	4	Spacer-Support, Handle
43	323-7	4	Screw-HH
44	84-2452	2	Chain-14 Link, Straight



Adapter and Lift Arm Assembly

Ref	Part No.	Qty.	Description
1	112-0040-03	1	Handle ASM
2	3296-25	1	Nut-Lock, NI
3	92-2651	1	Washer
4	112-0038	1	Spacer
5	112-1403	1	Adapter ASM
5:2	27-9080	2	Bearing-Flange
6	112-1408	1	Lift Arm ASM
6:2	106-5517	2	Decal-Surface, Hot
7	3272-17	2	Pin-Cotter
8	104-8301	3	Nut-Flange, NI
9	3256-3	6	Washer-Flat
10	323-52	2	Screw-HH
11	323-7	1	Screw-HH
13	110-3362	1	Pivot Bar ASM
14	3296-48	1	Nut-Lock, NI
15	3256-25	1	Washer-Flat
16	322-5	2	Screw-HH
17	323-10	1	Screw-HH
18	80-2050	1	Bolt-Shoulder
19	112-7100-03	1	Pivot ASM
20	283-83	2	Pin-Clevis
21	3256-26	5	Washer-Flat
22	3296-29	2	Nut-Lock, NI
23	323-11	1	Screw-HH

Ref	Part No.	Qty.	Description
24	110-8116	3	Spacer-Link
25	3272-11	2	Pin-Cotter
26	110-8105	1	Link ASM
28	99-7984	1	Knob-Soft Grip, Push-On
29	3296-44	1	Nut-Lock, NI
30	110-8154	1	Latch ASM
31	110-1391	1	Tube-Spacer
32	110-1385-03	1	Bracket-Pivot, Broom
33	325-22	1	Screw-HH
34	3296-23	1	Nut-Lock, NI



Link Assembly No. 110-8105

Ref	Part No.	Qty.	Description
1	110-8111-01	1	Yoke ASM
2	110-8110	1	Spacer
3	110-8114	1	Washer
4	66-7230	1	Spring-Compression
5	3256-3	3	Washer-Flat
6	3211-12	1	Screw-HH
7	3220-3	2	Nut-HJ
8	92-7008	2	End-Rod, Female
9	110-8108	1	Rod-Link
10	32128-12	1	Nut-Lock, Flange

Attachments and Accessories

For 08753 - Rear Broom, Sand/Infield Pro 3040 and 5040 Traction Unit

Product Name	Model/Part
Brush	110-8182
Rear Broom Weight Kit	112-0025

NOTES


TORO®