FORM NO. 3316–678


TORO®

MODEL NO. 79261–490001 & UP

PARTS CATALOG

42" (107cm) SNOWTHROWER

for WHEEL HORSE® Yard Tractor



Lift Assist Spring Assembly

C–1117A


AUGER ASSEMBLY

Ref. No.	Part No.	Description	Qty.
1	78–6240	Belt	1
2	115165	Chain	1
3	79–4000	Guard – Chain	1
4	3256–22	Washer	2
5	926671	Screw	2
6	3296–29	Nut – Nylok	6
7	110567	Collar – Bearing	2
8	110569	Bearing	2
9	110568	Collar – Bearing	2
10	3230–1	Bolt – Carriage	6
11	79–4840–01	Shaft Assembly	1
12	937159	Key – Hi–Pro	1
13	113356	Pulley	1
14	3242–2	Screw – Set	2
15	3256–28	Washer	4
16	101480	Bearing – Ball	2
17	93–1615–03	Auger Assembly	1

Ref. No.	Part No.	Description	Qty.
18	93–1619–01	Guard – Inner	1
19	32149–2	Nut – Keps	1
20	3256–2	Washer	1
21	321–3	Screw – Cap Hex. Hd.	1
22	3296–23	Nut – Lock	1
23	93–1614–03	Sprocket – Idler	1
24	3256–26	Washer	1
25	6417	Washer	1
26	325–8	Screw – Cap Hex. Hd.	1
27	93–1123–03	Bracket	1
28	92–9821	Spring	1
29	93–3161	Rod	1
30	79–3401–03	Tractor Lift Arm	1
31	1391	Screw – Rd. Hd. E.T.L.W.	1
32	322–6	Screw – Cap Hex. Hd.	2
33	85–7490	Decal – Warning	2

© The TORO Company –1994
All Rights Reserved


TPS



BLOWER ASSEMBLY

Ref. No.	Part No.	Description	Qty.
1	3296–39	Nut	23
2	3256–24	Washer – Flat	16
3	3231–2	Bolt – Carriage	13
4	93–1617–01	Plate	2
5	3229–25	Bolt – Carriage	9
6	3256–22	Washer – Flat	9
7	3296–42	Nut	9
8	93–1616–01	Plate	1
9	79–6170–01	Scraper	1
10	93–1620–01	Skid Assembly	2
11	93–1618–01	Support – Flange	2
12	3296–29	Nut	6
13	92–9777–01	Housing – Auger (Incl. Ref. #44–46)	1
14	323–6	Screw – Hex. Hd.	4
15	79–6800	Mounting – Frame	1
16	933506	Pin – Cotter	2
17	3256–27	Washer – Flat	1
18	79–3251–03	Tube – Lift	1
19	920232	Washer	6
20	92–9778–03	Rod – Lift (Incl. Ref. #43)	1
21	105797	Ring – Retaining	5
22	78–1720–01	Housing – Front Hitch	1

Ref. No.	Part No.	Description	Qty.
23	8616	Spring	1
24	3231–22	Bolt – Carriage	4
25	101751	Rod – Front Hitch	1
26	101707	Lock – Attachment	1
27	93–1613	Latch – Front Hitch	1
28	101750	Rod	1
29	105316	Cap – Lock Rod	1
30	932966	Pin – Clevis	1
31	79–3202–03	Bracket – Idler	1
32	79–3230	Slide – Idler	1
33	323–11	Screw – Hex. Hd.	1
34	79–3720	Bushing	1
35	92–7084	Pulley – Idler, Flat	1
36	92–7099	Pulley Idler	1
37	323–9	Screw – Hex. Hd.	1
38	933505	Pin – Cotter	1
39	79–3270–03	Spring – Tensioner	1
40	79–3310	Spring – Compression	1
41	79–7090	Retainer	1
43	85–7480	Decal – Warning	1
44	86–5100	Decal – Warning	1
45	63–2380	Decal – Danger	2
46	92–8652	Decal – Warning	1
47	92–8748	Decal – Attachment	1



CHUTE ASSEMBLY

Ref. No.	Part No.	Description	Qty.
1	11–9349–01	Deflector	1
2	20–4320	Washer – Rubber	2
3	3290–340	Washer – Belleville	2
4	3296–29	Nut	7
5	92–6335–01	Chute – Discharge (Incl. Ref.#19)	1
6	3231–2	Bolt – Carriage	2
7	322–2	Screw – Cap Hex. Hd.	3
8	12–2040	Guard – Chute	1
9	27–0220	Screw – Special	6
10	25–5450	Retainer – Chute	3
11	78–0160–01	Ring – Swivel	1
12	3296–39	Nut	6
13	3256–24	Washer	5
14	323–6	Screw – Hex.. Hd.	2
15	3256–23	Washer – Flat	7
16	78–0330–01	Adapter	1
17	920241	Washer	2

Ref. No.	Part No.	Description	Qty.
18	3290–326	Nut – Push	2
19	63–3740	Decal – Danger	2
20	26–1110–01	Extender – Chute	1
21	3230–1	Bolt – Carriage	3
22	3272–10	Pin – Cotter	1
23	3290–212	Washer	1
24	3230–2	Screw – Hex. Hd.	1
25	79–3770–01	Bracket – Worm	1
26	8–8600	Gear	1
27	78–7430	Shaft – Worm Gear	1
28	32121–50	Pin – Roll	3
29	78–0230	Universal	1
30	79–4090	Rod – Control, Chute	1
31	40–8230	Grip	1
32	3290–320	Retainer	1
33	79–3780	Support – Crank	1
34	933505	Pin – Cotter	3
35	78–0441–03	Bracket	1

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

Litho in U.S.A.