Form No. 3362-603 Rev B

TORO®

Count on it.

Parts Catalog

TimeCutter® Z5060 Riding Mower

Model No. 74375—Serial No. 290000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake clutch

CARR: carriage

CCW: counter clock wise

CW: clockwise

DEG: degrees

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

© 2010—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved

Contents

Frame and Castor Wheel Assembly 4
Deck Lift and Seat Support Assembly 5
Seat Assembly 6
Seat and Armrest Kit Assembly No. 117-1227 7
Control Assembly 8
Hydro Drive Assembly 9
RH Hydro Assembly No. 110-6771 10
LH Hydro Assembly No. 110-6770 11
Engine and Clutch Assembly 12
Styling and Fuel System Assembly 13
50 Inch Deck and Side Dicharge Assembly 14
50 Inch Deck Decal Assembly No. 117-1291 15
50 Inch Deck Spindle and Drive Belt Assembly 16
Electrical Assembly 17
Crankshaft Assembly Kohler SV730-0029 18
Crankcase Assembly Kohler SV730-0029 19
Head, Valve and Breather Assembly Kohler SV730-0029 20
Oil Pan and Lubrication Assembly Kohler SV730-0029 22
Ignition and Electrical Assembly Kohler SV730-0029 23
Blower Housing Assembly Kohler SV730-0029 24
Starter Assembly Kohler SV730-0029 25
Fuel System Assembly Kohler SV730-0029 26
Engine Control Assembly Kohler SV730-0029 27
Air Intake and Filtration Assembly Kohler SV730-0029 28
Gaskets Kohler SV730-0029 29
Decals Kohler SV730-0029 30
Attachments and Accessories 31



Frame and Castor Wheel Assembly

Ref.	Part Number	Qty.	Description
1	115-2464-01	1	Frame
2	110-6899-03	1	Bumper-Rear
3	115-5041-03	1	Seat Pivot/Control ASM
4	117-1160-01	1	Front Axle ASM
5	115-2554	2	Wheel And Tire ASM
5:2	115-2557	1	Tire-Smooth
5:3	114-1640	2	Bushing-Flange
5:4	232-27	1	Stem-Valve
5:5	302-5	1	Fitting-Grease
5:99	117-1234	1	Tube-Inner
6	104-3667	2	Spanner-Wheel
7	325-22	2	Screw-HH
8	3296-45	2	Nut-Lock, NI
9	110-6634-01	2	Caster Fork ASM
10	10-8110	2	Washer-Thrust

Ref.	Part Number	Qty.	Description
15	3234-47	7	Screw-HHF
16	108-7855-03	1	Footrest
17	3296-29	7	Nut-Lock, NI
18	32104-32	2	Screw-HWH
20	323-8	4	Screw-HH
21	80-6990	2	Washer-Hardened
22	3296-39	8	Nut-Lock, NI
23	323-13	4	Screw-HH
24	105-8278	1	Decal
25	3256-24	10	Washer-Flat
26	3234-47	2	Screw-HHF
27	109-3678	4	Bearing-Ball
28	109-3724	2	Washer
29	117-1237-03	1	Plate-Footrest



Deck Lift and Seat Support Assembly

Ref.	Part Number	Qty.	Description
1	112-4027-03	1	Sector-HOC
2	322-10	2	Screw-HH
3	322-6	3	Screw-HH
4	112-3960-03	1	Lift Arm ASM
5	108-7841-03	1	Lift Lever ASM
6	110-6800-03	1	Plate-Lift
7	110-6805-03	1	Bracket-Seat/Pods
8	110-1937-03	1	Tray-Battery
9	3296-29	8	Nut-Lock, NI
10	108-7840	1	Link-Lift
11	108-7839	1	Arm-Lift, Rear
12	108-7845	2	Block-Pivot
13	112-9802	1	Decal-HOC
14	105-3450	1	Grip-Lever, Lift
15	3272-10	4	Pin-Cotter
16	3256-26	3	Washer-Flat
17	104-8300	3	Nut-Flange, NI
18	3234-47	6	Screw-HHF
19	3256-23	3	Washer-Flat
20	106-8743	1	Decal-HOC
21	32104-32	1	Screw-HWH
22	112-4018-03	1	Pedal ASM
23	112-3954-03	2	Bracket-Footlift
24	256-156	2	Bushing-Flange
25	3256-24	2	Washer-Flat
26	3-6498	2	Washer-Thrust
27	112-3958	1	Rod-Lift
28	112-3959	1	Plate-Footlift
29	112-3961	2	Spacer



Seat Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	115-2465-03	1	Base-Seat
2	117-1227	1	18 Inch Seat ASM W/ Armrests
3	701178	2	Cap-Protector
4	3234-47	2	Screw-HHF
6	92-7054	2	Spring-Compression
7	104-8300	2	Nut-Flange, NI
8	5-4460	1	Washer-Pivot
9	92-9674	1	Knob
10	94-7582	2	Bolt-Shoulder
11	32128-21	2	Nut-HF
12	37-8771	4	Bolt-Shoulder
13	115-2469	1	Decal-Danger
14	117-1268	1	Decal-Timecutter
16	106-8717	1	Decal-Service
17	109-2628	1	Cable-Stop, Seat
18	60-1730	1	Pin-Clevis
19	1-806003	1	Pin-Cotter, Hair
20	321-5	1	Screw-HH
21	104-7201	1	Nut-HF



Seat and Armrest Kit Assembly No. 117-1227

Ref.	*Part Number*	*Qty.*	*Description*
1	117-1226	1	Seat-18 Inch
5	108-6163	1	Armrest Kit
5:1	110-6569	1	LH Armrest Kit
5:2	110-6570	1	RH Armrest Kit
5:3	108-6179	6	Screw-HSBH



Control Assembly

Ref.	Part Number	Qty.	Description
1	110-6814	1	RH Handle ASM ●
1:1	108-6187	1	Grip ●
2	110-6815	1	LH Handle ASM
2:1	108-6187	1	Grip
3	3256-24	4	Washer-Flat
4	323-6	4	Screw-HH
5	112-4004	2	Screw-Shoulder
6	110-6828	2	Activator Arm ASM
6:2	105-3455	2	Bushing
7	110-6810	2	Stud-Damper
8	103-2913	2	Damper-Control, Motion
9	3296-42	6	Nut-Lock, NI
10	46-8560	2	Screw-HHF
11	3296-48	2	Nut-Lock, NI
12	3256-22	4	Washer-Flat
13	32128-23	2	Nut-HF
14	3256-5	2	Washer-Flat
15	110-6693	2	Link-Hydro
16	1-303105	2	Yoke-Adjustable
17	1-808280	2	Pin-Clevis
18	1-806003	2	Pin-Cotter, Hair

Ref.	Part Number	Qty.	Description
19	3220-2	2	Nut-Jam
20	110-6845	2	Gear-Control
21	110-6783-03	1	Arm-Actuator, LH
22	110-6782-03	1	Arm-Actuator, RH ●
23	115-5023	2	Tab-Stop
24	110-6873	2	Eccentric
25	110-6874	2	Screw-Eccentric
26	110-6875	2	Bolt-Shoulder
27	110-6858	2	Cable-Brake, Parking
28	110-6751	2	Bracket-Return
29	110-6750	2	Plate-Return
30	110-6752	2	Spring-Compression
31	110-6894	8	Washer-Pivot
33	323-4	2	Screw-HH
34	110-0863	2	Screw-Torx
35	110-6784	2	Bolt-Shoulder
36	112-9750	1	Decal-Control Lever, LH
37	112-9751	1	Decal-Control Lever, RH
38	37-8771	2	Bolt-Shoulder
39	104-8300	2	Nut-Flange, NI
40	112-9771	2	Washer-Teflon

● Not illustrated



Hydro Drive Assembly

Ref.	Part Number	Qty.	Description
1	110-6771	1	Hydro-RH
2	110-6770	1	Hydro-LH
3	322-4	2	Screw-HH
4	322-11	2	Screw-HH
5	3230-9	4	Screw-CARR
6	104-8300	17	Nut-Flange, NI
7	322-6	1	Screw-HH
8	322-7	1	Screw-HH
9	110-6677	2	Clip-Spring
10	110-6774	1	V-Belt
11	63-1590	1	Spring-Idler
12	110-6775	2	Pulley-Idler
13	5-4460	3	Washer-Pivot
14	110-1925	1	Arm-Idler
15	37-8771	1	Bolt-Shoulder
16	110-6883	2	Wheel And Tire ASM
16:1	110-6887	1	Tire
16:3	232-27	1	Stem-Valve

Ref.	Part Number	Qty.	Description
16:99	232-37	1	Tube
17	242-50	8	Nut-Lug
18	110-6807	1	Shaft-Cross
19	110-1926	1	Plate-Pivot
20	110-6806-03	2	Strap-Torque
21	110-6878-03	2	Support-Hydro
22	110-6787	2	Rod-Bypass
23	1-806003	2	Pin-Cotter, Hair
24	3256-22	2	Washer-Flat
25	324-8	4	Screw-HH
26	3296-48	2	Nut-Lock, NI
27	112-3979	2	Hub ASM
28	112-3982	2	Nut-Lock
29	114-8532	1	Decal-Transport, LH
30	114-8531	1	Decal-Transport, RH
31	3234-47	8	Screw-HHF
32	115-5057	2	Cover-Nut, Axle



RH Hydro Assembly No. 110-6771

Ref.	Part Number	Qty.	Description
1	114-1630	1	RH Main Housing ASM
2	114-1631	1	RH Side ASM
4	110-8561	1	Pump Block ASM
6	104-2189	1	Plug-Thread, Straight
7	103-2666	1	Cylinder Block Kit
8	104-5305	16	Screw-HHF
13	106-8678	1	Rod-Bypass
17	104-5304	1	Swashplate-Trunnion
19	104-2116	1	Stud
20	112-9853	1	Puck-Friction
21	106-8747	1	Arm-Control
22	5-4460	1	Washer-Pivot
23	107-2488	1	Screw
24	105-1872	1	Nut
25	94-1936	1	Spring-Block
26	94-1937	1	Washer-Thrust, Block
27	104-5306	1	Shaft-Input
28	104-5311	1	Bearing-Ball
30	104-5308	1	Spacer
33	94-6922	2	Bearing-Thrust
34	104-5339	1	Washer-Flat
36	104-5316	1	Gear-Pinnion, 13T
37	114-1632	1	Shaft-Motor
38	104-5360	1	Washer-Shaft, Motor
39	94-1933	2	Washer

Ref.	Part Number	Qty.	Description
40	104-5317	1	Gear
41	104-5318	1	Gear-Jackshaft, 10T
42	104-5329	1	Pin-Jackshaft
44	112-9855	1	Gear-52T, Bull
45	112-9856	1	Washer
46	112-9857	1	Bearing-Sleeve
47	112-9858	1	Shaft-Axle
48	112-9859	1	Bushing-Axle
50	106-8686	1	Seal Kit
51	106-8697	1	RH Expansion Plate Kit
52	106-8698	1	Fan Pulley Kit
53	114-1633	1	Brake Arm Kit
54	112-9861	1	RH Center Section Filter Kit
55	104-2147	1	Sealant ●
56	107-2489	1	Bypass Arm Kit
57	114-1634	1	Filter Kit
59	106-8694	1	Disc-Brake, Cog
62	110-8566	1	Fan-6 Inch, 10 Blade
63	104-1754	1	Pulley
64	105-1875	1	Nut-Lock
65	107-9122	1	Washer-Slotted
67	112-9866	1	Breather Kit
68	114-1635	1	Breather ASM
69	115-5057	1	Cover-Nut, Axle

● Not illustrated



LH Hydro Assembly No. 110-6770

Ref.	Part Number	Qty.	Description
1	114-1636	1	LH Main Housing ASM
2	114-1637	1	LH Side ASM
4	110-8561	1	Pump Block ASM
6	104-2189	1	Plug-Thread, Straight
7	103-2666	1	Cylinder Block Kit
8	104-5305	16	Screw-HHF
13	106-8678	1	Rod-Bypass
17	104-5304	1	Swashplate-Trunnion
19	104-2116	1	Stud
20	112-9853	1	Puck-Friction
21	106-8747	1	Arm-Control
22	5-4460	1	Washer-Pivot
23	107-2488	1	Screw
24	105-1872	1	Nut
25	94-1936	1	Spring-Block
26	94-1937	1	Washer-Thrust, Block
27	104-5306	1	Shaft-Input
28	104-5311	1	Bearing-Ball
30	104-5308	1	Spacer
33	94-6922	2	Bearing-Thrust
34	104-5339	1	Washer-Flat
36	104-5316	1	Gear-Pinnion, 13T
37	114-1632	1	Shaft-Motor
38	104-5360	1	Washer-Shaft, Motor
39	94-1933	2	Washer

Ref.	Part Number	Qty.	Description
40	104-5317	1	Gear
41	104-5318	1	Gear-Jackshaft, 10T
42	104-5329	1	Pin-Jackshaft
44	112-9855	1	Gear-52T, Bull
45	112-9856	1	Washer
46	112-9857	1	Bearing-Sleeve
47	112-9858	1	Shaft-Axle
48	112-9859	1	Bushing-Axle
50	106-8686	1	Seal Kit
51	106-8687	1	LH Expansion Plate Kit
52	106-8698	1	Fan Pulley Kit
53	114-1633	1	Brake Arm Kit
54	112-9862	1	LH Center Section Filter Kit
55	104-2147	1	Sealant ●
56	107-2489	1	Bypass Arm Kit
57	114-1634	1	Filter Kit
59	106-8694	1	Disc-Brake, Cog
62	110-8566	1	Fan-6 Inch, 10 Blade
63	104-1754	1	Pulley
64	105-1875	1	Nut-Lock
65	107-9122	1	Washer-Slotted
67	112-9866	1	Breather Kit
68	114-1635	1	Breather ASM
69	115-5057	1	Cover-Nut, Axle

● Not illustrated



Engine and Clutch Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1		1	Engine-Kohler, Sv730-0029 ●■
3	3274-10	4	Screw-HSH
4	117-1271	1	Muffler-Kohler Twin
6	114-1622	1	Pulley-Engine
7	112-4033	1	Bumper-Pad
8	110-6896	1	Stop-Clutch
9	322-4	2	Screw-HH
10	3296-29	2	Nut-Lock, NI
11	110-6766	1	Clutch-Electric, PTO
12	3253-4	4	Washer-Lock
13	3212-11	1	Screw-HH
14	32144-109	4	Screw
18	2412-98	2	Clamp
19	107-0589	1	Hose-Fuel
20	110-6798	1	Support-Hydro, RH
21	110-6799	1	Support-Hydro, LH
24	112-9849	1	Tubing-Convoluted
25	82-4201	1	HYD Hose ASM
26	288-10	1	Cap-Pipe
28	114-8544	1	Shield-Heat
29	46-8560	2	Screw-HHF

● Not serviced separately

■ Obtain parts from www.kohlerplus.com



Styling and Fuel System Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	117-1219	1	Pod-RH
2	117-1220	1	Pod-LH
3	115-2500	1	Decal-Panel, Control
4	117-1295	1	Cable-Throttle/Choke
5	3258-166	4	Screw-PRH
6	107069	4	Clip
7	93-7198	1	Gas Cap ASM
8	110-1927-03	1	Panel-Control
9	110-6890	1	Fuel Tank ASM
9:2	46-6560	1	Bushing
9:3	95-3970	1	Fitting-90 Degree
10	112-4004	6	Screw-Shoulder
11	110-6786	2	Cover-Control
12	112-9760	1	Washer-Rubber
13	55-9310	1	Seal-Foam
17	100-9064	1	Tie-Cable
19	105-1853	1	Clamp-Hose
20	110-6685-03	1	Support-Cover, Rear
21	105-8278	1	Decal
22	325-8	2	Screw-HH
23	3256-26	4	Washer-Flat
24	3296-23	2	Nut-Lock, NI



50 Inch Deck and Side Dicharge Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	117-1291	1	50 Inch Deck ASM
2	108-7836	1	Bracket-Hanger, Right Rear
3	108-7838	1	Bracket-Hanger, Left Rear
4	3231-2	3	Screw-CARR
5	112-3980	1	Eccentric
6	80-6990	3	Washer-Hardened
7	95-2747	2	Fitting-Washout
8	46-6290	2	O-Ring, Seal
9	46-8560	4	Screw-HHF
12	95-3270	1	Connector-Hose
13	1-808284	1	Pin-Clevis
14	108-7847	1	Rod-Lift
15	87-7270	1	Washer-Thrust
16	3231-28	1	Screw-CARR
17	3296-23	1	Nut-Lock, NI
18	9335054	1	Pin-Hair
19	108-7895	1	Deflector-50 Inch
20	110-6694	1	Spring-Torsion
21	112-3950	1	Rod-Pivot
22	3296-39	8	Nut-Lock, NI
23	1-603299	3	Roller-Scalp, Anti
24	112-3977	3	Bolt-Shoulder
25	32104-76	6	Screw
26	108-7890	2	Cover-Belt



50 Inch Deck Decal Assembly No. 117-1291

Ref.	*Part Number*	*Qty.*	*Description*
2	114-1606	2	Decal-Danger, Pulley
3	93-7009	1	Decal-Danger, Deflector
4	110-6691	2	Decal-Danger
5	99-3943	1	Decal-Routing, Belt
6	3290-282	2	Rivet-Blind
7	322-2	1	Screw-HH
8	3230-23	1	Screw-CARR
9	104-8300	2	Nut-Flange, NI
10	112-9840	1	Decal-Scalp, Anti



50 Inch Deck Spindle and Drive Belt Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	110-6892	1	V-Belt
2	323-9	2	Screw-HH
3	3256-24	3	Washer-Flat
4	106-2175	3	Pulley-Idler, Flat
5	3296-39	1	Nut-Lock, NI
6	114-8540	1	Arm-Idler
7	110-9981	2	Washer-Plain
8	114-0463	2	Washer-Friction, Composite
9	115-4986	1	Spacer
10	323-8	1	Screw-HH
11	3219-6	3	Nut-Hex
12	110-6865	3	Pulley
13	32144-41	12	Screw-Taptite
14	26-0671	3	Screw-HH

Ref.	*Part Number*	*Qty.*	*Description*
15	3290-465	3	Washer-Belleville
16	106-2248-03	3	Stiffener-Blade
17	110-6837-03	3	Blade-17.5 Inch, High Lift
19	80-4360	3	Shield-Bearing
20	80-4380	3	Spacer
21	110-6866	3	Shaft-Spindle
22		3	Spindle ASM ●
22:1	88-4510	1	Housing-Spindle
22:2	100-1048	2	Bearing-Ball
22:3	62-3661	1	Spacer
23	112-3973	1	Hook-Return, Spring
24	1-603414	1	Spring-Extension
26	323-10	1	Screw-HH

● Not serviced separately



Electrical Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	104-2493	1	Battery
2	110-6764	1	Switch-Ignition
3	63-8360	1	Key-Ignition
4	93-9998	1	Switch-PTO
5	32103-22	1	Nut-Wing
6	110-6765	2	Switch-Single Pole No
7	82-2190	1	Switch-Bail
8	117-1197	1	Solenoid
9	110-6794	1	Cable-Battery, Red
10	3229-1	1	Screw-CARR
11	110-6793	1	Cable-Battery, Black
12	104-2466	1	Holddown-Battery
13	321-3	1	Screw-HH
14	117-1276	1	Harness-Wiring
14:1	109103	1	Fuse-30 Amp
14:2	109102	1	Fuse-25 Amp
14:3	100-4918	1	Diode
15	3256-22	2	Washer-Flat
16	32144-1	3	Screw-Taptite
17	110-6792	1	Cable-Battery, Red
18	32128-33	2	Nut-HF
19	98-7249	1	Relay
20	46-8560	2	Screw-HHF
21	3220-2	2	Nut-Jam



Crankshaft Assembly
Kohler SV730-0029

Ref.	*Part Number*	*Qty.*	*Description*
2	52 139 09-S	1	Plug-Cup ●
3	32 014 04-S	1	Crankshaft ASM (Includes 2) ●

● Obtain parts from www.kohlerplus.com



Crankcase Assembly
Kohler SV730-0029

Ref.	Part Number	Qty.	Description
2	25 153 02-S	1	O-Ring (Dipstick) ■
3	M-545013-S	1	Screw-Flg, Thd Frm (M5X0.8X13) ■
7	24 126 19-S	1	Bracket-Tube, Oil Fill ■
9	32 522 03	1	Sv710-740 Shortblock ■
10	24 018 04-S	1	Retainer-Reed, Breather ■
11	12 402 02-S	1	Reed-Breather ■
12	24 380 13-S	6	Pin-Locating ■
14	25 874 01-S	2	Piston W/Ring Set (STD) (Includes 15, 39) ■
15	24 018 01-S	4	Retainer-Pin, Piston ■
17	12 422 07-S	1	Shim-Camshaft (White .028) ■
18	32 012 01-S	1	Camshaft Kit (Includes 25 357 14-S) ■
19	28 032 09-S	1	Seal-Cross Shaft, Governor ■
20	24 018 09-S	1	Retainer-Ring ■
21	M-931010-S	1	Washer-Flat (9Mm) ■
22	24 468 15-S	1	Washer-Flat (11/32) ■
23	24 144 38-S	1	Shaft-Cross, Governor ■
24	24 038 04-S	1	Dipstick ASM (Includes 2) ■

Ref.	Part Number	Qty.	Description
25	25 874 03-S	2	Piston W/Ring Set (.25) ■
28	24 108 16-S	2	Piston Ring Set (.25) ■
29	12 422 08-S	1	Shim-Camshaft (Blue .03) ■
30	12 422 09-S	1	Shim-Camshaft (Red .032) ■
31	12 422 10-S	1	Shim-Camshaft (Yellow .034) ■
32	12 422 11-S	1	Shim-Camshaft (Green .036) ■
33	12 422 12-S	1	Shim-Camshaft (Gray .038) ■
34	12 422 13-S	1	Shim-Camshaft (Black .04) ■
36	24 032 19-S	1	Seal-Oil (Helix Lip) ■
37	24 067 24-S	2	Rod-Connecting (STD) ■
38	25 123 07-S	1	Dipstick Tube ASM ■
39	24 108 14-S	1	Piston Ring Set (STD) ■
40	32 874 09-S	1	Piston W/Ring Set (.08) (Use 24 874 27-S Kit) ■
41	24 874 27-S	1	Piston W/Ring Set (.08) (Use 25 874 02-S Kit) ■
	25 357 14-S	1	Lubricant-Camshaft ■ ●

● Not illustrated

■ Obtain parts from www.kohlerplus.com

Head, Valve and Breather Assembly
Kohler SV730-0029



Head, Valve and Breather Assembly
Kohler SV730-0029 (continued)

Ref.	Part Number	Qty.	Description
1	32 096 06-S	1	Breather Valve Cover Kit (Includes 2 [qty 1]) ■
2	24 153 30-S	2	O-Ring (Valve Cover) ■
3	M-651030-S	8	Screw-Flange (M6X1.0X30) ■
5	12 755 03-S	4	Retainer Kit ■
6	12 173 01-S	4	Cap-Spring, Valve ■
7	24 089 02-S	4	Spring-Valve ■
8	235011-S	4	Retainer-Spring ■
9	66 032 05-S	2	Seal-Stem, Valve ■
10	24 017 01-S	2	Valve-Intake (STD) ■
11	24 016 01-S	2	Valve-Exhaust (STD) ■
12	32 326 06-S	1	Breather Hose Kit (Includes 13) ■
13	25 237 14-S	1	Clamp-Hose, Spring (1/2) ■
14	32 081 02-S	1	Breather Housing Kit (Includes 15, 16) ■
15	M-547050-S	1	Nut-Lock (M5X.8) ■
16	32 468 01-S	1	Washer-Sealing ■
17	32 072 03-S	1	Stud-Cover, Breather ■
18	32 019 02-S	4	Tappet Kit ■
20	32 841 01-S	2	Cylinder Head Gasket Kit (Includes 26[qty 4], 24 041 49-S, 24 153 27-S) ■
26	12 086 16-S	8	Screw-Flange (M10X1.5X90) ■
28	24 755 141-S	1	Plain Rocker Cover Kit (Includes 2 [qty 1], 3 [qty 4]) ■
29	24 445 01-S	1	Strap-Lifting ■
30	M-645016-S	1	Screw-Flange, Thread Forming (M6X1.0X16) ■
31	32 096 04-S	1	Breather Cover Kit (Includes 32) ■
32	32 041 01-S	1	Gasket-Cover, Breather ■
33	32 050 01-S	1	Filter-Breather ■
34	32 318 13-S	1	Cylinder Head No.1 ASM (Includes Exhaust Mounting Hardware) ■
35	32 318 14-S	1	Cylinder Head No.2 ASM (Includes Exhaust Mounting Hardware) ■
36	32 146 09-S	2	Plate-Guide ■
37	32 072 04-S	4	Stud-Rocker ■
38	32 186 03-S	4	Arm-Rocker ■
39	32 100 05-S	4	Hex Nut ASM (Includes 40) ■
40	25 086 168-S	4	Screw-Set ■
41	25 599 01-S	4	Pivot-Arm, Rocker ■
42	32 411 04-S	4	Rod-Push (After S/N 3633510943) ■
43	32 326 07-S	1	Fuel Pump Hose W/Clamp Kit (Includes 44) ■
44	25 237 01-S	1	Clamp-Hose ■
	24 041 49-S	1	Gasket-Exhaust ■ ●
	24 153 27-S	1	O-Ring (Intake Port) ■ ●
	32 755 03-S	2	Cylinder Head Hardware Kit (Services 1 Head-Qtys Listed For Both Heads) (Includes 5-11, 19, 22, 25, 34) ■ ●

● Not illustrated

■ Obtain parts from www.kohlerplus.com



Oil Pan and Lubrication Assembly
Kohler SV730-0029

Ref.	*Part Number*	*Qty.*	*Description*
2	32 086 01-S	2	Screw-Shoulder, Thd Frm (M6X1.0X26.5) ●
3	32 393 10-S	1	Oil Pump ASM ●
4	24 043 12-S	1	Governor Gear W/Pin Kit (Includes 5) ●
5	12 380 01-S	1	Pin-Regulating, Governor ●
6	24 448 02-S	1	Tab-Locking ●
7	12 144 02-S	1	Shaft-Gear, Governor ●
8	25 032 06-S	1	Seal-Oil ●
9	32 123 01-S	1	Tube-Feed, Oil (Filter To Pan) ●
11	24 153 01-S	2	O-Ring ●
13	25 139 60-S	1	Plug-Pipe, Countersunk (1/8) ●
17	12 050 01-S	1	Filter-Oil ●
18	24 086 17-S	10	Screw-Flange (M8X1.25X45) ●
19	25 139 57-S	1	Plug-Pipe, Sq HD (3/8) ●
23	32 199 07-S	1	Oil Pan ASM (Includes 2-9, 11 [qty 1], 24-27) ●
24	32 123 06-S	1	Tube-Feed, Oil ●
25	32 153 05-S	1	O-Ring ●
26	32 136 05-S	1	Nipple-Filter, Oil ●
27	32 468 02-S	1	Washer-Flat ●
36	32 123 09-S	1	Oil Feed Tube ASM (Includes 11 [qty 1], 24, 25) ●

● Obtain parts from www.kohlerplus.com



Ignition and Electrical Assembly
Kohler SV730-0029

Ref.	*Part Number*	*Qty.*	*Description*
1	32 162 03-S	1	Screen-Grass ■
2	12 086 14-S	1	Screw-Flange (M10X1.5X45) ■
3	12 468 03-S	1	Washer-Flat (13/32) ■
4	20 146 05-S	1	Plate-Mounting, Fan ■
5	32 157 01-S	1	Fan ■
6	32 025 16-S	1	Flywheel ASM ■
7	X-42-15-S	1	Key (3/16 X 5/8) ■
8	25 155 41-S	1	Connector (3 Contact) ■
11	237878-S	1	15 Amp Stator Kit (Includes 25 452 01-S) ■
14	M-548025-S	2	Screw-Thread Forming (M5X0.8X25) ■
16	25 584 05-S	2	Ignition Module (Use 24 584 45-S) ■
17	M-545020-S	4	Screw-Flange, Thread Forming (M5X.8X20) ■
22	25 132 14-S	2	Spark Plug (R F I) ■
	25 454 03-S	2	Tie-Wire ■ ●
	25 452 01-S	2	Terminal ■ ●
	32 176 14-S	1	Wire Harness Kit ■ ●

● Not illustrated

■ Obtain parts from www.kohlerplus.com



Blower Housing Assembly
Kohler SV730-0029

Ref.	*Part Number*	*Qty.*	*Description*
2	32 096 08-S	1	Cover-Cleaner, Air ■
4	M-545016-S	6	Screw-Flange, Thread Forming (M5X0.8X16) ■
5	M-645016-S	8	Screw-Flange, Thread Forming (M6X1.0X16) ■
6	32 146 05-S	1	Plate-Backing ■
7	32 063 12-S	1	Baffle-Barrel, Cylinder (No.2 Side) ■
8	32 063 02-S	1	Baffle-Valley (No.2 Side) ■
9	M-545010-S	2	Screw-HHFTF (M5X.80X10) ■
10	32 063 03-S	1	Baffle-Valley (No.1 Side) ■
11	32 063 10-S	1	Baffle-Barrel, Cylinder (No.1 Side) ■
12	24 086 12-S	2	Screw-TAP (M6X1.7X18) ■
14	32 027 08-S	1	Blower Housing ASM (Fixed Guard) (Includes 2, 41 037 10-S) ■
15	41 403 10-S	1	Rectifier/Regulator ■
16	25 086 158-S	2	Screw-Flanged, Thread Forming (M6X1.0X11) ■
	41 037 10-S	1	Nameplate-Service ■ ●

● Not illustrated

■ Obtain parts from www.kohlerplus.com



Starter Assembly
Kohler SV730-0029

Ref.	*Part Number*	*Qty.*	*Description*
2	32 098 01-S	1	Starter ASM ●
2:1	12 755 39-S	1	Drive Kit ●
2:2	12 755 38-S	1	Drive Part Kit ●
2:3	32 141 01-S	1	Ring-Retaining ●
2:4	12 100 07-S	1	Nut-Flange, Hex (1/4-20) ●
2:5	12 243 04-S	1	Commutator-Cap, End ●
2:6	32 211 01-S	2	Bolt-Thru ●
2:7	32 227 01-S	1	Cap-End, Drive ●
4	M-851080-S	2	Screw-Flange (M8X1.25X80) ●

● Obtain parts from www.kohlerplus.com



Fuel System Assembly
Kohler SV730-0029

Ref.	*Part Number*	*Qty.*	*Description*
1	32 853 12-S	1	Carburetor Kit (22Mm Keihin) (Includes 2, 3) ■
2	24 041 52-S	1	Gasket-Carburetor ■
3	24 041 14-S	1	Gasket-Base, Air Cleaner ■
4	M-629105-S	2	Stud (M6X1.0X106) ■
5	M-641060-S	2	Nut-Flange (M6X1.0) ■
6	25 237 14-S	4	Clamp-Hose, Spring (1/2) ■
7	25 111 34-S	2	Line-Fuel (24.0 Cut To Length) ■
9	32 326 02-S	1	Fuel Pump Hose Kit (W/Clamp) (Includes 10) ■
10	25 237 01-S	1	Clamp-Hose ■
11	24 086 12-S	2	Screw-TAP (M6X1.7X18) ■
12	24 393 16-S	1	Pump-Fuel ■
13	25 050 22-S	1	Filter-Fuel ■
14	47 154 01-S	1	Clip-Cable ■
	24 757 36-S	1	Choke Repair/Service Kit (Includes 2, 3) ■ ●
	24 757 38-S	1	Gasket Repair/Service Kit (Includes 2, 3) ■ ●
	24 757 44-S	1	Float Repair Kit (Includes 2, 3) ■ ●
	24 757 45-S	1	Solenoid Valve Repair Kit (Includes 2, 3) ■ ●
	24 757 46-S	1	Overhaul Kit W/Gaskets (Includes 2, 3) ■ ●

● Not illustrated

■ Obtain parts from www.kohlerplus.com



Engine Control Assembly
Kohler SV730-0029

Ref.	Part Number	Qty.	Description
1	24 211 03-S	1	Bolt-Sq Neck, Rd HD (M6X1.0X25) ●
3	M-641060-S	1	Nut-Flange (M6X1.0) ●
4	24 089 01-S	1	Spring-Linkage ●
5	25 158 08-S	1	Bushing-Linkage, Throttle ●
6	24 079 04-S	1	Linkage-Throttle ●
7	25 158 11-S	1	Bushing-Retaining, Linkage ●
8	M-545016-S	1	Screw-Flange, Thread Forming (M5X0.8X16) ●
9	M-547050-S	1	Nut-Lock (M5X.8) ●
10	24 089 03-S	1	Spring-Return, Choke ●
12	M-645016-S	4	Screw-Flange, Thread Forming (M6X1.0X16) ●
14	12 237 01-S	1	Clamp-Cable ●
15	24 086 43-S	1	Screw-Lbd, Thd Frm (M5X0.8X16) ●

Ref.	Part Number	Qty.	Description
16	24 079 22-S	1	Linkage-Choke ●
17	24 112 27-S	2	Control Spacer ASM ●
20	24 468 01-S	1	Washer-Flat (5.5Mm) ●
22	41 468 03-S	1	Washer-Spring (1/4) ●
30	24 089 55-S	1	Spring-Governor ●
31	24 089 25-S	1	Spring-Governor ●
35	24 090 51-S	1	Lever-Governor ●
36	24 126 172-S	1	Bracket-Control ●
38	25 086 151-S	1	Screw-Thread Forming (M5X0.8X25Mm) ●
39	32 089 03-S	1	Spring-Control, Speed ●
40	32 090 07-S	1	Lever-Spring, Governor ●
41	32 090 08-S	1	Lever-Control, Speed ●
42	32 090 09-S	1	Lever-Setting, Speed ●
43	32 090 10-S	1	Lever-Choke ●

● Obtain parts from www.kohlerplus.com



Air Intake and Filtration Assembly
Kohler SV730-0029

Ref.	*Part Number*	*Qty.*	*Description*
1	24 164 91-S	1	Intake Manifold ASM (Includes 2-4) ●
2	24 041 52-S	1	Gasket-Carburetor ●
3	24 153 27-S	2	O-Ring (Intake Port) ●
4	25 139 60-S	1	Plug-Pipe, Countersunk (1/8) ●
5	32 094 04-S	1	Air Cleaner Base Kit (Includes 6, 7) ●
6	24 041 14-S	1	Gasket-Base, Air Cleaner ●
7	32 344 02-S	1	Latch-Element, Air Cleaner ●
8	32 083 03-S	1	Element-Filter, Air ●
9	M-651040-S	4	Screw-Flange (M6X1.0X40) ●

● Obtain parts from www.kohlerplus.com



Gaskets
Kohler SV730-0029

Ref.	*Part Number*	*Qty.*	*Description*
6	24 041 49-S	2	Gasket-Exhaust ■
	32 755 01-S	1	Overhaul Gasket Kit ■ ●

● Not illustrated

■ Obtain parts from www.kohlerplus.com







Artwork is representative
Actual labels may differ depending on model and specification number

Decals
Kohler SV730-0029

Ref.	*Part Number*	*Qty.*	*Description*
1	25 113 39-S	1	Decal-Laminate, Clear ●
4	32 113 60-S	1	Decal-Check, Fill ●
6	32 113 08-S	1	Decal-25 Hp ●

● Obtain parts from www.kohlerplus.com

Attachments and Accessories

For 74375 TimeCutter Z5060 Riding Mower

Product Name	Model/Part
Hour Meter Kit	112-9763
Deck Ring Kit	114-1608
Striping Kit	114-8545
Replacement Blade Kit (3 Blades)	79221
50 Inch Recycler Kit	79312
Engine Cover Kit	79314
Floor Mat Kit	79315
Storage Cover	79317
Rear Hitch Kit	79318
Sunshade	79319
42 Inch and 50 Inch Twin Bagger	79324
10 cu. ft. Poly Dump Cart	79991

Count on it.