Form No. 3372-420 Rev A

TORO®

Count on it.

Parts Catalog

50in Bagger

TimeCutter® MX Series Riding Mower

Model No. 79337—Serial No. 312000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LPG: Liquid Propane Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Contents

50 Inch Bagger Assembly 4
Bag Assembly No. 112-3994 5
Bagger Top Assembly No. 117-5370. 6
Chute Assembly 7
Chute Assembly No. 121-5651 8

© 2012—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved



50 Inch Bagger Assembly

Ref.	Part Number	Qty.	Description
1	104-8300	8	Nut-Flange, NI
2	104-8301	4	Nut-Flange, NI
4	109-7076	1	Decal-Maximum Drawbar Pull
5	112-3987	2	Bracket-Pivot, Hopper
6	112-3993	1	Screen-Bagger
7	112-3994	2	Bag ASM
8	117-5355-03	1	Plate
9	117-5370	1	Bagger Top ASM
10	112-3995	1	Tube-Bagger
11	119-8850-03	1	Support-Bagger
12	119-8852-03	1	Bracket-Stabilizer
13	119-8853	2	Rod-Support
14	120-5495-03	1	Plate
15	109-9742-03	1	Weight-35 Pound

Ref.	Part Number	Qty.	Description
16	120-2292-03	1	Frame-Pivot
18	32144-70	2	Screw-HWHTF
19	3256-24	4	Washer-Flat
20	3234-42	2	Screw-HHF
21	3230-1	2	Bolt-CARR
22	3230-2	4	Bolt-CARR
23	3234-29	2	Screw-HHF
24	3256-26	2	Washer-Flat
25	3290-355	3	Pin-Hair
26	92-2739	1	Pin-Clevis
27	120-5491-03	1	Channel-Bagger Weight
28	120-5502-03	1	Bracket-Bagger Weight, RH
29	119-4061	4	Screw-HHF
30	120-5497-03	1	Bracket-Bagger Weight
31	109-9759	1	Pin-Weight



Bag Assembly No. 112-3994

Ref.	*Part Number*	*Qty.*	*Description*
1	114972-03	1	Frame-Bag
2	112-4012-03	1	Hanger ASM
3	114974-03	1	Clamp
4	3230-1	2	Bolt-CARR
5	3296-29	2	Nut-Lock, NI
6	110-6674	1	Bag



Bagger Top Assembly No. 117-5370

Ref.	*Part Number*	*Qty.*	*Description*
2	116-1242-03	1	Stiffener-Bagger Top
3	112-4001	1	Gasket
4	112-4000-03	1	Ring-Retainer
5	114439	12	Rivet-Pop
6	9202704	4	Washer
7	109-6809	1	Decal-Caution Bagger



Chute Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	121-5651	1	Chute ASM
2	112-6950	1	Screw-CARR
3	104-8300	1	Nut-Flange, NI
4	3256-23	1	Washer-Flat
5	19-4050	1	Knob



Chute Assembly No. 121-5651

Ref.	*Part Number*	*Qty.*	*Description*
2	3274-69	2	Screw-HSBH
3	112-4038	1	Plate-Pivot
4	40-8350	1	Screw
5	121-0760	1	Latch
6	3296-42	3	Nut-Lock, NI
7	117344	1	Handle ASM
8	3269-31	2	Rivet-Pop
9	82-5690	1	Retainer-Duct
10	3256-3	1	Washer-Flat
11	322-5	1	Screw-HH
12	114-9015	1	Nut-Impeller
13	110-6691	1	Decal-Danger

Notes:

Notes:

Notes:

Count on it.