Form Number 3353-609 Rev A

Trench Filler
Compact Utility Loader

Model No. 22472 - 260000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

© The Toro Company - 2006
All Rights Reserved


Register your product at www.Toro.com



Trench Filler Assembly

Ref	Part No.	Qty.	Description
1	112-2604	1	Frame ASM
1:2	100-4708	1	Decal-Warning
1:3	93-7321	2	Decal-Danger
2	108-5595	1	Hydraulic Motor ASM
3	3274-89	2	Screw-HSH
4	340-6	2	Fitting-HYD, Straight
4:1	237-30	1	O-Ring
4:2	237-80	1	O-Ring
5	106-7702	2	Hose ASM
5:6	237-79	1	O-Ring
6	100-4617	2	Adapter-HYD
6:1	237-80	1	O-Ring
7	104-6134	1	Coupler-Face, Flush
7:1	105-8396	1	Seal Kit (Not Illustrated)
8	100-4701	1	Nipple-Connect, Pressure
8:1	100-6120	1	Seal Kit (Not Illustrated)
9	108-5586-03	1	Filler Shaft ASM
10	3245-41	1	Screw-HSH
11	99-0160	1	Bearing
11:1	251-249	1	Collar W/Set Screws
11:2	3245-35	1	Screw-Set
11:3	302-2	1	Fitting-Grease
12	324-5	2	Screw-HH
13	107-9393-01	2	Skid Plate ASM

Ref	Part No.	Qty.	Description
14	3234-6	4	Screw-HHF
15	112-2619	1	Qtach ASM
15:2	100-4652	2	Decal-Warning
16	110-0237	4	Roller-Float
17	3256-24	8	Washer-Flat
20	107-9378	1	Decal-Center Trench
21	62-7400	1	Decal
22	98-3269	1	Decal
23	110-0245	4	Spacer-Float
24	110-0179	4	Spacer-Wheel
25	323-25	4	Screw-HH
26	3296-39	20	Nut-Lock, NI
27	110-0175-01	4	Bracket-Cap, Float
28	110-0174-01	2	Bracket-Guide, Float
29	323-6	16	Screw-HH



Hydraulic Motor Assembly No. 108-5595

Ref	Part No.	Qty.	Description
1	94-8178	1	Seal Kit
1:1		1	Seal-Dirt And Water (Not Serviced Separately)
1:2		1	Washer-Backup (Not Serviced Separately)
1:3		5	Seal-Ring (Not Serviced Separately)
1:4		1	Washer-Backup (Not Serviced Separately)
1:5		1	Seal-Inner (Not Serviced Separately)
1:6		1	Seal-Commutator (Not Serviced Separately)
2	95-6137	1	Coupling Shaft
3	76-0850	1	Bearing-Thrust
6	95-6136	1	Housing ASM
6:1		1	Housing (Not Serviced Separately)
6:2		1	Bearing (Not Serviced Separately)
6:3		2	Washer-Thrust (Not Serviced Separately)
6:4		1	Bearing-Thrust (Not Serviced Separately)
7	11-5790	1	Key-Square
8	76-0940	1	End Cover ASM


TORO®