



# 20 Gallon Auxiliary Tank Kit

## 36in SprayMaster

Model No. 146-0604

### Installation Instructions

# Installation

## Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	Receptacle boot	1	Prepare the machine.
2	Right tank mount Left tank mount Front tank support Bolt (5/16-18 x 1 inch) Locknut (5/16-18) Bolt (3/8-16 x 1/4 inch) Tank assembly Bolt (3/8-16 x 3/4 inch) Locknut (3/8-16) Spring washer	1 1 1 4 4 2 1 6 2 6	Install the tank.
3	90 degree elbow fitting (discard 1 if the machine has 7 gallon tank installed) Nipple fitting Cross fitting (discard if the machine has 7 gallon tank installed) Hose clamp (discard 1 if the machine has 7 gallon tank installed) 90 degree side fitting Plug fitting (discard if the machine has 7 gallon tank installed) Valve	2 1 1 2 1 1 1	Connect the aux return hose.
4	Straight fitting (discard 1 if the machine does not have the 7 gallon tank installed) Hose clamp (discard 2 if the machine has 7 gallon tank installed) Side load valve Valve plug (discard if the machine has 7 gallon tank installed) Hose (6 inches) Tee fitting (discard if the machine has 7 gallon tank installed) Hose (2-1/2 inches) (discard if the machine has 7 gallon tank installed)	3 5 1 1 1 1 1	Connect the aux suction hose.
5	Cable tie	3	Complete the installation.



\* 3 4 5 6 - 5 2 1 \*

# 1


## Preparing the Machine

Parts needed for this procedure:

1	Receptacle boot
---	-----------------

### Procedure

1. Shut off the spreader and the sprayer; refer to the *Operator's Manual* for your machine.
2. Park the machine on a level surface.
3. Lock the caster wheels straight ahead; refer to the *Operator's Manual* for your machine.
4. Engage the parking brake; refer to the *Operator's Manual* for your machine.
5. Shut off the engine, remove the key, and wait for all moving parts to stop before leaving the operator's position.
6. Wait for the engine and hydraulic system to cool.
7. Disconnect the battery as follows:
  - A. Remove the flange nut and carriage bolt that secure the negative battery cable to the battery.
  - B. Move the cable away from the negative battery terminal.
8. Disconnect the hopper harness from the main machine harness (A of [Figure 1](#)). Install the receptacle boot onto the main harness (B of [Figure 1](#)).



**Figure 1**

9. With the hopper empty, remove and retain the prop rod and cotter pin, the rubber bumpers and mounting nuts, and the pivot bolts; remove and retain the hopper assembly.

# 2


## Installing the Tank

Parts needed for this procedure:

1	Right tank mount
1	Left tank mount
1	Front tank support
4	Bolt (5/16-18 x 1 inch)
4	Locknut (5/16-18)
2	Bolt (3/8-16 x 1/4 inch)
1	Tank assembly
6	Bolt (3/8-16 x 3/4 inch)
2	Locknut (3/8-16)
6	Spring washer

## Procedure

1. Connect the front tank support to the left and right tank mounts using 2 bolts (5/16-18 x 1 inch) and 2 locknuts (5/16-18).
2. Install the tank support brackets onto the frame of the machine using 2 bolts (5/16-18 x 1 inch), 2 locknuts (5/16-18), 2 bolts (3/8-16 x 1-1/4 inches), and 2 locknuts (3/8-16) as shown in [Figure 2](#).




g415824

Figure 2

1. Bolts (5/16-18 x 1 inch)	3. Bolt (3/8-16 x 1-1/4 inches)
2. Locknut (5/16-18)	4. Locknuts (3/8-16)

3. Install the tank assembly onto the tank support brackets and secure with 6 bolts (3/8-16 x 3/4 inch) and 6 spring washers (Figure 3).

**Note:** Apply thread-locking compound on the bolts before installing them.



**Figure 3**

1. Spring washer

2. Bolt (3/8-16 x 3/4 inch)

# 3

## Connecting the Aux Return Hose

### Parts needed for this procedure:

2	90 degree elbow fitting (discard 1 if the machine has 7 gallon tank installed)
1	Nipple fitting
1	Cross fitting (discard if the machine has 7 gallon tank installed)
2	Hose clamp (discard 1 if the machine has 7 gallon tank installed)
1	90 degree side fitting
1	Plug fitting (discard if the machine has 7 gallon tank installed)
1	Valve

## For Machines Without the 7 Gallon Aux Tank Already Installed

**Note:** When assembling fittings, use pipe sealant on all pipe threads.

1. Remove the existing hose clamp, hose, and elbow fitting connected to the spray pressure control valve (Figure 4).

**Note:** Discard the hose clamp and elbow fitting. Retain the hose.




Figure 4

g416386

1. Existing elbow fitting (remove and discard)
2. Existing hose clamp (remove and discard)
3. Existing hose (remove and retain)
4. Spray pressure control valve

---

2. Connect the 90 degree elbow fitting to the cross fitting using a nipple fitting (A of [Figure 5](#)).
3. Install the cross fitting on the spray pressure control valve port (B of [Figure 5](#)).
4. Install the 90 degree side fitting to the right side of the cross fitting and the plug to the bottom (C of [Figure 5](#)).
5. Install a 90 degree elbow to the left side of the cross fitting, connect the valve, and connect the spray hose (connected to the tank) with a hose clamp (D of [Figure 5](#)).

**Note:** Route the bottom of the spray tank hose under the left tank bracket and to the back side of the machine.

6. Connect a hose clamp on the hose that connects to the valve assembly and install the existing hose (removed in Step 1) onto the 90 degree side fitting (E of [Figure 5](#)).

Tighten the clamp to secure the hose. Connect the other end of the hose onto the top port of the valve assembly.




Figure 5

g426113

1. 90 degree elbow fitting
2. Nipple fitting
3. Cross fitting
4. Spray pressure control valve
5. 90 degree side fitting
6. Plug
7. Valve
8. Hose clamp
9. Spray hose (connected to tank)
10. Hose connecting to valve assembly (existing)


## For Machines With the 7 Gallon Aux Tank Already Installed

**Note:** If the 7 gallon auxiliary tank is already installed, discard the following items provided in this kit: plug fitting, cross fitting, 90 degree elbow fitting, and hose clamp.

**Note:** When assembling fittings, use pipe sealant on all pipe threads.

1. Remove the plug from the left side of the cross fitting (A of [Figure 6](#)).
2. Install a 90 degree elbow to the left side of the cross fitting, connect the valve, and connect the spray hose (connected to the tank) with a hose clamp (B of [Figure 6](#)).

**Note:** Route the bottom of the spray tank hose under the left tank bracket and to the back side of the machine.



g425697

**Figure 6**

1. Plug	4. Hose clamp
2. 90 degree elbow fitting	5. Spray hose (connected to tank)
3. Valve	

# 4

## Connecting the Aux Suction Hose

### Parts needed for this procedure:

3	Straight fitting (discard 1 if the machine does not have the 7 gallon tank installed)
5	Hose clamp (discard 2 if the machine has 7 gallon tank installed)
1	Side load valve
1	Valve plug (discard if the machine has 7 gallon tank installed)
1	Hose (6 inches)
1	Tee fitting (discard if the machine has 7 gallon tank installed)
1	Hose (2-1/2 inches) (discard if the machine has 7 gallon tank installed)


### For Machines Without the 7 Gallon Aux Tank Already Installed

**Note:** If the 7 gallon auxiliary tank is not already installed, discard 1 straight fitting provided in this kit.

1. Remove the existing hose clamp, hose, and 90 degree bottom fitting connected to the spray pump valve assembly ([Figure 7](#)).

**Note:** Discard the 90 degree bottom fitting. Retain the hose clamp and hose.

2. Install the tee fitting into the bottom spray pump valve assembly and connect the hose from Step 1.
3. Assemble 2 straight fittings and valve plug to the side load valve as shown in [Figure 7](#).
4. Connect the 2 hoses as shown in [Figure 7](#).



**Figure 7**


g411720

1. Spray pump valve assembly	6. Side load valve
2. 90 degree bottom fitting	7. Valve plug
3. Bottom spray tank hose	8. Hose—6 inches
4. Clamp	9. Tee fitting
5. Straight fitting	10. Hose—2-1/2 inches

### For Machines With the 7 Gallon Aux Tank Already Installed

**Note:** If the 7 gallon auxiliary tank is already installed, discard the following items provided in this kit: 2 hose clamps, valve plug, tee fitting, 2-1/2 inch hose.

1. Disconnect the 7 gallon tank hose from the tee fitting on the bottom spray pump valve assembly. Attach the 6 inch hose, from this kit, to the tee fitting and secure with a hose clamp ([Figure 8](#)).
2. Assemble 3 straight fittings to the side load valve. Connect the 3 hoses; see [Figure 8](#).



g422585

**Figure 8**

1. Spray pump valve assembly	5. Straight fitting
2. Tee fitting	6. Side load valve
3. Bottom spray tank hose	7. 7 gallon tank hose
4. Clamp	8. Hose—6 inches

# 5

## Completing the Installation

**Parts needed for this procedure:**

3	Cable tie
---	-----------

### Procedure

1. Use cable ties to secure the hoses away from the belt and other moving parts.
2. Connect the negative battery cable.
3. Add pure clean water to the tank. Turn the ignition key to the ON position, operate the spray system, and check for leaks. Repair all leaks before returning the sprayer to service.

**Note:** When using the auxiliary tank, ensure that the suction valve is ON and the return valve is ON.