



Dethatching Reel Greensmaster® 3000 Series

Model No. 04493—230000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

Contents

Description	Page	Description	Page
Dethatcher Assembly	3	Roller Assembly No. 95-5943	5
Dethatcher Shaft Assembly	4		


Accessories

Description	Model / Part No.	Description	Model / Part No.
Roller	95-5943	Scraper Kit	95-1600

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HYD	hydraulic
ASM	assembly	INC	incorporated
CARR	carriage	LH	left hand
DEG	degrees	NI	nylon insert
FH	flat head	PPH	Phillips pan head
GA	gauge	PTH	Phillips truss head
HF	hex flange	PTO	power take off
HH	hex head	RH	right hand
HHF	hex head flange	SFH	slotted fillister head
HLH	hex lag head	SHH	slotted hex head
HJ	hex jam	SQH	square head
HOC	height-of-cut	SHWH	slotted hex washer head
HS	hex socket	SPH	slotted pan head
HSBH	hex socket button head	SRH	slotted round head
HSFH	hex socket flat head	STD	standard
HSH	hex socket head	TAP	self tapping
HWH	hex washer head	TTH	Torx truss head
HWHTF	hex washer head thread forming	WH	wing head




Sheet No.:1

T-3932

Dethatcher Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	98-3587-01	1	Frame-Dethatcher	27	48-9590	4	Washer-Lock
4	93-2463	1	Roller-Lift	28	95-1642-01	1	Weight-Counter
5	93-2464	1	Spacer-Roller	29	93-2569	4	Screw-HHF
6	33115-080	1	Screw-HH	★30		1	Dethatcher Shaft ASM
★7		2	Wheel / Bearing ASM	31	93-1394	1	Nut-Spline
7:1	94-9211	1	Wheel ASM	32	94-9214	1	Nut-Spline, LH
7:2	95-7497	2	Bushing-Wheel	33	95-5943	1	Roller ASM
8	33025-00	3	Nut-Lock	34	94-9226	1	Bracket-Scraper
9	33125-025	2	Screw-CARR	35	33024-00	10	Nut-Lock
10	95-1638	2	Bracket-Rear , HOC Adjust	36	33014-00	4	Nut-Hex
11	99-8168	4	Collar-HOC	38	94-9210	1	Shaft-Wheel, Rear
12	95-1633	2	HOC Adjust ASM	39	94-9213	2	Collar-Shaft
13	3296-5	2	Nut-Lock, NI	40	94-9219	1	Scraper-Roller, RH
15	33114-025	2	Screw-HH	41	94-9220	1	Scraper-Roller, LH
16	98-3551	1	Grass Shield ASM	42	33114-030	2	Screw-HH
17	33114-020	4	Screw-HH	43	3256-24	6	Washer-Flat
18	3256-74	16	Washer-Flat	45	302-5	2	Fitting-Grease
21	98-2196	1	Rod-Shield	50	257-11	4	Washer-Thrust
22	33115-020	2	Screw-HH	51	302-5	2	Fitting-Grease
23	95-7148	2	Housing-Bearing	53	93-6688	1	Decal-Danger, Europe
24	2410-30	1	Cap-Plastic	54	36-7260	1	Bar-Of f, Cut
25	94-3405	2	Bearing-Ball	55	104-2065	5	Screw-HWH
25:1	3245-35	1	Screw-HS				
25:2	251-77	1	Lockcollar-Bearing				
26	33115-025	4	Screw-HH				

★ Not serviced separately



Sheet No.:A1


T-3933

Dethatcher Shaft Assembly

Ref. No.	Part No.	Qty.	Description
1	94-9202	1	Shaft-Dethatcher
2	106-6355	36	Blade-1 1 Tooth (Carbide)
*2	106-5422	36	Blade-1 1 Tooth (Narrow Carbide)
3	82-6600	2	Spacer
4	67-5840	2	Nut-Jam
5	17-1580	35	Spacer

Ref. No.	Part No.	Qty.	Description

* Not illustrated



Sheet No.:A2

T-3934

Roller Assembly No. 95-5943

Ref. No.	Part No.	Qty.	Description
2	302-5	2	Fitting-Grease
3	85-9970	2	Bearing-Ball
4	85-7190	2	Washer-Shield
5	32151-12	2	Ring-Retaining
6	95-5946	1	Shaft-Roller

Ref. No.	Part No.	Qty.	Description

Maintenance Record

[illegible]

Maintenance Record

[illegible]

