



Form No. 3474-921 Rev A

Count on it.

Parts Catalog

eTimeCutter™ eMR4275 Zero Turn Riding Mower

Model No. 75642—Serial No. 418178767 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Contents

Frame Assembly..... 4

Deck Lift Assembly..... 6

Caster Wheel Assembly 8

Traction Drive Assembly 10

Brake Assembly 12

Rear Tire Assembly 14

Seat Pan Assembly 16

Seat Assembly No. 147-8761 18

Motion Control Assembly 20

Battery Box Assembly 22

Battery Box Assembly No. 161-4483 24

Styling Pod Assembly 26


Electrical Assembly 28

Decal Specific Assembly..... 30

42 Inch Deck and Decal Assembly 32

Attachments and Accessories 34


Frame Assembly



Frame Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-3005-01	1	Frame ASM [red]	16	145-1978	1	Decal-Logo, Silver
2	138-7596-07	1	Footrest	18	139-2429	4	Screw-HHF
3	138-2527-01	1	Brace-Cross, Lower	19	139-2428	4	Screw-HWH
4	139-3260-01	1	Bracket-Mount Damper, Lower	20	139-2430	4	Nut-HF, NI
9	140-2098	2	Axle Stub ASM	21	139-2596	10	Screw-HHF
9:2	109-3678	2	Bearing-Ball	22	138-7516	2	Guard-Rail
10	138-7200	2	Cap-Grease	23	137-3099	4	Screw-Plastite, HWH
11	145-0415-01	1	Plate-Mount, Drive	24	140-3460	2	Bumper-Rubber
12	145-0416-01	1	Plate-Mount, Mr Drive	25	137-4803	2	Bumper-Rubber
13	147-5205-07	1	Guard-Rear	26	119-4041	12	Nut-HF
14	147-7579-01	1	Guard-Rear, Upper	27	138-9753	22	Screw
15	147-7640	1	Decal-Etimecutter	29	117-1232-03	1	Bracket-Hitch


Deck Lift Assembly



Deck Lift Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	137-7093-03	1	Deck Lift ASM	11	139-2611	7	Washer-Flat
2	138-6021	2	Bracket-Pivot, Decklift	12	139-2562	7	Pin-Hair
3	140-5063	2	Washer-Hardened, Cz	13	119-8810	1	Pin-Pivot
4	137-9844	1	LH Arm ASM	14	139-1725	1	Nut-Hex
5	137-9846	1	RH Arm ASM	16	137-7087-03	1	Lever-Lift
6	137-9847	2	Screw-Shoulder	18	1-633268	1	Grip-Lever
7	138-2564	2	Plate-Adjustment, HOC	26	139-2596	1	Screw-HHF
8	139-2350-01	1	Bracket-HOC	27	138-9753	5	Screw
9	140-2748	1	Decal-HOC	28	119-4041	1	Nut-HF
10	138-6050	1	Rod-Mount, Deck	29	119-4042	2	Nut-HF, NI

Caster Wheel Assembly




Caster Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-3274-01	2	Fork ASM	4	139-2607	2	Screw-HH
2	147-5203	2	Tire ASM	5	139-2617	2	Nut-Lock, NI
2:1	147-2936	1	Tire	6	136-5590	4	Washer
2:3	232-27	1	Stem-Valve	7	138-7208	4	Guard-Seal
2:4	136-4190	2	Bearing	8	115-1151	2	Washer-Flat
2:99	105-0844	1	Tube-Inner ●	9	139-2598	2	Screw-HHF
3	147-7593	2	Spacer-Spanner				

● Not illustrated


Traction Drive Assembly



Traction Drive Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	161-4488	1	Transaxle-Electric, 18"	4	119-4041	7	Nut-HF
2	144-5335-01	1	Bracket-Transmission	5	138-9753	3	Screw
3	147-5202	7	Screw-HH	6	139-2564	8	Nut-Lug


Brake Assembly



Brake Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-5182-03	1	Bracket-Pedal, Brake	9	119-4041	1	Nut-HF
2	147-7741	1	Bushing-Flange	10	137-7040	1	Spring-Return, Pedal
3	5-4460	1	Washer-Pivot	11	147-3048	1	Cover-Brake, Parking
4	145-0490	1	Cable-Brake	12	135-2015	1	Screw-Shoulder
5	147-5201-03	1	Bracket-Cable, Brake	13	120-7950	2	Screw-Torx
6	147-5181-03	1	Pedal-Brake	14	138-9753	3	Screw
7	142-6275	1	Screw-HHF	15	139-1271	1	Decal-Brake, Parking
8	120-5116	1	Washer-Wave	16	3290-378	1	Tie-Cable

Rear Tire Assembly




Rear Tire Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	139-5846	2	Tire ASM
1:1	126-1618	1	Tire

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1:3	232-27	1	Stem-Valve
1:99	107-2491	1	Tube-Tire ●

● Not illustrated


Seat Pan Assembly



Seat Pan Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-7739	1	Subframe ASM	27	133-9319-03	1	Bracket-Shock Mount, Upper (RH)
1:2	147-7616	1	Decal-Danger	28	147-7746	1	Shock/Spring ASM
1:3	140-0357	1	Decal-Myride	29	136-7198	2	Bolt-Shoulder
4	138-7517	2	Bracket-Mount, Swing Arm	30	138-2596	1	Rod-Prop, Seat
5	138-7548	1	Screw-HHF	31	135-0505	3	Bumper-Seat
6	138-7549	1	Tube-Spacer	32	138-9753	12	Screw
7	138-2563	1	Arm, Swing	33	138-9814	1	Pulley - Cam
8	138-2573	4	Bushing-Flange	34	138-9822	1	Lever - Adjustment
9	138-2547	2	Bolt-Shoulder	35	92-1057	1	Bolt-Shoulder
10	137-1983	1	Spring-Torsion, LH	36	139-5858	1	Spring-Compression
11	137-7018	1	Spring-Torsion, RH	37	140-3759	1	Bolt-Shoulder,HHF
12	138-7566-03	1	Plate-Adjuster	38	140-5176	1	Knob-Mr
13	138-9813	1	Rod-Adjustment	39	138-9848	1	Spring-Extension
14	138-9788	1	Bracket-Cable	40	139-1716	2	Screw-HH
15	139-2361-03	1	Bracket Lower	41	119-4041	7	Nut-HF
16	138-9812	1	Cable-Adjustment, Myride	42	119-4042	6	Nut-HF, NI
17	138-9776	2	Retainer-Spring	43	139-5800	1	Bushing - Flange
18	138-7522	2	Bracket-Seat	45	137-3083	1	Pin-Hair
19	120-7950	2	Screw-Torx	46	115-1166	1	Washer-Plain
20	147-7727-03	1	Pan-Seat [black]	47	32120-47	1	Ring-Retaining, External
21	135-2015	1	Screw-Shoulder	58	119-4036	4	Screw-HHF
22	147-8761	1	Seat ASM				
26	133-9318-03	1	Bracket-Shock Mount, Upper (LH)				

Seat Assembly No. 147-8761




Seat Assembly No. 147-8761 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	161-6183	1	Toro Back Cover
3	147-8736	1	Seat Switch Delta 6500-02 Open
4	161-6184	1	Toro Seat Cover

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
5	147-8740	1	Slide ASM-Seat
6	119-4036	4	Screw-HHF
7	82-2190	1	Switch-Bail


Motion Control Assembly



Motion Control Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	140-8322-03	1	Plate-Control Box, RH	15	117-1240	2	Washer
2	140-8342-03	1	Plate-Control Box, LH	16	119-8925	2	Washer-Belleville
3	147-7552	2	Spacer-Sensor	17	139-2556	2	Bolt-Pivot
4	147-7551	4	Bushing-Flange	18	119-4042	2	Nut-HF, NI
5	147-2903	2	Arm-Actuator	19	133-7057	1	Handle-Control, RH
6	147-3009	1	Pin-Lever Pivot, LH	19:1	121-0726	1	Grip
7	147-3010	1	Pin-Lever Pivot, RH	20	133-7055	1	Handle-Control, LH
8	119-8952	2	Washer-Spcl	20:1	121-0726	1	Grip
9	132-6853	2	Damper-Non Cavitating	21	139-2597	4	Screw-HHF
10	120-7950	2	Screw-Torx	22	138-7215	2	Stud-Damper
11	139-5803	2	Eccentric	23	137-3088	6	Nut-Hex
12	139-5811	2	Bolt-Pivot, Eccentric	24	119-1138	2	Screw-HHF,Patch
13	120-2273	2	Washer-Nylon	27	138-7539	2	Spring-Torsion
14	133-9299-05	2	Arm-Control	28	138-9753	10	Screw


Battery Box Assembly



Battery Box Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-7605	4	Isolator-1 In OD (5/16-18)	6	147-2192	1	Resistor-Regen
2	161-4468-01	1	Battery Mount ASM [red]	7	145-6922	2	Screw-HWH Thd Roll Zct+w
3	147-7672-03	2	Mount-Box, Rear	8	161-4483	1	Box-Battery, ASM
4	119-4041	8	Nut-HF	9	139-2598	4	Screw-HHF
5	138-9753	2	Screw				


Battery Box Assembly No. 161-4483



Battery Box Assembly No. 161-4483 (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
2	147-5348	1	Cover-Box, Battery	8	161-4487	1	Fan-ASM
3	147-5345	1	Filter-Air	9	161-4645	3	Magnet-Lid, Battery Box
4	147-5344	1	Housing-Filter	10	161-4646	3	Magnet-Base, Battery Box
5	161-4648	2	Hinge-Box ASM, Battery	11	147-4208	1	Decal-60V, Lithium
6	147-5342	1	Box-Battery, Outer	12	147-7621	1	Decal-Lithium
7	161-4486	16	Screw-Plastic 4Mmx14MM, Globe				


Styling Pod Assembly



Styling Pod Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	138-9810-03	1	Bracket-Pod	9	107069	1	Clip
2	138-6071-03	1	Support-Pod, LH	10	147-7576	1	Pod-Control
3	145-0501	1	Pod-LH	11	147-7577-03	1	Cover-Console
3:5	147-7620	1	Decal - Control Lever, LH	12	3258-166	1	Screw-PRH
4	147-7742	1	Pod-RH, Myride	13	145-5837	2	Screw-Plastic,Tbfb
4:4	147-7619	1	Decal - Control Lever, RH	14	147-7614	1	Decal-Panel, Control
4:5	139-2397	1	Decal-Adjustment	15	147-7629	1	Plug-Pod, LH
5	145-0502-03	1	Plate-Cover, Pod	16	147-7691	1	Plug-Sc
6	130-8451	4	Rivet-Trifold	17	147-7641	1	Decal-60V Lithium
7	138-9753	3	Screw	18	147-7666	1	Cover-Switch
8	120-7950	6	Screw-Torx	19	147-7715	1	Decal-Gt Display


Electrical Assembly



Electrical Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-7667-03	1	Mount-Controllers	24	147-5340	1	Busbar-2, Switch
2	147-7631	1	Controller-Master	25	122-2513	1	Switch-Ignition, Suns
3	147-7635	2	Controller-Traction	25:1	121-5160	1	Nut-Hex
4	147-7633	2	Controller-Deck	25:2	122-2704	1	Nut-Face, M22 (Plastic)
5	80-9330	1	Audio Alarm ASM	25:3	121-5162	1	Set-Key, Ignition
5:1	104-5107	1	Nut-Plastic, Knurled	26	147-7584	1	Harness-Wire, Power Cable
6	110-8823	1	Block-Junction	27	147-7668	1	Cover-Bottom
7	105-6849	2	Screw-Forming, Thread	28	147-7670	1	Cover-Controller
8	145-0586	6	Clip-Controller	29	117-2382	2	Plug-Plastic
9	138-5775	6	Screw-Delta Point	30	120-7950	2	Screw-Torx
10	147-5200-03	1	Mount-Holder, Fuse	31	147-7680	1	Cover-Outer
11	140-8373	2	Sensor	32	139-7488-01	1	Mount-Head Lights
12	147-7729	4	Screw-HWH	33	32144-70	2	Screw-HWHTF
13	147-7730	4	Nut-Hex NI	34	139-5825	2	ASM-Light,LED
14	110-6765	2	Switch	35	94-4496	4	Screw-PPH
15	139-6368	1	Switch-Rocker, On-None-On	36	147-7681-03	2	Cover-Sensor
16	145-0467	2	Switch-Rocker On- None- On	38	147-7719-03	1	Cover-Wire
17	140-7955	1	Port-Power, USB	39	138-9753	8	Screw
18	139-6393	1	Harness-Wire, 2 Blade	40	137-3099	5	Screw-Plastite, HWH
19	147-2198	1	Display	41	32180-078	1	Clip-Edge
20	161-6249	2	Holder-Fuse	42	3290-378	1	Tie-Cable
20:1	136-8682	4	Washer-Lock	43	145-7110	1	Adapter-Switch, Key
20:2	3256-74	8	Washer-Flat	45	119-4042	1	Nut-HF, NI
20:3	117-4059	4	Nut-Hex	46	147-8762	1	Harness-Wire, LED Lights
21	32144-4	6	Screw-HWH	47	32180-030	1	Clip-Tie
23	122-2559	2	Fuse-100 Amp	48	147-0290	1	Decal-Light, Warning


Decal Specific Assembly



Decal Specific Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
4	161-4550	1	Decal Emr4275

42 Inch Deck and Decal Assembly



42 Inch Deck and Decal Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	147-7654	1	42 In Deck And Decal ASM	14	1-603299	2	Roller-Scalp, Anti
1:2	147-7615	2	Decal-Danger, Deck	15	139-2551	2	Bolt-Shoulder
1:3	137-8127	2	Decal-No Spray	16	139-5871	2	Pin-Deck
1:4	130-0731	1	Decal-Danger	17	119-4042	4	Nut-HF, NI
5	140-8379	2	Motor-Deck	18	140-4184	1	Decal
6	136-7174	8	Screw-Thd Roll, HWH	19	147-7678-03	1	Baffle-Recycling [welded][black]
7	140-8361	2	Driver-Blade	20	139-2630	4	Bolt-CARR
8	144-1948-03	2	Blade-21.60 In, Combination	21	119-4041	6	Nut-HF
9	145-0411	2	Bolt-Blade, Sems	22	119-3389-03	2	Kicker-Flanged
10	137-2019	1	Rod-Pivot	23	32144-70	4	Screw-HWHTF
11	138-7502	1	Deflector-Discharge	27	161-6305-03	1	Deflector-42"
12	138-7268	1	Spring-Torsion				
13	121-4600	1	Nut-Hex				

Attachments and Accessories

For 75642 eTimeCutter eMR4275 Zero Turn Riding Mower

Product Name	Model/Part
Battery -LI-ION, 60V 10 AH, 540WH.....	66910
60V 2.0 AH Battery International.....	81820
60V 2.5 AH Battery CE	81825
60V 4.0 AH Battery CE	81850
60V 6.0 AH Battery CE	81860
60V 7.5 AH Battery CE	81875
Battery Charger, Six Pod 60V 12 Amp CE	66560
60V Battery Charger 2 Amp CE	81802
60v Battery Charger 5 Amp International	81805
Bagger	79841
42 Inch Bagging Enhancement Kit.....	161-4521
42 Inch Striping Kit.....	161-4523
Heavy Duty Spring Kit.....	161-4525
Rops Kit.....	79682
Slope Sensor Kit, Zero-Turn-Radius Riding Mower	79681
Deck Footlift Assist Kit	161-4527
Floormat Kit	161-4529
Arm Rest Kit.....	147-8773
Storage Cover	490-7516
Seat Cover w/Arm Rest	117-0097
Kit-Caster Wheel	161-4530
53cm 60V Snowblower Bare Tool	31853T

Notes:



Count on it.