



Cab Kit for Workman® 3000/4000 Series Vehicles

Model No. 07225 - 220000001 and up.

Model No. 07249 - 220000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.


Contents

Description	Page	Description	Page
Front and Rear Window Assembly	 3	Seat Belt Installation Assembly	 6
Frame Assembly	 4	Radiator Modification Assembly	 7

Part Description Abbreviations


Part descriptions in this catalog may include the following abbreviations.

AR.	as required	INC.	incorporated
ASM.	assembly	LH.	left hand
BBC.	blade brake clutch	NI.	nylon insert
CARR.	carriage	NPTF.	national pipe thread fine
DEG.	degrees	PFH.	phillips flat head
EXT.	external	PPH.	phillips pan head
FH.	flat head	PPHTF.	phillips pan head thread forming
GA.	gauge	PRH.	phillips round head
HF.	hex flange	PTH.	phillips truss head
HH.	hex head	PTO.	power-take-off
HHF.	hex head flange	RH.	right hand
HHFTF.	hex head flange thread forming	ROPS.	roll-over-protection-system
HJ.	hex jam	SFH.	slotted fillister head
HLH.	hex lag head	SHH.	slotted hex head
HOC.	height-of-cut	SHWH.	slotted hex washer head
HSBH.	hex socket button head	SPH.	slotted pan head
HSFH.	hex socket flat head	SQH.	square head
HS.	hex socket head	SRH.	slotted round head
HWH.	hex washer head	STD.	standard
HWHTF.	hex washer head thread forming	TAP.	self tapping
HYD.	hydraulic	TTH.	torx truss head




Front and Rear Window Assembly

Ref	Part No.	Qty.	Description				
1	95-7301	1	Glass-Front				
2	95-7336	2	Hinge				
3	95-7337	2	Opener-Window				
4	33114-045	2	Screw-HH				
5	3256-23	2	Washer-Flat				
6	48-9510	2	Nut				
7	95-7344	1	Switch-Wiper				
8	100-9400-06	1	Panel-Cover, Upper (Only On: 07225)				
8	95-7345-01	1	Panel-Cover, Upper (Only On: 07249)				
9	95-7372	1	Harness-Wire				
10	95-7338	2	Seal				
11	95-7339	1	Motor-Wiper				
12	95-7340	1	Arm-Wiper				
13	95-7341	1	Blade-Wiper				
14	95-7303	1	Glass-Rear				
15	95-7342	4	Glass Fixation Kit				
16	99-1098	1	Mirror-Rear View (Only On: 07225)				
17	99-1101	1	Connector-Wiper				
18	100-9379	1	Lens-Wiper				




Frame Assembly

Ref	Part No.	Qty.	Description	Ref	Part No.	Qty.	Description
1	100-9388	1	RH Side Panel ASM (Only On: 07225)	12	3290-382	2	Rivet-Pop
1	100-9386	1	RH Side Panel ASM (Only On: 07249)	13	95-7304	2	Nut-Special, Spring Clip
1:2	67-1300	1	Decal	14	95-7343	2	Nut-Special, Barrel
1:3	94-5275	1	Decal (G. V. W.)	15	95-7324	2	Mirror (Only On: 07249)
1:4	94-5276	1	Decal-Rollover	16	95-7325	1	Support-RH (Only On: 07249)
1:5	87-5980	1	Decal-ROPS	17	95-7326	1	Support-LH (Only On: 07249)
1:6	87-5930	1	Decal-Caution, Fuel	18	95-7327	2	Cover (Only On: 07249)
2	100-9387	1	LH Side Panel ASM (Only On: 07249)	19	95-7328	2	Seal
2	100-9389	1	LH Side Panel ASM (Only On: 07225)	20	95-7373	2	Seal-Lower, Cab
2:2	67-1300	1	Decal	21	33116-035	6	Screw-HH
2:3	87-5980	1	Decal-ROPS	22	33116-090	4	Screw-HH
3	95-7315-06	1	Roof	23	3256-26	12	Washer-Flat
4	95-7316-03	1	Bar-Front	24	48-9540	6	Nut-Lock, Hex NI
5	95-7317-03	1	Bar-Front	25	33115-060	8	Screw-HH
6	100-9391	1	Front Dash ASM	26	3256-4	28	Washer-Flat
6:2	94-5274	1	Decal-Danger	27	48-9520	14	Nut
7	95-7319-03	1	Molding-RH	28	33114-020	4	Screw-HH
8	95-7320-03	1	Molding-LH	29	33114-035	6	Screw-HH
9	95-7321	2	Striker	30	33114-045	8	Screw-HH
10	95-7322	2	Visor-Sun (Only On: 07249)	31	43-3220	2	Capscrew-HH
11	95-7323	2	Hook-Coat	32	95-7370	4	Washer-Seal
				33	95-7371	4	Washer-Seal
				34	3256-23	32	Washer-Flat
				35	48-9510	16	Nut



Frame Assembly (continued)

Ref	Part No.	Qty.	Description				
36	33113-016	10	Screw-HH				
37	3256-16	20	Washer-Flat				
38	49-7810	10	Nut-Lock				
39	95-7329	4	Plug				
40	95-7330	1	Holder-Cup				
41	95-7331	1	Seal				
42	100-9390	1	Rear Panel ASM				
42:2	87-7930	1	Decal-Warning				
43	95-7333-03	1	Bracket				
44	95-7334-06	1	Bail-RH (Only On: 07225)				
44	95-7334-01	1	Bail-RH (Only On: 07249)				
45	95-7335-01	1	Bail-LH (Only On: 07249)				
45	95-7335-06	1	Bail-LH (Only On: 07225)				
53	95-7374	1	Seal-Rear, Lower				
55	105-1703-03	1	Mount-Seat, LH				
56	105-1704-03	1	Strap-Seat Pad, RH				



NOTE: Passenger seat assembly is shown.

Seat Belt Installation Assembly

Ref	Part No.	Qty.	Description				
1	110-0413	2	Seatbelt-Retractable				
2	3212-4	4	Screw-HH				
3	3296-38	4	Nut-Lock, NI				
4	87-7280-03	2	Bracket-Belt, Seat				
5	322-10	4	Screw-HH				
6	3256-3	8	Washer-Flat				
7	3296-29	4	Nut-Lock, NI				
8	52-2480	4	Spacer-Wheel				

7

