Form No. 3358-862 Rev B

TORO®

Count on it.

Parts Catalog

Finish Grader

Sand/Infield Pro® 3040 and 5040 Traction Unit

Model No. 08754—Serial No. 280000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

3358-862 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping


TTH: torx truss head

Contents

Adapter Assembly 4
Link Assembly No. 110-8105 5
Box Assembly 6
Attachments and Accessories 7


© 2014—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved




Adapter Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	112-1432	1	Adapter ASM
1:2	106-5517	1	Decal-Warning, Hot Surface
2	3272-11	1	Pin-Cotter
3	3256-26	2	Washer-Flat
4	3296-44	2	Nut-Lock, NI
5	283-83	1	Pin-Clevis
6	112-7686	1	Latch
7	323-10	1	Screw-HH
8	99-2058	1	Spacer-Support, Handle
9	110-8105	1	Link ASM
10	323-12	1	Screw-HH
11	112-7695-03	1	Handle
12	99-7984	1	Knob-Soft Grip, Push-On
13	3296-25	1	Nut-Lock, NI
14	92-2651	1	Washer
15	112-0038	1	Spacer
18	114-4320	1	Rod-Handle
19	114-4384	1	Decal-Regulatory



Link Assembly No. 110-8105

Ref.	*Part Number*	*Qty.*	*Description*
1	110-8111-01	1	Yoke ASM
2	110-8110	1	Spacer
3	110-8114	1	Washer
4	66-7230	1	Spring-Compression
5	3256-3	3	Washer-Flat
6	3211-12	1	Screw-HH
7	3220-3	2	Nut-HJ
8	92-7008	2	End-Rod, Female
9	110-8108	1	Rod-Link
10	32128-12	1	Nut-Lock, Flange



Box Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	108-2928-01	1	Box ASM
2	3230-2	4	Bolt-CARR
3	3290-355	2	Pin-Hair
4	104-8300	4	Nut-Flange, NI
5	110-1376	2	Pivot Pin ASM
6	323-13	15	Screw-HH
7	110-0259-03	15	Tine-Scarifier
8	104-8301	27	Nut-Flange, NI
9	283-60	2	Pin-Clevis
10	3231-25	4	Bolt-CARR
11	23-2790-01	1	Blade-Scraper
12	110-1395-03	1	Tool Bar ASM
14	23-2770	2	Rod-Actuating
15	23-2740	2	Pin-Actuating
16	108-2288-01	2	Support-Spring
17	20-9420-01	2	Comp Spring
18	112-1400	2	Pivot ASM
18:2	95-3577	2	Bushing
19	3256-7	2	Washer-Flat
20	3296-53	2	Nut-Lock, NI
21	62-7400	1	Decal
22	323-6	8	Screw-HH
23	3256-24	12	Washer-Flat

Attachments and Accessories

For 08754 Finish Grader Sand/Infield Pro 3040 and 5040 Traction Unit

Product Name	Model/Part
Weeder Tine	110-0260-03
Carbide Tine Pack	119-2152
Drag Mat Kit (may require Weight Kit when installing 08850 on some models, refer to installation instructions)	08850
Weight Kit (may be needed when installing 08850 on some models, refer to installation instructions)	100-6442



Count on it.