



Count on it.

Parts Catalog

Commercial Walk-Behind Mower
Fixed Deck, T-Bar, Gear Drive with 48in
TURBO FORCE® Cutting Unit

Model No. 39678—Serial No. 315000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HP: high pressure

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: low pressure

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head


STD: standard

TAP: self tapping

TTH: torx truss head

Contents

| | |
|--|----|
| Engine and Exhaust Assembly..... | 4 |
| Fuel System Assembly | 5 |
| Frame and Transmission Assembly | 6 |
| Drive Wheel and Brake Assembly | 7 |
| Handle and Control Assembly | 9 |
| Wire Harness Assembly | 10 |
| Deck Assembly | 11 |
| Deck Decal Assembly No. 110-4909..... | 12 |
| Deflector Assembly No. 110-0758..... | 13 |
| Sheave, Spindle and Blade Assembly | 14 |
| Idler Assembly | 15 |
| Caster Assembly | 16 |
| Attachments and Accessories | 17 |




Engine and Exhaust Assembly

| Ref. | Part Number | Qty. | Description | Ref. | Part Number | Qty. | Description |
|------|-------------|------|---------------------------------|------|-------------|------|----------------------|
| 1 | | 1 | Engine-Kawasaki, Fs481V-As06 ●■ | 19 | 1-373034 | 1 | Washer |
| 2 | 116-3734 | 1 | Muffler-Horizontal, Offset | 20 | 1-603610 | 2 | Washer-Spring |
| 3 | 1-653313 | 2 | Gasket-Exhaust | 21 | 116-3702 | 1 | Screw-HH |
| 4 | 114-3550 | 4 | Washer-Lock, Spring | 23 | 103-1966 | 1 | Adapter |
| 5 | 114-3549 | 4 | Nut | 24 | 120-4321 | 1 | Valve-Drain, Oil |
| 6 | 1-303287 | 1 | Tie-Cable | 27 | 126-1400 | 1 | Decal-Warning, Sulky |
| 7 | 103-1796 | 1 | Cable-Choke | 28 | 3256-5 | 2 | Washer-Flat |
| 8 | 321-3 | 2 | Screw-HH | 29 | 130-8362 | 1 | Pulley-Idler, Flat |
| 9 | 103-1797-01 | 1 | Bracket-Cable, Choke | 30 | 3256-24 | 1 | Washer-Flat |
| 10 | 32128-33 | 2 | Nut-HF | 31 | 3296-39 | 1 | Nut-Lock, NI |
| 11 | 98-5975 | 12 | Washer-Belleville | 32 | 32128-21 | 1 | Nut-HF |
| 12 | 323-7 | 4 | Screw-HH | 33 | 3231-6 | 1 | Screw-CARR |
| 13 | 323-8 | 8 | Screw-HH | 34 | 110-4886 | 1 | Belt-V |
| 14 | 3290-357 | 9 | Nut-HHF, Whiz | 35 | 81-1690 | 1 | Clamp-Cable |
| 15 | 1-633453 | 1 | Spacer-Clutch | 36 | 323-14 | 1 | Screw-HH |
| 16 | 103-1666 | 1 | Sheave-Transmission | 37 | 116-6278-03 | 1 | Guard-Muffler |
| 17 | 110-4891 | 1 | Pulley | 38 | 323-6 | 4 | Screw-HH |
| 18 | 103-4177 | 1 | Key | 39 | 104-8301 | 4 | Nut-Flange, NI |
| | | | | 99 | 103-1964 | 1 | Hose-Drain, Oil |


● Not serviced separately

■ Obtain parts from www.kawpowerpc.com




Fuel System Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|------------------------|-------------|--------------------|-------------|--------------------------|
| 1 | 126-1526 | 1 | Fuel Tank ASM | 16 | 3229-1 | 2 | Bolt-CARR |
| 1:2 | 114-0284 | 1 | Grommet | 17 | 104-7201 | 4 | Nut-HF |
| 1:3 | 119-3547 | 1 | Valve-Vent, Fuel | 18 | 115-4486-01 | 1 | Bracket-Canister, Carbon |
| 1:4 | 103-2605 | 1 | Fitting-Fuel, Bulkhead | 19 | 114-0292 | 1 | Bracket-Canister, Carbon |
| 1:5 | 120-5461 | 1 | Cap-Fuel, Ratcheting | 20 | 321-2 | 2 | Screw-HH |
| 2 | 109-0650 | 1 | Hose-Fuel | 21 | 117-1221 | 1 | Canister-Carbon, 800Cc |
| 3 | 1-603770 | 1 | Valve-Fuel | 22 | 115-0962 | 1 | Hose-Vent, Canister |
| 4 | 2412-98 | 4 | Clamp-Hose | 23 | 114-0286 | 1 | Hose-Vent |
| 5 | 322-10 | 2 | Screw-HH | 24 | 116-2231 | 1 | Hose-Vent, Formed |
| 6 | 3256-3 | 2 | Washer-Flat | 25 | 116-2232 | 1 | Valve-Control, Vacuum |
| 7 | 107-4543 | 2 | Clamp | 26 | 119-8501 | 1 | Hose-Vent, Formed |
| 8 | 104-8300 | 2 | Nut-Flange, NI | 27 | 119-8502 | 1 | Hose-Vent, Formed |
| 9 | 99-9415 | 1 | Hose-Fuel | 28 | 116-2469 | 1 | Strap-Velcro, Cable Tie |
| 10 | 3290-378 | 3 | Tie-Cable | | | | |



Frame and Transmission Assembly


| Ref. | Part Number | Qty. | Description | Ref. | Part Number | Qty. | Description |
|------|-------------|------|---------------------|------|-------------|------|----------------------|
| 1 | 116-6084-01 | 1 | Frame-Gear | 27 | 3230-1 | 2 | Bolt-CARR |
| 2 | 1-323252 | 2 | Bearing-Shaft | 28 | 1-323387-03 | 1 | Plate-Shift |
| 3 | 1-323254 | 2 | Flange-Output | 29 | 98-3264 | 1 | Decal-Speed, Ground |
| 4 | 3246-18 | 2 | Setscrew | 30 | 1-303020 | 1 | Grip-Lever |
| 5 | 103-6511 | 2 | Sheave-Transmission | 31 | 98-3274-03 | 1 | Lever-Shift |
| 6 | 321-3 | 4 | Screw-HH | 32 | 98-5975 | 1 | Washer-Belleville |
| 7 | 3296-42 | 4 | Nut-Lock, NI | 33 | 3296-6 | 1 | Nut-Lock |
| 12 | 1-303287 | 1 | Tie-Cable | 35 | 1-323379 | 1 | Washer |
| 13 | 322-3 | 4 | Screw-HH | 36 | 104-8300 | 2 | Nut-Flange, NI |
| 14 | 1-805005 | 4 | Washer-Lock | 37 | 32144-11 | 4 | Screw-HWHTF |
| 17 | 32151-62 | 2 | Ring-Retaining | 38 | 1-603403 | 1 | Bolt-Shoulder |
| 18 | 3257-5 | 3 | Key-Woodruff | 39 | 1-323389-03 | 2 | Bracket-Plate, Shift |
| 19 | 1-323502 | 2 | Shaft-Transmission | 40 | 1-806003 | 2 | Pin-Cotter, Hair |
| 20 | 51-4220 | 2 | Guard-Coupler | 41 | 1-303186 | 1 | Bellcrank |
| 21 | 1-323680 | 2 | Coupler | 42 | 3290-357 | 1 | Nut-HHF, Whiz |
| 22 | 1-323630 | 1 | V-Belt | 43 | 1-303105 | 1 | Yoke-Adjustable |
| 23 | 3245-41 | 2 | Screw-HSH | 45 | 1-543296 | 1 | Grommet |
| 24 | 1-323278 | 1 | Sheave-Transmission | 46 | 1-808280 | 1 | Pin-Clevis |
| 25 | 302-19 | 2 | Fitting-Grease | 48 | 1-323303 | 1 | Arm-Assist, Linkage |
| 26 | 1-323500 | 1 | Transmission | | | | |



Drive Wheel and Brake Assembly

| Ref. | Part Number | Qty. | Description | Ref. | Part Number | Qty. | Description |
|------|-------------|------|---------------------|--------|-------------|------|--------------------------|
| 1 | 98-3273 | 2 | Spring-Extension | 21 | 1-323307 | 4 | Pin-Clevis |
| 2 | 323-10 | 2 | Screw-HH | 22 | 1-322209-03 | 2 | Arm-Brake |
| 3 | 32151-47 | 2 | Ring-Retaining | 23 | 32120-47 | 2 | Ring-Retaining, External |
| 4 | 1-806003 | 4 | Pin-Cotter, Hair | 24 | 1-803051 | 4 | Nut-Push |
| 5 | 3256-23 | 4 | Washer-Flat | 25 | 1-323595 | 2 | Band-Brake |
| 6 | 110-4925-03 | 1 | Arm-Idler, RH | 26 | 1-322212-03 | 1 | Axle |
| 7 | 110-4926-03 | 1 | Arm-Idler, LH | 27 | 1-543436 | 2 | Washer-Spacer |
| 8 | 74-0521 | 2 | Fitting-Rod | 30 | 130-8363 | 2 | Wheel And Tire ASM |
| 9 | 283-6 | 2 | Pin-Clevis | 30:1 | 130-8367 | 1 | Tire |
| 10 | 1-323296 | 2 | Rod-Brake | 30:2 | 130-4565 | 1 | Wheel And Hub ASM |
| 11 | 110-5866 | 2 | Swivel-Brake | 30:2:1 | 1-323329 | 2 | Bearing-Flanged |
| 12 | 1-513959 | 2 | Wingnut-Nylock | 30:2:2 | | 1 | Rim ASM ● |
| 13 | 3290-357 | 10 | Nut-HHF, Whiz | 30:2:3 | | 1 | Fitting-Grease ● |
| 14 | 323-16 | 4 | Screw-HH | 30:2:4 | | 1 | Stem-Valve ● |
| 16 | 98-5131-01 | 2 | Shield-Wheel, Drive | 31 | 109-4359 | 2 | Drum And Sheave ASM |
| 17 | 1-323694 | 4 | Spacer-Shield | 34 | 1-808519 | 2 | Ring-Snap |
| 18 | 1-323634 | 2 | Idler-Drive, Wheel | 36 | 322-5 | 8 | Screw-HH |
| 19 | 302-19 | 2 | Fitting-Grease | 37 | 1-523157 | 6 | Washer-Spacer |


● Not serviced separately



Drive Wheel and Brake Assembly (continued)


| Ref. | Part Number | Qty. | Description | Ref. | Part Number | Qty. | Description |
|------|-------------|------|-----------------|------|-------------|------|--------------------|
| 38 | 1-323631 | 2 | V-Belt | 43 | 98-5975 | 4 | Washer-Belleville |
| 39 | 3296-29 | 2 | Nut-Lock, NI | 44 | 323-6 | 4 | Screw-HH |
| 40 | 2412-104 | 2 | Clamp-R | 46 | 1-805005 | 8 | Washer-Lock |
| 41 | 98-3259 | 1 | Shield-Trailing | 47 | 1-323245 | 2 | Spring-Compression |
| 42 | 322-3 | 2 | Screw-HH | | | | |

● Not serviced separately




Handle and Control Assembly

| Ref. | Part Number | Qty. | Description | Ref. | Part Number | Qty. | Description |
|------|-------------|------|----------------------|------|-------------|------|-------------------------|
| 1 | 98-3282 | 2 | Rod-Control | 21 | 1-303335 | 2 | Tie-Plastic |
| 2 | 95-5522-03 | 1 | Bar-Control | 22 | 1-303160 | 1 | Spring-Compression |
| 3 | 3296-2 | 5 | Nut-Lock, NI | 23 | 3256-24 | 2 | Washer-Flat |
| 4 | 93-7298 | 1 | Decal-Bar, Control | 24 | 104-8301 | 1 | Nut-Flange, NI |
| 5 | 32105-1 | 1 | Screw-SHH | 26 | 98-3279 | 1 | Linkage-Drive, Blade |
| 6 | 82-7680-03 | 1 | Bail | 27 | 98-3287-03 | 1 | Lever-Engagement, Blade |
| 7 | 93-7299 | 1 | Decal-Reverse | 28 | 3234-11 | 4 | Screw-HHF |
| 8 | 3272-11 | 2 | Pin-Cotter | 30 | 110-6905 | 1 | Control Panel ASM |
| 9 | 106-5477-03 | 1 | Pivot-Control | 30:2 | 130-8374 | 1 | Decal-Panel, Control |
| 11 | 98-3261-03 | 1 | Lever-Brake, Parking | 30:3 | 106-5519 | 1 | Decal-Danger |
| 12 | 93-7442 | 1 | Decal-Lever, Parking | 32 | 32105-14 | 4 | Screw-SHH |
| 14 | 1-806003 | 3 | Pin-Cotter, Hair | 33 | 32128-21 | 4 | Nut-HF |
| 15 | 237-141 | 2 | Grommet-Rubber | 34 | 99-8509 | 1 | Spacer |
| 16 | 98-3267-03 | 1 | Handle-Upper | 35 | 1-303020 | 1 | Grip-Lever |
| 17 | 283-55 | 2 | Pin-Clevis | 36 | 323-10 | 1 | Screw-HH |
| 18 | 119-6539 | 1 | Cable-Throttle | 37 | 98-4387 | 1 | Decal-Protection, Ear |
| 20 | 95-5537 | 1 | Decal-Engage, Deck | 38 | 117-2718 | 1 | Decal-Arrester, Spark |



Wire Harness Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|-------------------------|
| 1 | 33114-016 | 1 | Screw-HH |
| 2 | 3253-4 | 1 | Washer-Lock |
| 3 | 1-633181 | 1 | Plate-Tapped |
| 4 | 1-513152 | 1 | Switch-Closed, Normally |
| 5 | 3290-500 | 2 | Screw-PPH |
| 6 | 29-5560 | 1 | Switch-On / Off |
| 6:1 | 218-461 | 1 | Nut-HH |
| 6:2 | 3254-5 | 1 | Washer-Tooth, Internal |
| 7 | 63-8360 | 1 | Key-Ignition |
| 8 | 740275 | 1 | Switch |
| 9 | 119-6535 | 1 | Harness-Wire |



Deck Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1 | 110-4909 | 1 | Deck ASM |
| 2 | 121-1775-03 | 1 | Baffle |
| 3 | 110-0744-01 | 1 | Baffle-Discharge |
| 4 | 107-3166-01 | 1 | Skid |
| 5 | 110-0758 | 1 | Deflector ASM |
| 6 | 110-2119-01 | 1 | Cover |
| 7 | 92-1624 | 5 | Screw-HWH |
| 8 | 104-8301 | 12 | Nut-Flange, NI |
| 9 | 322-50 | 1 | Screw-HH |
| 10 | 105-4622 | 1 | Spacer |
| 11 | 108-4052 | 1 | Spring-Torsion |
| 12 | 109-6658 | 1 | Nut-Flange, NI |


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------------|
| 13 | 3296-47 | 1 | Nut-Lock, NI |
| 14 | 106-4161 | 5 | Knob-Handle |
| 15 | 1-323417 | 5 | Washer |
| 16 | 1-303536 | 3 | Stud-Shield, Belt (Long) |
| 17 | 1-303537 | 2 | Stud-Shield, Belt (Short) |
| 18 | 3231-2 | 5 | Bolt-CARR |
| 19 | 32128-20 | 5 | Nut-HF |
| 20 | 112-9712 | 1 | Decal |
| 21 | 110-0735-03 | 1 | Baffle |
| 22 | 323-4 | 3 | Screw-HH |
| 23 | 106-5517 | 2 | Decal-Warning, Hot Surface |



Deck Decal Assembly No. 110-4909


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------------|
| 1 | | 1 | 48 Inch Deck ASM ● |
| 2 | 99-3943 | 1 | Decal-Routing, Belt |
| 3 | 112-8760 | 1 | Decal-Danger |
| 4 | 98-5130 | 1 | Decal-Torque, Bolt |
| 5 | 121-6049 | 1 | Decal-Danger |
| 6 | 112-9028 | 2 | Decal-Cover Missing |
| 7 | 131-1180 | 1 | Decal-Adjustment, Baffle |
| 8 | 93-7010 | 1 | Decal-Danger |

● Not serviced separately




Deflector Assembly No. 110-0758

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|----------------------|
| 1 | 3231-4 | 4 | Screw-CARR |
| 2 | 106-3246-01 | 1 | Deflector |
| 3 | 106-3248-03 | 1 | Strap-Discharge |
| 4 | 110-0759 | 1 | Deflector-Rubber |
| 5 | 107-4197-01 | 1 | Bracket-Hinge, Rear |
| 6 | 107-4196-01 | 1 | Bracket-Hinge, Front |
| 7 | 104-8301 | 4 | Nut-Flange, NI |




Sheave, Spindle and Blade Assembly

| Ref. | Part Number | Qty. | Description | Ref. | Part Number | Qty. | Description |
|------|-------------|------|-----------------------------|------|-------------|------|-------------------------|
| 1 | 108-6697 | 3 | Spindle Housing ASM | 11 | 1-800861 | 3 | Screw-Cap, HH |
| 1:1 | 119-7857 | 2 | Bearing-Ball, 1 Inch | 12 | 103-1330 | 3 | Guard-Bearing, Top |
| 1:2 | 110-2116 | 1 | Spacer-Bearing | 13 | 1-403183 | 3 | Sheave |
| 1:3 | 108-6694 | 1 | Housing-Spindle | 14 | 1-323339 | 3 | Washer-Retainer, Sheave |
| 1:4 | 32120-8 | 1 | Ring-Snap | 15 | 3219-6 | 3 | Nut-Hex |
| 2 | 92-1624 | 18 | Screw-HWH | 16 | 3246-18 | 3 | Setscrew |
| 3 | 104-8301 | 21 | Nut-Flange, NI | 17 | 1-413113 | 2 | Bushing-Idler |
| 4 | 110-4888 | 3 | Washer-Spacer | 18 | 116-4665 | 1 | Idler-Pulley, Flat |
| 5 | 103-2535 | 3 | Spacer-Guard, Bottom | 19 | 1-613098 | 1 | Pulley-Idler |
| 6 | 1-807267 | 3 | Key | 21 | 98-5975 | 3 | Washer-Belleville |
| 7 | 1-323529 | 3 | Tube-Spindle, Short | 22 | 1-403188 | 1 | Spacer |
| 8 | 1-323539 | 12 | Spacer | 23 | 323-15 | 1 | Screw-HH |
| 9 | 107-3192-03 | 3 | Blade-16.5 Inch (High Flow) | 24 | 323-14 | 2 | Screw-HH |
| 10 | 1-513208 | 3 | Washer-Spring | | | | |



Idler Assembly

| Ref. | Part Number | Qty. | Description | Ref. | Part Number | Qty. | Description |
|------|-------------|------|---------------------|------|-------------|------|------------------------|
| 1 | 1-324372 | 1 | Pad And Spring ASM | 18 | 1-303434 | 1 | Bushing-Engagement |
| 2 | 321-4 | 2 | Screw-HH | 19 | 103-3600 | 1 | Idler Arm ASM |
| 3 | 3296-42 | 2 | Nut-Lock, NI | 19:2 | 1-323729 | 2 | Sleeve-Bearing |
| 4 | 322-10 | 1 | Screw-HH | 20 | 32151-103 | 1 | Ring-Retaining, EXT |
| 5 | 1-403179 | 1 | Tube-Pivot | 21 | 116-3515 | 1 | Screw-HH, Special |
| 6 | 32120-35 | 1 | Ring-Retaining, EXT | 22 | 1-303352 | 1 | Washer-Spindle |
| 7 | 3256-23 | 1 | Washer-Flat | 23 | 1-806003 | 1 | Pin-Cotter, Hair |
| 8 | 1-322235 | 1 | Arm-Assist | 24 | 110-4932 | 1 | Rod-Brake |
| 9 | 3256-3 | 1 | Washer-Flat | 25 | 1-323748 | 1 | Ring-Push On |
| 10 | 3296-29 | 1 | Nut-Lock, NI | 26 | 1-323747 | 1 | Spring-Compression |
| 11 | 1-303238 | 1 | Eyebolt-Thread, RH | 27 | 1-323746 | 1 | Spacer-Flanged |
| 12 | 32128-20 | 3 | Nut-HF | 28 | 3296-56 | 1 | Nut-Lock, NI |
| 13 | 1-303236 | 1 | Body-Turnbuckle | 29 | 1-323071 | 1 | Spring-Extension |
| 14 | 1-303348 | 1 | Eyebolt-Thread, LH | 30 | 1-303334 | 1 | Washer-Spring |
| 15 | 702809 | 1 | Screw-HH | 31 | 302-40 | 1 | Fitting-Grease, 90 DEG |
| 16 | 98-5975 | 1 | Washer-Belleville | | | | |
| 17 | 116-3626 | 1 | Pulley-Idler | | | | |



Caster Assembly

| Ref. | Part Number | Qty. | Description | Ref. | Part Number | Qty. | Description |
|------|-------------|------|--------------------|------|-------------|------|-----------------|
| 1 | 130-4557 | 2 | Wheel And Tire ASM | 6 | 3253-7 | 2 | Washer-Lock |
| 1:1 | | 1 | Tire ● | 7 | 1-303314 | 8 | Spacer-Caster |
| 1:2 | 1-513809 | 1 | Bearing | 8 | 110-2130 | 2 | Support ASM |
| 1:3 | 1-513810 | 2 | Bushing | 8:2 | 1-303514 | 2 | Bearing-Flanged |
| 1:4 | 302-61 | 1 | Fitting-Grease | 8:3 | 302-52 | 1 | Fitting-Grease |
| 1:5 | | 1 | Wheel ● | 9 | 1-513338 | 2 | Washer-Flat |
| 2 | 1-513547 | 2 | Spacer | 10 | 1-809020 | 2 | Pin |
| 3 | 325-20 | 2 | Screw-HH | 11 | 323-6 | 8 | Screw-HH |
| 4 | 116-7942-01 | 2 | Fork-Caster | 12 | 104-8301 | 8 | Nut-Flange, NI |
| 5 | 3217-9 | 2 | Nut-HH | 13 | 3256-24 | 8 | Washer-Flat |

● Not serviced separately

Attachments and Accessories

For 39678 Commercial Walk-Behind Mower Fixed Deck, T-Bar, Gear Drive with 48in TURBO FORCE Cutting Unit

| Product Name | Model/Part |
|--|-------------------|
| Blade-Low Flow, 16.5in..... | 107-3193-03 |
| Blade-Mid Flow, 16.5in | 107-3194-03 |
| Blade-Atomic, 16.5in | 107-3195-03 |
| Blade-Recycling, 16.5in..... | 107-3196-03 |
| Bagging Enhancement Kit | 108-4091 |
| Blade-Hi Flow, 16.5in (6 Pack)..... | 110-0414 |
| Blade-Lo Flow, 16.5in (6 Pack) | 110-0415 |
| Blade-Recycler, 16.5in (6 Pack)..... | 110-0416 |
| Blade-Atomic, 16.5in (6 Pack) | 110-0417 |
| Blade-Mid Flow, 16.5in (6 Pack) | 110-0418 |
| 48in Recycler Kit..... | 110-2060 |
| Weight Kit | 110-2085 |
| Operator Controlled Discharge Chute Kit..... | 115-4195 |
| Oil-Synthetic, All Season | 117-0066 |
| Oil Filter | 119-5852 |
| Filter-fuel..... | 120-2235 |
| Element-Filter, Air | 120-7447 |
| Soft Bag (3 Bushel)..... | 30104 |
| Sulky..... | 30109 |
| Toro 4-cycle Sae 30 Oil (32oz Bottle)..... | 38903 |
| Spark Plug | 92-2153 |

Notes:

Notes:



Count on it.