



42" Side Discharge Mower

Lawn and Garden Tractor Attachment

Model No. 78232—200000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.


Contents

Description	Page	Description	Page
Blade, Spindle and Pulley Assembly	3	Chute, Belt Cover and Shield Assembly	5
Gage Wheel and Rollers Assembly	4		

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	INC	incorporated
ASM	assembly	LH	left hand
CARR	carriage	NI	nylon insert
DEG	degrees	PPH	Phillips pan head
FH	flat head	PTH	Phillips truss head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SHH	slotted hex head
HLH	hex lag head	SQH	square head
HJ	hex jam	SHWH	slotted hex washer head
HOC	height-of-cut	SPH	slotted pan head
HS	hex socket	SRH	slotted round head
HSBH	hex socket button head	STD	standard
HSFH	hex socket flat head	TAP	self tapping
HSH	hex socket head	TTH	Torx truss head
HWH	hex washer head	WH	wing head
HWHTF	hex washer head thread forming		




Sheet No.:2

Blade, Spindle and Pulley Assembly

Ref. No.	Part No.	Qty.	Description
1	109966	6	Bearing-Ball
2	92-7080	3	Pulley
3	92-6991	1	V-Belt
5	3253-8	3	Washer-Lock
6	3220-6	3	Nut-Jam
7	78-3140-03	1	Strap-Brace
8	3296-39	4	Nut-Lock, NI
9	92-7084	1	Pulley-Flat Idler
10	3256-24	2	Washer-Flat
11	109859	2	Bushing
12	79-2760	1	Spacer
13	323-11	1	Screw-HH
14	92-7082	1	Pulley - Idler
15	2844	1	Washer
16	116172	1	Spring - Extension
17	98-9006	1	Arm - Idler
17:1	302-5	1	Fitting-Lube
19	323-9	1	Screw-HH
20	323-14	1	Screw-HH
21	323-6	1	Screw-HH
22	9080326	12	Screw-HH
23	106636	1	Blade Kit
24	3256-28	3	Washer-Flat
25	3220-7	3	Nut-Jam
26	9202574	3	Washer-Flat
27	78-6710	3	Shaft-Spindle


Ref. No.	Part No.	Qty.	Description
28	106067	3	Cup-Spindle
29	302-5	3	Fitting-Lube
30	106068	3	Spacer-Blade
31	32120-42	3	Ring-Retaining
32	116085	3	Tube
33	114568	3	Housing-Spindle



Gage Wheel and Rollers Assembly

Ref. No.	Part No.	Qty.	Description
1	321-4	5	Screw-HH
2	118960-03	5	Shaft-Roller
3	110837-03	2	Bracket-Pivot
4	3296-39	7	Nut-Lock, NI
5	3296-42	5	Nut-Lock
6	29-4820	5	Roller
7	3272-21	7	Pin-Cotter
8	9335064	3	Pin-Hair
9	78-6681	1	Link-Rear
10	3256-26	5	Washer-Flat
11	3256-28	2	Washer-Flat
12	79-4140-03	1	Support-Gage Wheel
13	78-7340	2	Roller-Lift
14	9202394	2	Washer
15	32151-29	2	Ring-Snap, External
16	9335074	2	Pin-Hair
18	3231-4	2	Screw-CARR
19	325-13	1	Screw-HH
20	86-9240	1	Bracket-Lift, Lower
21	86-9250	1	Bracket-Lift, Upper
22	3218-5	1	Nut-Jam
23	3231-5	2	Screw-CARR
24	3231-22	3	Screw-CARR
25	79-2831-03	1	Plate-Wear RH
26	3256-24	2	Washer-Flat
27	110838-03	2	Bar

Ref. No.	Part No.	Qty.	Description
28	32146-2	2	Nut-Lock, NI
29	92-6959	2	Wheel
30	92-1057	2	Bolt-Shoulder



Sheet No.:4

Chute, Belt Cover and Shield Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	93-1631	1	Spring – Deflector				
4	98-1799	1	Deck ASM				
4:2	93-7317	1	Decal – Danger				
8	78-6891	2	Cover-Belt				
9	46-8560	6	Screw-HHF				
12	3296-39	4	Nut-Lock, NI				
13	3231-1	4	Screw-CARR				
14	78-8530-03	1	Plate-Deck				
15	93-7325	1	Decal – Belt Installation				
16	93-1633	2	Washer				
17	116080	1	Bushing-Pivot				
18	9152366	1	Nut-HJ				
19	99-3707	1	Chute ASM (Int'l)				
19:2	93-7316	1	Decal – Danger				
21	3256-26	1	Washer-Flat				
22	3272-10	1	Pin-Cotter				
23	3218-3	4	Nut-Jam				
24	9114454	4	Screw – HHCS				
25	93-0544-01	1	Shield – Front				

[illegible]

