

## 48" Blade Retro Kit

Part No. 95-4090

# **Parts Catalog**

#### ORDERING REPLACEMENT PARTS

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

#### **Contents**

Description	Page	Description	Page
Frame Assembly	1	Note:	

#### **Accessories**

Description Model / Parts No. Description Model / Parts No.

#### **Part Description Abbreviations**

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HWHTF	hex washer head
ASM	assembly		thread forming
CARR	carriage	INC	incorporated
DEG	degrees	LH	left hand
FH	flat head	PH	pan head
GA	gauge	PPH	Phillips pan head
HF	hex flange	PTO	power take off
HFW	hex flange washer	RH	right hand
HH	hex head	SFH	slotted fillister head
HHF	hex head flange	SH	square head
HHST	hex head self tapping	SHWH	slotted hex washer head
HJ	hex jam	SPH	slotted pan head
HOC	height-of-cut	STD	standard
HS	hex socket	TAP	self tapping
HSBH	hex socket button head	TH	truss head
HSFH	hex socket flat head	TTH	Torx truss head
HSH	hex socket head	WH	wing head
HWH	hex washer head		

### **Important Format Explanations**

This catalog uses special formats to convey information in illustrations and parts lists. Specifically, one format is used in conjunction with service assemblies and another with quantities associated with reference numbers.

#### Service Assemblies

Parts within service assemblies have reference numbers in the form *X:Y. X* is the reference number of the service assembly and *Y* is a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in part lists and as callouts in illustrations.

#### **Reference Numbers with Quantities**

Illustrations may have a quantity in parentheses next to a reference number, in the form X(Y). X is the reference number. Y in parentheses is the quantity of the part identified by the reference number.

For example, the illustration callout 4 (2) indicates that two parts are used in that instance.



Ref. No.	Part No.	Qty.	Description
1	283–2	1	Pin-Clevis
1	98–5055	1	Pin
2	94–7793–03	1	Link–Lift
2	94–7987–03	1	Link–Lift
3		1	Frame-ASM
1	88–6520	1	Index Pin
1	2354	1	Spring-Compression
3:3	3272–11	1	Pin–Cotter
4		1	Cable-Indexing
5		1	Bracket–Cable
6		1	Pin-Cotter
8		1	Nut-Hex Lock
9		1	Screw-HH
1	4944	2	Plug
11	· · · · · · ·	1	Pin-Cotter
	94–7787	1	Rod-Blade Control
1	98–5053–01	1	Lever-Indexing
1	9335124	1	Hairpin
1	321–6	1	Screw-HH
1	5359	1	Grip-Handle
1	98–1743	1	Index Lever W.a.
_	32146–17	1	Nut-Lock
19	9335054	2	Hairpin
		1	

Ref. No.	Part No.	Qty.	Description