

### Rear Baffle Kit

for 60" OFZ Deck

Part No. 100-2439

INSTALLATION INSTRUCTIONS

### **Loose Parts**

**Note:** Use the chart below to identify parts for assembly.

DESCRIPTION	QTY.	USE
Baffle	1	
Screw	1	Install New Baffle
Lock Nut	1	

### Pre-Installation

# **M** WARNING

### POTENTIAL HAZARD

• Blade is sharp.

### WHAT CAN HAPPEN

• Contact with sharp blade can cause serious personal injury.

### HOW TO AVOID THE HAZARD

• Wear gloves or wrap sharp edges of the blade with a rag.

- **1.** Disengage the power take off (PTO), set the parking brake, and turn the ignition key to "OFF" to stop the engine. Remove the key.
- 2. Tilt up deck and lock into vertical position.
- 3. Thoroughly clean mower deck. All debris must be removed to ensure baffle will fit properly against mower deck.
- **4.** Repair all bent or damaged areas of mower deck and replace any missing parts.

## **Removing Existing Wear Plate**

Remove existing righthand wear plate under deck. Save hardware that is removed (Fig. 1).




Figure 1

Deck Bolt

2.

- Nut Wear Plate

## **Installing New Baffle**

Note: Use existing three holes in which wear plate was located.




Figure 2

Deck

Hole to drill

2. Bolt Screw

3. Nut Flange Nut

Baffle

1.

Install new baffle into existing wear plate holes (Fig. 2).

Note: When installing bolts, the bolt heads need to be on the inside of cutting deck.

- Use the baffle as a template to drill a hole in side of deck. Mark location and drill a 11/32 in. hole. (Fig. 2).
- Install screw and flange nut into deck and baffle. Torque to 200±25 in-lb.
- Rotate blade to ensure it does not hit baffle.

# WARNING

### POTENTIAL HAZARD

• A blade that is bent or damaged could break apart and pieces could be thrown at bystanders or at you as you use the mower.

#### WHAT CAN HAPPEN

• Pieces of blade that may be thrown could seriously injure or kill you or bystanders.

#### HOW TO AVOID THE HAZARD

- Always replace bent or damaged blade with a new blade.
- Never file or create sharp notches in the edges or surfaces of blade.