Form No. 3427-980 Rev B

TORO®

Count on it.

Operator's Manual

Blower Kit

GrandStand® Multi Force Mower

Model No. 78593—Serial No. 403400000 and Up

Register at www.Toro.com.
Original Instructions (EN)

3427-980 B

⚠ WARNING

CALIFORNIA
Proposition 65 Warning

Use of this product may cause exposure to chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Introduction


This blower is intended to be used by professional, hired operators. It is primarily designed to use wind power to quickly clear large areas of unwanted debris on well-maintained lawns, parks, golf courses, sports fields, and on commercial grounds. Using this product for purposes other than its intended use could prove dangerous to you and bystanders.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

Visit www.Toro.com for more information, including safety tips, training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model and serial numbers of your product ready. Figure 1 identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.

Important: **With your mobile device, you can scan the QR code on the serial number decal (if equipped) to access warranty, parts, and other product information.**



g246145

Figure 1

1. Location of the model and serial numbers

Model No. _____

Serial No. _____

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol (Figure 2), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



g000502

Figure 2

1. Safety-alert symbol

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

© 2019—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA
All Rights Reserved

Contents

Safety 3
General Safety 3
Safety and Instructional Decals 4
Setup 5
1 Preparing the Machine 5
2 Installing the Wheel Weight Kit (Optional) 5
3 Positioning the Caster Wheels 6
4 Removing the Right Fan Guard 6
5 Installing the Idler Pulley 7
6 Installing the Blower 7
Operation 12
Operation Safety 12
Operating the Blower 12
Using the Kickstand 12
Removing the Blower 14
Operating Tips 17
Maintenance 18
Maintenance Safety 18
Checking the Belts 18
Replacing the Blower Belt 18
Replacing the Clutch Belt 19
Checking the Hydraulic Hoses 19
Removing Debris from the Machine 19

Safety

General Safety


This product is capable of throwing objects. Always follow all safety instructions to avoid serious personal injury.

- Read and understand the contents of this *Operator's Manual* before starting the engine.
- Use your full attention while operating the machine. Do not engage in any activity that causes distractions; otherwise, injury or property damage may occur.
- Do not put your hands or feet near moving components of the machine.
- Do not operate the machine without all guards and other safety protective devices in place and working on the machine.
- Keep clear of any discharge opening. Keep bystanders and pets a safe distance away from the machine.
- Keep children out of the operating area. Never allow children to operate the machine.
- Stop the machine, shut off the engine, and remove the key before servicing, fueling, or unclogging the machine.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol ⚠, which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

Safety and Instructional Decals

Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



decal119-0217


119-0217

1. Warning—stop the engine; stay away from moving parts; keep all guards and shields in place.



decal133-8061

133-8061



decal137-3999

137-3999

1. Warning—read the *Operator's Manual*.
2. Thrown object hazard—keep bystanders away from the machine.
3. Warning—wear hearing and eye protection.
4. Cutting/dismemberment hazard of hands—shut off the engine; keep hands away from moving parts; keep all guards and shields in place.

Setup

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	No parts required	–	Prepare the machine.
2	Wheel Weight Kit (sold separately)	1	Install the Wheel Weight Kit (optional).
3	No parts required	–	Position the caster wheels.
4	No parts required	–	Remove the fan guard.
5	Idler pulley Hex-flange head bolt Spacer Mounting bracket Carriage bolt Nut Plate	1 1 1 1 2 3 1	Install the idler pulley.
6	Blower assembly Bushing assembly Carriage bolt (3/8 x 2-1/4 inches) Locknut (3/8 inch) Receiver hitch Heat shield Bumper Thread-forming screw (1/4 x 1/2 inch) Stop bracket Carriage bolt (3/8 x 1 inch) Nut (3/8 inch) Washer Spacer Thread-forming screw (1/4 x 1-1/4 inch)	1 2 2 2 1 1 2 2 1 1 1 1 1 1	Install the blower.

Important: **Install the Low Flow Hydraulics Kit on your machine before installing this kit.**

1

Preparing the Machine

No Parts Required

Procedure

1. Park the machine on a level surface.
2. Lower the A-frame.
3. Disengage the PTO, engage the parking brake, and move the motion-control levers outward to the NEUTRAL-LOCK position.
4. Shut off the engine and remove the key.

2

Installing the Wheel Weight Kit (Optional)

Parts needed for this procedure:

1	Wheel Weight Kit (sold separately)

Procedure

Installing wheel weights can improve traction on the machine when using the blower; refer to the *Installation Instructions* for the Wheel Weight Kit.


3

Positioning the Caster Wheels

No Parts Required

Procedure

For both casters, remove the nut and bolt, move the caster to the front position, and install the nut and bolt (Figure 3). Torque to 91 to 113 N·m (67 to 83 ft-lb).



g230693

Figure 3

1. Nut and bolt


4

Removing the Right Fan Guard

No Parts Required

Procedure

1. Remove the fuel tank; refer to the *Operator's Manual* for the machine.
2. Remove and retain the 2 bolts, 2 nuts, and the right fan guard (Figure 4).



g246823

Figure 4

1. Nut (3/8 inch)
2. Bolt (3/8 x 1-1/4 inch)
3. Right fan guard

3. Install the bolts and nuts you removed and torque to 41 to 49 N·m (30 to 36 ft-lb).
4. Install the fuel tank.

5

Installing the Idler Pulley

Parts needed for this procedure:

1	Idler pulley
1	Hex-flange head bolt
1	Spacer
1	Mounting bracket
2	Carriage bolt
3	Nut
1	Plate

Procedure

1. Secure the idler pulley to the mounting bracket using the hex-flange head bolt, and spacer (Figure 5). Torque the bolt to 37 to 45 N·m (27 to 33 ft-lb).




Figure 5

1. Mounting bracket
2. Idler pulley
3. Spacer
4. Hex-flange head bolt
5. Nut
6. Shoulder bolt

2. Install the shoulder bolt to the mounting bracket using a nut (Figure 5). Torque the bolt to 37 to 45 N·m (27 to 33 ft-lb).

3. Secure the mounting bracket to the left machine frame tube, between the plates welded to the tube, using the plate, 2 carriage bolts, and 2 nuts (Figure 6). Torque the bolts to 37 to 45 N·m (27 to 33 ft-lb).




Figure 6

1. Nut (2)
2. Plate
3. Mounting bracket
4. Carriage bolt

4. Route the belt to the idler pulley (Figure 7).

Important: **Ensure that the wide side of the belt contacts the pulley as shown in Figure 7. Use the shoulder bolt as a guide for the belt.**




Figure 7

1. Shoulder bolt
2. Idler pulley
3. Belt

6

Installing the Blower

Parts needed for this procedure:

1	Blower assembly
2	Bushing assembly
2	Carriage bolt (3/8 x 2-1/4 inches)
2	Locknut (3/8 inch)
1	Receiver hitch
1	Heat shield
2	Bumper
2	Thread-forming screw (1/4 x 1/2 inch)
1	Stop bracket
1	Carriage bolt (3/8 x 1 inch)
1	Nut (3/8 inch)
1	Washer
1	Spacer
1	Thread-forming screw (1/4 x 1-1/4 inch)

Procedure

1. Remove the air-cleaner cover and filter; refer to the *Operator's Manual* for the machine.
2. Install the 2 bumpers on the heat shield (Figure 8).




Figure 8

1. Heat shield
2. Bumper

3. Remove the top carriage bolt and nut securing the muffler guard to the machine (Figure 9).




Figure 9

1. Carriage bolt
2. Nut
3. Muffler guard

4. **Loosely** install the heat shield over the muffler guard, with the tabs inside the muffler guard and to the inside of the console tower, using the 2 thread-forming bolts (1/4 x 1/2 inch) and the carriage bolt and nut you removed previously (Figure 10).

   Important: **To minimize debris buildup on the muffler, install the heat shield on the machine when using the blower.**





Figure 10

1. Carriage bolt
2. Nut
3. Drill here.
4. Heat shield
5. Thread-forming bolt—1/4 x 1/2 inch (2)
6. Tab (inside muffler guard)

5. Using the center hole in the heat shield as a template, drill a hole (7/32 inch) into the muffler guard (Figure 10).
6. Use the thread-forming bolt (1/4 x 1-1/4 inch) and washer to install the spacer between the heat shield and muffler guard (Figure 11).



g256854


Figure 11

1. Thread-forming bolt (1/4 x 1-1/4)
2. Washer
3. Spacer

7. Torque the 3 thread-forming bolts to 4.5 N·m (40 in-lb).

   Note: Do not torque the carriage bolt at this time.
8. Install the air-cleaner filter and cover.
9. Use a carriage bolt (3/8 x 2-1/4 inches) and nut (3/8 inch) to install the bushing assemblies to the machine (Figure 12). Torque the bolt to 37 to 45 N·m (27 to 33 ft-lb).

   Note: The rubber flange of the bushing should face toward the inside of the machine as shown in Figure 12.




g250302

Figure 12

1. Carriage bolt (3/8 x 2-1/4 inches)
2. Bushing assembly
3. Nut (3/8 inch)
4. Rubber flange

10. Use a carriage bolt (3/8 x 1 inch) and a locknut (3/8 inch) to install the stop bracket to the right side of the machine (Figure 13). Torque the bolt to 37 to 45 N·m (27 to 33 ft-lb).




g250341

Figure 13

1. Locknut (3/8 inch)
2. Stop bracket
3. Carriage bolt (3/8 x 1 inch)

11. Remove the hitch pin and cotter pin from the A-frame and use it to install the hitch receiver (Figure 14). Ensure that the pin locks the A-frame to the cross tube.




g230752

Figure 14

1. Hitch receiver
2. Hitch pin
3. Cotter pin

12. Move the blower in front of the machine and lay the belt underneath the machine so that it is lined up with the clutch (Figure 15).




g230767

Figure 15

1. Blower assembly
2. Belt
3. Clutch

13. Place the blower assembly forks onto the bushing assemblies (Figure 16).



g250511

Figure 16

14. Route the belt to the idler pulley.

Important: **Ensure that the wide side of the belt contacts the pulley as shown in Figure 17. Use the shoulder bolt as a guide for the belt.**




Figure 17

1. Shoulder bolt
2. Idler pulley
3. Belt

15. Install the belt onto the clutch. Verify that the belt is still routed on the blower pulleys and is seated properly in the pulley grooves.

    Note: You can use a drive ratchet (1/2 inch) to move the left idler pulley for the blower (Figure 18).




Figure 18

1. Drive ratchet
2. Pulley

16. Raise the blower as described in Raising the Blower (page 13).
17. Connect the hydraulic hoses to the quick-disconnect couplings on the Low Flow Hydraulics Kit.

⚠ WARNING

Hydraulic fluid escaping under pressure can penetrate skin and cause injury. Fluid injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury; otherwise, gangrene may result.

- **Ensure that all hydraulic-fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.**
- **Keep your body and hands away from pinhole leaks or nozzles that eject high-pressure hydraulic fluid.**
- **Use cardboard or paper to find hydraulic leaks; never use your hands.**

Operation


Operation Safety

- The machine exceeds noise levels of 85 dB(A) at the operator's position. Use hearing protection for prolonged exposure to reduce the potential of permanent hearing damage.
- Wear appropriate clothing including eye protection; long pants; substantial, slip-resistant footwear; and hearing protection. Tie back long hair and do not wear loose clothing or loose jewelry.
- Stay away from the nozzle opening when the machine is operating. Keep all bystanders away from the nozzle opening and do not direct discharge toward bystanders.
- When a person or pet appears unexpectedly in or near the operating area, stop operation. Careless operation, combined with terrain angles, ricochets, or improperly positioned guards can lead to thrown object injuries. Do not resume operation until the area is cleared of people and pets.
- Shut off the engine, remove the key, wait for all movement to stop, and allow the machine to cool before adjusting, cleaning, storing, or repairing it.

Operating the Blower

Important: **Do not operate the blower without the heat shield installed on the machine.**

To operate the blower, start the engine, move the motion-control levers to the center, unlocked position, move the throttle lever between half and full throttle, and engage the PTO (Figure 19).




g009174

Figure 19

Use the right switch for the low flow kit to rotate the nozzle to the desired direction (Figure 20), and use the throttle lever to adjust the blower speed.

Note: If you would like to change the direction the nozzle rotates when you move the switch a particular direction, remove the quick-disconnect couplings from the Low-Flow Hydraulics Kit hoses and install them on the opposite hoses.



g037041

Figure 20

1. Not used with this kit
2. Rotate the blower nozzle.

Ensure to clean debris from the machine regularly.

⚠ WARNING


Discharged air has considerable force and could cause injury or loss of footing.

- **Stay away from the nozzle opening when the machine is operating.**
- **Keep bystanders away from the nozzle opening when the machine is operating.**

Using the Kickstand

Lowering the Blower

1. Rotate the blower nozzle so that it points upward.
2. Park the machine on a level surface, disengage the PTO, move the motion-control levers to the NEUTRAL-LOCK position, and engage the parking brake.
3. Shut off the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
4. Pull out the kickstand locking pins on both sides of the machine, rotate them 90 degrees so that they are disengaged, and rotate the kickstand away from the machine (Figure 21). Engage the pins and ensure that they snap into position.




g230843

Figure 21

1. Kickstand locking pin in the engaged position
2. Kickstand locking pin in the disengaged position
3. Kickstand in the blower operating position
4. Kickstand in the blower storage position

5. Remove the hitch pin and hairpin cotter securing the blower assembly to the hitch receiver (Figure 22).




g230859

Figure 22

1. Hairpin cotter
2. Hitch pin

6. Hold the kickstand and push the release lever down. Slowly lower the kickstand to the ground.

   Note: Once the lever disengages the hitch pin, the blower rotates down.




g230858

Figure 23

1. Release lever

Raising the Blower

1. Raise the blower so that it latches on the hitch receiver (Figure 24 and Figure 25).



g230769

Figure 24




Figure 25

1. Hairpin cotter
2. Hitch pin

2. Secure the assembly to the hitch receiver using the hitch pin and hairpin cotter attached to the receiver (Figure 25).
3. Pull out the kickstand locking pins on both sides of the machine, rotate them 90 degrees so that they are disengaged, and raise the kickstand (Figure 26). Engage the knobs and ensure that the pins snap into position.




Figure 26

1. Kickstand locking pin in the engaged position
2. Kickstand locking pin in the disengaged position
3. Kickstand in the blower operating position
4. Kickstand in the blower storage position

Removing the Blower

1. Park the machine on a level surface, disengage the PTO, engage the parking brake, and move the motion-control levers outward to the NEUTRAL-LOCK position.
2. Shut off the engine and remove the key.
3. Disconnect the blower hydraulic hoses from the quick-disconnect couplings on the Low Flow Kit.
4. Lower the blower; refer to Lowering the Blower (page 12).
5. Remove the belt from the clutch.

   Note: If needed, use a drive ratchet (1/2 inch) to move the left idler pulley (Figure 27).





Figure 27

1. Drive ratchet
2. Pulley

6. Lift the blower assembly off the bushing assemblies on the machine.

7. Remove the hitch pin, cotter pin, and hitch receiver from the A-frame. Install the hitch pin and cotter pin to secure the A-frame (Figure 28).




g246845

Figure 28

1. Hitch receiver
2. Hitch pin
3. Cotter pin

8. Remove the stop brackets (Figure 29).




g250341

Figure 29

1. Locknut (3/8 inch)
2. Stop bracket
3. Carriage bolt (3/8 x 1 inch)

9. Remove both bushing assemblies (Figure 30).




g230751

Figure 30

1. Bolt
2. Bushing assembly
3. Nut

10. Use the fasteners to store the bushing assemblies on the left side of the blower frame (Figure 31).




g246867

Figure 31

1. Bolt
2. Bushing assembly
3. Nut

11. Remove the spacer




g256854

Figure 32

1. Thread-forming bolt (1/4 x 1-1/4)
2. Washer
3. Spacer

12. Remove the heat shield (Figure 33).

Important: **Whenever you install the blower on another machine, also install the heat shield.**



g256855


Figure 33

1. Carriage bolt
2. Nut
3. Heat shield
4. Thread-forming bolt (2)

13. Install the carriage bolt and nut to secure the muffler guard. Torque the bolt to 1978 to 2542 N·cm (175 to 225 in-lb).

14. Remove the fuel tank; refer to the *Operator's Manual* for the machine.

15. Remove the 2 bolts and 2 nuts from the right side of the machine and use them to install fan guard (Figure 34). Torque the bolts to 37 to 45 N·m (27 to 33 ft-lb).



g246823

Figure 34

1. Nut (3/8 inch)
2. Bolt (3/8 x 1-1/4 inches)
3. Fan guard

16. Install the fuel tank.

Operating Tips

- Practice operating the blower. Blow the same direction the wind is blowing to prevent material from blowing back into the cleared area.
- Be aware of the blower nozzle direction and do not point it at anyone.
- Adjust the nozzle opening so that it blows under the debris.
- Use caution when blowing around newly planted sod as the force of the air could disrupt the grass.
- The nozzle outlet position affects the distance debris can be blown.
- When you rotate the nozzle, rotate it upward and around to prevent blowing debris back into the cleared area.

Maintenance

Maintenance Safety

- Park the machine on a level surface. Never allow untrained personnel to service the machine.
- Use jack stands to support the machine when required.
- Remove the key from the switch on the traction unit to prevent accidental starting of the engine when servicing, adjusting, or storing the machine.
- Perform only those maintenance instructions described in this manual. If the blower requires a major repair, contact an authorized Toro distributor.
- Ensure that the machine is in safe operating condition by keeping nuts, bolts, and screws tight.
- Keep your hands and feet away from moving parts. Do not make adjustments with the engine running.
- Keep all parts in good working condition and all hardware tightened. Replace all worn or damaged decals.
- To ensure optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.


Checking the Belts

Service Interval: Every 300 hours

Check the belts for cracks, frayed edges, burn marks, or any other damage. Replace damaged belts.

Replacing the Blower Belt

1. Park the machine on a level surface, disengage the PTO, and engage the parking brake.
2. Shut off the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Remove the belt cover (Figure 35).




g246599

Figure 35

1. Bolt (3)
2. Belt cover

4. Loosen the nut on the top pulley and slide the pulley up to release tension on the belt (Figure 36).



g250730

Figure 36

Blower nozzle not shown for clarity

1. Top pulley
2. Belt
3. Roller bearing

5. Remove the roller bearing (Figure 36).
6. Remove the belt and install a new belt (Figure 36).
7. Install the roller bearing (Figure 36)
8. Slide the top pulley down until the belt deflection is 5 mm (0.19 inch) at the center of the largest span and tighten the nut (Figure 36).

Replacing the Clutch Belt

1. Park the machine on a level surface, disengage the PTO, and engage the parking brake.
2. Shut off the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Lower the blower.
4. Loosen the nozzle clamp and remove the nozzle.
5. Remove the belt from the machine clutch.

   Note: You can use a drive ratchet (1/2 inch) to move the left idler pulley (Figure 18).
6. Remove the belt from the fan pulley (Figure 37).




Figure 37

1. Fan pulley
2. Right idler pulley
3. Left idler pulley
4. Belt
5. Clutch pulley

7. Route the belt down through the drive adapter assembly, around the idler pulleys, and around the clutch pulley (Figure 37). Ensure that the belt is seated properly in the pulley grooves.

   Note: If needed, you may use a drive ratchet (1/2 inch) to move the left idler pulley (Figure 18).

Checking the Hydraulic Hoses

Service Interval: Every 100 hours

Check the hydraulic hoses for leaks, loose fittings, kinked lines, loose mounting supports, wear, weather, and chemical deterioration.

⚠ WARNING

Hydraulic fluid escaping under pressure can penetrate skin and cause injury. Fluid injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury; otherwise, gangrene may result.

- **Ensure that all hydraulic-fluid hoses and lines are in good condition and all hydraulic connections and fittings are tight before applying pressure to the hydraulic system.**
- **Keep your body and hands away from pinhole leaks or nozzles that eject high-pressure hydraulic fluid.**
- **Use cardboard or paper to find hydraulic leaks; never use your hands.**

Removing Debris from the Machine

Service Interval: After each use

1. Park the machine on a level surface, disengage the PTO, and engage the parking brake.
2. Shut off the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Clean debris from the drives, muffler, and engine after each use.

California Proposition 65 Warning Information

What is this warning?

You may see a product for sale that has a warning label like the following:



WARNING: Cancer and Reproductive Harm—www.p65Warnings.ca.gov.

What is Prop 65?

Prop 65 applies to any company operating in California, selling products in California, or manufacturing products that may be sold in or brought into California. It mandates that the Governor of California maintain and publish a list of chemicals known to cause cancer, birth defects, and/or other reproductive harm. The list, which is updated annually, includes hundreds of chemicals found in many everyday items. The purpose of Prop 65 is to inform the public about exposure to these chemicals.

Prop 65 does not ban the sale of products containing these chemicals but instead requires warnings on any product, product packaging, or literature with the product. Moreover, a Prop 65 warning does not mean that a product is in violation of any product safety standards or requirements. In fact, the California government has clarified that a Prop 65 warning "is not the same as a regulatory decision that a product is 'safe' or 'unsafe.'" Many of these chemicals have been used in everyday products for years without documented harm. For more information, go to https://oag.ca.gov/prop65/faqs-view-all.

A Prop 65 warning means that a company has either (1) evaluated the exposure and has concluded that it exceeds the "no significant risk level"; or (2) has chosen to provide a warning based on its understanding about the presence of a listed chemical without attempting to evaluate the exposure.

Does this law apply everywhere?

Prop 65 warnings are required under California law only. These warnings are seen throughout California in a wide range of settings, including but not limited to restaurants, grocery stores, hotels, schools, and hospitals, and on a wide variety of products. Additionally, some online and mail order retailers provide Prop 65 warnings on their websites or in catalogs.

How do the California warnings compare to federal limits?

Prop 65 standards are often more stringent than federal and international standards. There are various substances that require a Prop 65 warning at levels that are far lower than federal action limits. For example, the Prop 65 standard for warnings for lead is 0.5 µg/day, which is well below the federal and international standards.

Why don't all similar products carry the warning?

- Products sold in California require Prop 65 labelling while similar products sold elsewhere do not.
- A company involved in a Prop 65 lawsuit reaching a settlement may be required to use Prop 65 warnings for its products, but other companies making similar products may have no such requirement.
- The enforcement of Prop 65 is inconsistent.
- Companies may elect not to provide warnings because they conclude that they are not required to do so under Prop 65; a lack of warnings for a product does not mean that the product is free of listed chemicals at similar levels.

Why does Toro include this warning?

Toro has chosen to provide consumers with as much information as possible so that they can make informed decisions about the products they buy and use. Toro provides warnings in certain cases based on its knowledge of the presence of one or more listed chemicals without evaluating the level of exposure, as not all the listed chemicals provide exposure limit requirements. While the exposure from Toro products may be negligible or well within the "no significant risk" range, out of an abundance of caution, Toro has elected to provide the Prop 65 warnings. Moreover, if Toro does not provide these warnings, it could be sued by the State of California or by private parties seeking to enforce Prop 65 and subject to substantial penalties.