Form No. 3324–224

Tiller Attachment

For Toro® Sitework™ Systems

Model No. 22445—200000001 and Up

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.


Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 1999
All Rights Reserved




COMPONENT	FUNCTION	DISPLACEMENT	DIAMETER
M1	TILLING	6.2 IN^3 /REV 97 CC/REV	
P1			.50 IN 12.7 MM

Tiller Assembly

Ref. No.	Part No.	Qty.	Description
1	99–5046	1	Tiller Frame ASM
1:2	93–7321	2	Decal – Danger
1:3	100–4708	1	Decal–Warning
2	98–9087	1	Shaft – Tine
3	99–9979	2	Bearing ASM
5	325–6	4	Screw–HH
6	3296–23	10	Nut–Lock, NI
7	98–9931	4	Bolt
8	3246–4	2	Screw–Set
9	99–9984	18	Tine–RH
10	99–9985	18	Tine–LH
11	324–29	72	Bolt–HH
12	32146–7	72	Nut
13	98–9085	1	Sprocket
14	98–9935	1	Key – Square
15	3247–3	2	Screw–Set
16	98–9088	1	Chain – Roller
17	98–9089	1	Link – Connecting
18	98–9086	1	Sprocket
19	98–9934	1	Key – Square
20	3246–4	2	Screw–Set
21	98–9082	1	Chain Adjustment ASM
22	3219–6	1	Nut–Hex
23	3296–41	1	Nut–Lock NI
24	99–5044	1	Holder–Adjustment

Ref. No.	Part No.	Qty.	Description
25	3296–23	1	Nut–Lock, NI
26	98–9071	1	Cover – Chain, Tiller
27	321–2	4	Screw–HH
28	98–9070	1	Plate–Mount, Motor
29	325–8	1	Screw–HH
30	325–10	1	Screw–HH
31	98–9084	1	Motor – Hydraulic
32	3274–4	4	Screw–HSH
33	98–9083	2	Hose – Hydraulic
34	100–4701	1	Nipple–Connect, Pressure
*34:1	100–6120	1	Kit–Seal
35	100–4234	1	Coupler–Face, Flush
*35:1	100–6119	1	Kit–Seal
36	100–8828	1	Decal–Dingo, Front
40	98–3269	1	Decal–Made In USA
41	100–4618	2	Adapter–Hyd
*41:1	237–80	1	O–Ring
42	100–4702	1	Disconnect–Quick, Male
43	100–4703	1	Disconnect–Quick, Female
*43:1	100–4165	1	Seal

* Not illustrated



Sheet No.:A1

C–2931

Hydraulic Motor Assembly No. 98–9084

Ref. No.	Part No.	Qty.	Description
8	56–6890	1	Seal Kit

Ref. No.	Part No.	Qty.	Description


TORO®