Form No. 3438-158 Rev A

Height-of-Cut Bracket Kit

ProLine Commercial Walk-Behind Mower

Model No. 139-4063


Installation Instructions

Note: Determine the left and right sides of the machine from the normal operating position.

Safety

Safety and Instructional Decals

Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.



decal140-5475

140-5475

1. Attention—read the *Operator's Manual* for instructions on adjusting the height-of-cut; 1) Disengage the PTO; 2) Engage the parking brake; 3) Shut off the engine and remove the key; 4) Lock the height-of-cut lever in the transport position; 5) Install the brackets; 6) Insert the height-of-cut pin in the 76 mm (3 inch) location and lower the lever; 7) Loosen the adjustment bolts; 8) Apply downward pressure on the adjustment bolts/chains while tightening the adjustment bolts; 9) Remove the brackets.

Installation

Preparing the Machine

1. Park the machine on a level surface, disengage the PTO, and engage the parking brake.
2. Shut off the engine, remove the key, and wait for all moving parts to stop before leaving the operating position.
3. Check the air pressure in the rear tires; refer to the *Operator's Manual* for the machine.

© 2020—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Register at www.Toro.com.


CE

Original Instructions (EN)
Printed in the USA
All Rights Reserved

3438-158 A

Correcting the Height of Cut


1. Move the height-of-cut lever to the TRANSPORT position (Figure 1).



g315668

Figure 1


2. Rotate the blades until the ends face forward and backward.
3. Place the height-of-cut brackets below the mower deck so that the deck shell rests on the brackets when you lower the deck; refer to Figure 2 and Figure 3 for proper orientation.



g315884

Figure 2

Bracket Orientation for 36-inch Decks




g315885

Figure 3

Bracket Orientation for 48-inch, 54-inch, and 60-inch Decks


4. Lower the deck onto the brackets.
5. Move the height-of-cut pin to the 76 mm (3 inch) position; refer to Figure 4.



g315669

Figure 4

6. Loosen the adjustment bolts on all 4 corners of the deck so that the deck is sitting on all 4 brackets.



g300452

Figure 5

1. Adjustment bolt

7. Verify that only the deck shell is resting on the brackets and the chains are not tight.
8. Apply downward pressure on the adjustment bolts/chains while torquing the adjustment bolts to 37 to 44 N·m (27 to 33 ft-lb).

   Note: Ensure that the chains remain tight after all bolts are torqued.
9. Verify that you can raise the deck to the TRANSPORT position.
10. Remove the brackets.