Form No. 3324–750

TORO®

48” Dozer Blade

Garden Tractor

Model No. 79350–210000001 and Up

Parts Catalog

PROTOTYPE

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.


Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2000
All Rights Reserved

3324–750




Sheet No.:2

Frame Assembly

Ref. No.	Part No.	Qty.	Description
1	9321204	2	Pin–Clevis
2	3256–24	2	Washer–Flat
3	104659–01	1	Bracket–Axle
4	3231–25	2	Screw–CARR
5	105052	1	Link–Lift
6	283–2	2	Pin–Clevis
7	104–1289	1	Cable–Tension
8	3218–18	1	Nut–Jam
9	94–7782	1	Bracket – Cable End
10	3272–12	1	Pin–Cotter
11	4944	2	Plug
12	9156404	1	Nut–Lock
13	3216–7	1	Screw–HH
14	3272–11	1	Pin–Cotter
15	104338	1	Rod
16	9335124	1	Pin–Hair
18	9335054	2	Pin–Hair
19	325–4	1	Screw–HH
20	2412–32	3	R–Clamp–Throttle/Choke
21	104–5039–01	1	Frame
21:5	88–6520	1	Pin–Index
21:10	2354	1	Spring–Compression
21:11	3272–11	1	Pin–Cotter
22	321–6	4	Screw–HH
23	94–6686–01	1	Lever–Index

Ref. No.	Part No.	Qty.	Description
24	5359	1	Grip
25	98–1743	1	Lever
26	32146–17	4	Nut–Lock
27	104657	2	Plate–Latching
28	3231–11	4	Screw–CARR
29	3296–39	6	Nut–Lock, NI
30	9335044	2	Pin–Hair
31	7713	2	Spacer–Bracket
32	3697	2	Bracket–Rear Link Mounting

PROTOTYPE



Sheet No.:3

Blade Assembly

Ref. No.	Part No.	Qty.	Description
1	3296–39	5	Nut–Lock, NI
2	3231–1	5	Screw–CARR
3	93–1612–01	1	Plate – Blade Edge
4	78–1330–01	1	Blade ASM
5	88–2080–03	4	Lug–Spring
6	93–1611–03	2	Spring–Trip Return
7	3272–11	6	Pin–Cotter
8	5120	2	Rod–Blade Pivot
9	78–8760–01	1	Quadrant
10	92–8748	1	Decal–Attachment
11	4564	1	Rod–Lower Plated
12	9335124	1	Pin–hair

Ref. No.	Part No.	Qty.	Description

PROTOTYPE



PROTOTYPE