Form No. 3325-592

5, 7 and 11 Blade
Reelmaster® Cutting Unit
Model No. 01005—90001 and Up
Model No. 01007—90001 and Up
Model No. 01011—90001 and Up

Parts Catalog

Ordering Replacement Parts
To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers
Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers
Parts in service assemblies have reference numbers in the form **a:b.** The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity
In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y.** The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.

© The TORO Company — 2000
All Rights Reserved

Contents

Description	Page
Roller and Bracket Assembly	3
Gear Case Assembly	4
Reel and Bed Bar Assembly	6


Accessories

Description	Model / Part No.
Grass Dispersion Shield Kit	51-0800
Roller Scraper Kit	47-4540
Bearing Puller Service Tool	49-8060
C.E Internayional Kit (only on: 01005 & 01007	94-5327

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning
AR	as required
ASM	assembly
CARR	carriage
DEG	degrees
FH	flat head
GA	gauge
HF	hex flange
HH	hex head
HHF	hex head flange
HLH	hex lag head
HJ	hex jam
HOC	height-of-cut
HS	hex socket
HSBH	hex socket button head
HSFH	hex socket flat head
HSH	hex socket head
HWH	hex washer head
HWHTF	hex washer head thread forming
HYD	hydraulic
INC	incorporated
LH	left hand
NI	nylon insert
PPH	Phillips pan head
PTH	Phillips truss head
PTO	power take off
RH	right hand
SFH	slotted fillister head
SHH	slotted hex head
SQH	square head
SHWH	slotted hex washer head
SPH	slotted pan head
SRH	slotted round head
STD	standard
TAP	self tapping
TTH	Torx truss head
WH	wing head



T-0494


Roller and Bracket Assembly

Ref. No.	Part No.	Qty.	Description
1	11–5089	1	Bracket–Roller, RH (Incl. Ref. #2)
2	3–4010	2	Bushing ASM
3	47–4380	1	Nut–Roller, RH Adj.
4	5–4527	2	Washer–Thrust
5	3296–15	1	Nut–Lock
6	8–3990	1	Roller ASM (Incl. Ref. #5, 7–16)
7	4–5659	2	End Cap–Roller, Rear (Incl. Ref. #8)
8	302–5	2	Fitting–Grease
9	253–122	2	Seal
10	254–79	2	Bearing–Cup
11	254–78	2	Bearing–Cone
12	5–4523	2	Sleeve
13	253–117	2	Seal
14	8–3980	1	Shaft–Roller
15	47–7510	2	Washer–Nylon
16	3220–7	2	Nut–Jam
17	47–4390	1	Nut–Roller, LH Adj.
18	11–5079	1	Bracket–Roller, LH (Incl. Ref. #2)
19	3253–7	2	Washer–Lock
20	325–7	2	Screw–HH

Ref. No.	Part No.	Qty.	Description
*	100–4161	1	Kit–Roller, Rear (Incl. Ref. # 2, 5, 8–13, 15 & 16)

* Not illustrated

3325-592




Gear Case Assembly

Ref. No.	Part No.	Qty.	Description
1	11–8960	6	Fastener ASM
2	5–1460	2	Cover–Reel, Pinion
3	5–1458	2	Gasket
4	3–9117	1	Shaft–Idler, Pinion
*	3–9116	1	Shaft–Idler, Pinion
5	252–6	2	Bearing–Needle
6	12–1190	2	Pinion–Idler
7	3296–6	6	Nut–Lock
8	47–4470	1	Retainer–Ring, RH Ratchet
*	47–4480	1	Retainer–Ring, LH Ratchet
9	3–4170	1	Ring–Idler, RH Carrier
*	3–4160	1	Ring–Idler, LH Carrier
10	3–7445	6	Stud–Ring, Ratchet
11	95–1821	4	Spring–Compression
12	17–2520	6	Stud–Type, Drive
13	302–39	2	Fitting–Relief
14	3–3892	2	Bearing–Finger, Throwout
15	237–21	2	O–Ring
16	3283–1	2	Pin–Drive, Lock
17	5–1464	2	Handle–Ratchet, Throwout
18	68–7530	2	Rubber Bushing ASM
19	47–4430	2	Bushing–Flange

Ref. No.	Part No.	Qty.	Description
20	47–5640	2	Spacer–Rubber
21	47–4460	1	Bolt–Shoulder, Eccentric
*	47–4450	1	Bolt–Shoulder
22	11–9419	1	Case–Gear, LH (Incl. Ref. #12, 18, 2 & 3 on page 3)
23	3–3904	1	Finger–Throwout, RH Ratchet
*	3–3891	1	Finger–Throwout, LH Ratchet
24	281–3	2	Plug–Pipe
25	3219–10	2	Nut–Hex
26	3256–15	2	Washer–Flat
27	11–9409	1	Case–Gear, RH (Incl. Ref. #12, 18, 2 & 3 on page 3)
28	5–1457	2	Gear–Wheel, Drive
29	95–1828	2	Ring–Gear, Hub
30	84–8200	2	Seal–Oil
31	3262–3	12	Rivet–Head, Round
32	254–79	4	Bearing–Cup
33	254–78	4	Bearing–Cone
34	3–5002	2	Gasket
35	47–4060	2	Cover–Case, Gear
36	49–4100	2	Shaft–Axle, Stub

* Not illustrated




T-0495

Gear Case Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
37	3254–17	20	Washer–Lock, Int. Tooth
38	49–2040	20	Screw–Machine, Washer Head
39	3296–15	2	Nut–Lock
40	237–38	2	O–Ring
41	68–9970	2	Seal–Guard
*	13–3629	1	Kit–Overhaul
42	94–6305	1	Decal–Clutch, RH
*	94–6304	1	Decal–Clutch, LH

Ref. No.	Part No.	Qty.	Description

* Not illustrated




T-0496

Reel and Bed Bar Assembly

Ref. No.	Part No.	Qty.	Description
1	254–94	2	Bearing–Cone
2	254–72	2	Bearing–Cup
3	253–146	2	Seal–Oil
4	47–4250	2	Sleeve–Wear
5	47–4260	2	Slinger–Grass
6	11–5119	1	Reel ASM (Incl. Ref. #4 & 5) (only on: 01011)
*	11–6869	1	Reel ASM (Incl. Ref. #4 & 5) (only on: 01005)
*	11–6879	1	Reel Assembly (Incl. Ref. #4 & 5) (only on: 01007)
7	302–5	2	Fitting–Grease
8	322–1	2	Screw–HH
9	3290–244	2	Washer–Lock, Ext. Tooth
10	47–4300	1	Handle ASM
11	47–4420	2	Spacer–Sleeve, Adj.
12	47–4400	1	Arm–Spring
13	253–84	2	Seal–Grease
14	257–5	4	Washer–Thrust
15	257–6	2	Bearing–Thrust
16	47–4410	1	Retainer–Adj. Bearing Arm

Ref. No.	Part No.	Qty.	Description
17	32110–19	2	Screw–Set, Cone Point
18	3218–18	2	Nut–Jam
19	47–4080	1	Bar–Bed
20	3296–19	8	Nut–Lock
21	47–4440	2	Washer
22	47–6680	1	Bedknife (only on: 01011)
*	49–7660	1	Bedknife (only on: 01005 & 01007)
23	57–4910	11	Screw–Special
24	3296–57	1	Nut–Lock
25	47–4490	1	Pinion–Reel, LH
26	3296–62	1	Nut–Lock
27	68–7530	2	Rubber Bushing ASM
28	47–4530	2	Retainer
29	37–3490	2	Bracket–Drawbar
30	3253–21	4	Washer–Lock
31	323–6	4	Screw–HH
32	11–5069	1	Tube (Incl. Ref. #27 & 33)
33	47–4510	1	Shaft–Adjustment
34	47–5750	1	Decal–Reelmaster, 11 Blade (only on: 01011)

* Not illustrated



T-0496

Reel and Bed Bar Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
34	49–7580	1	Decal–Reelmaster, 5 Blade (only on: 01005)
*	49–7570	1	Decal–Reelmaster, 7 Blade (only on: 01007)
35	3257–3	1	Key
36	5–1463	1	Pinion–Reel, RH
37	3–8386	1	Nut–Pinion, Reel
38	5–4373	1	Spring–Compression
39	47–4420	2	Spacer–Adjustment, Sleeve
*†	49–8060	1	Puller–Bearing, Reel

Ref. No.	Part No.	Qty.	Description

* Not illustrated
† Optional equipment


TORO®