



## 5, 7 and 11 Blade Reelmaster<sup>®</sup> Cutting Unit

Model No. 01005—90001 and Up

Model No. 01007—90001 and Up

Model No. 01011—90001 and Up

## Parts Catalog

---

### Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

### Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

### Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number **6**, the tire by **6:1**, the valve by **6:2**, and the wheel by **6:3**. When you order the assembly identified by reference number **6**, you receive all parts identified by reference numbers **6:1**, **6:2**, and **6:3**. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

### Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number **37** are indicated.

## Contents

Description	Page	Description	Page
Roller and Bracket Assembly .....	3	Reel and Bed Bar Assembly .....	6
Gear Case Assembly .....	4		


## Accessories

Description	Model / Part No.	Description	Model / Part No.
Grass Dispersion Shield Kit .....	51-0800	C.E Internayional Kit	
Roller Scraper Kit .....	47-4540	(only on: 01005 & 01007 .....	94-5327
Bearing Puller Service Tool .....	49-8060		

## Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR .....	as required	HYD .....	hydraulic
ASM .....	assembly	INC .....	incorporated
CARR .....	carriage	LH .....	left hand
DEG .....	degrees	NI .....	nylon insert
FH .....	flat head	PPH .....	Phillips pan head
GA .....	gauge	PTH .....	Phillips truss head
HF .....	hex flange	PTO .....	power take off
HH .....	hex head	RH .....	right hand
HHF .....	hex head flange	SFH .....	slotted fillister head
HLH .....	hex lag head	SHH .....	slotted hex head
HJ .....	hex jam	SQH .....	square head
HOC .....	height-of-cut	SHWH .....	slotted hex washer head
HS .....	hex socket	SPH .....	slotted pan head
HSBH .....	hex socket button head	SRH .....	slotted round head
HSFH .....	hex socket flat head	STD .....	standard
HSH .....	hex socket head	TAP .....	self tapping
HWH .....	hex washer head	TTH .....	Torx truss head
HWHTF .....	hex washer head thread forming	WH .....	wing head




T-0494

## Roller and Bracket Assembly

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	11-5089	1	Bracket-Roller, RH (Incl. Ref. #2)	*	100-4161	1	Kit-Roller, Rear (Incl. Ref. # 2, 5, 8-13, 15 & 16)
2	3-4010	2	Bushing ASM				
3	47-4380	1	Nut-Roller, RH Adj.				
4	5-4527	2	Washer-Thrust				
5	3296-15	1	Nut-Lock				
6	8-3990	1	Roller ASM (Incl. Ref. #5, 7-16)				
7	4-5659	2	End Cap-Roller, Rear (Incl. Ref. #8)				
8	302-5	2	Fitting-Grease				
9	253-122	2	Seal				
10	254-79	2	Bearing-Cup				
11	254-78	2	Bearing-Cone				
12	5-4523	2	Sleeve				
13	253-117	2	Seal				
14	8-3980	1	Shaft-Roller				
15	47-7510	2	Washer-Nylon				
16	3220-7	2	Nut-Jam				
17	47-4390	1	Nut-Roller, LH Adj.				
18	11-5079	1	Bracket-Roller, LH (Incl. Ref. #2)				
19	3253-7	2	Washer-Lock				
20	325-7	2	Screw-HH				

\* Not illustrated




T-0495

## Gear Case Assembly

Ref. No.	Part No.	Qty.	Description
1	11-8960	6	Fastener ASM
2	5-1460	2	Cover-Reel, Pinion
3	5-1458	2	Gasket
4	3-9117	1	Shaft-Idler, Pinion
*	3-9116	1	Shaft-Idler, Pinion
5	252-6	2	Bearing-Needle
6	12-1190	2	Pinion-Idler
7	3296-6	6	Nut-Lock
8	47-4470	1	Retainer-Ring, RH Ratchet
*	47-4480	1	Retainer-Ring, LH Ratchet
9	3-4170	1	Ring-Idler, RH Carrier
*	3-4160	1	Ring-Idler, LH Carrier
10	3-7445	6	Stud-Ring, Ratchet
11	95-1821	4	Spring-Compression
12	17-2520	6	Stud-Type, Drive
13	302-39	2	Fitting-Relief
14	3-3892	2	Bearing-Finger, Throwout
15	237-21	2	O-Ring
16	3283-1	2	Pin-Drive, Lock
17	5-1464	2	Handle-Ratchet, Throwout
18	68-7530	2	Rubber Bushing ASM
19	47-4430	2	Bushing-Flange

Ref. No.	Part No.	Qty.	Description
20	47-5640	2	Spacer-Rubber
21	47-4460	1	Bolt-Shoulder, Eccentric
*	47-4450	1	Bolt-Shoulder
22	11-9419	1	Case-Gear, LH (Incl. Ref. #12, 18, 2 & 3 on page 3)
23	3-3904	1	Finger-Throwout, RH Ratchet
*	3-3891	1	Finger-Throwout, LH Ratchet
24	281-3	2	Plug-Pipe
25	3219-10	2	Nut-Hex
26	3256-15	2	Washer-Flat
27	11-9409	1	Case-Gear, RH (Incl. Ref. #12, 18, 2 & 3 on page 3)
28	5-1457	2	Gear-Wheel, Drive
29	95-1828	2	Ring-Gear, Hub
30	84-8200	2	Seal-Oil
31	3262-3	12	Rivet-Head, Round
32	254-79	4	Bearing-Cup
33	254-78	4	Bearing-Cone
34	3-5002	2	Gasket
35	47-4060	2	Cover-Case, Gear
36	49-4100	2	Shaft-Axle, Stub

\* Not illustrated




T-0495

### Gear Case Assembly (Continued)

Ref. No.	Part No.	Qty.	Description
37	3254-17	20	Washer-Lock, Int. Tooth
38	49-2040	20	Screw-Machine, Washer Head
39	3296-15	2	Nut-Lock
40	237-38	2	O-Ring
41	68-9970	2	Seal-Guard
*	13-3629	1	Kit-Overhaul
42	94-6305	1	Decal-Clutch, RH
*	94-6304	1	Decal-Clutch, LH

Ref. No.	Part No.	Qty.	Description

\* Not illustrated




T-0496

## Reel and Bed Bar Assembly

Ref. No.	Part No.	Qty.	Description
1	254-94	2	Bearing-Cone
2	254-72	2	Bearing-Cup
3	253-146	2	Seal-Oil
4	47-4250	2	Sleeve-Wear
5	47-4260	2	Slinger-Grass
6	11-5119	1	Reel ASM (Incl. Ref. #4 & 5) (only on: 01011)
*	11-6869	1	Reel ASM (Incl. Ref. #4 & 5) (only on: 01005)
*	11-6879	1	Reel Assembly (Incl. Ref. #4 & 5) (only on: 01007)
7	302-5	2	Fitting-Grease
8	322-1	2	Screw-HH
9	3290-244	2	Washer-Lock, Ext. Tooth
10	47-4300	1	Handle ASM
11	47-4420	2	Spacer-Sleeve, Adj.
12	47-4400	1	Arm-Spring
13	253-84	2	Seal-Grease
14	257-5	4	Washer-Thrust
15	257-6	2	Bearing-Thrust
16	47-4410	1	Retainer-Adj. Bearing Arm

Ref. No.	Part No.	Qty.	Description
17	32110-19	2	Screw-Set, Cone Point
18	3218-18	2	Nut-Jam
19	47-4080	1	Bar-Bed
20	3296-19	8	Nut-Lock
21	47-4440	2	Washer
22	47-6680	1	Bedknife (only on: 01011)
*	49-7660	1	Bedknife (only on: 01005 & 01007)
23	57-4910	11	Screw-Special
24	3296-57	1	Nut-Lock
25	47-4490	1	Pinion-Reel, LH
26	3296-62	1	Nut-Lock
27	68-7530	2	Rubber Bushing ASM
28	47-4530	2	Retainer
29	37-3490	2	Bracket-Drawbar
30	3253-21	4	Washer-Lock
31	323-6	4	Screw-HH
32	11-5069	1	Tube (Incl. Ref. #27 & 33)
33	47-4510	1	Shaft-Adjustment
34	47-5750	1	Decal-Reelmaster, 11 Blade (only on: 01011)

\* Not illustrated



T-0496

## Reel and Bed Bar Assembly (Continued)

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
34	49-7580	1	Decal-Reelmaster, 5 Blade (only on: 01005)				
*	49-7570	1	Decal-Reelmaster, 7 Blade (only on: 01007)				
35	3257-3	1	Key				
36	5-1463	1	Pinion-Reel, RH				
37	3-8386	1	Nut-Pinion, Reel				
38	5-4373	1	Spring-Compression				
39	47-4420	2	Spacer-Adjustment, Sleeve				
*†	49-8060	1	Puller-Bearing, Reel				

\* Not illustrated

† Optional equipment

