FORM NO. 95-4786 Rev. A

TORO®

MODEL NO. 44044 – 70001 & UP


OPERATOR'S MANUAL

TURF SWEEPER 4800

To understand this product for safety and optimum performance read this manual before starting the engine. Pay special attention to SAFETY INSTRUCTIONS highlighted by this symbol.



It means CAUTION, WARNING OR DANGER – personal safety instructions. Failure to comply with the instruction may result in personal injury.



FOREWORD

This operator's manual has instructions on safety, and operation, adjustments, and maintenance. Therefore, anyone involved with the product, including the operator, should read and understand this manual.
Major sections are:

1. **Safety Instructions**
2. **Specifications**
3. **Before Operating**
4. **Know Your Controls**
5. **Operating Instructions**
6. **Maintenance**
7. **Schematics**

This manual emphasizes safety, mechanical and general product information. **DANGER**, **WARNING**, and **CAUTION** identify safety messages. Whenever the triangular safety alert symbol appears, understand the safety message that follows. For complete safety instruction, read pages 4 – 7. **IMPORTANT** highlights special mechanical information and **NOTE** emphasizes general product information worthy of special attention.

⚠ WARNING ⚠

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Whenever you have questions or need service, contact your local Authorized TORO Distributor/Authorized TORO Landscape Contract Equipment Dealer. In addition to having a complete line of accessories and professional turf care service technicians, the distributor has a complete line of genuine TORO replacement parts to keep your machine operating properly. Keep your TORO all TORO. Buy genuine TORO parts and accessories.

OPTIONAL SPARK ARRESTER

In some places a spark arrester muffler must be used because of local, state, or federal regulations. The spark arrester is available from your Kohler engine dealer manufacturer (Part No. 25-189-02) and is approved by the United States Department of Agriculture and the United States Forest Service.

When the machine is used or operated on any California forest, brush, or grass covered land, a properly operating spark arrester must be attached to the muffler. The operator is violating state law, Section 4442 Public Resources Code if a spark arrester is not used.

TABLE OF CONTENTS

SAFETY INSTRUCTIONS ..... 4 – 6
SAFETY AND INSTRUCTION DECALS ..... 7 – 8
SPECIFICATIONS 9
LOOSE PARTS 10
BEFORE OPERATING ..... 10 – 13
- Grass Baffle 10
- Check Tire Pressure 10
- Check Crankcase Oil 10
- Fill Fuel Tank 11
- Check Hydraulic System Oil 12
- Check Torque Of Wheel Nuts 13

KNOW YOUR CONTROLS ..... 13 – 16
OPERATING INSTRUCTIONS ..... 17 – 19
LUBRICATION 20
MAINTENANCE ..... 21 – 30
- Changing Engine Oil and Filter 21
- General Precleaner and Air Cleaner Maintenance 22
- Clean and Lubricate Foam Precleaner 22
- Service Air Cleaner Paper Element 23
- Clean Air Intake/Cooling Areas 23
- Check Spark Plug Gap and Condition 23
- Changing Hydraulic Oil and Filter 24
- Checking Hydraulic Lines and Hoses 25
- Fuel Filter Replacement 25
- Sweeper Reel Height and Belt Adjustment 25
- Belt Removal/Installation 27
- Belt Tensioning/Belt Life 27
- Adjusting Parking Brake 27
- Adjusting Traction Pedal 27
- Steering Chain Adjustment 28
- Replacing Sweeper Reel Fingers 28
- Hopper and Reel Clean-out 29
- Wheel Motor Axle Nut Torque 29
- Battery Storage 29
- Battery Care 29

TROUBLESHOOTING 30
HYDRAULIC SCHEMATIC 31
ELECTRICAL SCHEMATIC 32
MAINTENANCE SCHEDULE 33
MAINTENANCE RECORD 34
STORAGE 35
IDENTIFICATION AND ORDERING 35
THE TORO COMMERCIAL PRODUCTS TWO YEAR LIMITED WARRANTY ..... Back Cover

SAFETY INSTRUCTIONS

Hazard control and accident prevention are dependent upon the awareness, concern, and proper training of the personnel involved in the operation, transport, maintenance, and storage of the machine. Improper use or maintenance of the machine can result in injury or death. To reduce the potential for injury or death, comply with the following safety instructions.

SUPERVISOR'S RESPONSIBILITIES

1. Ensure operators are thoroughly trained and familiar with the Operator's Manual and all decals on the machine.

2. Establish your own special procedures and work rules for unusual operating conditions (e.g., slopes too steep for machine operation, adverse weather conditions, etc.).

BEFORE OPERATING

3. Read, understand and follow the instructions in the Operator's Manual and on the machine before starting. Become familiar with all controls and know how to stop quickly. A free replacement manual is available by sending complete Model and Serial Number to:

The Toro Company
8111 Lyndale Avenue South
Minneapolis, Minnesota 55420-1196

4. **NEVER** allow children to operate the machine. **NEVER** allow adults to operate the machine without proper instruction. Only trained operators who have read this manual should operate this machine.

5. **NEVER** operate the machine while under the influence of drugs or alcohol.

6. Become familiar with the controls and know how to stop the engine quickly.

7. Keep all shields, safety devices, and decals in place. If a shield, safety device or decal becomes damaged, malfunctioning or illegible, repair or replace it before operation is commenced. Also tighten loose nuts and bolts to ensure machine is in safe operating condition.

8. Always wear substantial shoes. Do not operate machine while wearing sandals, tennis shoes, sneakers or when barefoot. Do not wear loose fitting clothing that could get caught in moving parts and possibly cause injury. Wearing safety glasses, safety shoes, long pants and a helmet is advisable and required by some local ordinances and insurance regulations.

9. Do not alter this equipment in any manner which may cause hazardous conditions.

10. Safety interlock switches are for the operator's protection. Disconnected or malfunctioning safety interlock switches could allow the machine to operate in an unsafe manner and may cause personal injury

A. Do not disconnect the safety interlock switches.
B. Check operation of the switches daily to be sure the interlock system is operating correctly.
C. If a switch is malfunctioning replace it before operating the machine.
D. Replace switches every 2 years to be sure of maximum safety.

11. In certain conditions gasoline is extremely flammable and highly explosive. A fire or explosion from gasoline can burn you, others, and cause property damage. Caution must be used when storing or handling gasoline.

A. Do not fill fuel tank while engine is running, hot or when machine is in an enclosed area. Vapors may build up and be ignited by a spark or flame source many feet away.
B. **DO NOT SMOKE** while filling the fuel tank to prevent possibility of explosion.
C. Always fill fuel tank outside and wipe up any spilled gasoline before starting engine.
D. Use a funnel or spout to prevent spilling gasoline and fill tank to about 1 inch (25 mm) below the filler neck.
E. Store gasoline in a clean safety approved container and keep the cap in place on the container.
F. Keep gasoline in a cool, well ventilated place; never in an enclosed area such as a hot storage shed.
G. To assure volatility, do not buy more than a 30 day supply of gasoline.

WHILE OPERATING

12. Rotating parts can cause serious personal injury. Keep hands and feet away from sweeper reels while machine is running. Keep hands, feet, hair, and clothing away from all moving parts to prevent injury. **NEVER** operate the machine with covers, shrouds, or guards removed.

13. Do not run the engine in a confined area without adequate ventilation. Exhaust fumes are hazardous and could possibly be deadly.

SAFETY INSTRUCTIONS

14. Operator should be seated when starting the engine and remain seated whenever the machine is in motion. Operator should keep both hands on steering wheel whenever possible.

15. DON'T TAKE AN INJURY RISK! When a person or pet appears unexpectedly in or near the sweeping area **STOP SWEEPING**. Careless operation, combined with terrain angles, ricochets, or missing or damaged guards can lead to thrown object injuries. Do not resume sweeping until area is cleared.

16. NEVER carry passengers.

17. ALWAYS look to the rear of machine before backing up and assure no one is behind the machine.

18. When starting the engine:

A. Sit on operator's seat and engage parking brake.
B. Make sure traction pedal is in neutral and Reel PTO Engagement handle is in the OFF position (disengaged).
C. After engine is started, release parking brake and keep foot off traction pedal. Machine must not move. If movement is evident, the neutral mechanism is adjusted incorrectly; shut off engine and adjust until machine does not move when traction pedal is released (refer to Adjusting Traction Pedal, page 27). If engine does not crank, check interlock switch connections.

19. Do not touch engine, muffler or muffler shield while engine is running or soon after it has stopped because these areas may be hot enough to cause a burn.

20. Tip over can cause serious injury or death.

A. **NEVER** operate on steep slopes.
B. Sweep slopes up and down, never across the face.
C. When going uphill or downhill, do not stop or start suddenly.
D. Stay alert for holes in the terrain or other hidden hazards. To avoid tipping or loss of control, do not drive close to a ditch, creek or drop off.
E. If engine stalls or machine loses headway and cannot make it to the top of a slope, do not turn machine around. Always back slowly straight down the slope.

21. Using the machine demands attention. Failure to operate machine safely may result in an accident, tip over of the machine, and possible serious injury or death. Drive carefully. To prevent tipping or loss of control:

A. Operate only in daylight or when there is good artificial light.
B. Drive slowly.
C. Watch for holes or other hazards.
D. Use care when backing machine.
E. Do not drive close to a sand trap, ditch, tall curb, creek, or other hazard.
F. Reduce speed when making sharp turns and when turning on a hillside.
G. Avoid sudden stops and starts.
H. Do not go from reverse to forward or forward to reverse without first coming to a complete stop.
I. Do not attempt sharp turns or abrupt maneuvers or other unsafe driving actions that may cause loss of control.
J. Watch out for traffic when near or crossing roads. Always yield the right-of-way.

22. Operator must be skilled and trained in how to drive on hillsides. Failure to use caution on slopes or hills may cause loss of control possibly resulting in personal injury or death.

23. Before getting off seat:

A. Move traction pedal to neutral position and remove foot from pedal.
B. Set parking brake and set Reel PTO Engagement handle to the OFF position (disengaged).
C. Shut engine off and remove key from ignition switch. Wait for all movement to stop before getting off seat.

24. Whenever the machine is left unattended, be sure engine is stopped, Reel PTO Engagement handle is in OFF position (disengaged), and key is removed from ignition.

WHILE DUMPING

25. Moving hopper door and dumping debris can cause serious injury. Stay clear of hopper while machine is backing up or dumping.

26. Keep bystanders a safe distance from hopper when operating to dump debris or when opening and closing hopper door.

27. Under rare circumstances wet, compressed grass clippings may generate heat. Always empty the hopper before storing the unit.

28. Raising and lowering of hopper door could cause injury to bystanders or pets. Keep bystanders and pets a safe distance from hopper when operating to dump debris or when opening and closing hopper door.

29. To avoid the risk of electrical shock, dump hopper only in area clear of overhead wires and other obstructions.

30. NEVER dump hopper on a slope. Always dump hopper on level ground.

31. Set Reel PTO Engagement handle to OFF (disengaged) before dumping.

MAINTENANCE

32. Hydraulic fluid escaping under pressure can penetrate skin and do serious damage. Keep body and hands away from pin hole leaks or nozzles that eject high pressure hydraulic fluid. Use cardboard or paper to find hydraulic leaks. Fluid accidentally injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.

33. Accidental starting of engine by others while maintenance is being performed could cause injury. Before servicing or making adjustments to the machine:

A. Stop engine.
B. Set parking brake.
C. Remove key from ignition switch.

34. Unexpected movement of the machine caused by an improperly adjusted traction pedal may cause personal injury. When foot is removed from traction pedal, the machine should stop; it must not move in either direction. If machine does move, do not operate until neutral assembly has been repaired or adjusted.

35. Accidental movement of machine due to parking brake not being set may cause personal injury. The hydrostatic transmission will not, at any time, act as a parking brake for the machine. To engage parking brake, pull back on lever. Whenever the engine is shut off, the parking brake must be engaged to prevent accidental movement of the machine.

36. Engine must be running so final adjustment of the traction adjustment cam can be performed. To guard against possible personal injury, keep hands, feet, face, and other parts of the body away from the muffler, other hot parts of the engine, and other rotating parts.

37. Perform only those maintenance instructions described in this manual. If major repairs are ever needed or assistance desired, contact an Authorized TORO Distributor/Authorized TORO Landscape Contract Equipment Dealer.

38. Failure to maintain proper torque could result in failure or loss of wheel and may result in personal injury.

A. Torque wheel motor axle nuts to 200 – 400 ft. lb.
B. Torque rear wheel lug nuts to 45 – 55 ft. lb.

39. To reduce potential fire hazard, keep the engine free of excessive grease, grass, leaves and accumulations of dirt.

40. Make sure all hydraulic line connectors are tight, and all hydraulic hoses and lines are in good condition before applying pressure to the system.

41. Performing maintenance on machine not properly supported with jack stands may cause machine to fall and could cause injury.

42. Do not over speed the engine by changing the governor settings. Maximum engine rpm with no load is 3000 RPM. To ensure safety and accuracy, have an Authorized TORO Distributor/Authorized TORO Landscape Contract Equipment Dealer check maximum engine speed with a tachometer.


43. Engine must be shut off before checking oil or adding oil to the crankcase.

44. If wheel is removed for maintenance or repairs on the wheel, brake, or hydraulic wheel motor, when remounting wheel **ALWAYS** ensure that the wheel motor axle nut is torqued to 200 – 400 ft. lb.


45. To be sure of optimum performance and safety, always purchase genuine TORO replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous. Altering this machine in any manner may affect the machine's operation, performance, or durability, or its use may result in injury or death. Such use could void product warranty of The Toro Company.

46. NEVER attempt to service gas springs located on hopper and hopper door. These springs are under high loads and improper handling can result in bodily harm. Special tools are required to replace worn or damaged gas springs, contact an Authorized TORO Distributor/Authorized TORO Landscape Contract Equipment Dealer.


SAFETY AND INSTRUCTION DECALS



On floorboard
Part No. 01-506-0090



On upper crossmember
Part No. 95-0387



On control panel
Part No. 95-0390



On control panel
Part No. 95-0370




On control panel
Part No. 95-0371



On control panel
Part No. 87-6020




On fuel tank
Part. No. 53-4420




On upper crossmember
Part No. 95-0388


SAFETY AND INSTRUCTION DECALS



On LH reel plate and RH reel plate belt guard
Part No. 95-3087




On inside of drive belt shield
Part No 95-4750



On control panel
Part. No. 95-0389




On floorboard under
battery cover
Under belt guard
Part No. 88-8950



On gas tank
Part No. 27-7310



On control panel
Part No. 95-0383




On control Panel
Part No. 95-0384



Riveted to engine heat shield
Part No. 80-9350



On gas springs
Part No. 85-7490



On battery cover
On lower belt guard
Part No. 67-5360

SPECIFICATIONS

Type: Three wheeled, front steer, rear drive, one person ride-on turf sweeper with welded steel frame and integral hopper for collecting debris.

Engine:
Manufacturer — Kohler, Model CH18S, air cooled, 4 cycle.
Horsepower — 18 @ 3600 RPM.
Max. Torque — 30 ft. lb. @ 2500 RPM.
Compression Ratio — 8.5:1.
Displacement — 38.1 cu. in. (624 CC).
Oil Capacity w/filter — 2.1 quarts (2 liters).
Governor — Mechanical.
Governor Limit — 3000 RPM.
Idle Speed — 1200 RPM.
Air Cleaner — High density paper element with oiled foam precleaner.
Fuel Filter — 15 micron in-line filter.

Battery: 12 volt with 370 cold cranking amps. (CCA) at 0°F. Type 24.

Fuel System: 5 gallon (18.9 liter) tank.

Electrical: Type 24. 12 volt with 370 Cold Cranking Amps (CCA) at 0° F.
Engine circuit is fused at 20 amps and ignition circuit is fused at 5.0 amps.

Traction System:
Sundstrand Series 15 pump coupled to Parker/Ross Model MB 10 wheel motors.
Filtration — 25 micron suction line filter (replaceable spin on element).
Foot pedal control with cable to ramped neutraling device on hydrostatic pump with eccentric neutral adjust.

Controls: Throttle, choke, Reel PTO Engagement handle, parking brake, hopper release handle, and ignition switch are all hand-operated. Forward/reverse traction pedal is foot operated.

Gauges: Hour meter, hydraulic vacuum gauge, and engine oil pressure warning light.

Reel Drive: Slack/Tight belt with idler and mechanical Reel PTO Engagement handle to lower fingers (2 heights). Sweeping pick-up with two counter-rotating finger reels, baffles and skirts. Reels rotate at 1100 RPM, and effectively pick up light debris on turf up to 5 mph.

Steering: Manual, 14 in. soft touch, 3 position tilt steering wheel, 6 to 1 ratio.

Brakes: Rear 6 in. drums with hand lever actuated to dual cables.

Tires, Wheels:
Front (1) — 18 x 8.5 – 8 in. turf tread.
Rear (2) — 18 x 9.5 – 8 in. ribbed tread.
All tires 4 ply rating, tubeless type.

Seat: High-back cushion with slide adjust.

Interlock Switches: Prevents engine starting if traction pedal or Reel PTO Engagement handle are engaged. Stops engine if operator leaves seat with either traction pedal or PTO switch engaged.

Hopper: Stationary, 1.25 cu. yd. capacity, with deflectors and grass filling baffles. Gas strut supported rear dumping door, with integral discharge duct and wire mesh screen for directing dust and air away from operator.

General Specifications (approx.):
Weight — 1600 lb.
Payload/Operator — 740 lb.
Ground Speed — 6.5 mph.
Width Overall — 70.0 in.
Height: Overall — 67.0 in.
Height: Overall (with optional ROPS) — 86.0 in.
Length Overall: — 111.0 in.
Curb Clearance — 4 in.

OPTIONAL EQUIPMENT

ROPS/Seat Belt Package: — Available from Authorized TORO Distributor/Authorized TORO Landscape Contract Equipment Dealer
SPARK ARRESTOR — Kohler Part No. 25-189-02

Specifications and design subject to change without notice.

LOOSE PARTS

DESCRIPTION	QTY.	USE
Operator's Manual	2	Read before operating machine.
Kohler Engines Owner's Manual	1	Read before operating machine.
Parts Catalog	1	
Registration Card	1	Fill out and return to TORO.

BEFORE OPERATING

GRASS BAFFLE

The sweeper comes with a hopper baffle extension installed. This extension greatly enhances the filling capacity of the hopper. You may find that the particular debris that you are sweeping tends to fall back into the hopper inlet and clogs the reels. When this occurs removal of the extension should alleviate hopper clogging. If you are sweeping fine dry material such as thatch or grass clippings the baffle extension should be used. When sweeping larger debris such as oak leaves you may prefer to remove the extension.

1. To remove the hopper baffle extension, remove the (5) bolts. Store the fasteners and the extension in a safe location.

CHECK TIRE PRESSURE

Check tire pressure every eight hours or daily to assure proper levels.

1. With lower air pressure, turf compaction and tire marks are minimized. Optimum pressure is 10 – 15 psi on front and rear tires. Lower pressure should not be used for heavy payloads or tire damage may result. Do not exceed the maximum pressure. Maximum air pressure in front tire is 22 psi and rear tires is 24 psi.

IMPORTANT: When replacing tires, use only replacements approved for the Turf Sweeper. Use of tires not approved may cause turf damage.

CHECK CRANKCASE OIL (Fig. 1)

The engine is shipped with 2.1 quarts (2 liters) of oil (with filter) in the crankcase; however, level of oil must be checked before the engine is first started.

1. Position the sweeper on a level surface and make sure engine is off.

2. Remove the dipstick and wipe it with a clean rag. Push dipstick down into the tube and ensure it is fully seated. Pull dipstick out of the tube and check level of oil.




Figure 1
1. Dipstick 2. Filler cap

3. Install dipstick into tube.

4. If oil is low, using a clean rag, clean area around oil fill cap. Remove cap and add oil until level is up to, but not over the F mark on the dipstick. Add the oil slowly and check the level often during this process. DO NOT OVERFILL. The engine requires high-quality detergent oil having the American Petroleum Institute (API) "service classification" SG or SH. Oil viscosity (weight) must be selected according to average anticipated ambient temperature. Temperature/viscosity recommendations are as follows:

A. Above 0°F (-18°C) – Use 10W-30 or 10W-40.
B. Below 32°F (0°C) – Use 5W-20 or 5W-30.

NOTE: Using other than service class SG or SH oil or extending oil change intervals longer than recommended can cause engine damage.

IMPORTANT: Check level of oil after every 5 hours of operation or daily. Change oil and filter after every 50 hours of operation. Change oil and filter

more frequently when engine is operated in extremely dusty or dirty conditions.

FILL FUEL TANK WITH GASOLINE (Fig. 2)

DANGER

IN CERTAIN CONDITIONS GASOLINE IS EXTREMELY FLAMMABLE AND HIGHLY EXPLOSIVE. A FIRE OR EXPLOSION FROM GASOLINE CAN BURN YOU, OTHERS, AND CAUSE PROPERTY DAMAGE.

- **Caution must be used when storing or handling gasoline.**
  - **Do not fill fuel tank while engine is running, hot or when machine is in an enclosed area. Vapors may build up and be ignited by a spark or flame source many feet away.**
  - **To prevent the possibility of explosion, DO NOT SMOKE while filling the fuel tank.**
  - **Always fill fuel tank outside and wipe up any spilled gasoline before starting engine.**
  - **Use a funnel or spout to prevent spilling gasoline before starting engine. Fill tank to about 1 inch (25 mm) below the filler neck.**
  - **Store gasoline in a clean safety approved container and keep the cap in place on the container.**
  - **Keep gasoline in a cool, well ventilated place; never in an enclosed area such as a hot storage shed.**
  - **To assure volatility, do not buy more than a 30 day supply of gasoline.**
- **Gasoline is a fuel for internal combustion engines; therefore, do not use it for any other purpose. Since many children like the smell of gas, keep it out of their reach because the fumes are explosive and dangerous to inhale.**

Fuel Type — For best results use only clean, fresh, **UNLEADED** gasoline with a pump sticker octane rating of 87 or higher. In countries using the Research method, it should be 90 octane minimum.

THE TORO COMPANY STRONGLY RECOMMENDS THE USE OF FRESH CLEAN, UNLEADED REGULAR GRADE GASOLINE IN TORO GASOLINE POWERED PRODUCTS. UNLEADED GASOLINE BURNS CLEANER, EXTENDS LIFE, AND PROMOTES GOOD STARTING BY REDUCING THE BUILD-UP OF COMBUSTION CHAMBER DEPOSITS.

NOTE: Gasoline/Alcohol Blends — Gasohol (up to 10% ethyl alcohol, 90% unleaded gasoline by volume) may be used. Do not use other gasoline/alcohol blends.

NOTE: Gasoline/Ether Blends — Methyl Tertiary Butyl Ether (MTBE) and unleaded gasoline blends (up to a maximum of 15% MTBE by volume) may be used. Do not use other gasoline/ether blends.

1. Using a clean rag, clean area around fuel tank cap.

2. Remove the cap from the fuel tank and fill the 5 gallon tank to within 1 inch (25 mm) from the top with unleaded gasoline. Install fuel cap tightly.




Figure 2
1. Fuel tank cap

2. Wipe up any gasoline that may have spilled to prevent a fire hazard.

CHECK HYDRAULIC SYSTEM OIL (Fig. 3)

DANGER

HYDRAULIC FLUID ESCAPING UNDER PRESSURE CAN PENETRATE SKIN AND DO SERIOUS DAMAGE.

- **Keep body and hands away from pin hole leaks or nozzles that eject high pressure hydraulic fluid. Use cardboard or paper to find hydraulic leaks. Fluid accidentally injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.**

Check level of hydraulic fluid before engine is first started and daily thereafter. The hydraulic system is designed to operate on Mobil DTE 13M or equivalent ISO VG 32 wide-temperature, shear-stable hydraulic fluid with controlled low-temperature flow properties and anti-wear protection. The reservoir is filled at the factory with approximately 28 quarts of Mobil DTE 13M hydraulic fluid. Hydraulic oil viscosity (weight) must be selected according to average anticipated ambient temperature. Temperature/viscosity recommendations are as follows:

EXPECTED AMBIENT TEMPERATURES		
Recommended Oil	Start-Up	Average Daily
Mobil DTE 13M or equivalent ISO VG 32	Less than 40°F – 50°F (4.5°C – 10°C)	Less than 80° (26.7°C)
Mobil DTE 26 or equivalent ISO VG 68	Greater than 60°F – 70°F (4.5°C – 10°C)	Greater than 80° (26.7°C)

IMPORTANT: Using Mobil DTE 26 or equivalent ISO VG 68 hydraulic oil when temperature at start-up is less than 40°F (4.5°C) could cause serious hydraulic system damage.

1. Position the sweeper on a level surface and make sure engine is off.

2. Remove dipstick cap (located under operator's seat) from filler neck and wipe it with a clean rag. Insert dipstick cap onto filler neck; then remove it and check level of oil. If level is below the L mark on dipstick add sufficient hydraulic fluid to bring to the F mark. **DO NOT OVERFILL.**




Figure 3
1. Dipstick cap

BEFORE OPERATING

IMPORTANT: To prevent system contamination, clean top of hydraulic oil containers before opening. Assure pour spout and funnel are clean. When adding oil to the hydraulic system, use a funnel with a fine screen - 200 mesh - and ensure funnel and oil are clean. This procedure prevents accidental contamination of the hydraulic oil which will damage the hydraulic system.

CHECK TORQUE OF WHEEL NUTS (Fig. 4)

WARNING

Failure to maintain proper torque could result in failure or loss of wheel and could result in personal injury. Torque rear wheel lug nuts to 45 – 55 ft. lb.




Figure 4
1. Lug nuts

KNOW YOUR CONTROLS

Choke (Fig. 5) — To start a cold engine, move the choke control forward to close the choke. After engine starts, regulate choke to keep engine running smoothly. As soon as possible, move the choke backwards to open the choke. A warm engine requires little or no choking.

Throttle Control (Fig. 5) — Throttle is used to operate engine at various speeds. Moving throttle forward increases engine speed; backwards decreases engine speed. The throttle regulates the speed of the sweeper reels and in conjunction with traction pedal controls ground speed of the sweeper.

Engine Oil Pressure Warning Light (Fig. 5) — Light glows if engine oil pressure drops below a safe level while engine is running. If light flickers or remains ON, stop machine, turn off engine and check oil level. If oil level is low, but adding oil does not cause light to go out when engine is restarted, turn off engine immediately and contact your local Authorized TORO Distributor/Authorized TORO Landscape Contract Equipment Dealer for assistance.

Ignition Key Switch (Fig. 5) — The key switch, which is used to start and stop the engine, has three positions: OFF, RUN, and START. Rotate key clockwise (START) to engage starter motor. When engine starts, release key and it will move automatically to the ON position. To shut engine off, rotate key counterclockwise to the OFF position.

Fuse: (Fig. 5) — Provides 5.0 amps ignition circuit protection. If fuse is blown the engine will not crank.

Hour Meter (Fig. 5) — Indicates total hours of machine operation. The hour meter starts to function whenever the key switch is rotated to the ON position.

Reel PTO Engagement Handle (Fig. 5) — The engagement of the sweeper reels is done with the Reel PTO Engagement handle. The handle also sets the height of the fingers. There are two settings for finger height. The height of the fingers is set so the fingers touch the top of the turf. The first setting will set the fingers at 1-1/4 inch from the surface. The second setting sets the fingers at 5/8 inch from the surface.

Hydraulic Vacuum Gauge (Fig. 5) — When the hydraulic oil filter becomes dirty the vacuum level within the hydraulic system will increase. Check vacuum gauge after each day's operation and before shutting off engine (refer to Changing Hydraulic Oil and Filter, page 24).

KNOW YOUR CONTROLS




Figure 5

1. Throttle Control
2. Choke
3. Reel PTO Engagement Handle
4. Engine Oil Pressure Warning Light
5. Parking Brake
6. Fuse
7. Hour Meter
8. Hydraulic Vacuum Gauge
9. Tow Valve Knob
10. Hydraulic Oil Filter
11. Ignition Key Switch

KNOW YOUR CONTROLS

Tow Valve Knob (Fig. 5) — The tow valve knob is located in the front of the hydraulic pump. With the knob turned fully clockwise the machine is in the operating position. With the knob turned 1/2 turn counterclockwise the machine is in towing position. After completion of towing operation, and before starting engine, close tow valve securely by rotating fully clockwise. Do not exceed 5 – 8 ft. lb. torque.

Parking Brake (Fig. 5) — Whenever the engine is shut off, the parking brake must be engaged to prevent accidental movement of the machine. To engage the parking brake, pull back on lever. To release the parking brake push forward on lever. Make sure parking brake is released before moving machine. If the machine is parked on a steep grade, make sure parking brake is applied.

Fuse: (Fig. 6) — Mounted on support behind engine. Provides 20 amps engine circuit protection. If fuse is blown the engine will not crank.




Figure 6

1. Fuse

Tilt Steering Lever (Fig. 7) — Lever on left side of steering tower. Lift lever to adjust steering wheel to desired fore or aft operating position and release lever to lock in place.

Seat Adjusting Lever (Fig. 7) — To adjust fore and aft position of seat, move lever on left side of seat outward, slide seat to desired position and release lever so it will lock in position.




Figure 7

1. Tilt Steering Lever
2. Seat Adjusting Lever

CAUTION

UNEXPECTED MOVEMENT OF THE MACHINE CAUSED BY AN IMPROPERLY ADJUSTED TRACTION PEDAL MAY CAUSE PERSONAL INJURY.

- **When foot is removed from traction pedal, the machine should stop; it must not move in either direction. If machine does move, do not operate until neutral assembly has been repaired or adjusted; refer to Adjusting Traction Pedal, page 27.**




Figure 8
1. Traction Pedal

Traction Pedal (Fig. 8) — The traction pedal is foot operated and is used to make the machine move forward, backward, and to stop the machine. Using the heel and toe of the right foot, depress top of pedal to move forward and bottom of pedal to move rearward. To stop machine remove foot from pedal. Ground speed is proportionate to how far pedal is depressed. For maximum ground speed with no load, traction pedal must be fully depressed while throttle is in full position. Allowing pedal to move to neutral position will stop machine.

Maximum forward speed is approximately 6.5 mph (10.5 Km/hr). Maximum forward speed while sweeping is 5 mph. To get maximum power under heavy load or when ascending a hill, have throttle in full position while depressing traction pedal slightly to keep engine rpm high. When engine rpm begins to decrease, release traction pedal slightly to allow rpm to increase. When sweeping wet debris or a thick layer of material, slower speeds may need to be used.

CAUTION

ACCIDENTAL MOVEMENT OF MACHINE DUE TO PARKING BRAKE NOT BEING SET MAY CAUSE PERSONAL INJURY.

- **The hydrostatic transmission will not, at any time, act as a parking brake for the machine. To engage parking brake, pull back on lever.**
- **Whenever the engine is shut off, the parking brake must be engaged to prevent accidental movement of the machine.**

Hopper Door Release Handle (Fig. 9) — The hopper is dumped manually with the Hopper Door Release Handle.




Figure 9
1. Hopper Door Release Handle
2. Hopper Door Locking Knob

OPERATING INSTRUCTIONS

STARTING/STOPPING ENGINE

WARNING

ROTATING PARTS CAN CAUSE SERIOUS PERSONAL INJURY.

- Keep hands and feet away from sweeper reels while machine is running.
- Keep hands, feet, hair, and clothing away from all moving parts to prevent injury.
- NEVER operate the machine with covers, shrouds, or guards removed.

1. Place the unit on a level surface and apply the parking brake.

2. Remove foot from traction pedal and make sure pedal is in neutral position.

3. With the throttle 1/2 open and the choke closed insert key into ignition switch and rotate it clockwise to start engine. Release key when engine starts and open the choke gradually.

NOTE: Do not run starter motor more than 10 seconds at a time or premature starter failure may result. If engine fails to start after 10 seconds, turn key to OFF position, recheck controls and procedure, wait 60 seconds and repeat starter operation.

4. When engine is started for the first time, after engine oil change, hydraulic oil change or hydraulic service work, operate the machine in forward and reverse for one to two minutes. Also operate the Reel PTO Engagement and Hopper Door Release to verify proper operation of all parts.

5. Turn steering wheel to the left and right to check steering response. Shut off engine and check fluid levels, check for oil leaks, loose parts and any other noticeable malfunctions.

CHECKING INTERLOCK SYSTEM

The purpose of the safety interlock system is to prevent the engine from cranking or starting unless the traction pedal is in neutral and the Reel PTO Engagement handle is in the OFF (disengaged) position. In addition, the engine will stop when the Reel PTO is engaged or the traction pedal is depressed with the operator off the seat. Indications of a disconnected or malfunctioning interlock switch are:

A. A disconnected or malfunctioning safety interlock switch could allow the engine to be started when the traction pedal is not in the neutral position or the Reel PTO Engagement handle is in the HIGH or LOW (engaged) position.

B. A disconnected or malfunctioning safety interlock switch could allow the engine to continue running when the Reel PTO Engagement handle is in the HIGH or LOW (engaged) position or the traction pedal is depressed with the operator off the seat.

CAUTION

SAFETY INTERLOCK SWITCHES ARE FOR THE OPERATOR'S PROTECTION. DISCONNECTED OR MALFUNCTIONING SAFETY INTERLOCK SWITCHES COULD ALLOW THE MACHINE TO OPERATE IN AN UNSAFE MANNER AND MAY CAUSE PERSONAL INJURY.

- Do not disconnect the safety interlock switches.
- Check operation of the switches daily to be sure the interlock system is operating correctly.
- If a switch is malfunctioning, replace it before operating the machine.
- Replace switches every 2 years to be sure of maximum safety.

1. Sit on operator's seat and engage parking brake.

2. Move the Reel PTO Engagement handle to the OFF position and remove foot from traction pedal (neutral position).

3. Rotate the ignition key to START. Engine should crank. If engine cranks, proceed to step 4. If engine fails to crank, there may be a malfunction in the interlock system.

4. Raise off the seat and position the Reel PTO engagement handle to either the HIGH or LOW position while the engine is running. The engine should stop within 2 seconds. If the engine stops the switch is operating correctly; proceed to step 5. If the engine does not stop, there is a malfunction in the interlock system.

5. Raise off the seat and depress the traction pedal while the engine is running and the Reel PTO is disengaged. The engine should stop within 2 seconds. If the engine stops, the switch is operating correctly; continue operation. If the engine does not stop, there is a malfunction in the interlock system.

OPERATING INSTRUCTIONS

OPERATING CHARACTERISTICS

Practice driving the TURF SWEEPER 4800 before initial operation because the hydrostatic transmission and its characteristics are different than some turf maintenance machines. Some points to consider when operating the sweeper are the engine speed, transmission speed, and the load on the sweeper reels.

The engine provides power to both the hydrostatic transmission and the sweeper reels. An increasing load on the hydrostatic transmission, such as hill climbing or a full hopper, will result in less power available to the sweeper reels, thereby decreasing the efficiency of debris pickup. To maintain enough power for the sweeper reels while operating, regulate traction pedal to keep engine speed high and somewhat constant. This allows the engine to provide sufficient power to the sweeper reels while maintaining a satisfactory ground speed. By contrast, pushing down too far on the traction pedal will increase load on the engine and decrease the power available to the sweeper reels.

A good rule to follow is: decrease ground speed as the load on the sweeper reels increases; and increase ground speed as load on the sweeper reels decreases. This allows the engine, working with the transmission, to maintain the proper ground speed while maintaining a high sweeper reel speed necessary for efficient pickup. Allow traction pedal to move upward as engine speed decreases, and depress pedal slowly as speed increases. By comparison, when driving from one work area to another—with no load and sweeper reel disengaged—have throttle in the full position and depress traction pedal slowly but fully to attain maximum ground speed. Sweeping, in some instances, can be improved by slower ground speed.

Before stopping the engine, disengage all controls and move the throttle to the slow position. Moving the throttle to the slow position reduces high engine speed, noise and vibration. Allow the engine to idle for a few seconds then turn ignition key OFF to stop engine.

PUSHING OR TOWING SWEEPER

In case of an emergency, the sweeper can be pushed or towed for a short distance. However, TORO does not recommend this as standard procedure.

IMPORTANT: Do not push or tow the sweeper faster than 2 – 3 mph because the drive system may be damaged. If sweeper must be moved a considerable distance, transport it on a truck or trailer.

1. Locate the tow valve knob in the front of the hydraulic pump.

2. Rotate tow valve knob 1/2 turn counterclockwise (Fig. 5, Item 9).

3. After completion of towing operation, and before starting engine, close tow valve securely by rotating fully clockwise. Do not exceed 5 – 8 ft. lb. torque.

TRANSPORTING SWEEPER (Fig. 10)

When transporting the sweeper use only the tie-downs welded into the frame of machine to secure it to a trailer. Use of hopper linkages, steering wheels, or anything other than the proper tie-down locations could cause damage to the machine.




Figure 10
1. Front tie-down
2. Rear tie-down

SWEEPER OPERATION

1. Release the parking brake.

2. With the throttle 1/2 open and the choke closed insert key into ignition switch and rotate it clockwise to start engine. Release key when engine starts and open choke gradually.

3. Using the toe of your foot, press the traction pedal forward to move forward. Using the heel of your foot, press down on the heel of the foot to move backward. Practice moving both ways to get a feel of the machine. For quick braking, when going forward, depress the heel of the traction pedal until hydrostatic transmission reaches neutral. For emergency braking, completely remove foot from the traction pedal.

4. Run engine to full throttle.

5. As you are moving forward engage the Reel PTO Engagement handle to engage the finger reels.

IMPORTANT: NEVER run the reels in one place for any amount of time because the turf will be damaged.

OPERATING INSTRUCTIONS

WHILE SWEEPING

DANGER

TIP OVER CAN CAUSE SERIOUS INJURY OR DEATH

- NEVER operate on steep slopes.
- Sweep slopes up and down, never across the face.
- When going uphill or downhill, do not stop or start suddenly.
- Stay alert for holes in the terrain or other hidden hazards. To avoid tipping or loss of control, do not drive close to a ditch, creek or drop off.
- If machine stops going uphill, disengage reels and back slowly downhill. Do not attempt to turn.

1. When the hopper is full, disengage reels and transport to dumping area. When the hopper is full the sweeper will no longer pickup as efficiently, leaving or throwing material back on the ground.

DUMPING THE HOPPER

DANGER

TIP OVER / ELECTRICAL SHOCK COULD CAUSE SERIOUS INJURY OR DEATH.

- NEVER dump hopper on a slope. Always dump hopper on level ground.
- Dump only in area clear of overhead wires and other obstructions.

1. Place the machine on a level surface and in position to dump.

CAUTION

RAISING AND LOWERING OF HOPPER DOOR COULD CAUSE INJURY TO BYSTANDERS OR PETS.

- Keep bystanders and pets a safe distance from hopper when opening and closing hopper door.

2. Pull the Hopper Door Release handle forward to dump the hopper.

3. Move machine forward to separate dumped material from hopper.

IMPORTANT: Debris caught between hopper and hopper door could cause damage to the machine. Make sure that debris is removed from area where hopper and hopper door meet before closing hopper door.

4. When hopper is empty, return the hopper door to the closed position.

LUBRICATE FITTINGS AND BEARINGS (Fig. 11 – 14)

The sweeper has four self sealing bearings and three grease fittings that must be lubricated regularly with No. 2 General Purpose Lithium Base Grease. If machine is operated under normal conditions, lubricate all bearings and bushings after every **50 hours** of operation or immediately after every washing. Bearings and bushings must be lubricated daily when operating conditions are extremely dusty and dirty. Dusty and dirty operating conditions could cause dirt to get into the bearings and bushings, resulting in accelerated wear.

1. Lubricate grease fittings:
   A. Hydraulic pump neutral device.
   B. front wheel bearing hub.
   C. belt tensioning idler arm.
2. Lubricate the four self-sealing bearings mounted on the sweeper reels with a No. 2 Lithium based grease.
3. Lubricate the 14 gate pivot bearings (7 on each side of hopper) with light weight general purpose lubricating oil.




Figure 11

1. Hydraulic pump neutral device grease fitting.




Figure 12

1. Front wheel hub grease fitting.




Figure 13

1. RH rear sweeper reel grease fitting.
2. RH front sweeper reel grease fitting.




Figure 14

1. LH rear sweeper reel grease fitting.
2. LH front sweeper reel grease fitting.

CHANGING ENGINE OIL AND FILTER (Fig. 15)

IMPORTANT: This product contains a exhaust emission certified engine. Always refer to the engine manufacturer's owner's manual for maintenance and service requirements concerning the emission control system.

NOTE: For further information on engine operation, maintenance, and repair of engine refer to engine manufacturer's owner's manual. In some cases TORO may recommend more frequent maintenance intervals than the engine manufacturer. This is due to the extremely dirty and dusty conditions that turf sweepers operate in.

WARNING

ACCIDENTAL STARTING OF ENGINE BY OTHERS WHILE MAINTENANCE IS BEING PERFORMED MAY CAUSE PERSONAL INJURY.

- Before servicing or making adjustments to the machine:
  - Stop engine.
  - Set parking brake.
  - Remove key from ignition switch.

Check oil after each day's operation or each time machine is used. **For new engine,** change oil and filter after the first **5 hours** of operation. Thereafter change oil and filter every **50 hours** or operation. If possible, run engine just before changing oil, warm oil flows better and carries away more impurities than cold oil.

1. Position machine on a level surface with engine off, parking brake set , and key removed from ignition switch.

2. To keep debris out of engine, clean the area around the oil fill cap/dipstick and oil filter before removing.

3. Remove oil drain plug, oil fill cap, and dipstick. Be sure to allow ample time for complete drainage.




Figure 15

1. Dipstick
2. Oil fill cap
3. Oil drain plug

4. Reinstall drain plug.

5. Remove the old filter. Wipe off surface where oil filter mounts. Allow oil filter to drain.

6. Apply a thin coating of new oil to the rubber gasket on replacement oil filter.

7. Install the replacement oil filter to the filter adapter. Turn the oil filter clockwise until rubber gasket contacts the filter adapter, then tighten the filter an additional 1/2 turn.

8. Slowly fill crankcase to the "F" mark on the dipstick. Always check the oil level with the dipstick before adding more oil. **DO NOT OVERFILL.** When changing only the filter, add 1/2 pint (0.24 liters) of new oil. The engine requires high-quality detergent oil having the American Petroleum Institute (API) "service classification" SG or SH. Oil viscosity (weight) must be selected according to anticipated ambient temperature. Temperature/viscosity recommendations are as follows:

A. Above 0°F (-18°C) – Use 10W-30 or 10W-40.
B. Below 32°F (0°C) – Use 5W-20 or 5W-30.

NOTE: Using other than service class SG or SH oil or extending oil change intervals longer than recommended can cause engine damage.

9. Reinstall dipstick and oil cap and tighten securely.

10. Start the engine and check for oil leaks. Correct any leaks before placing engine into service. Check oil to make sure it is up to but not over the F mark on the dipstick.

IMPORTANT: To prevent extensive engine wear or damage, always maintain the proper oil level in the crankcase. Never operate the engine with the oil level below the L mark or over the F mark on the dipstick.

GENERAL PRECLEANER AND AIR CLEANER MAINTENANCE (Fig. 16)

The engine is equipped with a replaceable, high density paper air cleaner element and an oiled, foam precleaner which surrounds the paper element.




Figure 16

1. Precleaner
2. Air cleaner cover
3. Air cleaner cover nut
4. Air cleaner

Check the air cleaner daily before starting the engine. Check for buildup of dirt and debris around the cleaner system. Keep this area clean. Also check for loose or damaged components. Replace all bent or damaged air cleaner components.

NOTE: Operating the engine with loose or damaged air cleaner components could allow unfiltered air in the engine causing premature wear and failure.

CLEAN AND LUBRICATE FOAM PRECLEANER (Fig. 17)

Wash and reoil precleaner every **25 hours** of operation **(more often if under extremely dusty and dirty conditions).**

1. Turn engine off, set parking brake, and remove key from ignition switch.

2. Loosen the air cleaner cover knob and remove air cleaner cover.




Figure 17

1. Air cleaner cover
2. Air cleaner cover knob

3. Remove precleaner from paper element.

4. Wash precleaner in warm water with detergent. Rinse precleaner thoroughly until all traces of detergent are eliminated. Squeeze out excess water (do not wring). Allow precleaner to air dry.

5. Saturate the precleaner with new engine oil. Squeeze out excess oil.

6. Reinstall the precleaner over the air cleaner.

7. Reinstall the air cleaner cover. Secure cover with retaining knob.

SERVICE AIR CLEANER PAPER ELEMENT (Fig. 16 and 17)

Every **100 hours** of operation **(more often under extremely dusty or dirty conditions)** check the aircleaner paper element. Replace the element as necessary.

1. Turn engine off, set parking brake, and remove key from ignition switch.

2. Loosen the cover retaining knob and remove cover.

3. Remove the precleaner from the air cleaner paper element.

4. Remove air cleaner cover nut, air cleaner cover and air cleaner paper element.

5. Do not wash the air cleaner paper element or use pressurized air, as this will damage element . Replace a dirty, bent, or damaged element. Handle new elements carefully; do not use if the sealing surfaces are bent or damaged.

6. When servicing air cleaner, check the air cleaner base. Make sure it is secured and not bent or damaged. Check element cover for damage or improper fit. Replace all damaged air cleaner components.

NOTE: Before reassembling air cleaner make sure rubber seal is in position around stud. Inspect and make sure it is not damaged. Seal with the element cover.

7. Reinstall the air cleaner paper element, precleaner, element cover, element cover nut, and air cleaner cover. Secure cover with retaining knob.

CLEAN AIR INTAKE/COOLING AREAS

To ensure proper cooling, check and clean grass screen, cooling fins, and other external surfaces of the engine **daily.**

Every **100 hours** of operation (more often under extremely dusty or dirty conditions), remove the blower housing and other cooling shrouds. Clean the cooling fins and external surfaces as necessary. Make sure the cooling shrouds are reinstalled.

IMPORTANT: Operating the engine with a blocked grass screen, dirty or plugged cooling fins, and/or cooling shrouds removed, will cause damage due to overheating.

CHECK SPARK PLUG GAP AND CONDITION (Fig. 18)

Air gap between center and side electrodes of the spark plug increases gradually during normal operation of the engine. check condition of electrodes after **200 hours** of operation. Recommended air gap is 0.030 in. (0.76 mm). Use Champion® type RC12YC (or equivalent) spark plugs.

IMPORTANT: A cracked, fouled, dirty, or otherwise malfunctioning spark plug must be replaced. Do not sand blast, scrape, or clean electrodes by using a wire brush because grit may eventually release from the plug and fall into the cylinder. The result is usually a damaged engine.

1. Turn engine off, set parking brake, and remove key from ignition switch.

2. Before removing spark plug, clean the area around the base of the plug to keep dirt and debris out of the engine.

3. Remove plug and check condition of side and center electrodes, and center insulator to assure there is no damage. Replace plug if worn or reuse is questionable.

4. Check the gap using a wire feeler gauge. Adjust the gap between center and side electrodes to 0.030 in. (0.76 mm) by carefully bending the ground electrode.




Figure 18

5. Reinstall spark plug into the cylinder head. Torque spark plug to 18 – 22 ft. lb.

6. Replace high tension leads onto spark plugs.

CHANGING HYDRAULIC OIL AND FILTER (Fig. 5 and 19)

The hydraulic oil must be changed **yearly**. The hydraulic oil filter must be changed initially at **50 hours**, and thereafter **yearly.** The hydraulic oil and/or filter must also be changed if hydraulic vacuum gauge reads, and stays, in the red zone. The hydraulic system is designed to operate on Mobil DTE 13M or equivalent ISO VG 32 wide-temperature, shear-stable hydraulic fluid with controlled low-temperature flow properties and anti-wear protection. The reservoir is filled at the factory with approximately 28 quarts of Mobil DTE 13M hydraulic fluid. Hydraulic oil viscosity (weight) must be selected according to average anticipated ambient temperature. Temperature/viscosity recommendations are as follows:

EXPECTED AMBIENT TEMPERATURES		
Recommended Oil	Start-Up	Average Daily
Mobil DTE 13M or equivalent ISO VG 32	Less than 40°F – 50°F (4.5°C – 10°C)	Less than 80° (26.7°C)
Mobil DTE 26 or equivalent ISO VG 68	Greater than 60°F – 70°F (4.5°C – 10°C)	Greater than 80° (26.7°C)

IMPORTANT: Using Mobil DTE 26 or equivalent ISO VG 68 hydraulic oil when temperatures average below 80°F (26.7°C) could cause hydraulic system damage.

The hydraulic vacuum gauge measures the vacuum levels within the hydraulic system. When the hydraulic oil filter becomes dirty the vacuum level within the system will increase. The vacuum level will also increase if the wrong viscosity oil is used (refer to above listed Expected Ambient Temperatures table). Check vacuum gauge after each day's operation, and before shutting off engine. The hydraulic vacuum gauge (Fig. 5, Item 8) has three color coded zones: the green zone (gage reads 1 – 5), the yellow zone (gage reads 4 – 6), and red zone (gage reads 7 – 31). It is safe to operate machine with gauge reading in the green or yellow zone. **DO NOT** continue to operate machine with the gauge in the red zone. The hydraulic oil and/or filter must be changed before operation can continue.

NOTE: When machine is first started and before the hydraulic oil has had time to reach a stable operating temperature (after approximately 2 hours of continuous operation), the vacuum gauge may read in the red zone. For an accurate reading allow oil to reach a stable operating temperature before checking vacuum gauge .

IMPORTANT: Do not continue to operate machine if hydraulic vacuum gauge remains in the red zone after hydraulic oil has reached stable operating temperature. Continuing to operate machine with gauge in the red zone may cause serious system damage.

IMPORTANT: If hydraulic oil becomes contaminated, contact your local Authorized TORO Distributor/Authorized TORO Landscape Contract Equipment Dealer because the system must be flushed. Contaminated oil looks milky or black when compared to clean oil. Continuing to operate machine with contaminated hydraulic oil could cause system damage.

1. Position machine on a level surface with the engine off, parking brake set, and key removed from ignition switch.

2. Remove drain plug (located under the floorboard on left-hand side), from reservoir and let hydraulic oil flow into drain pan. Reinstall and tighten plug when hydraulic oil stops draining.




Figure 19
1. Hydraulic oil drain plug

3. Clean area around hydraulic oil filter mounting area and remove filter using a filter wrench.

4. Lubricate the sealing gasket and hand turn until gasket contacts filter head. Then tighten 3/4 turn further. Filter should now be seated.

5. Fill the hydraulic tank with approximately 28 quarts of the proper hydraulic fluid.

IMPORTANT: To prevent system contamination, clean top of hydraulic oil containers before opening. Assure pour spout and funnel are clean. When adding oil to the hydraulic system, use a funnel with a fine screen - 200 mesh - and ensure funnel and oil are clean. This procedure prevents accidental contamination of the hydraulic oil which will damage the hydraulic system.

6. Place all controls in the neutral or disengaged position and start engine. Run engine at idle for 3 – 5 minutes to circulate hydraulic fluid and remove any air trapped in the system. Stop the engine and re-check the fluid level (refer to Check Hydraulic System Oil, page 12).

7. Check all connections for leaks.

DANGER

HYDRAULIC FLUID ESCAPING UNDER PRESSURE CAN PENETRATE SKIN AND DO SERIOUS DAMAGE.

- Keep body and hands away from pin hole leaks or nozzles that eject high pressure hydraulic fluid. Use a cardboard or paper to find hydraulic leaks. Fluid accidentally injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.

CHECKING HYDRAULIC LINES AND HOSES

After every **100 hours** of operation, check hydraulic lines and hoses for leaks, kinked lines, loose mounting supports, wear, loose fittings, weather deterioration and chemical deterioration. Make all necessary repairs before operating.

FUEL FILTER REPLACEMENT (Fig. 20)

A 15 micron in-line filter is incorporated into the fuel line. Replace fuel filter after **100 hours** of operation.

1. Place a drain pan under filter.




Figure 20

1. Fuel filter

2. Clamp both fuel lines that connect to fuel filter so gasoline cannot drain when lines are removed.

3. Loosen the hose clamps at both ends of the filter and pull lines off filter.

4. Install new filter with arrow on the filter body pointing towards fuel pump.

5. Secure with hose clamps.

SWEEPER REEL HEIGHT AND BELT ADJUSTMENT (Fig. 21)

The sweeper uses two belts to drive the front and rear sweeper reels. Check tension of drive belts after every 25 hours of operation. The rear idler is under spring tension to keep a constant tension on the reel drive belt. To adjust sweeper reel height and belt tension:

1. Position machine on a level surface with the engine off, parking brake set, and the key removed from ignition switch.




Figure 21

1. Adjustment arm
2. Locking collar
3. Jam nut
4. Tensioning nut
5. Spring rod
6. Belt guide
7. All-Thread
8. Trunnion
9. Adjusting nuts
10. Rod end

2. Remove the two belt guards.

3. Loosen bolts (2) securing adjustment arm.

4. Tighten belt until a 10 lb. force equals 0.25 inch deflection. Use a 3/8 inch ratchet with extension and no socket to apply belt tightening force. Insert ratchet into 3/8 inch square hole directly above the tightening nut on the adjustment arm.

5. Tighten down adjustment arm.

6. Loosen locking collar.

7. Loosen jam nut and tensioning nut, on the spring rod.

8. Place Reel PTO Engagement handle in the OFF (disengaged) position.

9. Turn front reel until a row of fingers is perpendicular to floor.

10. Place Reel PTO Engagement handle in the HIGH (engaged) position.

11. Adjust the finger height on right side until there is 1.25 inches between fingers and ground. Adjust by loosening and tightening the two nuts above and below the trunion. This moves the reels up and down on the reel lift all-thread. It is very important that left side and right side are adjusted from the machine frame equally. Do not use the floor to adjust the perpendicularity of the reel shaft to the sweeper frame.

12. Adjust tension in belt by tightening tensioning nut on the rod spring. Tension until a push spring scale positioned at point P reads 6 lb. (refer to Belt Tensioning/Belt Life, page 27) when the inside and

outside of the belt just touch at point A, or .25" of belt travel at Point A whichever comes first.

13. Lock jam nut on rod spring.

14. Adjust the locking collar to 0.125 inch of the guide plate, and lock down with set screw.

15. Verify that belt guide is positioned to the midpoint of the arc of belt contact to the idler pulley. There should be approximately 0.125 inch of space between guide and belt.

16. Adjust pin belt stop to 0.060 – 0.125 inch from belt.

17. Before replacing guards verify that the belt is disengaging properly when the Reel PTO Engagement handle is in the OFF (disengaged) position. A properly disengaging belt will show excess belt on the engine pulley or looping.

BELT REMOVAL/INSTALLATION (Fig. 21)

1. Remove upper and lower belt guards.

2. Loosen the two clamping bolts on the adjustment arm.

3. Lower the adjustment arm and remove small belt.

4. Loosen guide.

5. Slip the large belt off engine pulley.

6. Loosen the 5 bolts on the retainer until large belt can be slipped off the large reel pulley.

7. Replace belts in reverse order. Follow tensioning procedure (refer to Sweeper Reel Height and Belt Adjustment, page25).

BELT TENSIONING/BELT LIFE

POUNDS OF TENSIONING	CONDITIONS	RESULT
	Normal Clippings or Debris	
6 lb.	0 – 2 in. noncompacted leaves. 0 – 1 in. grass clippings.	Maximum belt life. Maximum bearing life. Heavy loads on reels will cause belt to slip and prematurely wear.
	Moist Clippings or Debris	
8 lb.	0 – 4 in. noncompacted leaves. 0 – 2 in. mulched leaves. 0 – 2 in. grass clippings	Medium belt life. Heavier loads on reels will cause belt to slip and prematurely wear.
	Wet, Dense Clippings or Debris	
10 lb.	0 – 6 in. noncompacted leaves. 0 – 4 in. mulched leaves. 0 – 2 in. grass clippings.	Short belt life. Shorter idler bearing life. Overall premature deterioration of reel components.

ADJUSTING PARKING BRAKE

Check adjustment every **200 hours** of operation.

1. Position machine on a level surface with the engine off and the key removed from the ignition switch.

2. Rotate knob until a force of 40 – 50 lb. is required to actuate lever

3. Tighten set screw after adjustment has been made.

ADJUSTING TRACTION PEDAL (Fig. 22)

If the machine moves in either direction when traction pedal is in the neutral position, the traction cam must be adjusted.

1. Position machine on a level surface with the engine off, parking brake off, and the key removed from ignition switch.

CAUTION

Performing maintenance on machine not properly supported with jack stands may cause machine to fall and could cause injury.

3. Raise one rear wheel off floor and support with jack stands under frame.

4. Loosen locknut on traction adjustment cam (located under operator's seat).




Figure 22

1. Traction adjustment cam
2. Locknut
3. Cam hex

WARNING

Engine must be running so final adjustment of the traction adjustment cam can be performed. To guard against possible personal injury, keep hands, feet, face, and other parts of the body away from the muffler, other hot parts of the engine, and other rotating parts.

5. Start engine and rotate cam hex in both directions to *determine mid-position of neutral span.*

6. Tighten locknut securing adjustment

7. Always tighten both nuts when final adjustments are completed.

8. Stop engine. Remove jack stands and lower machine to shop floor.

9. Test drive machine to be sure it does not creep.

STEERING CHAIN ADJUSTMENT (Fig. 23)

The steering chain should be adjusted after 100 hours of operation or when steering system is binding or excessive play in the column occurs.

1. Adjust steering chain idler until a force of 5 lb. at the midpoint of the chain deflects 0.25 inches.




Figure 23

1. Steering chain idler

REPLACING SWEEPER REEL FINGERS (Fig. 24)

Check condition of sweeper reel fingers after every **25 hours** of operation. Excessively worn or damaged sweeper reel fingers will affect the sweeper's ability to effectively pick-up debris and must be replaced.

The Rubber Finger Puller (TORO Part No. 0127900RFP) can be used to remove and install reel fingers.

To install new reel fingers:

1. Place the reel finger in the slot and pull as far as possible.

2. Place the end of the Puller on the finger.




Figure 24

3. Push down on Puller to install finger

NOTE: The Puller may be used in either direction for right or left handed use.

To remove reel fingers:

4. Place the end of the Puller on the finger.

5. Push down in the same manner as installing the reel finger.

HOPPER AND REEL CLEAN OUT

1. Position machine on a level surface with engine off, parking brake set, and the key removed from ignition switch.

2. Open hopper door and lock the door open by loosening the locking knob (Fig. 9) and sliding bolt into notch. Tighten locking knob.

3. Remove debris from hopper and reel area.

WHEEL MOTOR AXLE NUT TORQUE (Fig. 25)

WARNING

Failure to maintain proper torque could result in failure or loss of wheel and may result in personal injury. Torque wheel motor axle nuts to 200 – 400 ft. lb.




Figure 25
1. Wheel motor axle nut

BATTERY STORAGE

If the machine will be stored for more than 30 days, remove the battery and charge it fully. Either store it on the shelf or on the machine. Leave cables disconnected if stored on the machine. Store the battery in a cool atmosphere to avoid quick deterioration of the charge in the battery. to prevent battery from freezing, make sure it is fully charged. the specific gravity of a fully charged battery is 1.250.

BATTERY CARE

WARNING

ELECTROLYTES CONTAINED IN BATTERIES COULD CAUSE BURNS. GASSES PRODUCED WHILE CHARGING ARE EXPLOSIVE AND IF IGNITED BY SPARK OR FLAME MAY CAUSE SERIOUS INJURY. ALSO NAUSEA MAY RESULT IF GASSES ARE INHALED.

- Wear safety gloves and rubber gloves when working with electrolyte.
- Charge battery in a well ventilated place so gasses produced while charging can dissipate.
- Keep open flames and electrical spark away from the battery; DO NOT SMOKE.
- Unplug charger from electrical outlet before connecting to or disconnecting charger leads from battery posts.

1. Battery electrolyte level must be properly maintained and the top of the battery kept clean. If the machine is stored in a location where temperatures are extremely high, the battery will run down more rapidly than if the machine is stored in a location where temperatures are cool.

2. Keep top of battery clean by washing periodically with a brush dipped in ammonia or bicarbonate of soda solution. Flush the top surface with water after cleaning. Do not remove the fill cap while cleaning.

3. Check battery cable connections every **50 hours** of operation. Battery cables must be tight on terminals to provide good electrical contact.

WARNING

Connecting cables to the wrong post could result in personal injury and/or damage to the electrical system..

4. If corrosion occurs at terminals, remove battery cover, disconnect cables, negative (–) cable first and scrape clamps and terminals separately. Reconnect cables, positive (+) cable first and coat terminals with Grafo 112X skin over grease (TORO Part Number 505-46) or petroleum jelly.


5. Check the electrolyte level every **50 hours** of operation, or if machine is in storage, every 30 days.

6. Maintain cell level with distilled or demineralized water. Do not fill cells above bottom of the fill ring inside each cell.


TROUBLESHOOTING

CONDITION	CAUSE	CORRECTION
SWEEPER NOT PICKING UP	• Missing or broken fingers.	• Replace missing or broken fingers.
	• Broken belt or improper tension.	• Replace belt/adjust tension.
	• Check sheaves for sheared key.	• Replace key.
	• Finger height may be too low or too high.	• Adjust height. See Sweeper Reel Height and Belt Adjustment, page 25.
	• Hopper floor not sealed inside against the rear crossmember. Unit may be picking up but throwing it through gap onto the ground.	• Bend hopper floor back to seal hopper.
	• Screen in top of hopper door may be clogged, blocking air flow.	• Clean out screen blockage.
	• Build up on bottom of oil tank compartment or rear reel deflector above front reel.	• Clean off any buildup on these surfaces.
EXCESSIVE VIBRATION	• Check bearings on reel shaft. If they are excessively hot, they are probably damaged.	• Replace any damaged bearings.
	• Foreign materials wrapped around reel shaft.	• Clean off any foreign objects.
	• Reels could be bent. Should be within 0.015 for straightness	• Check shaft with dial calipers
	• Missing or broken sweeper fingers.	• Replace fingers.
	• Damaged belt.	• Replace belt.

HYDRAULIC SCHEMATIC



MAINTENANCE SCHEDULE



MAINTENANCE SCHEDULE

Minimum Recommended Maintenance Intervals:

Maintenance Procedure:	Maintenance Interval and Service Type			
	Every 25 hrs	Every 50 hrs	Every 100 hrs	Every 200 hrs
Clean and Lubricate Foam PreCleaner				
‡ Check Reel Drive Belts	*A Level Service*			
Check Battery Fluid level				
Lubricate Gate Pivots				
Lubricate All Grease Fittings				
Check Battery Cable Connections				
† Change Engine Oil and Filter		*B Level Service*		
Replace Air Filter				
Clean Air Intake/Cooling Areas				
Check Reel Fingers				
Replace Fuel Filter				
Inspect Condition of Tires				
Adjust Steering Chain			*C Level Service*	
‡ Torque Wheel Lug Nuts				
Service Spark Plugs				
Check Engine RPM (idle and full throttle)				*D Level Service*
† Initial Break in at 5 hours				
‡ Initial Break in at 10 hours				
Drain and flush Fuel Tank				
Inspect Hopper and Gate for damage				
Replace Hydraulic Fluid and Filter				

Annual Recommendations:

Items listed are recommended every (600) hours or (1) year, whichever occurs first.

See Operator's and Service Manual for specifications and procedures

MAINTENANCE RECORD

Maintenance Check Item	Daily Maintenance Check For Week Of: _____ Mon ____hrs	Tue ____hrs	Wed ____hrs	Thu ____hrs	Fri ____hrs	Sat ____hrs	Sun ____hrs
✓ Safety Interlock Operation							
✓ Parking Brake Operation							
✓ Engine Oil Level							
✓ Hydraulic Fluid Level							
✓ Air Filter Prefilter							
✓ Engine Cooling Fins							
✓ Unusual Engine Noises							
✓ Unusual Operating Noises							
✓ Tire Pressure							
✓ Hydraulic Hoses for Damage							
✓ Fluid Leaks							
✓ Instrument Operation							
✓ Clean Hopper Screen							
✓ Traction Pedal Operation							
✓ Rubber Reel Fingers[2]							
✓ Steering Chain Adjustment							
Lubricate All Grease Fittings[1]							
Touch-up damaged paint							

[1] = Immediately after every washing, regardless of the interval listed.
[2] = Replace if missing or broken

Notation of areas of concern: **Inspection performed by:** _____

Item	Date	Information
1.		
2.		
3.		
4.		
5.		
6.		
7.		
8.		

PREPARATION FOR SEASONAL STORAGE

1. Thoroughly clean the sweeper so it is free of dirt, leaves and debris.

2. Inflate tires to 22 PSI.

3. Check all fasteners. Tighten as necessary.

4. Grease all grease fittings. Wipe off excess lubricant.

5. Drain and replace hydraulic fluid and filter. Inspect all hydraulic lined and fittings. Replace if necessary. Refer to the Maintenance section.

6. Check the tension and condition of the reel belts. Adjust the tension if necessary.

7. Check the condition of the rubber fingers. Replace any broken, missing, or worn fingers.

8. Service the battery and cables as follows:

   A. Remove the battery terminals from the battery posts.
   B. Clean the battery, terminals and posts with a wire brush and baking soda solution.
   C. Coat the cable terminals and battery posts with Grafo 112X skin over grease (TORO Part Number 505-46), or petroleum jelly to prevent corrosion.
   D. Slowly recharge the battery every 60 days for 24 hours to prevent lead sulfating of the battery.

ENGINE

1. Drain the engine oil from the crankcase and replace drain plug.

2. Remove and discard the oil filter. Install a new oil filter.

3. Refill crankcase pan with 2.1 quarts (2 liters) of SG or SH, 10W-30 motor oil.

4. Start the engine and run at idle speed for approximately two minutes.

5. Stop the engine.

6. Thoroughly drain all fuel from the fuel tank, lines and the fuel pump filter.

7. Flush the fuel tank with fresh clean gasoline.

8. Re-secure all fuel system fittings.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBER

The model and serial number is on a plate that is mounted on the left side of operator platform above the left rear wheel. Use model and serial number in all correspondence and when ordering parts.

To order replacement parts from an Authorized TORO Distributor/Authorized TORO Landscape Contract Equipment Dealer, supply the following information:

1. Model and serial numbers of the machine

2. Part number, description and quantity of parts desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the part number.

The Toro Commercial Products Two Year Limited Warranty

The Toro Company warrants your 1996 or newer Toro Commercial Product ("Product") purchased after January 1, 1997, to be free from defects in materials or workmanship for the period of time listed below. Where a warrantable condition exists, Toro will repair the product at no cost to you including diagnosis, labor, parts, and transportation. This warranty begins on the date the product is delivered to the original retail purchaser.

Warranty Duration: Two years or 1500 operational hours*, whichever occurs first.

***Product equipped with hour meter.**

Owner Responsibilities:

As the Product owner, you are responsible for required maintenance and adjustments stated in your Owner's Manual. Failure to perform required maintenance and adjustments can be grounds for disallowing a warranty claim.

Instructions For Obtaining Warranty Service:

You are responsible for notifying The Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists.

If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro Commercial Products Service Department
8111 Lyndale Avenue South
Minneapolis, MN, 55420-1196
Telephone: (612) 888-8801
Facsimile: (612) 887-8258
E-Mail: Commercial.Service@Toro.Com

Maintenance Parts:

Parts scheduled for replacement as required maintenance ("Maintenance Parts"), are warranted for the period of time up to the scheduled replacement time for that part.

Items/Conditions Not Covered:

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. The items/conditions listed below are not covered by this warranty:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, modified, or unapproved accessories are not covered.
- Product failures which result from failure to perform required maintenance and/or adjustments are not covered.
- Product failures which result from operating the product in an abusive, negligent or reckless manner are not covered.
- This warranty does not apply to parts subject to consumption through use unless found to be defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, blades, reels, bedknives, tines, spark plugs, castor wheels, tires, filters, belts, etc.
- This warranty does not apply to failures caused by outside influence. Items considered to be outside influence include, but are not limited to, weather, storage practices, contamination, use of unapproved coolants, lubricants, additives, or chemicals, etc.
- This warranty does not apply to normal "wear and tear" items. Normal "Wear and Tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows, etc.

Other Legal Disclaimers:

The above remedy of product defects through repair by an authorized distributor or dealer is the purchaser's sole remedy for any defect. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of the express warranty.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

The Toro Company is not liable for indirect, incidental or consequential damages in connection with the use of the Product, including any cost or expense of providing substitute Product or service during periods of malfunction or non-use.

Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.

Note to California residents: The Emissions Control System on your product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA), or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System warranty. Refer to the California Emission Control Warranty Statement printed in your Owner's Manual or contained in the engine manufacturer's documentation for details.