

Seat Spring Kit

TimeCutter[™] Z
Part No. 105–6994

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form **a:b**. The **a** represents the reference number of the entire service assembly and the **b** represents a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form **nX y**. The **n** represents the quantity of the part, the **X** is the multiplication symbol, and the **y** represents the reference number.

For example, in an illustration, the reference number **2X 37** means that two of the parts identified by reference number 37 are indicated.



Spring and Knob Assembly

Ref. No.	Part No.	Qty.	Description
1 2 3 4 5 6 7 8 9	92–6986 3296–58 701178 700806	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	Screw-HH Spacer - Nylon Spring - Compression Bolt - Shoulder Nut-Lock NI Cap-Protector Knob Washer Spacer-Nylon

Ref. No.	Part No.	Qty.	Description