



Hand Spray Wand Kit

Serial Number 315000000 and After Multi Pro® 1750, Multi Pro® WM or Multi Pro® 5800 Turf Sprayer

Model No. 41118—Serial No. 416400000 and Up

Operator's Manual

The hand spray wand kit is an attachment for a turf spray application vehicle and is intended to be used by professional, hired operators in commercial applications. It is primarily designed for spraying on well-maintained lawns in parks, golf courses, sports fields, and on commercial grounds.

You may contact Toro directly at www.Toro.com for product safety and operation training materials, accessory information, help finding a dealer, or to register your product.

Setup

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	No parts required	—	Prepare the machine.
2	Hose hook Flanged locknut (3/8 inch) Flanged locknut (5/16 inch) Carriage bolt (3/8 x 3/4 inch) Carriage bolt (5/16 x 1 inch) R-clamp Spray-gun bracket	1 4 4 4 4 2 1	Install the hose hook and spray-gun bracket.
3	Female cap Shutoff valve	2 2	Install the shutoff valve (Multi Pro 1750 with and without GeoLink and Multi Pro WM only).
4	Refer to the Parts Table	0	Install the control valve.
5	Spray gun assembly Straight barbed fitting Hose clamp Hose	1 1 2 1	Connect the spray hose.



1

Preparing the Machine

No Parts Required

Procedure

1. Ensure that the machine is empty of all fluids. If chemicals have been used in the machine, flush the system thoroughly with clean water and drain the water; refer to your vehicle *Operator's Manual* for instructions.
2. Disconnect the negative battery terminal from the battery.

2

Installing the Hose Hook and Spray-Gun Bracket

Parts needed for this procedure:

1	Hose hook
4	Flanged locknut (3/8 inch)
4	Flanged locknut (5/16 inch)
4	Carriage bolt (3/8 x 3/4 inch)
4	Carriage bolt (5/16 x 1 inch)
2	R-clamp
1	Spray-gun bracket




Figure 1

Multi Pro 1750 and Multi Pro 5800

1. Flanged locknut (Multi Pro 1750—3/8 inch; Multi Pro 5800—5/16 inch)	5. Carriage bolt (5/16 x 3/4 inch)
2. Hose hook	6. Spray-gun bracket
3. Carriage bolt (Multi Pro 1750—3/8 x 3/4 inch; Multi Pro 5800—5/16 x 1 inch)	7. R-clamp
4. Front, right tank strap	8. Flanged locknut (5/16 inch)

- For the Multi Pro WM, loosen the rear, right strap ([Figure 2](#)).

Procedure

1. Loosen the tank strap.
 - For the Multi Pro 1750 and Multi Pro 5800, loosen the front, right strap ([Figure 1](#)).




Figure 2
Multi Pro WM

1. Flanged locknut (5/16 inch)	5. Carriage bolt (5/16 x 3/4 inch)
2. Hose hook	6. Spray-gun bracket
3. Carriage bolt (3/8 x 3/4 inch)	7. R-clamp
4. Rear, right tank strap	

2. Install the R-Clamps, spray-gun bracket, and hose hook as shown in [Figure 1](#) or [Figure 2](#) using a carriage bolt, flat washer, and flange-head nut.

3

Installing the Shutoff Valve (Multi Pro 1750 with and without GeoLink and Multi Pro WM Only)

Parts needed for this procedure:

2	Female cap
2	Shutoff valve

Installing the Shutoff Valve (Multi Pro 1750 without GeoLink and Multi Pro WM Only)

1. Remove the retainer that secures the actuator to the manifold valve for the section valve or agitation valve.

Note: Squeeze the 2 legs of the retainer together while pushing it down.

Note: Retain the actuator and retainer.




Figure 3

1. Actuator	3. Stem port
2. Retainer	

2. Remove the actuator from the manifold valve.

3. Remove the retainers holding the bypass adjustment assembly, end cap, and the fitting and hose assembly as shown in [Figure 4](#).

Note: You will not use the end cap, but keep the O-ring on the cap.




Figure 4




Figure 6

1. Female cap

2. Shutoff valve

Installing the Shutoff Valve for Multi Pro 1750 with GeoLink

1. Remove the end cap on the end of the manifold and replace it with a female cap. Secure the cap with the retainer.




Figure 5

1. Boom-valve cluster

5. Install the bypass-adjustment assembly, female cap, O-rings, shutoff valve, and fitting and hose assembly using the retainers previously removed as shown in Figure 6.




Figure 7

1. Retainer

2. Female cap

3. End cap

2. Remove the retainer securing the hose to the end of the manifold.




Figure 8

3. Install the shutoff valve on the hose and machine. Secure it with the retainers.




Figure 9

4

Installing the Control Valve for the Spray Gun

Parts needed for this procedure:

0	Refer to the Parts Table
---	--------------------------


Parts Table

Part	5800			1750			Workman		
	Qty	2023 and Before	2024 and After without GeoLink	2024 and After with GeoLink	2023 and Before	2024 and After without GeoLink	2024 and After with GeoLink	2023 and Before	2024 and After
Control valve		1	1			1	1		1
Control valve (with flange end cap)	1				1			1	
Control valve wing handle	1	1	1	1	1	1	1	1	1
Straight fitting	1	1	1	1	1	1	1	1	1
Valve mount	1	1	1		2	2		2	
Control valve bracket (2023)	1								
Control valve bracket (with hole)				1			1		
Control valve bracket (no hole)			1			1			1
Shutoff valve					1	1	2	1	1
90-degree elbow fitting					1			1	
T-fitting	1								
Manifold tee				1		1	1		1
Gasket clamp	1				1			1	
Bolt (M6 x 12 mm)	4	8	4		8	8			8

Part	5800			1750			Workman	
Qty	2023 and Before	2024 and After without GeoLink	2024 and After with GeoLink	2023 and Before	2024 and After without GeoLink	2024 and After with GeoLink	2023 and Before	2024 and After
Carriage bolt (1/4-20 X 5/8 inch)			2			2		
Hex head bolt (1/4-20 X 5/8 inch)	4				2			2
Locknut (1/4 inch)	4		2		2	2		2

Assembling the Control Valve (Multi Pro 1750—2023 and Before and Multi Pro WM—2023 and Before)

1. Assemble the green wing handle and straight fitting to the control valve.



1. Handle screw (6-32 x 5/8 inch)
2. Wing handle (green)
3. Control valve
4. Retainer
5. Straight fitting

2. Remove the flange clamp that secures the end cap and coupler at the pressure-gauge port.




Figure 11

3. Remove the coupler from the end cap.
4. Install the control valve assembly.
5. Install the coupler into the open port on the 90-degree fitting.

Note: The port in the side of the 90-degree fitting for the Multi Pro 1750 and Multi Pro WM is at the forward side (not shown) of the fitting.

6. Connect the hose-reel supply hose to the control valve using a hose clamp.

Removing the Control Valve from the Machine (Multi Pro 5800—2023 and Before)

1. Disconnect the 3-socket connector for the pressure transducer.




Figure 12

1. 3-socket connector 2. Pressure transducer

2. Remove the flange clamp that secures the pressure transducer to the 90° fitting, and remove the transducer, gasket and flange clamp.




Figure 13

1. Pressure transducer 4. Flange clamp
 2. 90° fitting 5. Gasket
 3. 90° fitting (with a connector for the sense tube)

3. Remove the flange clamp that secures 90° fitting to the 90° fitting with a connector for the sense tube, and remove the 90° fitting, gasket and flange clamp.

Preparing the Control Valve (Multi Pro 5800—2023 and Before)

1. Assemble the valve mount onto the control valve as shown in A of [Figure 14](#).




Figure 14

1. Control valve 2. Valve mount 3. Flange-head screw (#6)

2. Secure the valve mount to the control valve with the flange-head screw (#6), and tighten the screw by hand (B of [Figure 14](#)).
 3. Assemble the valve mount to the control-valve bracket with the 4 bolts (6 x 12 mm) and 4 flat washers; torque the bolts to 10 to 12 N·m (86 to 106 in-lb).




Figure 15

1. Valve mount 2. Control-valve bracket 3. Bolt (6 x 12 mm)

4. Align the flange of the T-fitting to the flange of the control valve.




Figure 16

1. Gasket	3. T-fitting
2. Flange clamp	4. Flange (control valve)

5. Loosely attach the T-fitting to the control valve with a gasket and flange clamp.
6. Align the flange of the pressure transducer with the flange of the T-fitting.




Figure 17

1. Flange (control valve)	3. Flange clamp
2. Flange (pressure transducer)	4. Gasket

7. Assemble the pressure transducer to the T-fitting with a gasket and flange clamp, and tighten the clamp by hand (Figure 17).

Drilling the Manifold Mount (Multi Pro 5800—2023 and Before)

1. Align the flange of the T-fitting with the flange of the 90° fitting with a connector for the sense tube.




Figure 18

1. Flange (T-fitting)	5. 90° fitting (section-valve bypass)
2. Flange clamp	6. Hose clamp
3. Gasket	7. Hose (section-valve bypass)
4. 90° fitting (with a connector for the sense tube)	

2. Loosely assemble the T-fitting and the 90° fitting with a gasket and a flange clamp.

Note: Rotate the control-valve bracket as necessary to align it flush with the surface of the valve mount.

3. Using the control-valve bracket as a template, mark the location of the holes in the bracket onto the surface of the manifold mount.




Figure 19

4. Remove the clamp, gasket, T-fitting with the flange from the 90° fitting with a connector for the sense tube.
5. Center punch the marks on the manifold mount that you made in step 3.
6. Drill 4 holes 6 mm (1/4 inch) into the manifold mount at the centerpunch marks that you made in step 5.




Figure 20

1. Drill and drill bit—6 mm
2. Manifold mount (1/4 inch)

Assembling the Control Valve (Multi Pro 5800—2023 and Before)

1. Align the flange of the T-fitting with the flange of the 90° fitting with a connector for the sense tube.




Figure 21

1. Flange clamps (with gasket)	5. Manifold mount
2. 90° fitting (section-valve bypass)	6. Flange locknut (6 mm)
3. Hex head bolt (1/4 x 5/8 inch)	7. Hose clamp
4. Control-valve bracket	8. Hose (section-valve bypass)

2. Loosely assemble the T-fitting and the 90° fitting with a gasket and a flange clamp.
3. Assemble the control-valve bracket to the manifold mount with 4 hex head bolts (1/4 x 5/8 inch) and 4 flange locknut (6 mm); torque the bolts to 10 to 12 N·m (86 to 106 in-lb).
4. Tighten by hand the flange clamp that secures the control valve and the T-fitting and the flange clamp that secures T-fitting to the 90° fitting with a connector for the sense tube.
5. Connect the 3-socket connector for the pressure transducer.




Figure 22

1. 3-socket connector

2. Pressure transducer




Figure 24

1. Control valve

2. Valve mount

3. Flange-head screw (#6)

3. Secure the valve mount to the control valve with the flange-head screw (#6), and tighten the screw by hand (B of [Figure 14](#)).

Assembling the Control Valve (All Multi Pro Machines—2024 and After)

1. Assemble the wing handle and straight fitting to the control valve.




Figure 23

1. Handle screw (6-32 x 5/8 inch)

2. Wing handle (green)

3. Control valve

g491707

Installing the Control Valve Assembly (Multi Pro 5800—2024 and After)

1. Secure the control valve assembly to the bracket using 4 bolts (M6)




Figure 25

1. Bracket (non GeoLink machines)

2. Bolt (M6)

2. Remove the existing hardware as shown in [Figure 26](#).




Figure 26

3. Secure the bracket to the machine using existing hardware.




Figure 27

1. Existing hardware

4. Secure the top of the bracket using 4 bolts (M6).




Figure 28

Installing the Manifold T-Fitting on the Control Valve Assembly (Multi Pro 1750 with and without GeoLink, Multi Pro WM, and Multi Pro 5800 with GeoLink—2024 and After)

1. Install the manifold T-fitting assembly onto the control valve.




Figure 29

g493704

Installing the Shutoff Valve Assembly (Multi Pro 1750 with and without Geolink and Multi Pro WM—2024 and After)

Assemble the valve mount onto the shutoff valve and secure it to the bracket using 4 bolts (M6).




Figure 31

g493706

- Secure the assembly onto the bracket using 4 bolts (M6).




Figure 30

g493701

- GeoLink bracket (non-GeoLink brackets do not have this hole)

- Bolts (M6)




Figure 32

g493705

- Bolt (M6)

- GeoLink bracket (non-GeoLink brackets do not have this hole)

Installing the Bracket Assembly (Multi Pro 5800 with GeoLink and Multi Pro 1750 with GeoLink—2024 and After)




Figure 33
Multi Pro 5800 shown

1. Carriage bolt (1/4 x 5/8 inch)
2. Locknut (1/4 inch)

Installing the Control Valve Assembly (Multi Pro 1750 and Multi Pro WM—2024 and After)




Figure 34

1. Hex head bolt (1/4 x 5/8 inch)
2. Locknut (1/4 inch)

5

Connecting the Spray Hose

Parts needed for this procedure:

1	Spray gun assembly
1	Straight barbed fitting
2	Hose clamp
1	Hose

Procedure

Note: Use PTFE tape to seal tapered pipe thread fittings.

1. Secure the straight barbed fitting to the open end of the hose-reel supply hose with a hose clamp.




Figure 35

1. Hose	3. Straight barbed fitting
2. Hose clamp	4. Spray gun

2. Secure the end of the hose on the control valve with a hose clamp.




Figure 36

3. Wrap the excess hose around the hook on the tank, and store the spray gun in the bracket.
4. Connect the negative battery wire to the battery.

5. Calibrate the bypass adjustment assembly; refer to your machine *Operator's Manual*.

Operation

⚠ WARNING

Fluid under pressure can penetrate skin and cause injury.

- Keep your body and hands away from nozzles that eject fluid that is under high pressure.
- Do not aim the sprayer at any person or animal.
- Ensure that all fluid hoses and lines are in good condition and all connections and fittings are tight before applying pressure to the system.
- Use cardboard or paper to find leaks.
- Safely relieve all pressure in the system before performing any work on it.
- Get immediate medical help if fluid is injected into the skin.
- Hot liquids and chemicals can cause burns or other harm.

Turf Care Precautions while Operating in Stationary Modes

Important: Under some conditions, heat from the engine, radiator, and muffler can potentially damage the grass when operating the sprayer in a stationary mode. Stationary modes include tank agitation, hand spraying, or using a walking boom.

Use the following precautions:

- **Avoid** stationary spraying when conditions are very hot and/or dry, as turf can be more stressed during these periods.
- **Avoid** parking on the turf while stationary spraying. Park on a cart path whenever possible.
- **Minimize** the amount of time the machine is left running over any particular area of turf. Both time and temperature affect how much the grass may be damaged.
- **Set the engine speed as low as possible** to achieve the desired pressure and flow. This will minimize the heat generated and the air velocity from the cooling fan.
- **Allow heat to escape** upward from the engine compartment by raising the engine guard/seat

assemblies during stationary operation rather than being forced out under the vehicle. Refer to your *Operator's Manual* for more information on raising the seat assemblies.

Note: Use a heat shield blanket underneath the vehicle during stationary operation if you desire additional heat protection. Contact an Authorized Toro Dealer to obtain a Toro heat shield blanket kit for turf sprayers.

Switching from Boom Spray Mode to Hand Spray Mode

1. Stop the machine, turn the booms off, and set the parking brake.

⚠ WARNING

Driving while using the hand sprayer can cause loss of control, resulting in injury or death. Do not operate the hand sprayer while driving.

2. At the back of the machine, ensure that the trigger lock on the spray gun is locked.
3. Rotate the green handle on the control valve 90 degrees.
4. At the operator's position, turn the pump on.
5. Switch the master boom to the ON position.
6. Set the engine to the desired speed, then engage the neutral engine speed lock.

Important: Do not use a pressure setting higher than 1034 kPa (150 psi) with the hand sprayer.

Switching from Hand Spray Mode to Boom Spray Mode

1. Rotate the green handle on the control valve 90 degrees..
2. Direct the spray gun nozzle at an area where it is safe to spray, release the trigger lock, and pull the trigger until all remaining fluid is out of the hose, then set the trigger lock.
3. Return the spray gun to the holder.
4. Return the engine to idle speed.
5. Stop the pump.

Important: Ensure that you flush the spray gun with fresh clean water during your daily cleaning routine (refer to your sprayer

Operator's Manual). Failure to properly clean the spray gun may degrade the performance and reliability of the spray gun.

6. Use the rate switch to set the desired spray pressure.

Notes:

Notes:

UK Declaration of Incorporation

The Toro Company, 8111 Lyndale Ave. South, Bloomington, MN, USA declares that the following unit(s) conform(s) to the directives listed, when installed in accordance with the accompanying instructions onto certain Toro models as indicated on the relevant Declarations of Conformity.

Model No.	Serial No.	Product Description	Invoice Description	General Description	Regulation
41118	315000001 and Up	Hand Spray Gun Kit	HAND SPRAY WAND KIT	Sprayer Accessories	2006/42/EC, 2000/14/EC and 2005/88/EC

Relevant technical documentation has been compiled as required per Part B of Annex VII of 2006/42/EC.

We will undertake to transmit, in response to requests by national authorities, relevant information on this partly completed machinery. The method of transmission shall be electronic transmittal.

This machinery shall not be put into service until incorporated into approved Toro models as indicated on the associated Declaration of Conformity and in accordance with all instructions, whereby it can be declared in conformity with all relevant Directives.

This declaration has been issued under the sole responsibility of the manufacturer.

The object of the declaration is in conformity with relevant UK legislation.

Authorized Representative:



Tom Langworthy
Engineering Director
8111 Lyndale Ave. South
Bloomington, MN 55420, USA
November 3, 2022

Marcel Dutrieux
Manager European Product Integrity
Toro U.K. Limited
Spellbrook Lane West
Bishop's Stortford
CM23 4BU
United Kingdom

UK Declaration of Incorporation

The Toro Company, 8111 Lyndale Ave. South, Bloomington, MN, USA declares that the following unit(s) conform(s) to the regulations listed, when installed in accordance with the accompanying instructions onto certain Toro models as indicated on the relevant Declarations of Conformity.

Model No.	Serial No.	Product Description	Invoice Description	General Description	Regulation
41118	315000001 and Up	Hand Spray Gun Kit	HAND SPRAY WAND KIT	Sprayer Accessories	S.I. 2001 No. 1701, S.I. 2008 No. 1597

Relevant technical documentation has been compiled as required per S.I. 2008 No. 1597.

We will undertake to transmit, in response to requests by national authorities, relevant information on this partly completed machinery. The method of transmission shall be electronic transmittal.

This machinery shall not be put into service until incorporated into approved Toro models as indicated on the associated Declaration of Conformity and in accordance with all instructions, whereby it can be declared in conformity with all relevant regulations.

This declaration has been issued under the sole responsibility of the manufacturer.

The object of the declaration is in conformity with relevant UK legislation.

Authorized Representative:



Tom Langworthy
Engineering Director
8111 Lyndale Ave. South
Bloomington, MN 55420, USA
November 3, 2022

Marcel Dutrieux
Manager European Product Integrity
Toro U.K. Limited
Spellbrook Lane West
Bishop's Stortford
CM23 4BU
United Kingdom