



PART NO. 95-9121

**SET-UP AND
PARTS MANUAL****SONIC BOOM™ Replacement Kit**
for the WORKMAN® and MULTI PRO® SPRAYERS

This manual includes set-up instructions for the MULTI PRO® 5500, MULTI PRO® 1100, and WORKMAN® Vehicles. Refer to the sections that contain information pertaining to the set-up for your Vehicle or Sprayer. The only Multi Pro 1100 Vehicles this Kit will install on are those with serial numbers of 30000 and up. Vehicles prior to this will require additional modifications not included in this manual.

Refer to the illustrated Parts for the details of parts used in assembling the Sonic Boom™ Replacement Kit.

NOTE: In order to use a Sonic Boom™ Replacement Kit your sprayer must first be equipped with an Electric Boom Lift Kit. The Harness included with the Electric Boom Lift Kit will not be used with the Sonic Boom™ accessory and may be discarded.

NOTE: "RIGHT" and "LEFT", "FRONT" and "REAR" reference the operator's directions when seated in the normal operating position.

SONAR SENSORS INSTALLATION:

1. Mount the Sensor Brackets to the Boom Pipes between the Vertical Support and the last Nozzle, using two (2) "U" Bolts, (4) locknuts, and flat washers. The Brackets should be tilted up 10°. Right side is shown in FIG. 1.

NOTE: Attach the left Sensor Bracket in the same manner on the left Boom Pipe.




FIG. 1

- | | |
|-------------------|----------------------------|
| 1. "U" Bolts | 4. Corrugated Split Tubing |
| 2. Sensor Bracket | 5. Boom Hinge |
| 3. Sonar Cord | |

2. Route the Sonar Cords along the top of the Boom Support and toward the center of the Vehicle. Install Corrugated Split Tubing over Sonar Cable and Boom Support. Use Tie Straps to secure the Sonar Cords and Corrugated Tubing to the Boom Support at each end and at the center. Allow sufficient slack in the Sonar Cord at the Boom Hinge to permit the Boom to pivot freely. See FIG. 1

NOTE: Be sure that no obstructions (hoses or nozzles) are in the path of the Sonar signal as it travels from the Sonar Head to the ground surface.

Refer to the following section that contains information pertaining to the set-up for your Vehicle or Sprayer.

NOTE: Due to the commonality of the Sonic Boom™ Kit, there will be extra length of Harness in some areas. This extra length should be doubled over and tied using the Tie Straps included with the Kit.

IMPORTANT: DO NOT ROUTE HARNESS NEAR MOVING PARTS!

SET-UP INSTRUCTIONS

MULTI PRO® 5500 VEHICLE:

1. Mount ECU to Plate using four (4) 1/4 NC x 2-1/2" hex hd cap screws, lock washers and hex nuts. See FIG. 2




FIG. 2

- | | |
|-------------|-------------------|
| 1. ECU | 4. Fuse Block |
| 2. Plate | 5. Wiring Harness |
| 3. 4 Relays | 6. Mounting Post |

2. Mount four (4) Relays to Plate using 1/4 NC x 5/8" hex hd cap screws, lock washers and hex nuts.

3. Mount Fuse Block to Plate using two (2) # 10 NC x 5/8" rec. rd. hd. mach. screws and hex nuts.

4. Connect Wiring Harness to ECU and Relays. Tighten ECU and connector screws.

5. Mount ECU Plate to Vehicle post on right side under Dash, using two (2) 5/16 NC x 3/4" cap screws and lock washers. See FIG. 2

6. Install Sonic Boom™ Decal and Indicator Light on Dash, and connect Harness Leads to Light. See FIG. 3




FIG. 3

- | | |
|--------------------|----------------------|
| 1. Indicator Light | 2. Sonic Boom™ Decal |
|--------------------|----------------------|

7. Route Wiring Harness through floor along side the Vehicle Harness and Hydraulic Lines. Route under floor toward the right side of the vehicle, through Harness guides, and to front right corner of the Seat Box.

8. Install "R" clamps provided in place of existing "R" clamps located under both Passenger and Operator Seats.

9. Route Harness through new "R" clamps with existing Harness. Identify Harness lead with 3 clear 6-way connectors. Route that portion to the Center Switch Panel.

10. Install two (2) Boom Switches (included in Boom Lift Kit) and Sonic Boom™ Mode Switch. Connect Wiring Harness as shown in FIG. 4.




FIG. 4

- | | |
|----------------------|---------------------|
| 1. Right Boom Switch | 3. Sonic Boom™ Mode |
| 2. Left Boom Switch | 4. Wiring Harness |

11. Route Harness to Fuse Block under Operator Seat. Connect power and ground wires as shown in FIG. 5




FIG. 5

- 1. Fuse
- 2. Power Wire
- 3. Ground Wire

12. Route remaining Harness along right side of Vehicle to the Boom, following the Vehicle Harness through the Harness Guides.

NOTE: Use Tie Straps provided to attach Harness to existing Harness or to tie up extra Sonic Boom™ Harness whenever necessary.

SET-UP INSTRUCTIONS

MULTI PRO® 1100 VEHICLE:

NOTE: Vehicles with serial numbers preceding 60231 will require the drilling of holes for ECU, Relays, Fuse Block, Indicator Light, and Sonic Boom™ Switch. See FIG. 6, 8, and 9.




FIG. 6

1. Visible side of Console Cover

1. Remove Console Cover.
2. Mount ECU to Console Cover using four (4) 1/4 NC x 2-1/2" hex hd cap screws, lock washers and hex nuts. See FIG. 7
3. Mount four (4) Relays using 1/4 NC x 5/8" hex hd cap screws, lock washers and hex nuts.




FIG. 7

- | | |
|------------------|-------------------|
| 1. ECU | 4. Fuse Block |
| 2. Console Cover | 5. Wiring Harness |
| 3. 4 Relays | |

4. Mount Fuse Block to Console Cover using two (2) # 10 NC x 5/8" rec. rd. hd. mach. screws and hex nuts.

5. Connect Wiring Harness to ECU and Relays.

6. Route Wiring Harness through floor and back through axle mounting bracket. Route the harness section with three (3) clear 6-way connectors back along left side of Vehicle to behind engine. Then guide up, into the Seat Box.

7. Install Sonic Boom™ Decal and Indicator Light on Dash (11/16" DIA. hole required.) Connect Harness Leads to Light. Reinstall the Console Cover. See FIG. 8




FIG. 8

- | | |
|--------------------|----------------------|
| 1. Indicator Light | 2. Sonic Boom™ Decal |
|--------------------|----------------------|

8. Install two (2) Boom Switches (included in Boom Lift Kit) and Sonic Boom™ Mode Switch (1/2" DIA. hole required). Install Decals, and connect Wiring Harness. See FIG. 9

NOTE: It may be necessary to temporarily remove the Air Cleaner to make connection to Switches.




FIG. 9

- | | |
|----------------------|---------------------|
| 1. Right Boom Switch | 3. Sonic Boom™ Mode |
| 2. Left Boom Switch | 4. Wiring Harness |

SET-UP INSTRUCTIONS

9. Route Harness to Fuse Block under Operator Seat. Connect power and ground wires as shown in FIG. 10




FIG. 10

1. Fuse

2. Power Wire

3. Ground Wire

10. Route remaining Harness along the right side of Vehicle to the Boom, following the Vehicle Harness through the Harness Guides.

NOTE: Use Tie Straps provided to attach Harness to existing Harness or to tie up extra Sonic Boom™ Harness whenever necessary.

SET-UP INSTRUCTIONS

WORKMAN VEHICLE:

1. Remove (15) screws and washers securing the Front Panel to Vehicle frame and remove Front Panel.
2. Locate and drill two (2) 3/8" holes in right Upright Post. See FIG. 11




FIG. 11

1. Upright Post 2. ECU Bracket




FIG. 12

1. Support Bracket 4. Four Relays
2. ECU Bracket 5. Fuse Blocks
3. ECU 6. Wiring Harness
7. Upright Post

3. Mount the Support Bracket to the ECU Bracket using (1) 5/16 NC x 3/4" cap screw, flat washer, lock washer, and hex nut. See FIG. 12

4. Mount ECU to Bracket using four (4) 1/4 NC x 2-1/2" hex hd cap screws, lock washers and hex nuts. See FIG. 12

5. Mount four (4) Relays using 1/4 NC x 5/8" hex hd cap screws, lock washers and hex nuts. See FIG. 12

6. Remove fasteners securing Vehicle Fuse Block(s). Slide Sonic Boom™ Fuse Block together with Vehicle Fuse Block(s) and remount all Fuse Blocks to Vehicle using fasteners previously removed. See FIG. 12

7. Connect Wiring Harness to ECU and Relays.

8. Mount ECU Bracket to Upright Post, using two (2) 5/16 NC x 3/4" cap screws, flat washers, lock washers, and hex nuts. See FIG. 12

9. Drill 3/8" hole in floor using the Support Bracket as a template for hole location.

10. Secure Support Bracket to floor, using a 5/16 NC x 3/4" cap screw, flat washer, lock washer, and hex nut. See FIG. 12

11. Install Switch Bracket to Dash using four (4) 1/4 NC x 5/8" hex hd cap screws, lock washers, and hex nuts as shown in FIG. 13




FIG. 13

1. Right Boom Switch 3. Sonic Boom™ Mode Switch
2. Left Boom Switch 4. Sonic Indicator Light

SET-UP INSTRUCTIONS

12. Install two (2) Boom Switches (included in Boom Lift Kit), Sonic Boom™ Mode Switch, Sonic Boom™ Indicator Light, and Decals. Connect Wiring Harness as shown in FIG. 13

13. Install (5) Fuse Decals. Connect power wire to available Vehicle Fuse Block lead, and connect ground wire to ground bolt as shown in FIG. 14




FIG. 14

- | | |
|----------------|---------------------|
| 1. Power Wire | 3. Ground Bolt |
| 2. Ground Wire | 4. Five Fuse Decals |
| | 5. 30 amp Fuse |

14. Install 30 amp Fuse to the Bay matching Power Wire Connection.

15. Route Harness to Boom following the Vehicle Brake Lines. Secure Harness to Vehicle using Tie Straps provided. Route Harness away from any moving parts.

16. Reattach Front Panel.

BOOM CONNECTIONS (Applicable to all sprayer vehicles)

1. Connect Wiring Harness to Sonar Sensor cable. The connector with black/orange stripe wire in center terminal mates to left Sensor cable. The connector with the black/blue stripe wire mates to right Sensor cable.

2. Connect Wiring Harness to Actuators. The connector with solid red and black wires mates to Left Actuator. The connector with striped red and black wire mates to Right Actuator.

BOOM HEIGHT ADJUSTMENT:

1. Tighten the adjustable clevis jam nut as close against the clevis as it will go. See FIG. 15.

2. Securely tighten the adjustable clevis end nut against the boom frame support member.

3. Repeat this procedure for the boom on opposite side.




FIG. 15

- | | |
|----------------------|------------|
| 1. Actuator | 3. Jam Nut |
| 2. Adjustable Clevis | 4. End Nut |

⚠ SAFETY AND INSTRUCTION DECALS

The following safety and instruction decals are installed on the vehicle. If any become damaged or illegible, replace them. Decal part numbers are listed below and in the Operator's Manual. Order replacements from your Authorized TORO Distributor.



Part No. 94-8576; Located on the Sensor Bracket on Workman® and MULTI PRO® Sprayers




Part No. 94-8584; Located at the Aux. Fuse Block of Workman® and MULTI PRO® Sprayers




Part No. 94-8585; Located at the Aux. Fuse Block of Workman® and MULTI PRO® Sprayers




Part No. 87-0570; Located on both corners of Rear Tank Band on Workman® and MULTI PRO® Sprayers



Part No. 94-8582; Located on the Dash of Workman® and MULTI PRO® Sprayers




Part No. 94-8583; Located on Switch Mounting Bracket of Workman® and on Console Control Panel on MULTI PRO® 1100 Sprayers



Part No. 87-0610; Located on left Control Panel of MULTI PRO® 1100 Sprayers



Part No. 92-2660; Located on the Dash Bracket of the Workman® Sprayers




SENSOR AND BRACKET ASS'Y 95-8577(RH) 95-8567(LH) (RIGHT SIDE SHOWN)

#	Part No.	Description	Qty
1	94-8586	Sonar Wire Conduit	2
2	21-107-AMD	#10 NC x 2 3/4 Machine Screw	4
3	95-2249	Sensor Bracket (right side)	1
*	95-2248	Sensor Bracket (left side)	1
4	94-6869	Ultrasonic Sensor	2
5	95-2245	Sensor Shield	2

#	Part No.	Description	Qty
6	95-2247	Foam Sensor Shield	2
7	23-7-GD	3/16" Lockwasher	4
8	22-9-AJD	#10 NC Hex. nut	4
9	92-0010	1/4" NC U-Bolt	4
10	32146-17	1/4" Locknut	8
11	24-9-AD	1/4" USS Flatwasher	8

* Not illustrated




ECU MOUNTING ASS'Y (5500 SHOWN)


#	Part No.	Description	Qty	#	Part No.	Description	Qty
1	94-8519	Wire Harness	1	9	70-1480	Relay	4
2	21-98-AGOD	#10 NCx5/8" Machine Screw	2	10	20-2-AGD	1/4 NC x 5/8" Hex Cap Screw	4
3	22-9-AJD	#10 NC Hex nut	2	11	92-5720	ECU (Computer)	1
4	22-11-AJD	1/4" NC Hex nut	8	12	20-11-AGD	1/4 NC x 2 1/2" Hex Cap Screw	4
5	23-9-GD	1/4" Lockwasher	8	**	42765	30 Amp Fuse	1
6	23-10-GD	5/16" Lockwasher	4*	**	95-2438	10 Amp Fuse	1
7	20-24-AGD	5/16 NC x 3/4" Hex Cap Screw	4*	**	95-2439	5 Amp Fuse	1
8	94-8564	5500 ECU Mount Plate	1				

* Four (4) used on Workman. Only two (2) needed for 5500. Zero (0) used for 1100 mounting.



** Items not illustrated.



MULTI PRO® 5500



MULTI PRO® 1100




WORKMAN®

SWITCH PANEL ASS'Y & HARNESS RESTRAINT

#	Part No.	Description	Qty
1	92-0250	Toggle Switch	1
2	92-8531	Switch Boot	1
3	40-6410	Warning Light	1
4	92-2662	Plug	2
5	23-9-GD	1/4" Lockwasher	4

#	Part No.	Description	Qty
6	22-11-AJD	14" NC	4
7	94-8598	Switch Mount Bracket	1
8	20-2-AGD	1/4 NC x 5/8" Hex Cap Screw	4
9	095672	Tie Strap	16
10	2412-104	"R" Clamp	2



WORKMAN ECU BRACKET ASS'Y

#	Part No.	Description	Qty
1	94-8565	ECU Mount Bracket (Workman)	1
2	23-10-GD	5/16" Lockwasher	4
3	22-12-AJD	5/16 NC Hex nut	4

#	Part No.	Description	Qty
4	24-10-AD	5/16" USS Flatwasher	4
5	94-8588	Support Bracket (Workman)	1
6	20-24-AGD	5/16" NC x 3/4" Hex Cap Screw	4